





# Adafruit BMP388 - Precision Barometric Pressure and Altimeter

Created by Kattni Rembor




Last updated on 2019-04-22 08:39:13 PM UTC

## Overview




Bosch has been a leader in barometric pressure sensors, from the [BMP085](https://adafruit.it/y8B) (<https://adafruit.it/y8B>), [BMP180](https://adafruit.it/y8A) (<https://adafruit.it/y8A>), and [BMP280](https://adafruit.it/ufr) (<https://adafruit.it/ufr>)... now we've got the next generation, the **Adafruit BMP388 Precision Barometric Pressure sensor**. As you would expect, this sensor is similar to its earlier versions but *even better*. The BMP388 has better precision than ever, which makes it excellent for environmental sensing or as a **precision altimeter**. It can even be used in either I2C and SPI configurations.

The BMP3xx is the next-generation of sensors from Bosch, and is the upgrade to the BMP280 - with a low altitude noise as low as 0.1m and the same fast conversion time. And like the previous BMP280, you can use I2C or SPI. For simple easy wiring, go with I2C. If you want to connect a bunch of sensors without worrying about I2C address collisions, go with SPI.



This sensor has a relative accuracy of 8 Pascals, which translates to about  $\pm 0.5$  meter of altitude (compare to the BMP280's 12 Pascal/  $\pm 1$  meter). The datasheet sort of implies they intend this sensor to be used for drones and quadcopters, to keep altitude stable, but you could also use this for wearables or any project that wants to track height-above-sea-level. Note that for absolute height you'll still need to enter in the barometric pressure at sea level, if the weather changes, but that's true of every altimeter sensor that uses pressure. You can also measure temperature with  $\pm 0.5^\circ\text{C}$  accuracy.




Nice sensor right? So we made it easy for you to get right into your next project. The surface-mount sensor is soldered onto a PCB and comes with a 3.3V regulator and level shifting so you can use it with a 3V or 5V logic microcontroller without worry. [Check out the Arduino library to get data out in under 10 minutes! \(https://adafruit.com/learn/arduino/using-the-bmp388\)](https://adafruit.com/learn/arduino/using-the-bmp388)





## Pinouts



### Power Pins

- **Vin** - this is the power pin. Since the sensor chip uses 3 VDC, we have included a voltage regulator on board that will take 3-5VDC and safely convert it down. To power the board, give it the same power as the logic level of your microcontroller - e.g. for a 5V micro like Arduino, use 5V
- **3Vo** - this is the 3.3V output from the voltage regulator, you can grab up to 100mA from this if you like
- **GND** - common ground for power and logic

### SPI Logic pins

All pins going into the breakout have level shifting circuitry to make them 3-5V logic level safe. Use whatever logic level is on **Vin**!

- **SCK** - This is the **SPI Clock** pin, its an input to the chip and can use 3 - 5V logic.
- **SDO** - this is the **Serial Data Out / Master In Slave Out** pin, for data sent from the BMP388 to your processor. Logic level is 3.3V output, so can be read by 5V microcontrollers.
- **SDI** - this is the **Serial Data In / Master Out Slave In** pin, for data sent from your processor to the BMP388. Its an input to the chip and can use 3 - 5V logic.
- **CS** - this is the **Chip Select** pin, drop it low to start an SPI transaction. Its an input to the chip and can use 3 - 5V logic.
- **INT** - this is the **Interrupt** pin. The BMP388 can send an output signal to tell you when data is read (we don't use this in our libraries but it is available for your use). The logic level is 3.3V output, so it can be read by 5V microcontrollers.


If you want to connect multiple BMP388 sensors to one microcontroller, have them share the SDI, SDO and SCK pins. Then assign each one a unique CS pin.


### I2C Logic pins

- **SCK** - this is *also* the I2C clock pin, connect to your microcontroller's I2C clock line.
- **SDI** - this is *also* the I2C data pin, connect to your microcontroller's I2C data line.

Leave the **CS** and **SDO** pins disconnected for I2C use.


## Assembly







Prepare the header strip:

Cut the strip to length if necessary. It will be easier to solder if you insert it into a breadboard - **long pins down**






Add the breakout board:  
Place the breakout board over the pins so that the short pins poke through the breakout pads






And Solder!  
Be sure to solder all 8 pins for reliable electrical contact.

*(For tips on soldering, be sure to check out our [Guide to Excellent Soldering](https://adafruit.it/aTk) (<https://adafruit.it/aTk>)).*










You're done! Check your solder joints visually and continue onto the next steps.

## Arduino

You can easily wire this breakout to any microcontroller, we'll be using an Arduino Uno/328P compatible. For another kind of microcontroller, as long as you have 4 available pins it is possible to 'bit-bang SPI' or you can use two I2C pins, but usually those pins are fixed in hardware. Just check out the library, then port the code.

### I2C Wiring


Use this wiring if you want to connect via I2C interface:



- Connect **Vin** to the power supply, 3-5V is fine. Use the same voltage that the microcontroller logic is based off of. For most older Arduinos, that is 5V.
- Connect **GND** to common power/data ground.
- Connect the **SCK** pin to the I2C clock **SCL** pin on your Arduino. On an UNO & '328 based Arduino, this is also known as **A5**, on a Mega it is also known as **digital 21** and on a Leonardo/Micro, **digital 3**.
- Connect the **SDI** pin to the I2C data **SDA** pin on your Arduino. On an UNO & '328 based Arduino, this is also known as **A4**, on a Mega it is also known as **digital 20** and on a Leonardo/Micro, **digital 2**.

### SPI Wiring

Since this is a SPI-capable sensor, we can use hardware or 'software' SPI. To make wiring identical on all Arduinos, we'll begin with 'software' SPI. The following pins should be used:




- Connect **Vin** to the power supply, 3V or 5V is fine. Use the same voltage that the microcontroller logic is based off of. For most Arduinos, that is 5V.
- Connect **GND** to common power/data ground.
- Connect the **SCK** pin to **Digital #13** but any pin can be used later.
- Connect the **SDI** pin to **Digital #12** but any pin can be used later.
- Connect the **SDI** pin to **Digital #11** but any pin can be used later.
- Connect the **CS** pin **Digital #10** but any pin can be used later.

Later on, once we get it working, we can adjust the library to use hardware SPI if you desire, or change the pins assignments.


## Download Adafruit\_BMP3XX library

To begin reading sensor data, you will need to [install the Adafruit\\_BMP3XX library \(code on our github repository\) \(https://adafru.it/EdV\)](https://adafru.it/EdV). It is available from the Arduino library manager so we recommend using that.


From the IDE open up the library manager...



And type in **adafruit bmp3xx** to locate the library. Click **Install**



You'll also need to install the **Adafruit Unified Sensor** library




We also have a great tutorial on Arduino library installation at:

<http://learn.adafruit.com/adafruit-all-about-arduino-libraries-install-use> (<https://adafru.it/aYM>)

## Load Demo

Open up **File -> Examples -> Adafruit\_BMP3XX -> bmp3xx\_simpletest** and upload to your Arduino wired up to the sensor.






Depending on whether you are using I2C or SPI, change the pin names and comment or uncomment the following lines.

```
#define BMP_SCK 13
#define BMP_MISO 12
#define BMP_MOSI 11
#define BMP_CS 10

#define SEALEVELPRESSURE_HPA (1013.25)

Adafruit_BMP3XX bmp; // I2C
//Adafruit_BMP3XX bmp(BMP_CS); // hardware SPI
//Adafruit_BMP3XX bmp(BMP_CS, BMP_MOSI, BMP_MISO, BMP_SCK); // Software SPI
```

Once uploaded to your Arduino, open up the serial console at 115200 baud to see data being printed out:



**Temperature** is calculated in degrees C, you can convert this to F by using the classic  $F = C * 9/5 + 32$  equation.

**Pressure** is returned in the SI units of **Pascals**. 100 Pascals = 1 hPa = 1 millibar. Often times barometric pressure is reported in millibar or inches-mercury (Hg). For future reference 1 pascal = 0.000295333727 inches of mercury, or 1 inch Hg = 3386.39 Pascal. So if you take the Pascal value of say 100734 and divide by 3389.39 you'll get 29.72 inches-Hg.

You can also calculate Altitude. **However, you can only really do a good accurate job of calculating altitude if you know the hPa pressure at sea level for your location and day!** The sensor is quite precise but if you do not have the data updated for the current day, then it can be difficult to get more accurate than 10 meters.

Pass in the current sea level pressure in **hPa** - so the value will be somewhere around ~1000. You can also test with the generic 1013.25 value.

## Example Code

The following example code is part of the standard library. It illustrates how you can retrieve sensor data from the BMP388 for the temperature, pressure and approximate altitude:

```

/*****
  This is a library for the BMP3XX temperature & pressure sensor

  Designed specifically to work with the Adafruit BMP388 Breakout
  ----> http://www.adafruit.com/products/3966

  These sensors use I2C or SPI to communicate, 2 or 4 pins are required
  to interface.

  Adafruit invests time and resources providing this open source code,
  please support Adafruit and open-source hardware by purchasing products
  from Adafruit!

  Written by Limor Fried & Kevin Townsend for Adafruit Industries.
  BSD license, all text above must be included in any redistribution
  *****/

#include <Wire.h>
#include <SPI.h>
#include <Adafruit_Sensor.h>
#include "Adafruit_BMP3XX.h"

#define BMP_SCK 13
#define BMP_MISO 12
#define BMP_MOSI 11
#define BMP_CS 10

#define SEALEVELPRESSURE_HPA (1013.25)

Adafruit_BMP3XX bmp; // I2C
//Adafruit_BMP3XX bmp(BMP_CS); // hardware SPI
//Adafruit_BMP3XX bmp(BMP_CS, BMP_MOSI, BMP_MISO, BMP_SCK);

void setup() {
  Serial.begin(115200);
  while (!Serial);
  Serial.println("BMP388 test");

  if (!bmp.begin()) {
    Serial.println("Could not find a valid BMP3 sensor, check wiring!");
    while (1);
  }

  // Set up oversampling and filter initialization
  bmp.setTemperatureOversampling(BMP3_OVERSAMPLING_8X);
  bmp.setPressureOversampling(BMP3_OVERSAMPLING_4X);
  bmp.setIIRFilterCoeff(BMP3_IIR_FILTER_COEFF_3);
  //bmp.setOutputDataRate(BMP3_ODR_50_HZ);
}

void loop() {
  if (! bmp.performReading()) {
    Serial.println("Failed to perform reading :(");
  }
}
```

```

    Serial.println( "Failed to perform reading : ( ", );
    return;
}
Serial.print("Temperature = ");
Serial.print(bmp.temperature);
Serial.println(" *C");

Serial.print("Pressure = ");
Serial.print(bmp.pressure / 100.0);
Serial.println(" hPa");

Serial.print("Approx. Altitude = ");
Serial.print(bmp.readAltitude(SEALEVELPRESSURE_HPA));
Serial.println(" m");

Serial.println();
delay(2000);
}

```


## Python & CircuitPython

It's easy to use the BMP388 sensor with CircuitPython and the [Adafruit CircuitPython BMP3XX \(https://adafruit.it/Ei6\)](https://adafruit.it/Ei6) module. This module allows you to easily write Python code that reads the barometric pressure, temperature and more from the sensor.


You can use this sensor with any CircuitPython microcontroller board or with a computer that has GPIO and Python [thanks to Adafruit\\_Blinka, our CircuitPython-for-Python compatibility library \(https://adafruit.it/BSN\)](https://adafruit.it/BSN).

### CircuitPython Microcontroller Wiring

First wire up a BMP280 to your board as shown below. You can use either I2C or SPI wiring, although it's recommended to use I2C for simplicity. Here's an example of wiring a Feather M0 to the sensor with I2C:



And an example of a Feather M0 wired with hardware SPI:




### Python Computer Wiring

Since there's *dozens* of Linux computers/boards you can use, we will show wiring for Raspberry Pi. For other platforms, [please visit the guide for CircuitPython on Linux to see whether your platform is supported \(https://adafruit.it/BSN\)](https://adafruit.it/BSN).

Here's the Raspberry Pi wired with I2C:






- Pi 3V3 to sensor VIN
- Pi GND to sensor GND
- Pi SCL to sensor SCK
- Pi SDA to sensor SDI

fritzing

And an example on the Raspberry Pi 3 Model B wired with SPI:



- Pi 3V3 to sensor VIN
- Pi GND to sensor GND
- Pi MOSI to sensor SDI
- Pi MISO to sensor SDO
- Pi SCLK to sensor SCK
- Pi #5 to sensor CS (or use any other free GPIO pin)

fritzing

## CircuitPython Installation of BMP3XX Library

You'll need to install the [Adafruit CircuitPython BMP3XX \(https://adafru.it/Ei6\)](https://adafru.it/Ei6) library on your CircuitPython board.

First make sure you are running the [latest version of Adafruit CircuitPython \(https://adafru.it/Amd\)](https://adafru.it/Amd) for your board.

Next you'll need to install the necessary libraries to use the hardware--carefully follow the steps to find and install these libraries from [Adafruit's CircuitPython library bundle \(https://adafru.it/uap\)](https://adafru.it/uap). Our CircuitPython starter guide has [a great page on how to install the library bundle \(https://adafru.it/ABU\)](https://adafru.it/ABU).

For non-express boards like the Trinket M0 or Gemma M0, you'll need to manually install the necessary libraries from the bundle:

- `adafruit_bmp3xx.mpy`
- `adafruit_bus_device`

Before continuing, make sure your board's `lib` folder or root filesystem has the `adafruit_bmp3xx.mpy`, and `adafruit_bus_device` files and folders copied over.

Next [connect to the board's serial REPL \(https://adafru.it/Awz\)](https://adafru.it/Awz) so you are at the CircuitPython `>>>` prompt.

## Python Installation of BMP3XX Library

You'll need to install the **Adafruit\_Blinka** library that provides the CircuitPython support in Python. This may also

require enabling I2C on your platform and verifying you are running Python 3. [Since each platform is a little different, and Linux changes often, please visit the CircuitPython on Linux guide to get your computer ready \(https://adafru.it/BSN\)](#)!

Once that's done, from your command line run the following command:

- `sudo pip3 install adafruit-circuitpython-bmp3xx`

If your default Python is version 3 you may need to run 'pip' instead. Just make sure you aren't trying to use CircuitPython on Python 2.x, it isn't supported!

## CircuitPython & Python Usage

To demonstrate the usage of the sensor, we'll initialize it and read the pressure, temperature and more from the Python REPL.

If you're using an I2C connection, run the following code to import the necessary modules and initialize the I2C connection with the sensor:

```
import time
import board
import busio
import adafruit_bmp3xx
i2c = busio.I2C(board.SCL, board.SDA)
bmp = adafruit_bmp3xx.BMP3XX_I2C(i2c)
```

Or if you're using a SPI connection run this code instead to setup the SPI connection and sensor:

```
import time
import board
import busio
import adafruit_bmp3xx
import digitalio
spi = busio.SPI(board.SCK, board.MOSI, board.MISO)
cs = digitalio.DigitalInOut(board.D5)
bmp = adafruit_bmp3xx.BMP3XX_SPI(spi, cs)
```

Now you're ready to read values from the sensor using any of these properties:

- `temperature` - The sensor temperature in degrees Celsius.
- `pressure` - The pressure in hPa.
- `altitude` - The altitude in meters.

For example to print temperature and pressure:

```
print("Pressure: {:.1f}".format(bmp.pressure))
print("Temperature: {:.2f}".format(bmp.temperature))
```

```
>>> print("Pressure: {:.1f}".format(bmp.pressure))
Pressure: 985.0
>>> print("Temperature: {:.2f}".format(bmp.temperature))
Temperature: 19.25
```

For altitude, you'll want to set the pressure at sea level for your location to get the most accurate measurement (remember these sensors can only infer altitude based on pressure and need a set calibration point). Look at your local weather report for a pressure at sea level reading and set the `sea_level_pressure` property:

```
bmp.sea_level_pressure = 1013.25
```

Then read the `altitude` property for a more accurate altitude reading (but remember this altitude will fluctuate based on atmospheric pressure changes!):

```
print('Altitude: {} meters'.format(bmp.altitude))
```

```
>>> bmp.sea_level_pressure = 1013.25
>>> print('Altitude: {} meters'.format(bmp.altitude))
Altitude: 238.16 meters
```

That's all there is to using the BMP388 sensor with CircuitPython!

## Full Example Code

```
import time
import board
import busio
import adafruit_bmp3xx

# I2C setup
i2c = busio.I2C(board.SCL, board.SDA)
bmp = adafruit_bmp3xx.BMP3XX_I2C(i2c)

# SPI setup
# from digitalio import DigitalInOut, Direction
# spi = busio.SPI(board.SCK, board.MOSI, board.MISO)
# cs = DigitalInOut(board.D5)
# bmp = adafruit_bmp3xx.BMP3XX_SPI(spi, cs)

bmp.pressure_oversampling = 8
bmp.temperature_oversampling = 2


while True:
    print("Pressure: {:.1f} Temperature: {:.2f}".format(bmp.pressure, bmp.temperature))
    time.sleep(1)
```

## Downloads

### Files


- [BMP388 datasheet \(https://adafru.it/EfL\)](https://adafru.it/EfL)
- [Fritzing object in the Adafruit Fritzing Library \(https://adafru.it/EfM\)](https://adafru.it/EfM)
- [EagleCAD PCB files on GitHub \(https://adafru.it/EfN\)](https://adafru.it/EfN)

### Schematic



### Fab Print





## Arduino Docs

[Arduino Docs \(https://adafru.it/EqL\)](https://adafru.it/EqL)

# Python Docs

[Python Docs \(https://adafru.it/Efl\)](https://adafru.it/Efl)