

HP 75000 SERIES C

64-Channel Scanning A/D HP E1413A

Service Manual

Serial Numbers

The information in this manual applies directly to HP E1413A 64-Channel Scanning A/Ds with serial number prefixes 3313A.



Copyright © Hewlett-Packard Company, 1994

CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (formerly National Bureau of Standards), to the extent allowed by that organization's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard product is warranted against defects in materials and workmanship for a period of three years from date of shipment. Duration and conditions of warranty for this product may be superseded when the product is integrated into (becomes a part of) other HP products. During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Hewlett-Packard (HP). Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with a product will execute its programming instructions when properly installed on that product. HP does not warrant that the operation of the product, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied products or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

The design and implementation of any circuit on this product is the sole responsibility of the Buyer. HP does not warrant the Buyer's circuitry or malfunctions of HP products that result from the Buyer's circuitry. In addition, HP does not warrant any damage that occurs as a result of the Buyer's circuit or any defects that result from Buyer-supplied products.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

NOTICE

The information contained in this document is subject to change without notice. HEWLETT-PACKARD (HP) MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. HP shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material. This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company. HP assumes no responsibility for the use or reliability of its software on equipment that is not furnished by HP.

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subdivision (b)(3)(ii) of the Rights in Technical Data and Computer Software clause at 52.227-7013. Hewlett-Packard Company; 3000 Hanover Street; Palo Alto, California 94304

Declaration of Conformity

According to ISO/IEC Guide 22 and EN 45014

The Hewlett-Packard Company declares that the HP E1413A conforms to the following Product Specifications.

Safety: IEC 1010-1 (1990) Incl. Amend 1 (1992)/EN61010 (1993)
CSA C22.2 #1010.1 (1992)
UL 1244

EMC: CISPR 11:1990/EN 55011 (1991): Group 1 Class A
IEC 801-2:1991/EN 50082-1 (1992): 4kVCD, 8kVAD
IEC 801-3:1984/EN 50082-1 (1992): 3 V/m
IEC 801-4:1988/EN 50082-1 (1992): 1kV Power Line

Supplementary Information: The product herewith complies with the requirements of the low voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC.

Tested in a typical configuration in an HP C-Size VXi mainframe.


J.A. Manager
January 1994

Hewlett-Packard Company
P.O. Box 301
815 14th Street S.W.
Loveland, Colorado 80539 U.S.A.

Printing History

The Printing History shown below lists all Editions and Updates of this manual and the printing date(s). The first printing of the manual is Edition 1. The Edition number increments by 1 whenever the manual is revised. Updates, which are issued between Editions, contain replacement pages to correct the current Edition of the manual. Updates are numbered sequentially starting with Update 1. When a new Edition is created, it contains all the Update information for the previous Edition. Each new Edition or Update also includes a revised copy of this printing history page. Many product updates or revisions do not require manual changes and, conversely, manual corrections may be done without accompanying product changes. Therefore, do not expect a one-to-one correspondence between product updates and manual updates.

Edition 1 (Part Number E1413-90010) January 1994

Safety Symbols



Instruction manual symbol affixed to product. Indicates that the user must refer to the manual for specific Warning or Caution information to avoid personal injury or damage to the product.



Indicates the field wiring terminal that must be connected to earth ground before operating the equipment—protects against electrical shock in case of fault.



OR Frame or chassis ground terminal—typically connects to the equipment's metal frame.



Alternating current (AC).



Direct current (DC).



Indicates hazardous voltages.

WARNING

Calls attention to a procedure, practice, or condition that could cause bodily injury or death.

CAUTION

Calls attention to a procedure, practice, or condition that could possibly cause damage to equipment or permanent loss of data.

WARNINGS

The following general safety precautions must be observed during all phases of operation, service, and repair of this product. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the product. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

Ground the equipment: For Safety Class 1 equipment (equipment having a protective earth terminal), an uninterruptible safety earth ground must be provided from the mains power source to the product input wiring terminals or supplied power cable.

DO NOT operate the product in an explosive atmosphere or in the presence of flammable gases or fumes.

For continued protection against fire, replace the line fuse(s) only with fuse(s) of the same voltage and current rating and type. DO NOT use repaired fuses or short-circuited fuse holders.

Keep away from live circuits: Operating personnel must not remove equipment covers or shields. Procedures involving the removal of covers or shields are for use by service-trained personnel only. Under certain conditions, dangerous voltages may exist even with the equipment switched off. To avoid dangerous electrical shock, DO NOT perform procedures involving cover or shield removal unless you are qualified to do so.


DO NOT operate damaged equipment: Whenever it is possible that the safety protection features built into this product have been impaired, either through physical damage, excessive moisture, or any other reason, REMOVE POWER and do not use the product until safe operation can be verified by service-trained personnel. If necessary, return the product to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

DO NOT service or adjust alone: Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT substitute parts or modify equipment: Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the product. Return the product to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

HP 75000 Series C Service Documentation

Suggested Sequence to Use Manuals



C_SEQ

Manual Descriptions

Title	Description
Series C Installation and Getting Started Guide	Step-by-step instructions for all aspects of plug-in module, mainframe, and command module installation. Also contains programming information and examples.
Mainframe User's Manual	Information to prepare the mainframe and to install plug-in modules.
Command Module User's Manual	Programming information for the command module and general programming information for instruments installed in the mainframe.
Command Module Service Manual	Command module service information. Includes information and procedures for functional verification, operation verification, performance verification, troubleshooting, and repair.
Plug-In Module User's Manuals	Plug-in module programming and configuration information. Contains programming examples and SCPI command reference for the module.
Plug-In Module Service Manuals	Plug-in module service information. Depending on the module, includes information and procedures for functional verification, operation verification, performance verification, adjustment, troubleshooting, and repair.

What's in this Manual

Manual Overview

This manual shows how to service the HP E1413A 64-Channel Scanning A/D and associated Signal Conditioning Plug-Ons (SCPs). See the *HP E1413A User's Manual* for additional information on installing, configuring, and operating the instrument. Consult the appropriate mainframe manual for information on configuring and operating the mainframe.

Manual Content

Chap	Title	Content
1	General Information	Lists basic instrument descriptions, tools and test equipment required for service, and procedures to inspect and ship the instrument.
2	Verification Tests	Describes functional, operational, and performance verification tests for the instrument.
3	Adjustments	Shows how to perform A/D adjustments for the instrument.
4	Replaceable Parts	Lists part numbers of replaceable parts for the instrument. Also includes information to order spare parts and to exchange/replace instruments.
5	Service	Procedures to aid in fault isolation and repair of the instrument.
A	Calculating Scanning A/D Accuracy	Shows how to calculate instrument accuracy, test equipment uncertainty, and test accuracy ratio (TAR).
B	Error Messages	Lists error messages for the instrument.
C	Command Reference	Summarizes the CALibration subsystem commands for the Scanning A/D and describes Common Commands for the instrument.

Contents

Chapter 1 - General Information

Introduction	1-1
Safety Information	1-2
Scanning A/D Description	1-3
Inspection/Shipping	1-6
Recommended Test Equipment	1-8

Chapter 2 - Verification Tests

Introduction	2-1
Test Conditions/Procedures	2-1
Performance Test Record	2-1
Verification Test Examples	2-1
Functional Verification	2-2
Test F-1: Scanning A/D Self-Test	2-2
Test F-2: A/D Overrange Detection	2-4
Test F-3: Open Transducer Detection	2-7
Operation Verification	2-10
Performance Verification	2-10
Test 2-1: DCV Accuracy - Option 11	2-11
Test 2-2: DCV Accuracy - Option 12	2-17
Test 2-3: DCV Accuracy - Option 13	2-21
Performance Test Record	2-28

Chapter 3 - Adjustments

Introduction	3-1
A/D Adjustment Procedure	3-2

Chapter 4 - Replaceable Parts

Introduction	4-1
Exchange Modules	4-1
Replaceable Parts Lists	4-1
Component Locators	4-3

Chapter 5 - Service

Introduction	5-1
Recommended Repair Strategy	5-1
Troubleshooting Guidelines	5-2
Disassembly	5-5
Repair/Maintenance Guidelines	5-8

A - Calculating Scanning A/D Accuracy

Introduction	A-1
Scanning A/D Accuracy Calculations	A-2
Measurement Uncertainty Calculations	A-4
Test Accuracy Ratio (TAR) Calculations	A-5

B - Error Messages

C - Command Reference

Introduction	C-1
CALibration Commands	C-1
Common Commands	C-11

General Information

Introduction

This service manual contains information to test, troubleshoot, and repair the HP E1413A 64-Channel Scanning A/D (Scanning A/D) and associated Signal Conditioning Plug-Ons (SCPs). Figure 1-1 shows a typical E1413A Scanning A/D and the SCPs described in this manual.

NOTE

See "HP 75000 Series C Service Documentation", page iv, for a list of manuals that describe mainframe and command module operation and hardware. The information in this manual assumes you are familiar with HP E1413A operation. If incoming inspection is required, see "Inspection/Shipping" in this chapter.




Figure 1-1. HP E1413A Scanning A/D Converter

Safety Information

The HP E1413A Scanning A/D is a Safety Class I instrument that is provided with a protective earth terminal when installed in the mainframe. Check the mainframe and all related documentation for safety markings and instructions before operating or servicing a Scanning A/D.

See the WARNINGS page (page iii) for a summary of safety information. Safety information to test and service the HP E1413A Scanning A/D follows and is also found throughout this manual.

WARNINGS

Follow the WARNINGS listed to avoid possible injury to yourself or others when operating, repairing, or servicing a Scanning A/D.

WARNING

SERVICE-TRAINED PERSONNEL ONLY. The information in this manual is for service-trained personnel who are familiar with electronic circuitry and are aware of the hazards involved. To avoid personal injury or damage to the instrument, do not perform procedures in this manual or do any servicing unless you are qualified to do so.

CHECK MAINFRAME POWER SETTINGS. Before applying power, verify that the mainframe setting matches the line voltage and the correct fuse is installed. An uninterruptible safety earth ground must be provided from the main power source to the supplied power cord set.

GROUNDING REQUIREMENTS. Interruption of the protective (grounding) conductor (inside or outside the mainframe) or disconnecting the protective earth terminal will cause a potential shock hazard that could result in personal injury. (Grounding one conductor of a two-conductor outlet is not sufficient protection.)

IMPAIRED PROTECTION. Whenever it is likely that instrument protection has been impaired, the mainframe must be made inoperative and be secured against any unintended operation.

REMOVE POWER IF POSSIBLE. Some procedures in this manual may be performed with power supplied to the mainframe while protective covers are removed. Energy available at many points may, if contacted, result in personal injury. (If service can be performed without power applied, remove the power.)

WARNING

USING AUTOTRANSFORMERS. If the mainframe is to be energized via an autotransformer (for voltage reduction) make sure the common terminal is connected to neutral (that is, the grounded side of the main's supply).

USE PROPER FUSES. For continued protection against fire hazard, replace the line fuse(s) only with fuses of the same current rating and type (such as normal blow, time delay, etc.). Do not use repaired fuses or short-circuited fuseholders.

CAUTIONS

Follow the CAUTIONS listed to avoid possible damage to the equipment when performing instrument operation, service, or repair.

CAUTION

MAXIMUM INPUT VOLTAGE/CURRENT. To avoid possible damage to the instrument, maximum input voltage (normal mode plus common mode) is ± 42 V_{peak}. Maximum operating voltage is ± 16 V_{peak}. Maximum current per channel or common: 100 mA DC or AC RMS.

STATIC ELECTRICITY. Static electricity is a major cause of component failure. To prevent damage to the electrical components in the Scanning A/D or SCPs, observe anti-static techniques when removing an HP E1413A from the mainframe or when handling an HP E1413A or SCP. Also, be sure to tighten the front panel screws when installing an HP E1413A in a mainframe slot.

Scanning A/D Description

The HP E1413A Scanning A/D Converter is a VXIbus C-Size, register-based instrument. The Scanning A/D can operate in a C-Size VXIbus mainframe using an HP E1406 Command Module and Standard Commands for Programmable Instruments (SCPI).

The instrument can measure DC voltage, resistance, temperature, and strain when appropriate Signal Conditioning Plug-Ons (SCPs) are installed on the instrument (see "Scanning A/D Options" for a list of SCPs). The Scanning A/D has 100 kHz scanning rate up to 100,000 readings/sec with full autozeroing and autocalibration. See *Chapter 5 - Service* for a block diagram description of the instrument.

Scanning A/D Specifications

See *Appendix A - Specifications* in the *HP E1413A User's Manual* for HP E1413A Scanning A/D specifications. These specifications are the performance standards or limits against which the instrument may be tested.


Scanning A/D Environment

The HP E1413A Scanning A/D and SCPs should be stored in a clean, dry environment. Recommended operating/storage environments for the HP E1413A Scanning A/D and SCPs are:

	Temperature	Relative Humidity
Operating Environment	0°C to +55°C	<65% (0°C to +40°C)
Storage/Shipment	-40°C to +75°C	<65% (0°C to +40°C)

Scanning A/D Serial Numbers

Figure 1-2 shows Hewlett-Packard serial number structure. HP E1413A Scanning A/Ds covered by this manual are identified by the serial number prefixes listed on the title page.



E1450 F_1_2

Figure 1-2. Hewlett-Packard Serial Numbers

Scanning A/D Options

Options for the HP E1413A Scanning A/D that are described in this manual include:

Option	Description
E1413A Opt 011	Eight-Channel Straight-Through SCP
E1413A Opt 012	Eight-Channel Fixed Filter SCP
E1413A Opt 013	Eight-Channel Amplifier+Filter SCP

Service Programs Disk

An *HP E1413A Service Programs* disk is shipped with this manual. The programs on the disk are in LIF format, with the program *filename* shown in line 10 of each program. To run a program, load the disk in the disk drive, select the disk drive as the primary drive, type LOAD "*filename*" and press RUN.

For example, to run the HP E1413A Self-Test (Test F-1 in Chapter 2), load the disk and type LOAD "SELFTEST". Then, press RUN to run the program. The following table summarizes *Service Programs* disk contents.

HP E1413A Service Programs

Chap	Category	filename	Description
2	Functional Verification Tests	SELFTEST	Performs a self-test of the Scanning A/D
		OVERRANG	Checks Scanning A/D overrange detection function
		OPENTRAN	Checks Scanning A/D open transducer detection (OTD) function
	Performance Verification Tests	PERF11	Tests DCV measurement accuracy using Option 11 SCP
		PERF12	Tests DCV measurement accuracy using Option 12 SCP
		PERF131	Tests DCV measurement accuracy using Option 13 SCP @ Gain X1
		PERF138	Tests DCV measurement accuracy using Option 13 SCP @ Gain X8
		PERF1364	Tests DCV measurement accuracy using Option 13 SCP @ Gain X64
3	Adjustments	ADJSPROC	Performs internal A/D adjustments for the Scanning A/D
5	Service	SERVTEST	Performs troubleshooting tests for the Scanning A/D

Inspection/ Shipping


This section shows initial (incoming) inspection and shipping guidelines for the HP E1413A Scanning A/D and associated SCPs.

Initial Inspection

Use the steps in Figure 1-3 as guidelines to perform initial (incoming) inspection of the HP E1413A Scanning A/D.

WARNING

To avoid possible hazardous electrical shock, do not perform electrical tests if there are signs of shipping damage to the shipping container or to the instrument.




E1413A F_1_2

Figure 1-3. Initial (Incoming) Inspection Guidelines

Shipping Guidelines

Follow the steps in Figure 1-4 to return an HP E1413A Scanning A/D and/or SCPs to a Hewlett-Packard Sales and Support Office or to a Service Center.




1 Remove Terminal Block/SCPs

- Remove SCP(s) from instrument*
- Remove terminal block from instrument

2 Prepare Instrument/SCP

- Attach tag to instrument that identifies
 - Owner
 - Model Number/Serial Number
 - Service Required
- Place tagged device in anti-static bag



3 Package Instrument/SCP

- Place packaged instrument in shipping carton**
- Place 75 to 100 mm (3 to 4 inches) of shock-absorbing material around the device
- Seal the shipping carton securely
- Mark the shipping carton FRAGILE

4 Ship Instrument to Hewlett-Packard

- Place address label on shipping carton ***
- Send carton to Hewlett-Packard

* When returning an HP E1413A, first remove and save all installed SCPs. See *Chapter 5 - Service* for procedures to remove SCPs from the HP E1413A Scanning A/D.

** We recommend you use the same shipping materials as those used in factory packaging (available from Hewlett-Packard). For other (commercially-available) shipping materials, use a double-wall carton with minimum 2.4 MPa (350 psi) test.

*** See Sales and Support Offices at the back of this manual for shipping address.

Figure 1-4. Packaging/Shipping Guidelines

Recommended Test Equipment

See Table 1-1 for test equipment recommended to test and service the HP E1413A Scanning A/D and SCPs. Essential requirements for each piece of test equipment are listed in the *Requirements* column. You may substitute other equipment if it meets the requirements in Table 1-1.

Table 1-1. Recommended Test Equipment

Instrument	Requirements	Recommended Model	Use*
Controller, HP-IB	HP-IB compatibility as defined by IEEE Standard 488-1987 and the identical ANSI Standard MC1.1: SH1, AH1, T2, TE0, L2, LE0, SR0, RL0, PP0, DC0, DT0, and C1, 2, 3, 4, 5	HP 9000 Series 300	F,P
Mainframe	Compatible with HP E1405B or HP E1406A Command Module	HP HP E1401A (requires HP E1405B or E1406A)	F,P
Digital Multimeter	Voltage Range: ± 20 Vdc Resistance Range: 1 M Ω	HP 3458A	A,T
Voltage Source	Voltage Range: ± 20 Vdc	Datron 4708 Option 10	F,P

*A = Adjustments, F = Functional Verification Tests, P = Performance Verification Tests,
T = Troubleshooting

Verification Tests

Introduction

The three levels of test procedures described in this chapter are used to verify that the HP E1413A Scanning A/D and associated Signal Conditioning Plug-Ons (SCPs):

- are functional (Functional Verification)
- meet selected testable specifications (Operation Verification)
- meet all testable specifications (Performance Verification)

WARNING

Do not perform any of the following verification tests unless you are a qualified, service-trained technician and have read the WARNINGS and CAUTIONS in Chapter 1.

Test Conditions/ Procedures

See Table 1-1 for test equipment requirements. You should complete the performance verification tests at least once a year. For heavy use or severe operating environments, perform the tests more often. For best results, the test environment temperature should be $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$.

The verification tests assume that the person performing the tests understands how to operate the mainframe, the Scanning A/D, and specified test equipment. The test procedures do not specify equipment settings for test equipment, except in general terms. It is assumed that a qualified, service-trained technician will select and connect any cables, adapters, and probes required for the test.

Performance Test Record

The results of each performance verification test may be recorded in Table 2-1, *HP E1413A Performance Test Record*. This form can be copied, if desired.

Verification Test Examples

Each verification test includes an example program, and all example programs are on the *HP E1413A Service Programs* disk sent with this manual. All example programs assume the following:

- Controller is an HP 9000 Series 300 computer
- Programming language is HP BASIC
- Scanning A/D address is 70903 (logical address is 24)
- DMM is an HP 3458A at address 722

Functional Verification

The purpose of the functional verification tests is to verify that the Scanning A/D is functioning properly. No attempt is made to verify that the instrument is meeting specifications. Functional verification tests for the Scanning A/D include:

- Test F-1: Scanning A/D Self-Test
- Test F-2: A/D Overrange Detection
- Test F-3: Open Transducer Detection

NOTE

For a quick functional check of the A/D, perform only the Self-Test.

Test F-1: Scanning A/D Self-Test

Description

The self-test provides a high degree of confidence that the HP E1413A Scanning A/D is functional. The self-test may take several minutes to complete.

NOTE

During the first 5 minutes after power-on, the self-test may fail. Allow the Scanning A/D to warm up before running the self-test.

Test Procedure

1. Execute the self-test:

*TST?

Self-test command

2. Read the result. A "0" indicates that the test passed. Any other number returned indicates a self-test failure.

Example Program

This program performs a self-test of the Scanning A/D. If the test passes, "Self-test PASSED" is displayed. If the test fails, "Self-test FAILED" and a list of the error messages is displayed.


```

10! RE-STORE "SELFTEST"
20 !
30 DIM Message$(256)
40 INTEGER Result
50 ASSIGN @Ad TO 70903 Assign @Ad to Scanning A/D
60 CLEAR SCREEN
70 PRINT "Allow AT LEAST 5 minutes warmup time before running self-test"
80 DISP " Press Continue to run self-test "
90 PAUSE
100 CLEAR SCREEN
110 PRINT "Performing Self-test (may take several minutes) ..."
120 OUTPUT @Ad;"*TST?" Send self-test command (may take several minutes to complete)

130 ENTER @Ad;Result
140 CLEAR SCREEN
150 IF Result <> 0 THEN
160 PRINT "Self-test FAILED"
170 REPEAT
180 OUTPUT @Ad;"SYST:ERR?" Query error queue (See Error Messages in Appendix B)
190 ENTER @Ad;Code,Message$
200 PRINT Code,Message$
210 UNTIL NOT Code
220 ELSE
230 PRINT "Self-test PASSED"
240 END IF
250 END

```

Typical Results

If the self-test passes, a typical display is:

Self-test PASSED

If the self-test fails, a typical display is as follows. If the self-test fails, you may want to run the "SERVTEST" program (see *Chapter 5 - Service*) to determine the specific test(s) and channel number(s) that failed.

Self-test FAILED

```

3052 "Self test failed. Test info in FIFO"
0    "No error"

```

Test F-2: A/D Overrange Detection

Description

This test checks the overrange detection function of the A/D. An input of ± 17 Vdc is applied with the Scanning A/D set to the 16V range. The result should be an overrange indication ($\pm 9.90\text{E}+37$).

Equipment Setup

- Set up the equipment as shown in Figure 2-1 (Connections are shown to channel 07. You can connect inputs to any channel.)
- Be sure an SCP is installed for the channel(s) tested

WARNING

The DC Standard (Datron 4708, Option 10) can produce dangerous voltages that are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.




Figure 2-1. A/D Overrange Detection Connections

Test Procedure

Test with +17 Vdc applied (Input to channel 07 used)

1. Reset the Scanning A/D:

*RST;*CLS

*Reset Scanning A/D and
clear status registers*

2. Set Channel 07 for DCV, 16V range:

FUNC:VOLT 16, (@107,107)

*Set Scanning A/D for
voltage meas, 16 Vdc
range on ch 07*

3. Initiate Measurement Cycle:

INIT

Set Wait For Trigger state

4. Trigger the Scanning A/D:

TRIG

Trigger the instrument

5. Read measurement from Current Value Table

DATA:CVT? (@107)

*Reads channel 07 voltage
from CVT*

ENTER statement

*Returns reading - should
be 9.90E+37*

Repeat Steps 3 through 5 for -17 Vdc input

Example Program

This program performs an overrange check for +17 Vdc and -17 Vdc input to channel 07 of the Scanning A/D. If you use a different channel, change lines 60, 130, and 250 to the channel number used.

```

10! RE-STORE "OVERRANG"
20 !
30 ASSIGN @Ad TO 70903
40 OUTPUT @Addr;"*RST;*CLS"
50 WAIT 5
60 OUTPUT @Ad;"FUNC:VOLT 16, (@107,107)"
70 OUTPUT @Ad;"INIT"
80 PRINT "Apply +17 Vdc to Scanning A/D"
90 DISP " Press Continue when ready "
100 PAUSE
110 CLEAR SCREEN
120 OUTPUT @Ad;"TRIG"
130 OUTPUT @Ad;"DATA:CVT? (@107)"
140 ENTER @Ad;Result1
150 PRINT "+17 Vdc overrange indication = ";Result1
160 DISP " Record result as desired. Then, press Continue for -17 Vdc test "
170 PAUSE
180 CLEAR SCREEN
190 OUTPUT @Ad;"INIT"
200 PRINT "Apply -17 Vdc to Scanning A/D"
210 DISP " Press Continue when ready "
220 PAUSE
230 CLEAR SCREEN
240 OUTPUT @Ad;"TRIG"
250 OUTPUT @Ad;"DATA:CVT? (@107)"
260 ENTER @Ad;Result2
270 PRINT "-17 Vdc overrange indication = ";Result2
280 DISP " Record result as desired. Then, press Continue to end this test. "
290 PAUSE
300 CLEAR SCREEN
310 END

```

Assign @Ad to Scanning A/D

Reset instr and clear status registers

Wait 5 sec for reset to complete

Set ch 07 for DCV, 16V range

Set Wait For Trigger State

Trigger the instrument

Returns ch 07 value from CV Table

Set Wait For Trigger State

Trigger the instrument

Returns ch 07 value from CV Table

Typical Result

A typical result when the test passes is:

+17 Vdc overrange indication = 9.90E+37
-17 Vdc overrange indication = -9.90E+37

Test F-3: Open Transducer Detection

Description

This test checks the HP E1413A "Open Transducer Detection (OTD)" capability. If a channel with OTD capability enabled has an open transducer, the channel returns an overrange indication (9.90E+37).

To do this test, an input short is applied and the channel voltage is measured. Then, the input is opened and the channel voltage is again measured. The short should return <1 Vdc and the open should return 9.90E+37 (overrange).

NOTE

Enabling any SCP channel for OTD selects all eight channels on that SCP. Thus, an open transducer on any channel to an enabled SCP results in an OTD indication for the SCP. You will need to determine which channel(s) have open transducers. See Chapter 5 - Service for guidelines.

Equipment Setup

- Set up the equipment as shown in Figure 2-2 (Connections are shown for channel 07 - modify as required)
- Be sure an SCP is installed for the channel tested




Figure 2-2. Open Transducer Detection Connections

Test Procedure

The procedure shown is for channel 07. Modify the steps as required to check the desired channel.

Test with short applied to Scanning A/D:

1. Reset the Scanning A/D:

*RST;*CLS

*Reset Scanning A/D and
clear status registers*

2. Set channel 07 for DCV, 4V range:

FUNC:VOLT 4, (@107,107)

*Set for voltage meas,
4 Vdc range*

3. Enable channels 00-07 for OTD capability:

DIAG:OTD ON, (@107)

*Enable OTD capability on
channels 00 - 07 (SCP 0)*

4. Initiate Measurement Cycle:

INIT

Set Wait For Trigger state

5. Trigger the Scanning A/D:

TRIG

Trigger the instrument

6. Read measurement from Current Value Table:

DATA:CVT? (@107)

*Reads channel 07 voltage
from CVT*

ENTER statement

*Returns reading - should
be <1 Vdc*

**Repeat Steps 4 through 6 for open input.
Reading should now be 9.90E+37 (overrange)**

Example Program This program performs an open transducer check for channel 07. Modify lines 60, 70, 130, and 240 as required if you use a different channel.

```

10! RE-STORE "OPENTRAN"
20  !
30  ASSIGN @Ad TO 70903           Assign @Ad to Scanning A/D
40  OUTPUT @Ad;"*RST;*CLS"       Reset A/D and clear status register
50  WAIT 5                       Wait 5 sec for reset to complete
60  OUTPUT @Ad;"FUNC:VOLT 4, (@107,107)" Set ch 07 for voltage meas, 4V range
70  OUTPUT @Ad;"DIAG:OTD ON, (@107)" Enable Open Transducer Detection capability on ch 00-07 (SCP 0)

80  DISP " Apply shorted input to Scanning A/D. Press Continue when ready. "
90  PAUSE
100 CLEAR SCREEN
110 OUTPUT @Ad;"INIT"           Set Wait For Trigger State
120 OUTPUT @Ad;"TRIG"           Trigger the instrument
130 OUTPUT @Ad;"DATA:CVT? (@107)" Returns ch 07 value from CVT
140 ENTER @Ad;Result1           Enter result for shorted input
150 PRINT "Shorted input value = ";Result1 Display result - should be <1 Vdc
160 DISP "Record result as desired. Then, press Continue for open input test. "
170 PAUSE
180 CLEAR SCREEN
190 DISP " Apply open input to Scanning A/D. Press Continue when ready. "
200 PAUSE
210 CLEAR SCREEN
220 OUTPUT @Ad;"INIT"           Set Wait For Trigger State
230 OUTPUT @Ad;"TRIG"           Trigger the instrument
240 OUTPUT @Ad;"DATA:CVT? (@107)" Returns ch 07 value from CVT
250 ENTER @Ad;Result2           Enter result for open transducer
260 PRINT "Open input value = ";Result2 Display result - should be 9.90E+37
270 DISP " Record result as desired. Then, press Continue to end this test. "
280 PAUSE
290 CLEAR SCREEN
300 END

```

Typical Result

A typical result for this test is:

Shorted input value = -.002929688

Open input value = 9.90E+37

Operation Verification

For the HP E1413A Scanning A/D, operation verification tests are the same as the performance verification tests.

Performance Verification

The procedures in this section are used to test the Scanning A/D's DC voltage accuracy using the 1-year specifications in the *HP E1413A User's Manual* as the performance standards. The results of each performance verification test can be recorded on the *HP E1413A Performance Test Record* (Table 2-1 at the end of this chapter).

NOTE

If the Scanning A/D fails a performance verification test, adjust the instrument using the procedures in Chapter 3 - Adjustments and then rerun the test. If the test fails again, replace the instrument.

Verification Tests This table summarizes Scanning A/D performance verification tests.

Test	filename	Test Name	Checks DCV Meas Accuracy for:	Uses SCP:
2-1	PERF11	DCV Accuracy - Option 11	.0625V, .25V, 1.0V, 4.0V, 16.0V	Option 11
2-2	PERF12	DCV Accuracy - Option 12	.0625V, .25V, 1.0V, 4.0V, 16.0V	Option 12
2-3	PERF131	DCV Accuracy - Option 13 (Gain X1)	.0625V, .25V, 1.0V, 4.0V, and 16.0V ranges using gain X1 and 2 Hz, 10 Hz, 100 Hz filter or filter OFF	Option 13
	PERF138	DCV Accuracy - Option 13 (Gain X8)	.0625V, .25V, 1.0V, 4.0V, and 16.0V ranges using gain X8 and 2 Hz, 10 Hz, 100 Hz filter or filter OFF	Option 13
	PERF1364	DCV Accuracy - Option 13 (Gain X64)	.25V, 1.0V, 4.0V, and 16.0V ranges using gain X64 and 2 Hz, 10 Hz, 100 Hz filter or filter OFF	Option 13

Verification Test Conditions The assumed conditions for the HP E1413A performance verification tests are based on the following specifications/conditions.

- *Minimum* 1 hour warmup for the Scanning A/D and DC Standard
- Test environment temperature $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$
- Linearity = $\pm 0.02\%$ of reading (1-year specifications)
- *CAL? command executed before measurements
- CAL:ZERO? executed within 5 minutes after *CAL?
- [SENSe:]FILTer[:LPASs][:STATe] ON set

Test 2-1: DCV Accuracy - Option 11

Description

This test checks if the HP E1413A Scanning A/D meets its specifications for DC Voltage Measurement Accuracy when an Option 11 Straight-Through SCP is used.

Equipment Setup

- For channel tare/calibration connections, see Figure 2-3.
- For connections to the DC Standard (Datron 4708), see Figure 2-4.




Figure 2-3. Channel Tare/Calibration Connections




Figure 2-4. DC Standard Connections

Test Procedure

The procedure shown uses channel 07. Substitute the appropriate channel number if you use another channel.

1 Make Channel Tare/Calibration Connections

- [a] Connect wiring to terminal module (see Figure 2-2)
- [b] Connect terminal module to installed Scanning A/D

2 Check SCP 0 type (must be Option 11)

SYST:CTYP? (@107)	<i>Check SCP 0 type</i>
ENTER statement	<i>Should return "HEWLETT-PACKARD, E1413 Opt 11 8-Channel Straight- Through SCP,0,0"</i>

3 Perform Channel Calibrations

CAL:TARE (@107)	<i>Perform channel tare for wiring (*CAL? also performed)</i>
CAL:ZERO?	<i>Perform A/D Zero</i>

4 Make Connections to DC Standard

WARNING

The DC Standard (Datron 4708, Option 10) can produce dangerous voltages that are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.

- [a] Connect HI and LO leads to DC Standard (see Figure 2-4)
- [b] Set DC Standard OUTPUT to -50 mV

5 Make DCV Measurements

*RST;*CLS	<i>Reset Scanning A/D, clear status reg</i>
WAIT 5	<i>Wait 5 seconds for reset to complete</i>
FUNC:VOLT .0625, (@107,107)	<i>Set DCV meas, .0625V range on ch 07</i>
ROUT:SEQ:DEF LIST1, (@107,107)	<i>Defines ch 07 as scan list for LIST1</i>
ROUT:SCAN LIST1	<i>Sets LIST1 as Scan List</i>
TRIG:SOUR IMM	<i>Sets continuous triggering</i>
SAMP:TIM LIST1, 1E-3	<i>Pace measurements at 1 msec intervals</i>
SENS:FILT ON	<i>Enables A/D filter</i>
INIT:CONT ON	<i>Sets continuous Wait for Trigger state</i>
DATA:FIFO:PART? 100	<i>Returns 100 readings from FIFO buffer</i>

ENTER Statement

Enters 100 readings

INIT:CONT OFF

Finish scan, return to Trigger Idle state

Average = SUM(Result)/100.0

Result is average of 100 readings

6 Repeat Measurements for each Input and Range

[a] Set DC Standard OUTPUT to -37 mV and repeat Step 5

[b] Repeat [a] for the inputs and ranges in the following table

Range	.0625 V	.25 V	1.0 V	4.0 V	16.0 V
Input (Vdc)		-0.20	-0.80	-3.2	-12.8
		-0.15	-0.60	-2.4	- 9.6
	-0.025	-0.10	-0.40	-1.6	- 6.4
	-0.012	-0.05	-0.20	-0.8	- 3.2
	0.000	0.00	0.00	0.0	0.0
	0.012	0.05	0.20	0.8	3.2
	0.025	0.10	0.40	1.6	6.4
	0.037	0.15	0.60	2.4	9.6
	0.050	0.20	0.80	3.2	12.8

Example Program

An example program (TEST11) follows to show the measurement procedure. A more complete program for *Test 2-1: DCV Accuracy - Option 11* is in file "PERF11" on the *HP E1413A Service Programs* disk. To run the "PERF11" program, load the disk, type LOAD "PERF11", and then press RUN.

The "PERF11" program allows the user to make nine DCV measurements on each of the five ranges (45 measurements) when an Option 11 Straight-Through SCP is used. In addition, the "PERF11" program allows you to select the channel to be used, checks the SCP for this channel, and provides error-checking and test failure routines.

```
10! RE-STORE "TEST11"
20 !
30 ASSIGN @Ad TO 70903
40 !
50 DIM Input(1:45),Limit(1:45),Rng(1:5),Fifo(1:100)
60 DIM Avg(1:45),Offset(1:5),Range$(1:5)[7]
70 !
80 !——— Perform Channel Tare/Calibration ——
90 !
100 PRINT "Make Channel Tare/Calibration Connections"
110 PRINT
120 PRINT " 1. Connect HI lead to H07 on terminal block"
```

(continued on next page)

```

130 PRINT " 2. Connect LO lead to L07 on terminal block"
140 PRINT " 3. Connect lead between L07 and GND on terminal block"
150 PRINT " 4. Short HI and LO leads at DC Standard Conn Point"
160 PRINT " (Do NOT connect leads to DC Standard)"
170 DISP " Press Continue when ready to run channel calibration "
180 PAUSE
190 CLEAR SCREEN
200 PRINT "Performing Channel Tare, Channel Calibration, and A/D Zero"
210 PRINT "(These calibrations require about 1 - 2 minutes)"
220 OUTPUT @Ad;"CAL:TARE (@107)"
230 OUTPUT @Ad;"CAL:TARE?"
240 ENTER @Ad;Tare_res
250 OUTPUT @Ad;"CAL:ZERO?"
260 ENTER @Ad;Zero_res
270 DISP " Channel Calibrations Complete. Press Continue to make measurements "
280 PAUSE
290 CLEAR SCREEN
300 !
310 !——— Make DC Voltage Measurements ———
320 !
330 PRINT "Make Connections to DC Standard"
340 PRINT
350 PRINT " 1. Set DC Std to 0V OUTPUT and OUTPUT switch OFF"
360 PRINT " 2. Remove short between HI and LO leads at DC Std conn point"
370 PRINT " 3. Connect HI and LO leads to DC Std Hi and Lo connectors"
380 DISP " Press Continue when connections are complete "
390 PAUSE
400 CLEAR SCREEN
410 !
420 DATA -.05,-.037,-.025,-.012,0.0,.012,.025,.037,.05 !.0625 V range
430 DATA -.2,-.15,-.1,-.05,0.0,.05,.1,.15,.2 !.25 V range
440 DATA -.8,-.6,-.4,-.2,0.0,.2,.4,.6,.8 !1.0 V range
450 DATA -3.2,-2.4,-1.6,-.8,0.0,.8,1.6,2.4,3.2 !4.0 V range
460 DATA -12.8,-9.6,-6.4,-3.2,0.0,3.2,6.4,9.6,12.8 !16.0 V range
470 READ Input(*)
480 DATA .0625,.25,1.0,4.0,16.0
490 READ Rng(*)
500 DATA 1.33E-5,34.3E-5,1.21E-4,4.88E-4,1.988E-3
510 READ Offset(*)
520 DATA .0625 V,.25 V,1.0 V,4.0 V,16.0 V
530 READ Range$(*)
540 OUTPUT @Ad;"*RST;*CLS"
550 PRINT "Resetting Scanning A/D"

```

(continued on next page)

```

560 WAIT 5
570 CLEAR SCREEN
580 FOR J=1 TO 5           !5 ranges
590   FOR I=1+9*(J-1) TO 9*J   !9 meas on each range
600   Retry: !
610   PRINT "DC Volts Measurement Accuracy Test"
620   PRINT "Option 11 Straight-Through Filter SCP"
630   PRINT
640   PRINT "Scanning A/D Range: ";Rng(J);"V"
650   PRINT "Input Voltage:  ";Input(I);"V"
660   PRINT TABXY(1,12),"1. Set DC Standard OUTPUT to ";Input(I);"V"
670   PRINT TABXY(1,13),"2. Set DC Standard OUTPUT switch to ON"
680   IF I=37 OR I=45 THEN
690     BEEP
700     PRINT TABXY(1,9),"To avoid inputting an overvoltage to the Scanning A/D:"
710     PRINT TABXY(1,11),"1. Set DC Standard OUTPUT switch OFF"
720     PRINT TABXY(1,12),"2. Select the 100 V RANGE          "
730     PRINT TABXY(1,13),"3. Set DC Standard OUTPUT to ";Input(I);"V  "
740     PRINT TABXY(1,14),"4. Set DC Standard OUTPUT switch to ON"
750   END IF
760   DISP " Press Continue when ready "
770   PAUSE
780   CLEAR SCREEN
790   OUTPUT @Ad;"FUNC:VOLT "&VAL$(Rng(J))&"," (@107,107)"
800   OUTPUT @Ad;"ROUT:SEQ:DEF LIST1, (@107,107)"
810   OUTPUT @Ad;"ROUT:SCAN LIST1"
820   OUTPUT @Ad;"TRIG:SOUR IMM"
830   OUTPUT @Ad;"SAMP:TIM LIST1, 1E-3"
840   OUTPUT @Ad;"SENS:FILT ON"
850   OUTPUT @Ad;"INIT:CONT ON"
860   OUTPUT @Ad;"DATA:FIFO:PART? 100"
870   ENTER @Ad;Fifo(*)
880   OUTPUT @Ad;"INIT:CONT OFF"
890   Avg(I)=SUM(Fifo)/100.0
900   Limit(I)=Offset(J)+.0002*ABS(Input(I))
910   NEXT I
920 NEXT J
930 DISP " This completes the DCV Measurements Tests. Press Continue for results. "
940 PAUSE
950 CLEAR SCREEN
960 !
970 !————— Display Results —————
980 !

```

(continued on next page)

```

990 PRINT "                HP E1413A Scanning A/D"
1000 PRINT "                DC Voltage Accuracy Test"
1010 PRINT "                Option 11 Straight-Through SCP"
1020 PRINT
1030 PRINT "Date: ";DATE$(TIMEDATE)
1040 PRINT "Time: ";TIME$(TIMEDATE)
1050 PRINT
1060 PRINT "Range      Input      Minimum      Reading      Maximum"
1070 PRINT
1080 FOR J=1 TO 5
1090   FOR I=1+9*(J-1) TO 9*J
1100    IF ABS(Avg(I))>1.E+37 THEN Avg(I)=0
1110    IF J=1 OR J=2 THEN
1120     Input(I)=Input(I)*1.E+3
1130     Limit(I)=Limit(I)*1.E+3
1140     Avg(I)=Avg(I)*1.E+3
1150     Inp$="mV"
1160    END IF
1170    IF J>2 THEN Inp$="V"
1180 Fmt: IMAGE (7A,2X,S3D.4D,X,2A,2X,S3D.4D,X,2A,3X,S3D.4D,X,2A,3X,S3D.4D,X,2A)
1190    PRINT USING Fmt;Range$(J),Input(I),Inp$,Input(I)-Limit(I),Inp$,Avg(I),Inp$,Input(I)+Limit(I),Inp$
1200  NEXT I
1210 NEXT J
1220 END

```

Typical Result

A typical result after running "TEST11" follows.

HP E1413A Scanning A/D
DC Voltage Accuracy Test
Option 11 Straight-Through SCP

Date: 23 Nov 1993
Time: 11:15:05

Range	Input	Minimum	Reading	Maximum
.0625 V	-50.0000 mV	-50.0233 mV	-50.0071 mV	-49.9767 mV
.0625 V	-37.0000 mV	-37.0207 mV	-37.0063 mV	-36.9793 mV
16.0 V	+12.8000 V	+12.7972 V	+12.8001 V	+12.8028 V

Test 2-2: DCV Accuracy - Option 12

Description

This test checks if the HP E1413A Scanning A/D meets its specifications for DC Voltage Measurement Accuracy when an Option 12 Fixed Filter SCP is used.

Equipment Setup

- For channel tare/calibration connections, see Figure 2-5
- For connections to DC Standard (Datron 4708), see Figure 2-6




Figure 2-5. Channel Tare/Calibration Connections




Figure 2-6. DC Standard Connections

Test Procedure

The procedure shown uses channel 07. Substitute the appropriate channel number if you use another channel.

1 Make Channel Tare/Calibration Connections

- [a] Connect wiring to terminal module (see Figure 2-5)
- [b] Connect terminal module to installed Scanning A/D

2 Check SCP 0 type (must be Option 12)

SYST:CTYP? (@107)	<i>Check SCP 0 type</i>
ENTER statement	<i>Should return "HEWLETT- PACKARD,E1413 Opt 12 8-Channel Fixed Filter SCP,0,0"</i>

3 Perform Channel Calibrations

CAL:TARE (@107)	<i>Perform channel tare for wiring (*CAL? also performed)</i>
CAL:ZERO?	<i>Perform A/D Zero</i>

4 Make Connections to DC Standard

WARNING

The DC Standard (Datron 4708, Option 10) can produce dangerous voltages that are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.

- [a] Connect HI and LO leads to DC Standard (see Figure 2-6)
- [b] Set DC Standard OUTPUT to -50 mV

5 Make DCV Measurements

*RST;*CLS	<i>Reset Scanning A/D,clear status reg</i>
WAIT 5	<i>Wait 5 seconds for reset to complete</i>
FUNC:VOLT .0625, (@107,107)	<i>Set DCV meas, .0625V range on ch 07</i>
ROUT:SEQ:DEF LIST1, (@107,107)	<i>Defines ch 07 as scan list for LIST1</i>
ROUT:SCAN LIST1	<i>Sets LIST1 as Scan List</i>
TRIG:SOUR IMM	<i>Sets continuous triggering</i>
SAMP:TIM LIST1, 1E-3	<i>Pace measurements at 1 msec intervals</i>
SENS:FILT ON	<i>Enables A/D filter</i>
INIT:CONT ON	<i>Sets continuous Wait for Trigger state</i>
DATA:FIFO:PART? 100	<i>Returns 100 readings from FIFO buffer</i>

ENTER Statement	<i>Enters 100 readings</i>
INIT:CONT OFF	<i>Finish scan, return to Trigger Idle state</i>
Average = SUM(Result)/100.0	<i>Result is average of 100 readings</i>

6 Repeat Measurements for each Input and Range

- [a] Set DC Standard OUTPUT to -37 mV and repeat Step 5
- [b] Repeat [a] for the inputs and ranges in the following table

Range	.0625 V	.25 V	1.0 V	4.0 V	16.0 V
Input (Vdc)		-0.20	-0.80	-3.2	-12.8
		-0.15	-0.60	-2.4	- 9.6
	-0.025	-0.10	-0.40	-1.6	- 6.4
	-0.012	-0.05	-0.20	-0.8	- 3.2
	0.000	0.00	0.00	0.0	0.0
	0.012	0.05	0.20	0.8	3.2
	0.025	0.10	0.40	1.6	6.4
	0.037	0.15	0.60	2.4	9.6
	0.050	0.20	0.80	3.2	12.8

Example Program

An example program ("TEST11") is listed in *Test 2-1: DCV Accuracy - Option 11*. You can use this program for Test 2-2 by changing the "TEST11" program lines as follows:

```

500 DATA 2.22E-5,40.2E-5,1.25E-4,4.88E-4,1.988E-3
620 PRINT "Option 12 Fixed Filter SCP"
1010 PRINT "Option 12 Fixed Filter SCP"

```

You can also use the "PERF12" program in file "PERF12" on the *HP E1413A Service Programs* disk. To run the "PERF12" program, load the disk, type LOAD "PERF12", and then press RUN.

The "PERF12" program allows the user to make nine DCV measurements on each of the five ranges (45 measurements) when an Option 12 Fixed Filter SCP is used. In addition, the "PERF12" program allows you to select the channel to be used, checks the SCP for this channel, and provides error-checking and test failure routines.

Typical Result

A typical result after running "TEST11" with modifications to lines 500, 620, and 1010 follows.

HP E1413A Scanning A/D
DC Voltage Accuracy Test
Option 12 Fixed Filter SCP

Date: 23 Nov 1993

Time: 11:15:05

Range	Input	Minimum	Reading	Maximum
.0625 V	-50.0000 mV	-50.0322 mV	-50.0071 mV	-49.9678 mV
.0625 V	-37.0000 mV	-37.0296 mV	-37.0063 mV	-36.9704 mV
16.0 V	+12.8000 V	+12.7955 V	+12.8001 V	+12.8045 V

Test 2-3: DCV Accuracy - Option 13

Description

This test checks if the HP E1413A Scanning A/D meets its specifications for DC Voltage Measurement Accuracy when an Option 13 Amplifier+ Filter SCP is used.

Equipment Setup

- For channel tare/calibration connections, see Figure 2-7
- For connections to DC Standard (Datron 4708), see Figure 2-8




Figure 2-7. Channel Tare/Calibration Connections




Figure 2-8. DC Standard Connections

Test Procedure

The procedure shown uses channel 07, gain X1, and 100 Hz filter cutoff frequency. Substitute the appropriate channel number, gain, and filter cutoff frequency as required for your application.

1 Make Channel Tare/Calibration Connections

- [a] Connect wiring to terminal module (see Figure 2-7)
- [b] Connect terminal module to installed Scanning A/D

2 Check SCP 0 type (must be Option 13)

SYST:CTYP? (@107)	<i>Check SCP 0 type</i>
ENTER statement	<i>Should return "HEWLETT-PACKARD, E1413 Opt 13 8-Channel Amp+Filter SCP,0,0"</i>

3 Perform Channel Calibrations

CAL:TARE (@107)	<i>Perform channel tare for wiring (*CAL? also performed)</i>
CAL:ZERO?	<i>Perform A/D Zero</i>

4 Make Connections to DC Standard

WARNING

The DC Standard (Datron 4708, Option 10) can produce dangerous voltages that are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.

- [a] Connect HI and LO leads to DC Standard (see Figure 2-8)
- [b] Set DC Standard OUTPUT to -50 mV

5 Make DCV Measurements

*RST;*CLS	<i>Reset Scanning A/D, clear status reg</i>
WAIT 5	<i>Wait 5 seconds for reset to complete</i>
INP:GAIN 1, (@107)	<i>Set SCP gain X1</i>
INP:FILT:FREQ 100, (@107)	<i>Set 100 Hz as filter cutoff freq</i>
FUNC:VOLT .0625, (@107,107)	<i>Set DCV meas, .0625V range on ch 07</i>
ROUT:SEQ:DEF LIST1, (@107,107)	<i>Defines ch 07 as scan list for LIST1</i>
ROUT:SCAN LIST1	<i>Sets LIST1 as Scan List</i>
TRIG:SOUR IMM	<i>Sets continuous triggering</i>
SAMP:TIM LIST1, 1E-3	<i>Pace measurements at 1 msec intervals</i>
SENS:FILT ON	<i>Enables A/D filter</i>

INIT:CONT ON	<i>Sets continuous Wait for Trigger state</i>
DATA:FIFO:PART? 400	<i>Returns 400 readings from FIFO buffer</i>
ENTER Statement	<i>Enters 400 readings</i>
INIT:CONT OFF	<i>Finish scan, return to Trigger Idle state</i>
Average = SUM(Result)/400.0	<i>Result is average of 400 readings</i>

6 Repeat Measurements for each Input and Range

- [a] Set DC Standard OUTPUT to -37 mV and repeat Step 5
 [b] Repeat [a] for the inputs and ranges in the following table

Range	.0625V	.25V	1.0 V	4.0 V	16.0 V
Gain X1	-50 mV	-0.20 V	-0.80 V	-3.2 V	-12.8 V
	-37 mV	-0.15 V	-0.60 V	-2.4 V	- 9.6 V
	-25 mV	-0.10 V	-0.40 V	-1.6 V	- 6.4 V
	-12 mV	-0.05 V	-0.20 V	-0.8 V	- 3.2 V
	0 mV	0.00 V	0.00 V	0.0 V	0.0 V
	12 mV	0.05 V	0.20 V	0.8 V	3.2 V
	25 mV	0.10 V	0.40 V	1.6 V	6.4 V
	37 mV	0.15 V	0.60 V	2.4 V	9.6 V
	50 mV	0.20 V	0.80 V	3.2 V	12.8 V
Gain X8	-6.0 mV	-25 mV	-100 mV	-0.4 V	-1.6 V
	-4.5 mV	-18 mV	- 75 mV	-0.3 V	-1.2 V
	-3.0 mV	-12 mV	- 50 mV	-0.2 V	-0.8 V
	-1.5 mV	- 6 mV	- 25 mV	-0.1 V	-0.4 V
	0.0 mV	0 mV	0 mV	0.0 V	0.0 V
	1.5 mV	6 mV	25 mV	0.1 V	0.4 V
	3.0 mV	12 mV	50 mV	0.2 V	0.8 V
	4.5 mV	18 mV	75 mV	0.3 V	1.2 V
	6.0 mV	25 mV	100 mV	0.4 V	1.6 V
Gain X64	N/A	-3.0 mV	-12.8 mV	-50.0 mV	-200 V
		-2.5 mV	- 9.6 mV	-37.5 mV	-150 V
		-1.5 mV	- 6.4 mV	-25.0 mV	-100 V
		-0.8 mV	- 3.2 mV	-12.5 mV	- 50 V
		0.0 mV	0.0 mV	0.0 mV	0 V
		0.8 mV	3.2 mV	12.5 mV	50 V
		1.5 mV	6.4 mV	25.0 mV	100 V
		2.5 mV	9.6 mV	37.5 mV	150 V
		3.0 mV	12.8 mV	50.0 mV	200 V

Example Program

An example program ("TEST131") follows to show the measurement procedure. More complete programs for *Test 2-3: DCV Accuracy - Option 13* are in files "PERF131" (for gain X1), "PERF138" (for gain X8), and "PERF1364" (for gain X64) on the *HP E1413A Service Programs* disk. To run the "PERF13X" programs, load the disk, type LOAD "PERF131", "PERF138", or "PERF1364" and then press RUN.

The "PERF131" and "PERF138" programs allow the user to make nine DCV measurements on each of the five ranges (45 measurements) when an Option 13 Amplifier+Filter SCP is used. The "PERF1364" program allows the user to make nine DCV measurements on each of four ranges (36 measurements), since the .0625V range is not allowed for gain X64 measurements.

In addition, the "PERF13X" programs allow you to select the channel to be used and the filter cutoff frequency (2 Hz, 10 Hz, 100 Hz or filter OFF), checks the SCP for the channel selected, and provides error-checking and test failure routines.

NOTE

Use the "PERF138" program for SCP gain X8 or use the "PERF1364" program for SCP gain X64. For gain X64, note that only four ranges are measured, as the .0625V range is not allowed for gain X64 measurements.

There are 12 performance verification tests available for the Option 13 SCP. You may do any or all tests, depending on your specific application requirements. The Option 13 SCP was factory-tested at 2 Hz, 10 Hz, 100 Hz and filter OFF for gain X1; at 100 Hz for gain X8; and at 100 Hz for gain X64.

```
10! RE-STORE "TEST131"
20 !
30 ASSIGN @Ad TO 70903
40 !
50 DIM Input(1:45),Limit(1:45),Rng(1:5),Fifo(1:400)
60 DIM Avg(1:45),Offset(1:5),Range$(1:5)[7]
70 !
80 !————— Perform Channel Tare/Calibration —————
90 !
100 PRINT "Make Channel Tare/Calibration Connections"
110 PRINT
```

(continued on next page)

```

120 PRINT " 1. Connect HI lead to H07 on terminal block"
130 PRINT " 2. Connect LO lead to L07 on terminal block"
140 PRINT " 3. Connect lead between L07 and GND on terminal block"
150 PRINT " 4. Short HI and LO leads at DC Standard Conn Point"
160 PRINT " (Do NOT connect leads to DC Standard)"
170 DISP " Press Continue when ready to run channel calibration "
180 PAUSE
190 CLEAR SCREEN
200 PRINT "Performing Channel Tare, Channel Calibration, and A/D Zero"
210 PRINT "(These calibrations require about 1 - 2 minutes)"
220 OUTPUT @Ad;"CAL:TARE (@107)"
230 OUTPUT @Ad;"CAL:TARE?"
240 ENTER @Ad;Tare_res
250 OUTPUT @Ad;"CAL:ZERO?"
260 ENTER @Ad;Zero_res
270 DISP " Channel Calibrations Complete. Press Continue to make measurements "
280 PAUSE
290 CLEAR SCREEN
300 !
310 !——— Make DC Voltage Measurements ———
320 !
330 PRINT "Make Connections to DC Standard"
340 PRINT
350 PRINT " 1. Set DC Std to 0V OUTPUT and OUTPUT switch OFF"
360 PRINT " 2. Remove short between HI and LO leads at DC Std conn point"
370 PRINT " 3. Connect HI and LO leads to DC Std Hi and Lo connectors"
380 DISP " Press Continue when connections are complete "
390 PAUSE
400 CLEAR SCREEN
410 !
420 DATA -.05,-.037,-.025,-.012,0.0,.012,.025,.037,.05 !.0625 V range
430 DATA -.2,-.15,-.1,-.05,0.0,.05,.1,.15,.2 !.25 V range
440 DATA -.8,-.6,-.4,-.2,0.0,.2,.4,.6,.8 !1.0 V range
450 DATA -3.2,-2.4,-1.6,-.8,0.0,.8,1.6,2.4,3.2 !4.0 V range
460 DATA -12.8,-9.6,-6.4,-3.2,0.0,3.2,6.4,9.6,12.8 !16.0 V range
470 READ Input(*)
480 DATA .0625,.25,1.0,4.0,16.0
490 READ Rng(*)
500 DATA 3.28E-5,4.28E-5,1.243E-4,4.88E-4,1.988E-3
510 READ Offset(*)
520 DATA .0625 V,.25 V,1.0 V,4.0 V,16.0 V
530 READ Range$(*)
540 OUTPUT @Ad;"*RST;*CLS"

```

(continued on next page)

```

550 PRINT "Resetting Scanning A/D"
560 WAIT 5
570 CLEAR SCREEN
580 OUTPUT @Ad;"INP:GAIN 1, (@107)"
590 OUTPUT @Ad;"INP:FILT:FREQ 100, (@107)"
600 FOR J=1 TO 5           !5 ranges
610   FOR I=1+9*(J-1) TO 9*J   !9 meas on each range
620   Retry: !
630     PRINT "DC Volts Measurement Accuracy Test"
640     PRINT "Option 13 Amplifier+Filter SCP"
650     PRINT "Gain X1 and 100 Hz Filter"
660     PRINT
670     PRINT "Scanning A/D Range: ";Rng(J);"V"
680     PRINT "Input Voltage:  ";Input(I);"V"
690     PRINT TABXY(1,12),"1. Set DC Standard OUTPUT to ";Input(I);"V"
700     PRINT TABXY(1,13),"2. Set DC Standard OUTPUT switch to ON"
710     IF I=37 OR I=45 THEN
720       BEEP
730       PRINT TABXY(1,9),"To avoid inputting an overvoltage to the Scanning A/D:"
740       PRINT TABXY(1,11),"1. Set DC Standard OUTPUT switch OFF"
750       PRINT TABXY(1,12),"2. Select the 100 V RANGE          "
760       PRINT TABXY(1,13),"3. Set DC Standard OUTPUT to ";Input(I);"V  "
770       PRINT TABXY(1,14),"4. Set DC Standard OUTPUT switch to ON"
780     END IF
790     DISP " Press Continue when ready "
800     PAUSE
810     CLEAR SCREEN
820     OUTPUT @Ad;"FUNC:VOLT "&VAL$(Rng(J))&," (@107,107)"
830     OUTPUT @Ad;"ROUT:SEQ:DEF LIST1, (@107,107)"
840     OUTPUT @Ad;"ROUT:SCAN LIST1"
850     OUTPUT @Ad;"TRIG:SOUR IMM"
860     OUTPUT @Ad;"SAMP:TIM LIST1, 1E-3"
870     OUTPUT @Ad;"SENS:FILT ON"
880     OUTPUT @Ad;"INIT:CONT ON"
890     OUTPUT @Ad;"DATA:FIFO:PART? 400"
900     ENTER @Ad;Fifo(*)
910     OUTPUT @Ad;"INIT:CONT OFF"
920     Avg(I)=SUM(Fifo)/400.0
930     Limit(I)=Offset(J)+.0002*ABS(Input(I))
940   NEXT I
950 NEXT J
960 DISP " This completes the DCV Measurements Tests. Press Continue for results. "
970 PAUSE

```

(continued on next page)


```

980 CLEAR SCREEN
990 !
1000 !----- Display Results -----
1010 !
1020 PRINT "          HP E1413A Scanning A/D"
1030 PRINT "          DC Voltage Accuracy Test"
1040 PRINT "          Option 13 Amplifier+Filter SCP"
1050 PRINT "          Gain X1 and 100 Hz Filter"
1060 PRINT
1070 PRINT "Date: ";DATE$(TIMEDATE)
1080 PRINT "Time: ";TIME$(TIMEDATE)
1090 PRINT
1100 PRINT "Range      Input      Minimum      Reading      Maximum"
1110 PRINT
1120 FOR J=1 TO 5
1130   FOR I=1+9*(J-1) TO 9*J
1140    IF ABS(Avg(I))>1.E+37 THEN Avg(I)=0
1150    IF J=1 OR J=2 THEN
1160     Input(I)=Input(I)*1.E+3
1170     Limit(I)=Limit(I)*1.E+3
1180     Avg(I)=Avg(I)*1.E+3
1190     Inp$="mV"
1200    END IF
1210    IF J>2 THEN Inp$="V"
1220 Fmt: IMAGE (7A,2X,S3D.4D,X,2A,2X,S3D.4D,X,2A,3X,S3D.4D,X,2A,3X,S3D.4D,X,2A)
1230    PRINT USING Fmt;Range$(J),Input(I),Inp$,Input(I)-Limit(I),Inp$,Avg(I),Inp$,Input(I)+Limit(I),Inp$
1240   NEXT I
1250 NEXT J
1260 END

```

Typical Result

A typical result after running "TEST131" follows.

HP E1413A Scanning A/D
DC Voltage Accuracy Test
Option 13 Amplifier+Filter SCP
Gain X1 and 100 Hz Filter

Date: 23 Nov 1993
Time: 11:15:05

Range	Input	Minimum	Reading	Maximum
.0625 V	-50.0000 mV	-50.0428 mV	-50.0071 mV	-49.9572 mV
.0625 V	-37.0000 mV	-37.0402 mV	-37.0063 mV	-36.9598 mV
16.0 V	+12.8000 V	+12.7955 V	+12.8001 V	+12.8045 V

Performance Test Record

Table 2-1, *HP E1413A Performance Test Record*, is a form you can copy and use to record performance verification test results for the HP E1413A Scanning A/D. This table shows HP E1413A Scanning A/D instrument accuracy, Datron 4708 Option 10 measurement uncertainty, and test accuracy ratio (TAR) values. See *Appendix A - Calculating Scanning A/D Accuracy* for information on accuracy, measurement uncertainty, and TAR calculations.

Scanning A/D Test Limits

Test limits are defined using the 1-year specifications in *Appendix A - Specifications* of the *HP E1413A User's Manual*. See *Appendix A - Calculating Scanning A/D Accuracy* in this manual for sample calculations of Scanning A/D test limits.

Measurement Uncertainty

For the performance verification tests in this manual, the measurement uncertainties are based on the 90-day accuracy specifications for the Datron 4708 Source. See *Appendix A - Calculating Scanning A/D Accuracy* in this manual for sample calculations of measurement uncertainty.

Test Accuracy Ratio (TAR)

Test Accuracy Ratio (TAR) for the HP E1413A is defined as Scanning A/D Accuracy divided by Measurement Uncertainty, where accuracy = maximum allowable value - expected reading. That is:

$$\text{TAR} = \frac{\text{Maximum Value} - \text{Expected Reading}}{\text{Measurement Uncertainty}}$$

For TARs that exceed 10:1, the entry is ">10:1".

[illegible]

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 2 of 16)

Test Equipment Used: Description	Model No.	Trace No.	Cal Due Date
1. _____	_____	_____	_____
2. _____	_____	_____	_____
3. _____	_____	_____	_____
4. _____	_____	_____	_____
5. _____	_____	_____	_____
6. _____	_____	_____	_____
7. _____	_____	_____	_____
8. _____	_____	_____	_____
9. _____	_____	_____	_____
10. _____	_____	_____	_____
11. _____	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____
14. _____	_____	_____	_____
15. _____	_____	_____	_____
16. _____	_____	_____	_____
17. _____	_____	_____	_____
18. _____	_____	_____	_____
19. _____	_____	_____	_____
20. _____	_____	_____	_____

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 3 of 16)

Test 2-1: DCV Measurement Accuracy - Option 11 Straight-Through SCP						
Range	Input	Minimum	Measured	Maximum	M.U.*	TAR**
.0625 V	- 50.0000 mV	- 50.0233 mV		- 49.9767 mV	7.5E-7 V	>10:1
	- 37.0000 mV	- 37.0207 mV		- 36.9793 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0183 mV		- 24.9817 mV	5.8E-7 V	>10:1
	- 12.0000 mV	- 12.0157 mV		- 11.9843 mV	4.8E-7 V	>10:1
	0.0000 mV	0.0133 mV		+ 0.0133 mV	4.0E-7 V	>10:1
	+ 12.0000 mV	+ 11.9843 mV		+ 12.0157 mV	4.8E-7 V	>10:1
	+ 25.0000 mV	+ 24.9817 mV		+ 25.0183 mV	5.8E-7 V	>10:1
	+ 37.0000 mV	+ 36.9793 mV		+ 37.0207 mV	6.6E-7 V	>10:1
	+ 50.0000 mV	+ 49.9796 mV		+ 50.0233 mV	7.5E-7 V	>10:1
.25 V	- 200.0000 mV	- 200.0743 mV		- 199.9257 mV	1.6E-6 V	>10:1
	- 150.0000 mV	- 150.0643 mV		- 149.9357 mV	1.4E-6 V	>10:1
	- 100.0000 mV	- 100.0543 mV		- 99.9457 mV	1.2E-6 V	>10:1
	- 50.0000 mV	- 50.0443 mV		- 49.9557 mV	1.0E-6 V	>10:1
	0.0000 mV	0.0343 mV		+ 0.0343 mV	8.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9557 mV		+ 50.0443 mV	1.0E-6 V	>10:1
	+ 100.0000 mV	+ 99.9457 mV		+ 100.0543 mV	1.2E-6 V	>10:1
	+ 150.0000 mV	+ 149.9357 mV		+ 150.0643 mV	1.4E-6 V	>10:1
	+ 200.0000 mV	+ 199.9257 mV		+ 200.0743 mV	1.6E-6 V	>10:1
1.0V	- 0.8000 V	- 0.8003 V		- 0.7997 V	5.0E-6 V	>10:1
	- 0.6000 V	- 0.6002 V		- 0.5998 V	4.5E-6 V	>10:1
	- 0.4000 V	- 0.4002 V		- 0.3998 V	4.0E-6 V	>10:1
	- 0.2000 V	- 0.2002 V		- 0.1998 V	3.5E-6 V	>10:1
	0.0000 V	- 0.0001 V		+ 0.0001 V	3.0E-6 V	>10:1
	+ 0.2000 V	+ 0.1998 V		+ 0.2002 V	3.5E-6 V	>10:1
	+ 0.4000 V	+ 0.3998 V		+ 0.4002 V	4.0E-6 V	>10:1
	+ 0.6000 V	+ 0.5998 V		+ 0.6002 V	4.5E-6 V	>10:1
	+ 0.8000 V	+ 0.7997 V		+ 0.8003 V	5.0E-6 V	>10:1
4.0V	- 3.2000 V	- 3.2011 V		- 3.1989 V	1.1E-5 V	>10:1
	- 2.4000 V	- 2.4010 V		- 2.3990 V	9.0E-6 V	>10:1
	- 1.6000 V	- 1.6008 V		- 1.5992 V	7.0E-6 V	>10:1
	- 0.8000 V	- 0.8006 V		- 0.7994 V	5.0E-6 V	>10:1
	0.0000 V	- 0.0005 V		+ 0.0005 V	3.0E-6 V	>10:1
	+ 0.8000 V	+ 0.7994 V		+ 0.8006 V	5.0E-6 V	>10:1
	+ 1.6000 V	+ 1.5992 V		+ 1.6008 V	7.0E-6 V	>10:1
	+ 2.4000 V	+ 2.3990 V		+ 2.4010 V	9.0E-6 V	>10:1
	+ 3.2000 V	+ 3.1989 V		+ 3.2011 V	1.1E-5 V	>10:1
16.0V	- 12.8000 V	- 12.8045 V		- 12.7955 V	1.0E-4 V	>10:1
	- 9.6000 V	- 9.6039 V		- 9.5961 V	8.8E-5 V	>10:1
	- 6.4000 V	- 6.4033 V		- 6.3967 V	7.6E-5 V	>10:1
	- 3.2000 V	- 3.2026 V		- 3.1974 V	6.3E-5 V	>10:1
	0.0000 V	- 0.0020 V		+ 0.0020 V	5.0E-5 V	>10:1
	+ 3.2000 V	+ 3.1974 V		+ 3.2026 V	6.3E-5 V	>10:1
	+ 6.4000 V	+ 6.3967 V		+ 6.4033 V	7.6E-5 V	>10:1
	+ 9.6000 V	+ 9.5961 V		+ 9.6039 V	8.8E-5 V	>10:1
	+ 12.8000 V	+ 12.7955 V		+ 12.8045 V	1.0E-4 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 4 of 16)

Test 2-2: DCV Measurement Accuracy - Option 12 Fixed Filter SCP						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 50.0000 mV	- 50.0322 mV		- 49.9678 mV	7.5E-7 V	>10:1
	- 37.0000 mV	- 37.0296 mV		- 36.9704 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0272 mV		- 24.9728 mV	5.8E-7 V	>10:1
	- 12.0000 mV	- 12.0246 mV		- 11.9754 mV	4.8E-7 V	>10:1
	0.0000 mV	- 0.0222 mV		+ 0.0222 mV	4.0E-7 V	>10:1
	+ 12.0000 mV	+ 11.9754 mV		+ 12.0246 mV	4.8E-7 V	>10:1
	+ 25.0000 mV	+ 24.9728 mV		+ 25.0272 mV	5.8E-7 V	>10:1
	+ 37.0000 mV	+ 36.9704 mV		+ 37.0296 mV	6.6E-7 V	>10:1
	+ 50.0000 mV	+ 49.9678 mV		+ 50.0322 mV	7.5E-7 V	>10:1
.25 V	- 200.0000 mV	- 200.0802 mV		- 199.9198 mV	1.6E-6 V	>10:1
	- 150.0000 mV	- 150.0702 mV		- 149.9298 mV	1.4E-6 V	>10:1
	- 100.0000 mV	- 100.0602 mV		- 99.9398 mV	1.2E-6 V	>10:1
	- 50.0000 mV	- 50.0502 mV		- 49.9498 mV	1.0E-6 V	>10:1
	0.0000 mV	- 0.0402 mV		+ 0.0402 mV	8.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9498 mV		+ 50.0502 mV	1.0E-6 V	>10:1
	+100.0000 mV	+ 99.9398 mV		+100.0602 mV	1.2E-6 V	>10:1
	+150.0000 mV	+149.9298 mV		+150.0702 mV	1.4E-6 V	>10:1
	+200.0000 mV	+199.9198 mV		+200.0802 mV	1.6E-6 V	>10:1
1.0V	- 0.8000 V	- 0.8003 V		- 0.7997 V	5.0E-6 V	>10:1
	- 0.6000 V	- 0.6002 V		- 0.5998 V	4.5E-6 V	>10:1
	- 0.4000 V	- 0.4002 V		- 0.3998 V	4.0E-6 V	>10:1
	- 0.2000 V	- 0.2002 V		- 0.1998 V	3.5E-6 V	>10:1
	0.0000 V	- 0.0001 V		+0.0001 V	3.0E-6 V	>10:1
	+0.2000 V	+0.1998 V		+0.2002 V	3.5E-6 V	>10:1
	+0.4000 V	+0.3998 V		+0.4002 V	4.0E-6 V	>10:1
	+0.6000 V	+0.5998 V		+0.6002 V	4.5E-6 V	>10:1
	+0.8000 V	+0.7997 V		+0.8003 V	5.0E-6 V	>10:1
4.0V	- 3.2000 V	- 3.2011 V		- 3.1989 V	1.1E-5 V	>10:1
	- 2.4000 V	- 2.4010 V		- 2.3990 V	9.0E-6 V	>10:1
	- 1.6000 V	- 1.6008 V		- 1.5992 V	7.0E-6 V	>10:1
	- 0.8000 V	- 0.8006 V		- 0.7994 V	5.0E-6 V	>10:1
	0.0000 V	- 0.0005 V		+0.0005 V	3.0E-6 V	>10:1
	+0.8000 V	+0.7994 V		+0.8006 V	5.0E-6 V	>10:1
	+1.6000 V	+1.5992 V		+1.6008 V	7.0E-6 V	>10:1
	+2.4000 V	+2.3990 V		+2.4010 V	9.0E-6 V	>10:1
	+3.2000 V	+3.1989 V		+3.2011 V	1.1E-5 V	>10:1
16.0V	- 12.8000 V	- 12.8045 V		- 12.7955 V	1.0E-4 V	>10:1
	- 9.6000 V	- 9.6039 V		- 9.5961 V	8.8E-5 V	>10:1
	- 6.4000 V	- 6.4033 V		- 6.3967 V	7.6E-5 V	>10:1
	- 3.2000 V	- 3.2026 V		- 3.1974 V	6.3E-5 V	>10:1
	0.0000 V	- 0.0020 V		+ 0.0020 V	5.0E-5 V	>10:1
	+ 3.2000 V	+ 3.1974 V		+ 3.2026 V	6.3E-5 V	>10:1
	+ 6.4000 V	+ 6.3967 V		+ 6.4033 V	7.6E-5 V	>10:1
	+ 9.6000 V	+ 9.5961 V		+ 9.6039 V	8.8E-5 V	>10:1
	+12.8000 V	+12.7955 V		+12.8045 V	1.0E-4 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 5 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X1, 2 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 50.0000 mV	- 50.0490 mV		- 49.9510 mV	7.5E-7 V	>10:1
	- 37.0000 mV	- 37.0464 mV		- 36.9536 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0440 mV		- 24.9560 mV	5.8E-7 V	>10:1
	- 12.0000 mV	- 12.0414 mV		- 11.9586 mV	4.8E-7 V	>10:1
	0.0000 mV	- 0.0390 mV		+ 0.0390 mV	4.0E-7 V	>10:1
	+ 12.0000 mV	+ 11.9586 mV		+ 12.0414 mV	4.8E-7 V	>10:1
	+ 25.0000 mV	+ 24.9560 mV		+ 25.0440 mV	5.8E-7 V	>10:1
	+ 37.0000 mV	+ 36.9536 mV		+ 37.0464 mV	6.6E-7 V	>10:1
	+ 50.0000 mV	+ 49.9510 mV		+ 50.0490 mV	7.5E-7 V	>10:1
.25 V	- 200.0000 mV	- 200.0860 mV		- 199.9140 mV	1.6E-6 V	>10:1
	- 150.0000 mV	- 150.0760 mV		- 149.9240 mV	1.4E-6 V	>10:1
	- 100.0000 mV	- 100.0660 mV		- 99.9340 mV	1.2E-6 V	>10:1
	- 50.0000 mV	- 50.0560 mV		- 49.9440 mV	1.0E-6 V	>10:1
	0.0000 mV	- 0.0460 mV		+ 0.0460 mV	8.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9440 mV		+ 50.0560 mV	1.0E-6 V	>10:1
	+100.0000 mV	+ 99.9340 mV		+100.0660 mV	1.2E-6 V	>10:1
	+150.0000 mV	+149.9240 mV		+150.0760 mV	1.4E-6 V	>10:1
	+200.0000 mV	+199.9140 mV		+200.0860 mV	1.6E-6 V	>10:1
1.0V	- 0.8000 V	- 0.8003 V		- 0.7997 V	5.0E-6 V	>10:1
	- 0.6000 V	- 0.6002 V		- 0.5998 V	4.5E-6 V	>10:1
	- 0.4000 V	- 0.4002 V		- 0.3998 V	4.0E-6 V	>10:1
	- 0.2000 V	- 0.2002 V		- 0.1998 V	3.5E-6 V	>10:1
	0.0000 V	- 0.0001 V		+0.0001 V	3.0E-6 V	>10:1
	+0.2000 V	+0.1998 V		+0.2002 V	3.5E-6 V	>10:1
	+0.4000 V	+0.3998 V		+0.4002 V	4.0E-6 V	>10:1
	+0.6000 V	+0.5998 V		+0.6002 V	4.5E-6 V	>10:1
	+0.8000 V	+0.7997 V		+0.8003 V	5.0E-6 V	>10:1
4.0V	- 3.2000 V	- 3.2011 V		- 3.1989 V	1.1E-5 V	>10:1
	- 2.4000 V	- 2.4010 V		- 2.3990 V	9.0E-6 V	>10:1
	- 1.6000 V	- 1.6008 V		- 1.5992 V	7.0E-6 V	>10:1
	- 0.8000 V	- 0.8006 V		- 0.7994 V	5.0E-6 V	>10:1
	0.0000 V	- 0.0005 V		+0.0005 V	3.0E-6 V	>10:1
	+0.8000 V	+0.7994 V		+0.8006 V	5.0E-6 V	>10:1
	+1.6000 V	+1.5992 V		+1.6008 V	7.0E-6 V	>10:1
	+2.4000 V	+2.3990 V		+2.4010 V	9.0E-6 V	>10:1
	+3.2000 V	+3.1989 V		+3.2011 V	1.1E-5 V	>10:1
16.0V	- 12.8000 V	- 12.8045 V		- 12.7955 V	1.0E-4 V	>10:1
	- 9.6000 V	- 9.6039 V		- 9.5961 V	8.8E-5 V	>10:1
	- 6.4000 V	- 6.4033 V		- 6.3967 V	7.6E-5 V	>10:1
	- 3.2000 V	- 3.2026 V		- 3.1974 V	6.3E-5 V	>10:1
	0.0000 V	- 0.0020 V		+ 0.0020 V	5.0E-5 V	>10:1
	+ 3.2000 V	+ 3.1974 V		+ 3.2026 V	6.3E-5 V	>10:1
	+ 6.4000 V	+ 6.3967 V		+ 6.4033 V	7.6E-5 V	>10:1
	+ 9.6000 V	+ 9.5961 V		+ 9.6039 V	8.8E-5 V	>10:1
	+12.8000 V	+12.7955 V		+12.8045 V	1.0E-4 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 6 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X1, 10 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 50.0000 mV	- 50.0455 mV		- 49.9545 mV	7.5E-7 V	>10:1
	- 37.0000 mV	- 37.0429 mV		- 36.9571 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0405 mV		- 24.9595 mV	5.8E-7 V	>10:1
	- 12.0000 mV	- 12.0379 mV		- 11.9621 mV	4.8E-7 V	>10:1
	0.0000 mV	- 0.0355 mV		+ 0.0355 mV	4.0E-7 V	>10:1
	+ 12.0000 mV	+ 11.9621 mV		+ 12.0379 mV	4.8E-7 V	>10:1
	+ 25.0000 mV	+ 24.9595 mV		+ 25.0405 mV	5.8E-7 V	>10:1
	+ 37.0000 mV	+ 36.9571 mV		+ 37.0429 mV	6.6E-7 V	>10:1
	+ 50.0000 mV	+ 49.9545 mV		+ 50.0455 mV	7.5E-7 V	>10:1
.25 V	- 200.0000 mV	- 200.0835 mV		- 199.9165 mV	1.6E-6 V	>10:1
	- 150.0000 mV	- 150.0735 mV		- 149.9265 mV	1.4E-6 V	>10:1
	- 100.0000 mV	- 100.0635 mV		- 99.9365 mV	1.2E-6 V	>10:1
	- 50.0000 mV	- 50.0535 mV		- 49.9465 mV	1.0E-6 V	>10:1
	0.0000 mV	- 0.0435 mV		+ 0.0435 mV	8.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9465 mV		+ 50.0535 mV	1.0E-6 V	>10:1
	+ 100.0000 mV	+ 99.9365 mV		+ 100.0635 mV	1.2E-6 V	>10:1
	+ 150.0000 mV	+ 149.9265 mV		+ 150.0735 mV	1.4E-6 V	>10:1
	+ 200.0000 mV	+ 199.9165 mV		+ 200.0835 mV	1.6E-6 V	>10:1
1.0V	- 0.8000 V	- 0.8003 V		- 0.7997 V	5.0E-6 V	>10:1
	- 0.6000 V	- 0.6002 V		- 0.5998 V	4.5E-6 V	>10:1
	- 0.4000 V	- 0.4002 V		- 0.3998 V	4.0E-6 V	>10:1
	- 0.2000 V	- 0.2002 V		- 0.1998 V	3.5E-6 V	>10:1
	0.0000 V	- 0.0001 V		+ 0.0001 V	3.0E-6 V	>10:1
	+ 0.2000 V	+ 0.1998 V		+ 0.2002 V	3.5E-6 V	>10:1
	+ 0.4000 V	+ 0.3998 V		+ 0.4002 V	4.0E-6 V	>10:1
	+ 0.6000 V	+ 0.5998 V		+ 0.6002 V	4.5E-6 V	>10:1
	+ 0.8000 V	+ 0.7997 V		+ 0.8003 V	5.0E-6 V	>10:1
4.0V	- 3.2000 V	- 3.2011 V		- 3.1989 V	1.1E-5 V	>10:1
	- 2.4000 V	- 2.4010 V		- 2.3990 V	9.0E-6 V	>10:1
	- 1.6000 V	- 1.6008 V		- 1.5992 V	7.0E-6 V	>10:1
	- 0.8000 V	- 0.8006 V		- 0.7994 V	5.0E-6 V	>10:1
	0.0000 V	- 0.0005 V		+ 0.0005 V	3.0E-6 V	>10:1
	+ 0.8000 V	+ 0.7994 V		+ 0.8006 V	5.0E-6 V	>10:1
	+ 1.6000 V	+ 1.5992 V		+ 1.6008 V	7.0E-6 V	>10:1
	+ 2.4000 V	+ 2.3990 V		+ 2.4010 V	9.0E-6 V	>10:1
	+ 3.2000 V	+ 3.1989 V		+ 3.2011 V	1.1E-5 V	>10:1
16.0V	- 12.8000 V	- 12.8045 V		- 12.7955 V	1.0E-4 V	>10:1
	- 9.6000 V	- 9.6039 V		- 9.5961 V	8.8E-5 V	>10:1
	- 6.4000 V	- 6.4033 V		- 6.3967 V	7.6E-5 V	>10:1
	- 3.2000 V	- 3.2026 V		- 3.1974 V	6.3E-5 V	>10:1
	0.0000 V	- 0.0020 V		+ 0.0020 V	5.0E-5 V	>10:1
	+ 3.2000 V	+ 3.1974 V		+ 3.2026 V	6.3E-5 V	>10:1
	+ 6.4000 V	+ 6.3967 V		+ 6.4033 V	7.6E-5 V	>10:1
	+ 9.6000 V	+ 9.5961 V		+ 9.6039 V	8.8E-5 V	>10:1
	+ 12.8000 V	+ 12.7955 V		+ 12.8045 V	1.0E-4 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 7 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X1 and 100 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 50.0000 mV	- 50.0428 mV		- 49.9572 mV	7.5E-7 V	>10:1
	- 37.0000 mV	- 37.0402 mV		- 36.9598 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0378 mV		- 24.9622 mV	5.8E-7 V	>10:1
	- 12.0000 mV	- 12.0352 mV		- 11.9648 mV	4.8E-7 V	>10:1
	0.0000 mV	- 0.0328 mV		+ 0.0328 mV	4.0E-7 V	>10:1
	+ 12.0000 mV	+ 11.9648 mV		+ 12.0352 mV	4.8E-7 V	>10:1
	+ 25.0000 mV	+ 24.9622 mV		+ 25.0378 mV	5.8E-7 V	>10:1
	+ 37.0000 mV	+ 36.9598 mV		+ 37.0402 mV	6.6E-7 V	>10:1
	+ 50.0000 mV	+ 49.9572 mV		+ 50.0428 mV	7.5E-7 V	>10:1
.25 V	- 200.0000 mV	- 200.0822 mV		- 199.9178 mV	1.6E-6 V	>10:1
	- 150.0000 mV	- 150.0722 mV		- 149.9278 mV	1.4E-6 V	>10:1
	- 100.0000 mV	- 100.0622 mV		- 99.9378 mV	1.2E-6 V	>10:1
	- 50.0000 mV	- 50.0522 mV		- 49.9478 mV	1.0E-6 V	>10:1
	0.0000 mV	- 0.0422 mV		+ 0.0422 mV	8.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9478 mV		+ 50.0522 mV	1.0E-6 V	>10:1
	+ 100.0000 mV	+ 99.9378 mV		+ 100.0622 mV	1.2E-6 V	>10:1
	+ 150.0000 mV	+ 149.9278 mV		+ 150.0722 mV	1.4E-6 V	>10:1
	+ 200.0000 mV	+ 199.9178 mV		+ 200.0822 mV	1.6E-6 V	>10:1
1.0V	- 0.8000 V	- 0.8003 V		- 0.7997 V	5.0E-6 V	>10:1
	- 0.6000 V	- 0.6002 V		- 0.5998 V	4.5E-6 V	>10:1
	- 0.4000 V	- 0.4002 V		- 0.3998 V	4.0E-6 V	>10:1
	- 0.2000 V	- 0.2002 V		- 0.1998 V	3.5E-6 V	>10:1
	0.0000 V	- 0.0001 V		+ 0.0001 V	3.0E-6 V	>10:1
	+ 0.2000 V	+ 0.1998 V		+ 0.2002 V	3.5E-6 V	>10:1
	+ 0.4000 V	+ 0.3998 V		+ 0.4002 V	4.0E-6 V	>10:1
	+ 0.6000 V	+ 0.5998 V		+ 0.6002 V	4.5E-6 V	>10:1
	+ 0.8000 V	+ 0.7997 V		+ 0.8003 V	5.0E-6 V	>10:1
4.0V	- 3.2000 V	- 3.2011 V		- 3.1989 V	1.1E-5 V	>10:1
	- 2.4000 V	- 2.4010 V		- 2.3990 V	9.0E-6 V	>10:1
	- 1.6000 V	- 1.6008 V		- 1.5992 V	7.0E-6 V	>10:1
	- 0.8000 V	- 0.8006 V		- 0.7994 V	5.0E-6 V	>10:1
	0.0000 V	- 0.0005 V		+ 0.0005 V	3.0E-6 V	>10:1
	+ 0.8000 V	+ 0.7994 V		+ 0.8006 V	5.0E-6 V	>10:1
	+ 1.6000 V	+ 1.5992 V		+ 1.6008 V	7.0E-6 V	>10:1
	+ 2.4000 V	+ 2.3990 V		+ 2.4010 V	9.0E-6 V	>10:1
	+ 3.2000 V	+ 3.1989 V		+ 3.2011 V	1.1E-5 V	>10:1
16.0V	- 12.8000 V	- 12.8045 V		- 12.7955 V	1.0E-4	>10:1
	- 9.6000 V	- 9.6039 V		- 9.5961 V	8.8E-5	>10:1
	- 6.4000 V	- 6.4033 V		- 6.3967 V	7.6E-5	>10:1
	- 3.2000 V	- 3.2026 V		- 3.1974 V	6.3E-5	>10:1
	0.0000 V	- 0.0020 V		+ 0.0020 V	5.0E-5	>10:1
	+ 3.2000 V	+ 3.1974 V		+ 3.2026 V	6.3E-5	>10:1
	+ 6.4000 V	+ 6.3967 V		+ 6.4033 V	7.6E-5	>10:1
	+ 9.6000 V	+ 9.5961 V		+ 9.6039 V	8.8E-5	>10:1
	+ 12.8000 V	+ 12.7955 V		+ 12.8045 V	1.0E-4	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 8 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter Input SCP (Gain X1, Filter OFF)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 50.0000 mV	- 50.0423 mV		- 49.9577 mV	7.5E-7 V	>10:1
	- 37.0000 mV	- 37.0397 mV		- 36.9603 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0373 mV		- 24.9627 mV	5.8E-7 V	>10:1
	- 12.0000 mV	- 12.0347 mV		- 11.9653 mV	4.8E-7 V	>10:1
	0.0000 mV	- 0.0323 mV		+ 0.0323 mV	4.0E-7 V	>10:1
	+ 12.0000 mV	+ 11.9653 mV		+ 12.0347 mV	4.8E-7 V	>10:1
	+ 25.0000 mV	+ 24.9627 mV		+ 25.0373 mV	5.8E-7 V	>10:1
	+ 37.0000 mV	+ 36.9603 mV		+ 37.0397 mV	6.6E-7 V	>10:1
	+ 50.0000 mV	+ 49.9577 mV		+ 50.0423 mV	7.5E-7 V	>10:1
.25 V	- 200.0000 mV	- 200.0818 mV		- 199.9182 mV	1.6E-6 V	>10:1
	- 150.0000 mV	- 150.0718 mV		- 149.9282 mV	1.4E-6 V	>10:1
	- 100.0000 mV	- 100.0618 mV		- 99.9382 mV	1.2E-6 V	>10:1
	- 50.0000 mV	- 50.0518 mV		- 49.9482 mV	1.0E-6 V	>10:1
	0.0000 mV	- 0.0418 mV		+ 0.0418 mV	8.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9482 mV		+ 50.0518 mV	1.0E-6 V	>10:1
	+ 100.0000 mV	+ 99.9382 mV		+ 100.0618 mV	1.2E-6 V	>10:1
	+ 150.0000 mV	+ 149.9282 mV		+ 150.0718 mV	1.4E-6 V	>10:1
	+ 200.0000 mV	+ 199.9182 mV		+ 200.0818 mV	1.6E-6 V	>10:1
1.0V	- 0.8000 V	- 0.8003 V		- 0.7997 V	5.0E-6 V	>10:1
	- 0.6000 V	- 0.6002 V		- 0.5998 V	4.5E-6 V	>10:1
	- 0.4000 V	- 0.4002 V		- 0.3998 V	4.0E-6 V	>10:1
	- 0.2000 V	- 0.2002 V		- 0.1998 V	3.5E-6 V	>10:1
	0.0000 V	- 0.0001 V		+ 0.0001 V	3.0E-6 V	>10:1
	+ 0.2000 V	+ 0.1998 V		+ 0.2002 V	3.5E-6 V	>10:1
	+ 0.4000 V	+ 0.3998 V		+ 0.4002 V	4.0E-6 V	>10:1
	+ 0.6000 V	+ 0.5998 V		+ 0.6002 V	4.5E-6 V	>10:1
	+ 0.8000 V	+ 0.7997 V		+ 0.8003 V	5.0E-6 V	>10:1
4.0V	- 3.2000 V	- 3.2011 V		- 3.1989 V	1.1E-5 V	>10:1
	- 2.4000 V	- 2.4010 V		- 2.3990 V	9.0E-6 V	>10:1
	- 1.6000 V	- 1.6008 V		- 1.5992 V	7.0E-6 V	>10:1
	- 0.8000 V	- 0.8006 V		- 0.7994 V	5.0E-6 V	>10:1
	0.0000 V	- 0.0005 V		+ 0.0005 V	3.0E-6 V	>10:1
	+ 0.8000 V	+ 0.7994 V		+ 0.8006 V	5.0E-6 V	>10:1
	+ 1.6000 V	+ 1.5992 V		+ 1.6008 V	7.0E-6 V	>10:1
	+ 2.4000 V	+ 2.3990 V		+ 2.4010 V	9.0E-6 V	>10:1
	+ 3.2000 V	+ 3.1989 V		+ 3.2011 V	1.1E-5 V	>10:1
16.0V	- 12.8000 V	- 12.8045 V		- 12.7955 V	1.0E-4	>10:1
	- 9.6000 V	- 9.6039 V		- 9.5961 V	8.8E-5	>10:1
	- 6.4000 V	- 6.4033 V		- 6.3967 V	7.6E-5	>10:1
	- 3.2000 V	- 3.2026 V		- 3.1974 V	6.3E-5	>10:1
	0.0000 V	- 0.0020 V		+ 0.0020 V	5.0E-5	>10:1
	+ 3.2000 V	+ 3.1974 V		+ 3.2026 V	6.3E-5	>10:1
	+ 6.4000 V	+ 6.3967 V		+ 6.4033 V	7.6E-5	>10:1
	+ 9.6000 V	+ 9.5961 V		+ 9.6039 V	8.8E-5	>10:1
	+ 12.8000 V	+ 12.7955 V		+ 12.8045 V	1.0E-4	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 9 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X8 and 2 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 6.0000 mV	- 6.0107 mV		- 5.9893 mV	4.4E-7 V	>10:1
	- 4.5000 mV	- 4.5104 mV		- 4.4896 mV	4.3E-7 V	>10:1
	- 3.0000 mV	- 3.0101 mV		- 2.9899 mV	4.2E-7 V	>10:1
	- 1.5000 mV	- 1.5098 mV		- 1.4902 mV	4.1E-7 V	>10:1
	0.0000 mV	- 0.0095 mV		+ 0.0095 mV	4.0E-7 V	>10:1
	+ 1.5000 mV	+ 1.4902 mV		+ 1.5098 mV	4.1E-7 V	>10:1
	+ 3.0000 mV	+ 2.9899 mV		+ 3.0101 mV	4.2E-7 V	>10:1
	+ 4.5000 mV	+ 4.4896 mV		+ 4.5104 mV	4.3E-7 V	>10:1
.25 V	+ 6.0000 mV	+ 5.9893 mV		+ 6.0107 mV	4.4E-7 V	>10:1
	- 25.0000 mV	- 25.0220 mV		- 24.9780 mV	5.8E-7 V	>10:1
	- 18.0000 mV	- 18.0206 mV		- 17.9794 mV	5.3E-7 V	>10:1
	- 12.0000 mV	- 12.0194 mV		- 11.9806 mV	4.8E-7 V	>10:1
	- 6.0000 mV	- 6.0182 mV		- 5.9818 mV	4.4E-7 V	>10:1
	0.0000 mV	- 0.0170 mV		+ 0.0170 mV	4.0E-7 V	>10:1
	+ 6.0000 mV	+ 5.9818 mV		+ 6.0182 mV	4.4E-7 V	>10:1
	+12.0000 mV	+11.9806 mV		+ 12.0194 mV	4.8E-7 V	>10:1
1.0V	+18.0000 mV	+17.9794 mV		+ 18.0206 mV	5.3E-7 V	>10:1
	+25.0000 mV	+24.9780 mV		+ 25.0220 mV	5.8E-7 V	>10:1
	- 100.800 mV	- 100.038 mV		- 99.962 mV	1.2E-6 V	>10:1
	- 75.000 mV	- 75.033 mV		- 74.967 mV	1.1E-6 V	>10:1
	- 50.000 mV	- 50.028 mV		- 49.972 mV	1.0E-6 V	>10:1
	- 25.000 mV	- 25.023 mV		- 24.977 mV	9.0E-7 V	>10:1
	0.000 mV	- 0.018 mV		+ 0.018 mV	8.0E-7 V	>10:1
	+ 25.000 mV	+ 24.977 mV		+ 25.023 mV	9.0E-7 V	>10:1
4.0V	+ 50.000 mV	+ 49.972 mV		+ 50.028 mV	1.0E-6 V	>10:1
	+ 75.000 mV	+ 74.967 mV		+ 75.033 mV	1.1E-6 V	>10:1
	+100.000 mV	+ 99.962 mV		+100.038 mV	1.2E-6 V	>10:1
	- 0.4000 V	- 0.4001 V		- 0.3999 V	2.4E-6 V	>10:1
	- 0.3000 V	- 0.3001 V		- 0.2999 V	2.0E-6 V	>10:1
	- 0.2000 V	- 0.2001 V		- 0.1999 V	1.6E-6 V	>10:1
	- 0.1000 V	- 0.1001 V		- 0.0999 V	1.2E-6 V	>10:1
	0.0000 V	- 0.0001 V		+0.0001 V	8.0E-7 V	>10:1
16.0V	+0.1000 V	+0.0999 V		+0.1001 V	1.2E-6 V	>10:1
	+0.2000 V	+0.1999 V		+0.2001 V	1.6E-6 V	>10:1
	+0.3000 V	+0.2999 V		+0.3001 V	2.0E-6 V	>10:1
	+0.4000 V	+0.3999 V		+0.4001 V	2.4E-6 V	>10:1
	- 1.6000 V	- 1.6006 V		- 1.5994 V	7.0E-6 V	>10:1
	- 1.2000 V	- 1.2005 V		- 1.1995 V	6.0E-6 V	>10:1
	- 0.8000 V	- 0.8004 V		- 0.7996 V	5.0E-6 V	>10:1
	- 0.4000 V	- 0.4003 V		- 0.3997 V	4.0E-6 V	>10:1
	0.0000 V	- 0.0002 V		+0.0002 V	3.0E-6 V	>10:1
	+0.4000 V	+0.3997 V		+0.4003 V	4.0E-6 V	>10:1
	+0.8000 V	+0.7996 V		+0.8004 V	5.0E-6 V	>10:1
	+1.2000 V	+1.1995 V		+1.2005 V	6.0E-6 V	>10:1
	+1.6000 V	+1.5994 V		+1.6006 V	7.0E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 10 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X8 and 10 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 6.0000 mV	- 6.0103 mV		- 5.9897 mV	4.4E-7 V	>10:1
	- 4.5000 mV	- 4.5100 mV		- 4.4900 mV	4.3E-7 V	>10:1
	- 3.0000 mV	- 3.0097 mV		- 2.9903 mV	4.2E-7 V	>10:1
	- 1.5000 mV	- 1.5094 mV		- 1.4906 mV	4.1E-7 V	>10:1
	0.0000 mV	0.0091 mV		+ 0.0091 mV	4.0E-7 V	>10:1
	+ 1.5000 mV	+ 1.4906 mV		+ 1.5094 mV	4.1E-7 V	>10:1
	+ 3.0000 mV	+ 2.9903 mV		+ 3.0097 mV	4.2E-7 V	>10:1
	+ 4.5000 mV	+ 4.4900 mV		+ 4.5100 mV	4.3E-7 V	>10:1
	+ 6.0000 mV	+ 5.9897 mV		+ 6.0103 mV	4.4E-7 V	>10:1
.25 V	- 25.0000 mV	- 25.0200 mV		- 24.9800 mV	5.8E-7 V	>10:1
	- 18.0000 mV	- 18.0186 mV		- 17.9814 mV	5.3E-7 V	>10:1
	- 12.0000 mV	- 12.0174 mV		- 11.9826 mV	4.8E-7 V	>10:1
	- 6.0000 mV	- 6.0162 mV		- 5.9838 mV	4.4E-7 V	>10:1
	0.0000 mV	0.0150 mV		+ 0.0150 mV	4.0E-7 V	>10:1
	+ 6.0000 mV	+ 5.9838 mV		+ 6.0162 mV	4.4E-7 V	>10:1
	+ 12.0000 mV	+ 11.9826 mV		+ 12.0174 mV	4.8E-7 V	>10:1
	+ 18.0000 mV	+ 17.9814 mV		+ 18.0186 mV	5.3E-7 V	>10:1
	+ 25.0000 mV	+ 24.9800 mV		+ 25.0200 mV	5.8E-7 V	>10:1
1.0V	- 100.800 mV	- 100.0373 mV		- 99.9627 mV	1.2E-6 V	>10:1
	- 75.000 mV	- 75.0323 mV		- 74.9677 mV	1.1E-6 V	>10:1
	- 50.000 mV	- 50.0273 mV		- 49.9727 mV	1.0E-6 V	>10:1
	- 25.000 mV	- 25.0223 mV		- 24.9777 mV	9.0E-7 V	>10:1
	0.000 mV	0.0173 mV		+ 0.0173 mV	8.0E-7 V	>10:1
	+ 25.000 mV	+ 24.9777 mV		+ 25.0223 mV	9.0E-7 V	>10:1
	+ 50.000 mV	+ 49.9727 mV		+ 50.0273 mV	1.0E-6 V	>10:1
	+ 75.000 mV	+ 74.9677 mV		+ 75.0323 mV	1.1E-6 V	>10:1
	+ 100.000 mV	+ 99.9627 mV		+ 100.0373 mV	1.2E-6 V	>10:1
4.0V	- 0.4000 V	- 0.4001 V		- 0.3999 V	2.4E-6 V	>10:1
	- 0.3000 V	- 0.3001 V		- 0.2999 V	2.0E-6 V	>10:1
	- 0.2000 V	- 0.2001 V		- 0.1999 V	1.6E-6 V	>10:1
	- 0.1000 V	- 0.1001 V		- 0.0999 V	1.2E-6 V	>10:1
	0.0000 V	- 0.0001 V		+ 0.0001 V	8.0E-7 V	>10:1
	+ 0.1000 V	+ 0.0999 V		+ 0.1001 V	1.2E-6 V	>10:1
	+ 0.2000 V	+ 0.1999 V		+ 0.2001 V	1.6E-6 V	>10:1
	+ 0.3000 V	+ 0.2999 V		+ 0.3001 V	2.0E-6 V	>10:1
	+ 0.4000 V	+ 0.3999 V		+ 0.4001 V	2.4E-6 V	>10:1
16.0V	- 1.6000 V	- 1.6006 V		- 1.5994 V	7.0E-6 V	>10:1
	- 1.2000 V	- 1.2005 V		- 1.1995 V	6.0E-6 V	>10:1
	- 0.8000 V	- 0.8004 V		- 0.7996 V	5.0E-6 V	>10:1
	- 0.4000 V	- 0.4003 V		- 0.3997 V	4.0E-6 V	>10:1
	0.0000 V	- 0.0002 V		+ 0.0002 V	3.0E-6 V	>10:1
	+ 0.4000 V	+ 0.3997 V		+ 0.4003 V	4.0E-6 V	>10:1
	+ 0.8000 V	+ 0.7996 V		+ 0.8004 V	5.0E-6 V	>10:1
	+ 1.2000 V	+ 1.1995 V		+ 1.2005 V	6.0E-6 V	>10:1
	+ 1.6000 V	+ 1.5994 V		+ 1.6006 V	7.0E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 11 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X8 and 100 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 6.0000 mV	- 6.0099 mV		- 5.9901 mV	4.4E-7 V	>10:1
	- 4.5000 mV	- 4.5096 mV		- 4.4904 mV	4.3E-7 V	>10:1
	- 3.0000 mV	- 3.0093 mV		- 2.9907 mV	4.2E-7 V	>10:1
	- 1.5000 mV	- 1.5090 mV		- 1.4910 mV	4.1E-7 V	>10:1
	0.0000 mV	- 0.0087 mV		+ 0.0087 mV	4.0E-7 V	>10:1
	+ 1.5000 mV	+ 1.4910 mV		+ 1.5090 mV	4.1E-7 V	>10:1
	+ 3.0000 mV	+ 2.9907 mV		+ 3.0093 mV	4.2E-7 V	>10:1
	+ 4.5000 mV	+ 4.4904 mV		+ 4.5096 mV	4.3E-7 V	>10:1
	+ 6.0000 mV	+ 5.9901 mV		+ 6.0099 mV	4.4E-7 V	>10:1
.25 V	- 25.0000 mV	- 25.0153 mV		- 24.9847 mV	5.8E-7 V	>10:1
	- 18.0000 mV	- 18.0139 mV		- 17.9861 mV	5.3E-7 V	>10:1
	- 12.0000 mV	- 12.0127 mV		- 11.9873 mV	4.8E-7 V	>10:1
	- 6.0000 mV	- 6.0115 mV		- 5.9885 mV	4.4E-7 V	>10:1
	0.0000 mV	- 0.0103 mV		+ 0.0103 mV	4.0E-7 V	>10:1
	+ 6.0000 mV	+ 5.9885 mV		+ 6.0115 mV	4.4E-7 V	>10:1
	+ 12.0000 mV	+ 11.9873 mV		+ 12.0127 mV	4.8E-7 V	>10:1
	+ 18.0000 mV	+ 17.9861 mV		+ 18.0139 mV	5.3E-7 V	>10:1
	+ 25.0000 mV	+ 24.9847 mV		+ 25.0153 mV	5.8E-7 V	>10:1
1.0V	- 100.800 mV	- 100.0370 mV		- 99.9630 mV	1.2E-6 V	>10:1
	- 75.000 mV	- 75.0320 mV		- 74.9680 mV	1.1E-6 V	>10:1
	- 50.000 mV	- 50.0270 mV		- 49.9730 mV	1.0E-6 V	>10:1
	- 25.000 mV	- 25.0220 mV		- 24.9780 mV	9.0E-7 V	>10:1
	0.000 mV	- 0.0170 mV		+ 0.0170 mV	8.0E-7 V	>10:1
	+ 25.000 mV	+ 24.9780 mV		+ 25.0220 mV	9.0E-7 V	>10:1
	+ 50.000 mV	+ 49.9730 mV		+ 50.0270 mV	1.0E-6 V	>10:1
	+ 75.000 mV	+ 74.9680 mV		+ 75.0320 mV	1.1E-6 V	>10:1
	+ 100.000 mV	+ 99.9630 mV		+ 100.0370 mV	1.2E-6 V	>10:1
4.0V	- 0.4000 V	- 0.4001 V		- 0.3999 V	2.4E-6 V	>10:1
	- 0.3000 V	- 0.3001 V		- 0.2999 V	2.0E-6 V	>10:1
	- 0.2000 V	- 0.2001 V		- 0.1999 V	1.6E-6 V	>10:1
	- 0.1000 V	- 0.1001 V		- 0.0999 V	1.2E-6 V	>10:1
	0.0000 V	- 0.0001 V		+ 0.0001 V	8.0E-7 V	>10:1
	+ 0.1000 V	+ 0.0999 V		+ 0.1001 V	1.2E-6 V	>10:1
	+ 0.2000 V	+ 0.1999 V		+ 0.2001 V	1.6E-6 V	>10:1
	+ 0.3000 V	+ 0.2999 V		+ 0.3001 V	2.0E-6 V	>10:1
	+ 0.4000 V	+ 0.3999 V		+ 0.4001 V	2.4E-6 V	>10:1
16.0V	- 1.6000 V	- 1.6006 V		- 1.5994 V	7.0E-6 V	>10:1
	- 1.2000 V	- 1.2005 V		- 1.1995 V	6.0E-6 V	>10:1
	- 0.8000 V	- 0.8004 V		- 0.7996 V	5.0E-6 V	>10:1
	- 0.4000 V	- 0.4003 V		- 0.3997 V	4.0E-6 V	>10:1
	0.0000 V	- 0.0002 V		+ 0.0002 V	3.0E-6 V	>10:1
	+ 0.4000 V	+ 0.3997 V		+ 0.4003 V	4.0E-6 V	>10:1
	+ 0.8000 V	+ 0.7996 V		+ 0.8004 V	5.0E-6 V	>10:1
	+ 1.2000 V	+ 1.1995 V		+ 1.2005 V	6.0E-6 V	>10:1
	+ 1.6000 V	+ 1.5994 V		+ 1.6006 V	7.0E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 12 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X8 and Filter OFF)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.0625 V	- 6.0000 mV	- 6.0098 mV		- 5.9902 mV	4.4E-7 V	>10:1
	- 4.5000 mV	- 4.5095 mV		- 4.4905 mV	4.3E-7 V	>10:1
	- 3.0000 mV	- 3.0092 mV		- 2.9908 mV	4.2E-7 V	>10:1
	- 1.5000 mV	- 1.5089 mV		- 1.4911 mV	4.1E-7 V	>10:1
	0.0000 mV	- 0.0086 mV		+ 0.0086 mV	4.0E-7 V	>10:1
	+ 1.5000 mV	+ 1.4911 mV		+ 1.5089 mV	4.1E-7 V	>10:1
	+ 3.0000 mV	+ 2.9908 mV		+ 3.0092 mV	4.2E-7 V	>10:1
	+ 4.5000 mV	+ 4.4905 mV		+ 4.5095 mV	4.3E-7 V	>10:1
	+ 6.0000 mV	+ 5.9902 mV		+ 6.0098 mV	4.4E-7 V	>10:1
.25 V	- 25.0000 mV	- 25.0152 mV		- 24.9848 mV	5.8E-7 V	>10:1
	- 18.0000 mV	- 18.0138 mV		- 17.9862 mV	5.3E-7 V	>10:1
	- 12.0000 mV	- 12.0126 mV		- 11.9874 mV	4.8E-7 V	>10:1
	- 6.0000 mV	- 6.0114 mV		- 5.9886 mV	4.4E-7 V	>10:1
	0.0000 mV	- 0.0102 mV		+ 0.0102 mV	4.0E-7 V	>10:1
	+ 6.0000 mV	+ 5.9886 mV		+ 6.0114 mV	4.4E-7 V	>10:1
	+12.0000 mV	+ 11.9874 mV		+ 12.0126 mV	4.8E-7 V	>10:1
	+18.0000 mV	+ 17.9862 mV		+ 18.0138 mV	5.3E-7 V	>10:1
	+25.0000 mV	+ 24.9848 mV		+ 25.0152 mV	5.8E-7 V	>10:1
1.0V	- 100.800 mV	- 100.0369 mV		- 99.9631 mV	1.2E-6 V	>10:1
	- 75.000 mV	- 75.0319 mV		- 74.9681 mV	1.1E-6 V	>10:1
	- 50.000 mV	- 50.0269 mV		- 49.9731 mV	1.0E-6 V	>10:1
	- 25.000 mV	- 25.0219 mV		- 24.9781 mV	9.0E-7 V	>10:1
	0.000 mV	- 0.0169 mV		+ 0.0171 mV	8.0E-7 V	>10:1
	+ 25.000 mV	+ 24.9781 mV		+ 25.0219 mV	9.0E-7 V	>10:1
	+ 50.000 mV	+ 49.9731 mV		+ 50.0269 mV	1.0E-6 V	>10:1
	+ 75.000 mV	+ 74.9681 mV		+ 75.0319 mV	1.1E-6 V	>10:1
	+100.000 mV	+ 99.9631 mV		+100.0369 mV	1.2E-6 V	>10:1
4.0V	- 0.4000 V	- 0.4001 V		- 0.3999 V	2.4E-6 V	>10:1
	- 0.3000 V	- 0.3001 V		- 0.2999 V	2.0E-6 V	>10:1
	- 0.2000 V	- 0.2001 V		- 0.1999 V	1.6E-6 V	>10:1
	- 0.1000 V	- 0.1001 V		- 0.0999 V	1.2E-6 V	>10:1
	0.0000 V	- 0.0001 V		+0.0001 V	8.0E-7 V	>10:1
	+0.1000 V	+0.0999 V		+0.1001 V	1.2E-6 V	>10:1
	+0.2000 V	+0.1999 V		+0.2001 V	1.6E-6 V	>10:1
	+0.3000 V	+0.2999 V		+0.3001 V	2.0E-6 V	>10:1
	+0.4000 V	+0.3999 V		+0.4001 V	2.4E-6 V	>10:1
16.0V	- 1.6000 V	- 1.6006 V		- 1.5994 V	7.0E-6 V	>10:1
	- 1.2000 V	- 1.2005 V		- 1.1995 V	6.0E-6 V	>10:1
	- 0.8000 V	- 0.8004 V		- 0.7996 V	5.0E-6 V	>10:1
	- 0.4000 V	- 0.4003 V		- 0.3997 V	4.0E-6 V	>10:1
	0.0000 V	- 0.0002 V		+0.0002 V	3.0E-6 V	>10:1
	+0.4000 V	+0.3997 V		+0.4003 V	4.0E-6 V	>10:1
	+0.8000 V	+0.7996 V		+0.8004 V	5.0E-6 V	>10:1
	+1.2000 V	+1.1995 V		+1.2005 V	6.0E-6 V	>10:1
	+1.6000 V	+1.5994 V		+1.6006 V	7.0E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 13 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X64 and 2 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.25 V	- 3.0000 mV	- 3.0048 mV		- 2.9952 mV	4.2E-7 V	>10:1
	- 2.5000 mV	- 2.5057 mV		- 2.4953 mV	4.2E-7 V	>10:1
	- 1.5000 mV	- 1.5045 mV		- 1.4955 mV	4.1E-7 V	>10:1
	- 0.8000 mV	- 0.8044 mV		- 0.7956 mV	4.1E-7 V	>10:1
	0.0000 mV	- 0.0042 mV		+0.0042 mV	4.0E-7 V	10:1
	+0.8000 mV	+0.7956 mV		+0.8044 mV	4.1E-7 V	>10:1
	+1.5000 mV	+1.4955 mV		+1.5045 mV	4.1E-7 V	>10:1
	+2.5000 mV	+2.4953 mV		+2.5047 mV	4.2E-7 V	>10:1
	+3.0000 mV	+2.9952 mV		+3.0048 mV	4.2E-7 V	>10:1
1.0V	- 12.8000 mV	- 12.8075 mV		- 12.7925 mV	4.9E-7 V	>10:1
	- 9.6000 mV	- 9.6068 mV		- 9.5932 mV	4.7E-7 V	>10:1
	- 6.4000 mV	- 6.4062 mV		- 6.3938 mV	4.4E-7 V	>10:1
	- 3.2000 mV	- 3.2055 mV		- 3.1945 mV	4.2E-7 V	>10:1
	0.0000 mV	- 0.0049 mV		+ 0.0049 mV	4.0E-7 V	>10:1
	+ 3.2000 mV	+ 3.1945 mV		+ 3.2055 mV	4.2E-7 V	>10:1
	+ 6.4000 mV	+ 6.3938 mV		+ 6.4062 mV	4.4E-7 V	>10:1
	+ 9.6000 mV	+ 9.5932 mV		+ 9.6068 mV	4.7E-7 V	>10:1
	+12.8000 mV	+12.7925 mV		+12.8075 mV	4.9E-7 V	>10:1
4.0V	- 50.0000 mV	- 50.0192 mV		- 49.9808 mV	7.5E-7 V	>10:1
	- 37.5000 mV	- 37.5167 mV		- 37.4833 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0142 mV		- 24.9858 mV	5.8E-7 V	>10:1
	- 12.5000 mV	- 12.5117 mV		- 12.4883 mV	4.9E-7 V	>10:1
	0.0000 mV	- 0.0092 mV		+ 0.0092 mV	4.0E-7 V	>10:1
	+12.5000 mV	+12.4883 mV		+12.5117 mV	4.9E-7 V	>10:1
	+25.0000 mV	+24.9858 mV		+25.0142 mV	5.8E-7 V	>10:1
	+37.5000 mV	+37.4833 mV		+37.5167 mV	6.6E-7 V	>10:1
	+50.0000 mV	+49.9808 mV		+50.0192 mV	7.5E-7 V	>10:1
16.0V	- 200.0000 mV	- 200.0712 mV		- 199.9288 mV	1.2E-6 V	>10:1
	- 150.0000 mV	- 150.0612 mV		- 149.9388 mV	1.0E-6 V	>10:1
	- 100.0000 mV	- 100.0512 mV		- 99.9488 mV	8.0E-7 V	>10:1
	- 50.0000 mV	- 50.0412 mV		- 49.9588 mV	6.0E-7 V	>10:1
	0.0000 mV	- 0.0312 mV		+ 0.0312 mV	4.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9588 mV		+ 50.0412 mV	6.0E-7 V	>10:1
	+100.0000 mV	+ 99.9488 mV		+100.0512 mV	8.0E-7 V	>10:1
	+150.0000 mV	+149.9388 mV		+150.0612 mV	1.0E-6 V	>10:1
	+200.0000 mV	+199.9288 mV		+200.0712 mV	1.2E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 14 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X64 and 10 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.25 V	- 3.0000 mV	- 3.0042 mV	_____	- 2.9958 mV	4.2E-7 V	10:1
	- 2.5000 mV	- 2.5041 mV	_____	- 2.4959 mV	4.2E-7 V	10:1
	- 1.5000 mV	- 1.5039 mV	_____	- 1.4961 mV	4.1E-7 V	10:1
	- 0.8000 mV	- 0.8038 mV	_____	- 0.7962 mV	4.1E-7 V	9:1
	0.0000 mV	- 0.0036 mV	_____	+0.0036 mV	4.0E-7 V	9:1
	+0.8000 mV	+0.7962 mV	_____	+0.8038 mV	4.1E-7 V	9:1
	+1.5000 mV	+1.4961 mV	_____	+1.5039 mV	4.1E-7 V	10:1
	+2.5000 mV	+2.4959 mV	_____	+2.5041 mV	4.2E-7 V	10:1
	+3.0000 mV	+2.9958 mV	_____	+3.0042 mV	4.2E-7 V	10:1
1.0V	- 12.8000 mV	- 12.8069 mV	_____	- 12.7931 mV	4.9E-7 V	>10:1
	- 9.6000 mV	- 9.6062 mV	_____	- 9.5938 mV	4.7E-7 V	>10:1
	- 6.4000 mV	- 6.4056 mV	_____	- 6.3944 mV	4.4E-7 V	>10:1
	- 3.2000 mV	- 3.2049 mV	_____	- 3.1951 mV	4.2E-7 V	>10:1
	0.0000 mV	- 0.0043 mV	_____	+ 0.0043 mV	4.0E-7 V	>10:1
	+ 3.2000 mV	+ 3.1951 mV	_____	+ 3.2049 mV	4.2E-7 V	>10:1
	+ 6.4000 mV	+ 6.3944 mV	_____	+ 6.4056 mV	4.4E-7 V	>10:1
	+ 9.6000 mV	+ 9.5938 mV	_____	+ 9.6062 mV	4.7E-7 V	>10:1
	+12.8000 mV	+12.7931 mV	_____	+12.8069 mV	4.9E-7 V	>10:1
4.0V	- 50.0000 mV	- 50.0187 mV	_____	- 49.9813 mV	7.5E-7 V	>10:1
	- 37.5000 mV	- 37.5162 mV	_____	- 37.4838 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0137 mV	_____	- 24.9863 mV	5.8E-7 V	>10:1
	- 12.5000 mV	- 12.5112 mV	_____	- 12.4888 mV	4.9E-7 V	>10:1
	0.0000 mV	- 0.0087 mV	_____	+ 0.0087 mV	4.0E-7 V	>10:1
	+12.5000 mV	+12.4888 mV	_____	+12.5112 mV	4.9E-7 V	>10:1
	+25.0000 mV	+24.9863 mV	_____	+25.0137 mV	5.8E-7 V	>10:1
	+37.5000 mV	+37.4838 mV	_____	+37.5162 mV	6.6E-7 V	>10:1
	+50.0000 mV	+49.9813 mV	_____	+50.0187 mV	7.5E-7 V	>10:1
16.0V	- 200.0000 mV	- 200.0710 mV	_____	- 199.9290 mV	1.2E-6 V	>10:1
	- 150.0000 mV	- 150.0610 mV	_____	- 149.9390 mV	1.0E-6 V	>10:1
	- 100.0000 mV	- 100.0510 mV	_____	- 99.9490 mV	8.0E-7 V	>10:1
	- 50.0000 mV	- 50.0410 mV	_____	- 49.9590 mV	6.0E-7 V	>10:1
	0.0000 mV	- 0.0310 mV	_____	+ 0.0310 mV	4.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9590 mV	_____	+ 50.0410 mV	6.0E-7 V	>10:1
	+100.0000 mV	+ 99.9490 mV	_____	+100.0510 mV	8.0E-7 V	>10:1
	+150.0000 mV	+149.9390 mV	_____	+150.0610 mV	1.0E-6 V	>10:1
	+200.0000 mV	+199.9290 mV	_____	+200.0710 mV	1.2E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 15 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X64 and 100 Hz Filter)						
Range	Input	Minimum	Measured	Maximum	M.U.	TAR
.25 V	- 3.0000 mV	- 3.0044 mV		- 2.9956 mV	4.2E-7 V	10:1
	- 2.5000 mV	- 2.5043 mV		- 2.4957 mV	4.2E-7 V	10:1
	- 1.5000 mV	- 1.5041 mV		- 1.4959 mV	4.1E-7 V	10:1
	- 0.8000 mV	- 0.8040 mV		- 0.7960 mV	4.1E-7 V	10:1
	0.0000 mV	- 0.0038 mV		+0.0038 mV	4.0E-7 V	9:1
	+0.8000 mV	+0.7960 mV		+0.8040 mV	4.1E-7 V	10:1
	+1.5000 mV	+1.4959 mV		+1.5041 mV	4.1E-7 V	10:1
	+2.5000 mV	+2.4957 mV		+2.5043 mV	4.2E-7 V	10:1
	+3.0000 mV	+2.9956 mV		+3.0044 mV	4.2E-7 V	10:1
1.0V	- 12.8000 mV	- 12.8067 mV		- 12.7933 mV	4.9E-7 V	>10:1
	- 9.6000 mV	- 9.6060 mV		- 9.5940 mV	4.7E-7 V	>10:1
	- 6.4000 mV	- 6.4054 mV		- 6.3946 mV	4.4E-7 V	>10:1
	- 3.2000 mV	- 3.2047 mV		- 3.1953 mV	4.2E-7 V	>10:1
	0.0000 mV	- 0.0041 mV		+ 0.0041 mV	4.0E-7 V	10:1
	+ 3.2000 mV	+ 3.1953 mV		+ 3.2047 mV	4.2E-7 V	>10:1
	+ 6.4000 mV	+ 6.3946 mV		+ 6.4054 mV	4.4E-7 V	>10:1
	+ 9.6000 mV	+ 9.5940 mV		+ 9.6060 mV	4.7E-7 V	>10:1
	+12.8000 mV	+12.7933 mV		+12.8067 mV	4.9E-7 V	>10:1
4.0V	- 50.0000 mV	- 50.0186 mV		- 49.9814 mV	7.5E-7 V	>10:1
	- 37.5000 mV	- 37.5161 mV		- 37.4839 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0136 mV		- 24.9864 mV	5.8E-7 V	>10:1
	- 12.5000 mV	- 12.5111 mV		- 12.4889 mV	4.9E-7 V	>10:1
	0.0000 mV	- 0.0086 mV		+ 0.0086 mV	4.0E-7 V	>10:1
	+12.5000 mV	+12.4889 mV		+12.5111 mV	4.9E-7 V	>10:1
	+25.0000 mV	+24.9864 mV		+25.0136 mV	5.8E-7 V	>10:1
	+37.5000 mV	+37.4839 mV		+37.5161 mV	6.6E-7 V	>10:1
	+50.0000 mV	+49.9814 mV		+50.0186 mV	7.5E-7 V	>10:1
16.0V	- 200.0000 mV	- 200.0710 mV		- 199.9290 mV	1.2E-6 V	>10:1
	- 150.0000 mV	- 150.0610 mV		- 149.9390 mV	1.0E-6 V	>10:1
	- 100.0000 mV	- 100.0510 mV		- 99.9490 mV	8.0E-7 V	>10:1
	- 50.0000 mV	- 50.0410 mV		- 49.9590 mV	6.0E-7 V	>10:1
	0.0000 mV	- 0.0310 mV		+ 0.0310 mV	4.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9590 mV		+ 50.0410 mV	6.0E-7 V	>10:1
	+100.0000 mV	+ 99.9490 mV		+100.0510 mV	8.0E-7 V	>10:1
	+150.0000 mV	+149.9390 mV		+150.0610 mV	1.0E-6 V	>10:1
	+200.0000 mV	+199.9290 mV		+200.0710 mV	1.2E-6 V	>10:1

Table 2-1. Performance Test Record for the HP E1413A Scanning A/D (Page 16 of 16)

Test 2-3: DCV Measurement Accuracy - Option 13 Amplifier+Filter SCP (Gain X64 and Filter OFF)						
Range	Input	Minimum	Measured	Maximum	M.U.*	TAR**
.25 V	- 3.0000 mV	- 3.0030 mV		- 2.9970 mV	4.2E-7 V	7:1
	- 2.5000 mV	- 2.5029 mV		- 2.4971 mV	4.2E-7 V	7:1
	- 1.5000 mV	- 1.5027 mV		- 1.4973 mV	4.1E-7 V	7:1
	- 0.8000 mV	- 0.8026 mV		- 0.7974 mV	4.1E-7 V	6:1
	0.0000 mV	- 0.0024 mV		+0.0024 mV	4.0E-7 V	6:1
	+0.8000 mV	+0.7974 mV		+0.8026 mV	4.1E-7 V	6:1
	+1.5000 mV	+1.4973 mV		+1.5027 mV	4.1E-7 V	7:1
	+2.5000 mV	+2.4971 mV		+2.5029 mV	4.2E-7 V	7:1
	+3.0000 mV	+2.9970 mV		+3.0030 mV	4.2E-7 V	7:1
1.0V	- 12.8000 mV	- 12.8067 mV		- 12.7933 mV	4.9E-7 V	>10:1
	- 9.6000 mV	- 9.6060 mV		- 9.5940 mV	4.7E-7 V	>10:1
	- 6.4000 mV	- 6.4054 mV		- 6.3946 mV	4.4E-7 V	>10:1
	- 3.2000 mV	- 3.2047 mV		- 3.1953 mV	4.2E-7 V	>10:1
	0.0000 mV	- 0.0041 mV		+ 0.0041 mV	4.0E-7 V	10:1
	+ 3.2000 mV	+ 3.1953 mV		+ 3.2047 mV	4.2E-7 V	>10:1
	+ 6.4000 mV	+ 6.3946 mV		+ 6.4054 mV	4.4E-7 V	>10:1
	+ 9.6000 mV	+ 9.5940 mV		+ 9.6060 mV	4.7E-7 V	>10:1
	+12.8000 mV	+12.7933 mV		+12.8067 mV	4.9E-7 V	>10:1
4.0V	- 50.0000 mV	- 50.0186 mV		- 49.9814 mV	7.5E-7 V	>10:1
	- 37.5000 mV	- 37.5161 mV		- 37.4839 mV	6.6E-7 V	>10:1
	- 25.0000 mV	- 25.0136 mV		- 24.9864 mV	5.8E-7 V	>10:1
	- 12.5000 mV	- 12.5111 mV		- 12.4889 mV	4.9E-7 V	>10:1
	0.0000 mV	- 0.0086 mV		+ 0.0086 mV	4.0E-7 V	>10:1
	+12.5000 mV	+12.4889 mV		+12.5111 mV	4.9E-7 V	>10:1
	+25.0000 mV	+24.9864 mV		+25.0136 mV	5.8E-7 V	>10:1
	+37.5000 mV	+37.4839 mV		+37.5161 mV	6.6E-7 V	>10:1
	+50.0000 mV	+49.9814 mV		+50.0186 mV	7.5E-7 V	>10:1
16.0V	- 200.0000 mV	- 200.0710 mV		- 199.9290 mV	1.2E-6 V	>10:1
	- 150.0000 mV	- 150.0610 mV		- 149.9390 mV	1.0E-6 V	>10:1
	- 100.0000 mV	- 100.0510 mV		- 99.9490 mV	8.0E-7 V	>10:1
	- 50.0000 mV	- 50.0410 mV		- 49.9590 mV	6.0E-7 V	>10:1
	0.0000 mV	- 0.0310 mV		+ 0.0310 mV	4.0E-7 V	>10:1
	+ 50.0000 mV	+ 49.9590 mV		+ 50.0410 mV	6.0E-7 V	>10:1
	+100.0000 mV	+ 99.9490 mV		+100.0510 mV	8.0E-7 V	>10:1
	+150.0000 mV	+149.9390 mV		+150.0610 mV	1.0E-6 V	>10:1
	+200.0000 mV	+199.9290 mV		+200.0710 mV	1.2E-6 V	>10:1

Adjustments

Introduction

The procedures in this chapter show how to electronically adjust the HP E1413A Scanning A/D to compensate for A/D source voltage and reference resistor offsets.

Recommended Equipment/Environment

A digital multimeter (DMM) is required for the procedures in this chapter. The HP 3458A is the recommended DMM. Before performing these procedures, allow the HP E1413A to warm up for at least one hour. The temperature should be within $\pm 1^\circ\text{C}$ of the temperature of the most recent calibration and between 22°C and 24°C .

Flash Memory Access

The Flash Memory Protect Jumper (JM 2201) (see Figure 3-1 for location) is shipped in the "PROG" position. If the jumper is changed to the "PROTECT" position, you will not be able to store new calibration constants into Flash Memory (Electrically Erasable Programmable Read Only Memory or EEPROM). If the adjustment program shown in this chapter displays an error message, you may need to change the jumper to the PROG position and rerun the program.




Figure 3-1. Flash Memory Protect Jumper

A/D Adjustment Procedure

This adjustment performs internal A/D adjustments using the CAL:CONF, CAL:VAL, and CAL:STOR commands. (See *Appendix C - Command Reference* for command descriptions.)

Description

The adjustment procedure consists of measuring the values of the 7.5 k Ω reference resistor and ± 16 Vdc voltage source with an external DMM and then entering the values into Scanning A/D RAM. After the new values have been entered into RAM, they can be stored in Flash Memory (Electrically Erasable Programmable Read Only Memory or EEPROM). See Figure 3-2 for commands and steps. You can perform these adjustments using either the Cal Bus connectors on the Scanning A/D or the HOHM, LOHM, HCAL, and LCAL connectors on the Terminal Module.




Figure 3-2. Scanning A/D Adjustments

Equipment Setup

- Perform an autocalibration on the HP 3458A DMM (unless an autocal has been performed within the last 24 hours).
- Connect the equipment as shown in Figures 3-3 through 3-6, using the connections on the terminal module or the Cal Bus connections on the Scanning A/D.
- If you use the Cal Bus connections, remove the terminal module and make connections between the DMM and Scanning A/D #1. You can use the 555 mm (22 inch) calibration cable supplied.
- To adjust two or more Scanning A/Ds (one at a time), connect additional HP E1413As (in adjacent mainframe slots) using the 60 mm (2.4 inch) connecting cable supplied. For three or more A/Ds, you must order additional connecting cables as required.

Resistance Measurements - Terminal Module Connections




Figure 3-3. Resistance Measurements - Term Mod Conn

Resistance Measurements - Cal Bus Connections




Figure 3-4. Resistance Measurements - Cal Bus Conn

DCV Measurements - Terminal Module Connections




Figure 3-5. DCV Measurements - Term Module Conn

DCV Measurements - Cal Bus Connections




Figure 3-6. DCV Measurements - Cal Bus Conn

Adjustment Procedure

This procedure adjusts the Scanning A/D using the HP 3458A DMM for external measurements.

1 Measure Reference Resistance

[a] Make 4-wire resistance connections (see Figure 3-3 or 3-4)

[b] Reset Scanning A/D:

*RST;*CLS	<i>Reset and clear status reg</i>
WAIT 5	<i>Wait 5 seconds for reset to complete</i>

[c] Set Scanning A/D to measure resistance

CAL:CONF:RES	<i>Set for resistance measurements</i>
*OPC?	<i>Use *OPC? and ENTER to ensure A/D setup is complete</i>
ENTER statement	

[d] Set and Trigger DMM

RESET	<i>Reset DMM</i>
FUNC OHMF	<i>Set 4-wire ohms</i>
OCOMP ON	<i>Set offset compensation</i>
NPLC 20	<i>Set NPLC 20</i>
TRIG SGL	<i>Trigger DMM</i>
WAIT1	<i>Wait 1 second</i>
ENTER <ref_ohms>	<i>Measure value of ref resistor</i>

[e] Send measured value to Scanning A/D

CAL:VAL:RES <ref_ohms>	<i>Send ref resistor value to E1413A RAM</i>
------------------------	--

2 Make Source Voltage Measurements

[a] Make DCV connections (see Figure 3-5 or 3-6)

[b] Reset Scanning A/D

*RST;*CLS	<i>Reset and clear status register</i>
WAIT 5	<i>Wait 5 seconds for reset to complete</i>

[c] Set DMM

RESET	<i>Set DMM for DCV, autorange</i>
NPLC 20	<i>Set NPLC 20</i>

[d] Set Scanning A/D for first voltage measurement

CAL:CONF:VOLT .0625, ZERO	<i>Connect DMM to source voltage, set .0625V range and ZERO source output.</i>
*OPC?	<i>Use *OPC? to ensure setup completed</i>
ENTER statement	

[e] Trigger DMM and Send Voltage Value to RAM

TRIG SGL *Measure source voltage and store result*
 WAIT 1 *in ref_volts*
 ENTER <ref_volts>

[f] Send measured value to Scanning A/D

CAL:VAL:VOLT <ref_volts> *Send meas voltage value to E1413A RAM*

Perform voltage measurements for all ranges and levels in the order shown in the following table

Range	Level
.0625 V	ZERO
.0625V	FULL-SCALE
.25V	ZERO
.25V	FULL-SCALE
1.0V	ZERO
1.0V	FULL-SCALE
4.0V	ZERO
4.0V	FULL-SCALE
16.0V	ZERO
16.0V	FULL-SCALE

3 Store Results in Flash Memory (EEPROM)

CAL:STOR ADC *Store new resistance and voltage calibration constants in Flash memory*

Repeat the adjustment procedure for each HP E1413A to be adjusted.

NOTE

As shipped from the factory, the Flash Memory Protect Jumper (JM 2201) is set to the "PROG" position. If the jumper is not set to the PROG position, values cannot be loaded into Flash memory. In this case, the following error message is displayed. If the jumper has been set to the PROTECT position, change the setting to the PROG position (see Figure 3-1) and rerun the adjustment procedure.

Error Messages

+3034,"0x4: DSP-Flash rom erase failure"
 +3035,"0x8: DSP-Programming voltage not present"
 "+0, No error"

Example Program

This program performs A/D adjustments and channel calibrations for an HP E1413A Scanning A/D. An HP 3458A DMM is used to measure the reference resistor and reference voltage values.

NOTE

If you want to perform A/D adjustments for more than one HP E1413A, start by making the HP 3458A DMM connections to HP E1413A #1. Run the program once for each Scanning A/D, and enter the appropriate Logical Address when requested by the program.

```
10! RE-STORE "ADJSPROC"
20 !
30 Ad=70903
40 Dmm=722
50 CLEAR SCREEN
60 PRINT "Scanning A/D Adjustments"
70 INPUT " Enter Logical Address for this Scanning A/D (default = 70903) ",Ad
80 ASSIGN @Ad TO Ad
90 INPUT " Enter the HP 3458A DMM HP-IB Address (default = 722) ",Dmm
100 ASSIGN @Dmm TO 722
110 !
120 ! -----Reference Resistor Measurement-----
130 !
140 CLEAR SCREEN
150 PRINT "Resistance Measurement"
160 PRINT
170 PRINT "Make 4-wire ohms connections from DMM to Scanning A/D"
180 PRINT
190 DISP " Press Continue when ready "
200 PAUSE
210 CLEAR SCREEN
220 PRINT "Resetting Scanning A/D ..."
230 OUTPUT @Ad;"*RST;*CLS"
240 WAIT 5
250 CLEAR SCREEN
260 Retry_res: !
270 PRINT "Measuring reference resistor value ..."
280 OUTPUT @Ad;"CAL:CONF:RES"
290 OUTPUT @Ad;"*OPC?"
300 ENTER @Ad;Opc_r
310 OUTPUT @Dmm;"RESET"
```

Continued on next page

```

320 OUTPUT @Dmm;"FUNC OHMF;OCOMP ON;NPLC 20"
330 WAIT 1
340 OUTPUT @Dmm;"TRIG SGL"
350 ENTER @Dmm;Ref_ohms
360 CLEAR SCREEN
370 PRINT "Reference Resistor Value"
380 PRINT
390 PRINT "Nominal Value: 7.5 kOhms"
400 PRINT USING "15A,X,D.4D,X,5A";"Measured Value:";Ref_ohms*1.E-3;"kOhms"
410 IF Ref_ohms<7450 OR Ref_ohms>7550 THEN
420 BEEP
430 PRINT
440 PRINT "      NOTE"
450 PRINT
460 PRINT "Measured value is too high or low."
470 PRINT "Check DMM and Scanning A/D connections."
480 PRINT "Then, rerun this measurement"
490 DISP " Press Continue to rerun this measurement "
500 PAUSE
510 CLEAR SCREEN
520 GOTO Retry_res
530 ELSE
540 END IF
550 OUTPUT @Ad;"CAL:VAL:RES ";Ref_ohms
560 DISP " Press Continue for Source Voltage Measurements "
570 PAUSE
580 CLEAR SCREEN
590 !
600 ! —————Source Voltage Measurements —————
610 !
620 DIM Dmm_rng(1:10),Ref_volts(1:10),Ad_rng(1:10),Zero_fs$(1:10)[4],Err_msg$(256)
630 DATA .0625,.0625,.25,.25,1.0,1.0,4.0,4.0,16.0,16.0
640 READ Ad_rng(*)
650 DATA ZERO,FSC,ZERO,FSC,ZERO,FSC,ZERO,FSC,ZERO,FSC
660 READ Zero_fs$(*)
670 PRINT "Source Voltage Measurements"
680 PRINT
690 PRINT "Make voltage connections between DMM and Scanning A/D"
700 DISP " Press Continue when ready "
710 PAUSE
720 CLEAR SCREEN
730 OUTPUT @Ad;"*RST"

```

Continued on next page

```

740 WAIT 5
750 OUTPUT @Dmm;"RESET;NPLC 20"
760 WAIT 1
770 !
780 ! — Measure voltage reference values and send values to A/D RAM ———
790 !
800 FOR J=1 TO 10
810 CLEAR SCREEN
820 PRINT "Measuring Source Voltage ..."
830 PRINT
840 PRINT "Range: ";Ad_rng(J);"V"
850 PRINT "Level: ";Zero_fs$(J)
860 OUTPUT @Ad;"CAL:CONF:VOLT "&VAL$(Ad_rng(J))&","&Zero_fs$(J)
870 OUTPUT @Ad;"**OPC?"
880 ENTER @Ad;Opc_v
890 OUTPUT @Dmm;"TRIG SGL"
900 WAIT 1
910 ENTER @Dmm;Ref_volts(J)
920 OUTPUT @Ad;"CAL:VAL:VOLT ";Ref_volts(J)
930 NEXT J
940 !
950 Fmt:IMAGE(2D.4D,8X,4A,8X,2D.4D,11X,3D.D)
960 Fmt1:IMAGE(2D.4D,8X,4A,8X,2D.4D)
970 CLEAR SCREEN
980 PRINT "Measured Voltage Values"
990 PRINT
1000 PRINT "1. Voltage should be ~90% FULL-SCALE range (except 16V range)."
1010 PRINT "2. For the 16V range, voltage value should be ~10.0V."
1020 PRINT
1030 PRINT "Range (V)   Level   Measured (V)   % of Full-Scale"
1040 PRINT
1050 FOR K=1 TO 10
1060 IF K MODULO 2=0 THEN
1070 PRINT USING Fmt;Ad_rng(K),Zero_fs$(K),Ref_volts(K),(Ref_volts(K)/Ad_rng(K))*100
1080 ELSE
1090 PRINT USING Fmt1;Ad_rng(K),Zero_fs$(K),Ref_volts(K)
1100 END IF
1110 NEXT K
1120 PRINT
1130 PRINT USING "17A,X,D.4D,X,5A";"Resistance Value: ";Ref_ohms*1.E-3;"kOhms"
1140 !
1150 ! — Store resistance and voltage calibration constants in Flash ROM ———

```

Continued on next page

```

1160 !
1170 INPUT " Store these values into Flash memory (EEPROM) (Y/N)? ",Ans$
1180 CLEAR SCREEN
1190 IF Ans$="Y" OR Ans$="y" THEN
1200  OUTPUT @Ad;"CAL:STOR ADC"
1210 ELSE
1220  PRINT "New calibration constants NOT stored in Flash memory"
1230 END IF
1240 !
1250 !————— Error Messages —————
1260 !
1270 REPEAT
1280  OUTPUT @Ad;"SYST:ERR?"
1290  ENTER @Ad;Err_msg$
1300  IF Err_msg$<>"0","No error" THEN
1310    BEEP
1320    PRINT "Error Messages"
1330    PRINT
1340    PRINT Err_msg$
1350    PRINT
1360    PRINT "          NOTE"
1370    PRINT
1380    PRINT "If errors +3034 and/or +3035 appear, the Flash Memory"
1390    PRINT "Protect jumper (JM 2201) may be in the ""PROTect""
1400    PRINT "position, and the new calibration constants were not"
1410    PRINT "stored in Flash memory. Check the jumper position and"
1420    PRINT "rerun this adjustment if necessary."
1430 ELSE
1440 END IF
1450 UNTIL Err_msg$="0","No error"
1460 PRINT
1470 PRINT "Scanning A/D Adjustments Completed."
1480 END

```

Typical Display

After the reference resistor and 10 source voltage values are stored in RAM, the results are displayed and the program asks you if you want to store the values into Flash memory. A typical display for measured voltage and resistance values follows.

Measured Voltage Values

1. Voltage should be ~90% FULL-SCALE range (except 16V range).
2. For the 16V range, voltage value should be ~10.0V.

Range (V)	Level	Measured (V)	% of Full-Scale
.0625	ZERO	.0001	
.0625	FSC	.0564	90.3
.2500	ZERO	.0001	
.2500	FSC	.2253	90.1
1.0000	ZERO	.0001	
1.0000	FSC	.8941	89.4
4.0000	ZERO	.0001	
4.0000	FSC	3.5988	90.0
16.0000	ZERO	.0001	
16.0000	FSC	10.0035	62.5

Resistance Value: 7.4981 kOhms

Replaceable Parts

Introduction

This chapter contains information to order replaceable parts and/or exchange modules for the HP E1413A Scanning A/D. To order a part or exchange assembly listed in this chapter, specify the Hewlett-Packard part number and the quantity required. Send the order to your nearest Hewlett-Packard Sales and Support Office.

Exchange Modules

Table 4-1 lists modules described in this manual that may be replaced on an exchange basis (Exchange Modules). Exchange modules are available only on a trade-in basis. Defective modules must be returned for credit. Order modules for spare parts stock by the new module part number.

Table 4-1. E1413A Scanning A/D - Exchange/New Modules

Description	Option	Exchange Part Number	New Part Number
Scanning A/D Module	---	E1413-69201	E1413A
Straight-Through SCP	011	---	E1413A Option 011
Fixed Filter SCP	012	---	E1413A Option 012
Amplifier+Filter SCP	013	E1413-69213	E1413A Option 013

Replaceable Parts Lists

Table 4-2 lists replaceable parts for the HP E1413A Scanning A/D. See "Component Locators" (Figures 4-1 through 4-4) for locations of parts in Table 4-2. Table 4-3 shows reference designators for parts in Table 4-2, and Table 4-4 shows the manufacturer code list for the parts.

NOTE

If a Scanning A/D defect can be traced to a fuse or replaceable mechanical part, replace the fuse and/or part and retest the module. If the defect cannot be traced to a fuse or replaceable mechanical part, replace the entire module. Individual printed circuit assemblies (PCAs) cannot be returned for replacement or exchange. There are no replaceable parts on Signal Conditioning Plug-Ons (SCPs).

Table 4-2. HP E1413A Scanning A/D Replaceable Parts

Reference Designator	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
HP E1413A HARDWARE PARTS (FIG 4-1)					
CBL1	E1400-61605	1	CONNECTOR CABLE	28480	E1400-61605
CBL2	E1326-61604	1	CALIBRATION CABLE	28480	E1326-61604
HDL1	E1400-84105	1	EXT HANDLE KIT-BOTTOM	28480	E1400-84105
HDL2	E1400-84106	1	EXT HANDLE KIT-TOP	28480	E1400-84106
PNL1	E1405-00201	1	FRONT PANEL	28480	E1405-01201
SCR5-SCR9	0515-1135	5	SCREW-M3 X 0.5 25MM-LG FLAT-HEAD	28480	0515-1135
SCR10-SCR11	0515-0368	2	SCREW-M2.5 X 0.45 12MM-LG PAN-HEAD	28480	0515-0368
SCR12-SCR13	0515-1375	2	SCREW-M2.5 X 0.45 6MM-LG FLAT-HEAD	83486	343-300-02506
SHD1	E1413-00601	1	TOP SHIELD	28480	E1413-00601
SHD2	E1413-00602	1	BOTTOM SHIELD	28480	E1413-00602
SHD3	E1413-00603	1	COVER SCP	28480	E1413-00603
SHD4	E1413-00604	1	INNER SHIELD	28480	E1413-00604
A1 PCA REPLACEABLE PARTS (FIG 4-2)					
A1	E1413-66501	1	PRINTED CIRCUIT ASSEMBLY	28480	E1413-66501
F101-F105	2110-0712	5	FUSE-SUBMINIATURE 4A 125V NTD AX	75915	R251004T1
J1-J2	1251-7799	4	CONN-POST TYPE 2.54-PIN-SPCG 96-CONTACT	91662	10-8457-096-002-037
J3	1252-0776	1	CONN-POST TYPE .100-PIN-SPCG 12-CONTACT	00779	102979-6
J4100-J4470 ^a	1252-4618	8	50-PIN CONNECTOR 104549-7	00779	104549-7
J4101-J4471 ^b	1252-5357	8	50-PIN RECEPTACLE 104550-6	00779	104550-6
JM2201	1251-4682	1	CONN-POST TYPE .100-PIN-SPCG 3-CONTACT	26742	1102-1-103-02
K4100-K4463 ^c	0490-1937	67	RELAY 2C 3VDC COIL 1A 125VAC	28480	0490-1937
P1-P2	1251-7799		CONN-POST TYPE 2.54-PIN-SPCG 96-CONTACT	91662	10-8457-096-002-037
SP1	3101-2243	1	SWTCH-DIP ROCKER 8-1A 0.05A 30VDC	81073	76YY22318S
TERMINAL CASE ASSEMBLY PARTS (FIG 4-3)					
A1	E1400-84401	1	CASE TERMINAL BLOCK ASSEMBLY	28480	E1400-84401
MP1	03852-01201	1	CLAMP	28480	03852-01201
MP2	03852-86701	1	PAD-CLAMP	28480	03852-86701
MP3	0515-2109	1	SCREW-MACH 10-24 .625-IN-LG PAN-HD-SLT	28480	0515-2109
MP4	1390-0846	2	FASTENER-CAPTIVE SCREW M2.5 X 0.45	28480	1390-0846
MP5	E1300-01202	1	CLAMP STRAIN RELIEF	28480	E1300-01202
MP6	E1400-44104	1	TERMINAL HOUSING-BOTTOM	28480	E1400-44104
MP7	E1400-44105	1	TERMINAL HOUSING-TOP	28480	E1400-44105
TERMINAL MODULE PARTS (FIG 4-4)					
A1	E1413-66510	1	TERMINAL CARD ASSEMBLY	28480	E1413-66510
JM1	1251-6001	1	CONNECTOR POST TP 2 X 3P	28480	1251-6001
P1-P2	1252-1593	2	CONNECTOR-RA RCPT, 96P	28480	1252-1593
TB1-TB2	0360-2391	4	TERMINAL BLOCK 12 POS	28480	0360-2391
TB3-TB5	0360-2501	6	TERMINAL BLOCK 10 POS	28480	0360-2501
TB6-TB11	0360-2502	6	TERMINAL BLOCK 8 POS	28480	0360-2502
TB12-TB13	0360-2391		TERMINAL BLOCK 12 POS	28480	0360-2391
TB14-TB16	0360-2501		TERMINAL BLOCK 10 POS	28480	0360-2501

a Includes J4100, J4110, J4220, J4230, J4340, J4350, J4460, and J4470

b Includes J4101, J4111, J4221, J4231, J4341, J4351, J4461, and J4471

c Includes K4100-K4115, K4190-K4192, K4216-K4231, K4332-K4347, and K4448-K4463

Table 4-3. HP E1413A Scanning A/D Reference Designators

Reference Designators		
A assembly	Jelectrical connector (jack)	S switch (rotary)
CBL cable	JMjumper	SCR screw
F fuse	MP misc. mech part	SHD shield
HDmisc hardware	P electrical conn (plug)	SP switch (push-button)
	PNL panel	TP test connector

Table 4-4. HP E1413A Scanning A/D Code List of Manufacturers

Mfr Code	Manufacturer Name	Manufacturer Address			Zip Code
00779	AMP INC	HARRISBURG	PA	US	17111
05791	LYN-TRON INC	BURBANK	CA	US	91505
26742	METHODE ELECTRONICS INC	CHICAGO	IL	US	60656
28480	HEWLETT-PACKARD CO - CORPORATE	PALO ALTO	CA	US	94304
30817	INSTRUMENT SPECIALTIES CO INC	DEL WATER GAP	PA	US	18327
75915	LITTELFUSE INC	DES PLAINES	IL	US	60016
81073	GRAYHILL INC	LA GRANGE	IL	US	60525
83486	ELCO INDUSTRIES INC	ROCKFORD	IL	US	61125
91662	ELCO CORP	NEWPORT BEACH	CA	US	92660

Component Locators

Figures 4-1 through 4-4 show locations of selected replaceable parts for the E1413A Scanning A/D. Note that there are no replaceable parts for the Signal Conditioning Plug-Ons (SCPs).




Figure 4-1. HP E1413A Mechanical Parts

A1 PCA Relay Number Legend


[illegible]

Figure 4-2. HP E1413A A1 PCA Replaceable Parts




Figure 4-3. HP E1413A Terminal Case Parts




Figure 4-4. HP E1413A Terminal Module Parts

Introduction

This chapter contains information to service the HP E1413A 64-Channel Scanning A/D Converter, including recommended repair strategy, troubleshooting guidelines, and disassembly/repair guidelines.

WARNING

Do not perform any of the service procedures shown unless you are a qualified, service-trained person, and have read the WARNINGS and CAUTIONS in Chapter 1.

Equipment Required

Equipment required for HP E1413A Scanning A/D troubleshooting and repair is listed in Table 1-1, *Recommended Test Equipment*. To avoid damage to the screw head slots, use T8 and T10 Torx drivers as described in the "Disassembly" section in this chapter.

Service Aids

See *Chapter 4 - Replaceable Parts* for descriptions and locations of HP E1413A replaceable parts. Service notes and service literature for the Scanning A/D may be available through Hewlett-Packard. For information, contact your nearest Hewlett-Packard Sales and Support Office.

Recommended Repair Strategy

The recommended repair strategy for the HP E1413A Scanning A/D and associated SCPs is assembly-level repair.

- Before replacing an HP E1413A Scanning A/D, check fuses F101 through F105 on the A1 Printed Circuit Assembly (PCA) and check other replaceable parts listed in Table 4-2.
- If the fault can be traced to a part listed in Table 4-2, repair the fault and retest the instrument. If not, exchange or replace the entire HP E1413A. (There are no replaceable parts for SCPs.)
- See "Shipping Guidelines" in *Chapter 1 - General Information* to return an HP E1413A Scanning A/D to Hewlett-Packard.

Troubleshooting Guidelines

This section shows suggested steps to troubleshoot HP E1413A Scanning A/D faults to a replaceable part listed in Table 4-2. If the fault cannot be isolated to a replaceable part in Table 4-2, do not attempt further repairs. Instead, replace the instrument. The first step in troubleshooting the Scanning A/D is to run the service test (SERVTEST) program.

Running Service Test Program

To begin troubleshooting, you can run the following program to test the Scanning A/D. (The self-test may take several minutes to complete.) If the self-test passes, "Self-test (*TST?) PASSED" is displayed. If the self-test fails, error messages are displayed. Table 5-1 shows suggested actions, depending on the program results.

NOTE

*During the first 5 minutes after power is applied, the self-test (*TST?) may fail. Allow the Scanning A/D to warm up before running the SERVTEST program.*

Table 5-1. Scanning A/D Troubleshooting Steps

If the SERVTEST program result is:	The most likely cause is:	See this section:
No return	Mechanical part failure	"Checking Mechanical Parts"
+3052, "Self test failed. Check info in FIFO"	SCP is not properly seated or is defective	"Checking SCPs"

For example, the following result for the SERVTEST program indicates test #72 (SCP continuity) failed and channel 100 is the failed channel. See *Appendix C - Command Reference* for a description of the *TST? and SYST:ERR? error messages.

System Error Messages

+3052,"Self test failed. Test info in FIFO"
+0,"No error"

FIFO Error Messages

1 - 99 = Failed test number
100 - 163 = Failed channel number
200 - 204 = Range for failed test

+7.200000E+001,+1.000000E+002

```

10! RE-STORE "SERVTEST"
20 !
30 ASSIGN @Ad TO 70903
40 !
50 !————— Self-Test (*TST?) —————
60 !
70 OUTPUT @Ad;"*TST?"
80 PRINT "Performing Self-Test (Takes about 2 minutes) ..."
90 ENTER @Ad;Tst_res
100 IF Tst_res<>0 THEN GOTO Syst_err
110 PRINT "Self-Test (*TST?) PASSED"
120 GOTO End_test
130 !
140 !————— Error Messages —————
150 !
160 Syst_err: !
170 CLEAR SCREEN
180 PRINT "System Error Messages"
190 PRINT
200 DIM Err_msg$(256)
210 REPEAT
220   OUTPUT @Ad;"SYST:ERR?"
230   ENTER @Ad;Err_msg$
240   PRINT Err_msg$
250   UNTIL Err_msg$="+0","No error""
260 !
270 !————— Check FIFO Error Messages —————
280 !
290 Fifo_err: !
300 PRINT
310 PRINT "FIFO Error Messages"
320 PRINT
330 PRINT "  1 - 99 = Failed test number"
340 PRINT "100 - 163 = Failed channel number"
350 PRINT "200 - 204 = Range for failed channel"
360 PRINT
370 DIM Err$(1000)
380 OUTPUT @Ad;"DATA:FIFO:COUN?"
390 ENTER @Ad;Fifo_count
400 OUTPUT @Ad;"DATA:FIFO:PART? ";Fifo_count
410 ENTER @Ad;Err$
420 PRINT Err$
430 End_test: !
440 END

```

Checking Mechanical Parts

If the self-test service (SERVTEST) program does not respond, remove the Scanning A/D from the mainframe and check the mechanical parts listed in Table 5-2 (see Figures 4-1 through 4-4 for component locations).

Change/repair/replace components as required and then retest the instrument using the SERVTEST program. If the SERVTEST still does not return a response, replace the instrument. See "Repair Guidelines" before removing or installing any Scanning A/D components.

Table 5-2. Scanning A/D Mechanical Checks

Test/Check	Reference Designator	Check	Comments
Heat Damage	-----	Discolored PC board Damaged insulation Evidence of arcing	If there is damage, do not operate the instrument until you have corrected the problem.
Logical Address	SP1	LADDR setting (factory set to 24)	See the <i>HP E1413A User's Manual</i> for information on switch settings.
A1 PCA	F101 - F105 J1 - J3, J1203, J4100 - J4471 P1 - P2	Fuse continuity Damaged connectors	See "Repair/Maintenance Guidelines" before replacing fuse(s)/connectors. See "Disassembly" to remove covers/shields.
Terminal Module	JM1 MP1 - MP7 P1 - P2 TB1 - TB16	Damaged connectors	See Figures 4-3 and 4-4 for terminal module parts locations.

Checking SCPs

If there are no apparent mechanical problems but the instrument does not pass the service test (SERVTEST) program, check all installed SCPs. Table 5-3 gives some guidelines to check/replace SCPs.

Table 5-3. Guidelines to Check/Replace SCPs

If the SERVTEST shows failure for test number(s):	Do This:
20 or 30 through 37	Remove all SCPs and rerun the SERVTEST program. If *TST? then passes, replace SCPs one at a time until you find the one causing the problem. Then, replace the SCP causing the problem.
72 or 74 through 76	Try to reseat the SCP that the channel number(s) point to and then rerun SERVTEST. Or, move the SCP and see if the problems follow the SCP. If so, replace the SCP and rerun SERVTEST.
Other test numbers	Replace the instrument.

Disassembly

To perform Scanning A/D disassembly, you will need a T-8 and T-10 Torx driver. See Figure 5-1 for steps to disassemble a Scanning A/D. Reverse the steps to reassemble the Scanning A/D.

CAUTION

Do not handle or disassemble the Scanning A/D module unless you are familiar with the precautions listed in the "Repair/Maintenance Guidelines" section of this chapter.

1 Remove Top Shield





Figure 5-1. Scanning A/D Disassembly

2 Remove SCP Cover



3 Remove SCP(s)





Figure 5-1. Scanning A/D Disassembly (Cont'd)

4 Remove Inner Shield



5 Remove A1 PCA




Figure 5-1. Scanning A/D Disassembly (cont'd)

Repair/ Maintenance Guidelines

Guidelines to repair and maintain an HP E1413A Scanning A/D follow, including:

- ESD precautions
 - Soldering printed circuit boards
 - Post-repair safety checks
-

CAUTION

Do not touch the Scanning A/D or SCP edge connector pins at any time unless you are actively using a static-free workstation.

ESD Precautions

Electrostatic discharge (ESD) may damage CMOS and other static-sensitive devices in the Scanning A/D such as ROM or RAM ICs. This damage can range from slight parameter degradation to catastrophic failure. When working on Scanning A/D or SCP modules, follow these guidelines to avoid damaging components:

- Always use a static-free work station with a pad of conductive rubber or similar material when handling module components.
- After you remove a module from the frame, place the module on a conductive surface to guard against ESD damage.
- Do not use pliers to remove a CMOS device from a high-grip socket. Instead, use a small screwdriver to pry the device up from one end. Slowly lift the device up, one pair of pins at a time.
- After you remove a CMOS device from a module, place the device onto a pad of conductive foam or other suitable holding material.
- If a device requires soldering, be sure the device is placed on a pad of conductive material. Also, be sure you, the pad, and the soldering iron tip are grounded to the device. Apply as little heat as possible when soldering.

Soldering Printed Circuit Boards

The etched circuit boards on Scanning A/D module printed circuit assemblies (PCAs) have plated-through holes that allow a solder path to both sides of the insulating material. Soldering can be done from either side of the board with equally good results. When soldering to any circuit board, keep in mind the following guidelines:

CAUTION

Do not use a sharp metal object such as an awl or twist drill, since sharp objects may damage the plated-through conductor.

- Avoid unnecessary component unsoldering and soldering. Excessive replacement can result in damage to the circuit board and/or adjacent components.
- Do not use a high power soldering iron on etched circuit boards, as excessive heat may lift a conductor or damage the board.
- Use a suction device or wooden toothpick to remove solder from component mounting holes. When using a suction device, be sure the equipment is properly grounded to prevent electrostatic discharge from damaging CMOS devices.

**Post-Repair
Safety Checks**

After making repairs to Scanning A/D module components, inspect the device for any signs of abnormal internally generated heat, such as discolored printed circuit boards or components, damaged insulation, or evidence of arcing. Determine and correct the cause of the condition. Then, run the power-on self-test to verify that the Scanning A/D module is operational.

NOTE

As desired, you may want to run the functional and/or performance verification tests in Chapter 2 - Verification Tests.

Calculating Scanning A/D Accuracy

Introduction

This appendix shows how scanning A/D accuracy, source equipment measurement uncertainty, and test accuracy ratio (TAR) values are defined and calculated for the performance verification tests for the HP E1413A Scanning A/D.

See Table 2-1, "HP E1413A Performance Test Record" for 1-year specification values of Scanning A/D accuracy, 90-day specification values for the Datron 4708 measurement uncertainty, and test accuracy ratios (TARs).

NOTE

Scanning A/D accuracy, measurement uncertainty, and test accuracy ratios in Table 2-1 are valid ONLY for the specified test conditions and assumptions described in this manual.

Scanning A/D Accuracy Definition

Scanning A/D accuracy is the expected accuracy of the measurement due ONLY to the Scanning A/D. The "Minimum" entry in Table 2-1 is the lower value of Scanning A/D accuracy, while the "Maximum" entry is the upper value of Scanning A/D accuracy. If a measured reading is between the Minimum and Maximum values in Table 2-1, the test passes for this input.

Measurement Uncertainty Definition

Measurement Uncertainty is the expected accuracy of the source used to input signals to the multimeter. Since the Datron 4708 Autocal Multifunction Standard Option 10 is the source used for inputs, the measurement uncertainty is that of the Datron 4708.

Test Accuracy Ratio (TAR) Definition

Test Accuracy Ratio (TAR) for the HP E1413A is defined by:

$$\text{TAR} = \frac{\text{Maximum Value} - \text{Expected Reading}}{\text{Measurement Uncertainty}}$$

where maximum value = largest amount of variation from the expected reading (the input), and measurement uncertainty is that of the test equipment (Datron Standard). If a TAR exceeds 10:1, the entry in Table 2-1 is ">10:1".

Scanning A/D Accuracy Calculations

For HP E1413A Scanning A/D performance verification tests, accuracy is defined for DC Voltage measurements using the 1-year specifications in the *HP E1413A User's Manual*. The assumed test conditions are:

- 1 year since the last adjustment
- Operating temperature $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$
- At least one hour warmup time

DC Voltage Accuracy Equations

From the *HP E1413A User's Manual*, DC voltage accuracy (1-year) = $\pm (0.02\% \text{ of reading} + \text{offset error} + \text{noise})$. Tables A-1 through A-5 list DCV accuracy equations for the ranges used in the performance verification tests.

Table A-1. Scanning A/D - DCV Accuracy (Option 11 SCP, 1-year)

Range $\pm$ FS	Linearity % of rdg	Offset error	Noise 3 sigma	Total offset
.0625 V	$\pm .02\%$	5.3 μV	8 μV	$\pm [.02\% + 13.3 \mu\text{V}]$
.25 V	$\pm .02\%$	10.3 μV	24 μV	$\pm [.02\% + 34.3 \mu\text{V}]$
1.0 V	$\pm .02\%$	31 μV	90 μV	$\pm [.02\% + 121 \mu\text{V}]$
4.0 V	$\pm .02\%$	122 μV	366 μV	$\pm [.02\% + 488 \mu\text{V}]$
16.0 V	$\pm .02\%$	488 μV	1500 μV	$\pm [.02\% + 1988 \mu\text{V}]$
Test Conditions: $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$ with *CAL? done after a one-hour warmup, A/D Zero done within 5 minutes before the measurement, autoranging OFF, and A/D Filter ON. Temperature coefficients: (0-40°C) 0.14 $\mu\text{V}/^{\circ}\text{C}$, (40-55°C) 0.8 μV + 0.27 $\mu\text{V}/^{\circ}\text{C}$.				

Table A-2. Scanning A/D - DCV Accuracy (Option 12 SCP, 1-year)

Range $\pm$ FS	Linearity % of rdg	Offset error	Noise 3 sigma	Total offset
.0625 V	$\pm .02\%$	7.2 μV	15 μV	$\pm [.02\% + 22.2 \mu\text{V}]$
.25 V	$\pm .02\%$	12.2 μV	28 μV	$\pm [.02\% + 40.2 \mu\text{V}]$
1.0 V	$\pm .02\%$	33 μV	92 μV	$\pm [.02\% + 125 \mu\text{V}]$
4.0 V	$\pm .02\%$	122 μV	366 μV	$\pm [.02\% + 488 \mu\text{V}]$
16.0 V	$\pm .02\%$	488 μV	1500 μV	$\pm [.02\% + 1988 \mu\text{V}]$
Test Conditions: $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$ with *CAL? done after a one-hour warmup, A/D Zero done within 5 minutes before the measurement, autoranging OFF, and A/D Filter ON. Temperature coefficients: Gain - 10ppm/ $^{\circ}\text{C}$ after *CAL?. Offset (0-30°C) no additional error, (30-40°C) 0.14 $\mu\text{V}/^{\circ}\text{C}$, (40-55°C) 2.4 μV + 0.27 $\mu\text{V}/^{\circ}\text{C}$.				

Table A-3. Scanning A/D - DCV Accuracy (Option 13 SCP Gain X1, 1-year)

Range ± FS	Linearity % of rdg	Offset Error				Noise 3 sigma
		2 Hz	10 Hz	100 Hz	Filter OFF	
.0625 V	± .02%	13 µV	9.5 µV	6.8 µV	6.3 µV	26 µV
.25 V	± .02%	15 µV	12.5 µV	11.2 µV	10.8 µV	31 µV
1.0 V	± .02%	33 µV	31.8 µV	31.3 µV	31.2 µV	93 µV
4.0 V	± .02%	123 µV	122 µV	122 µV	122 µV	366 µV
16.0 V	± .02%	488 µV	488 µV	488 µV	488 µV	1500 µV

Test Conditions:

23°C ± 1°C with *CAL? done after a one-hour warmup, A/D Zero done within 5 minutes before the measurement, autoranging OFF, and A/D Filter ON. Temperature coefficients: Gain - 15 ppm/°C after *CAL?. Offset - Add tempco + fixed offset to offset above.

Temp	Tempco	2 Hz	10 Hz	100 Hz	Filt OFF
0-30°C	0.16 µV/°C	0 µV	0 µV	0 µV	0 µV
30-40°C	0.18 µV/°C	13 µV	9 µV	1.1 µV	0.2 µV
40-55°C	0.39 µV/°C	31 µV	22 µV	6.4 µV	1.1 µV

Table A-4. Scanning A/D - DCV Accuracy (Option 13 SCP Gain X8, 1-year)

Range ± FS	Linearity % of rdg	Offset Error				Noise 3 sigma
		2 Hz	10 Hz	100 Hz	Filter OFF	
.0078 V	± .02%	4.6 µV	4.2 µV	3.8 µV	3.7 µV	4.9 µV
.031 V	± .02%	4.8 µV	4.6 µV	4.4 µV	4.3 µV	5.9 µV*
.125 V	± .02%	6 µV	5.3 µV	5 µV	4.9 µV	12 µV
.5 V	± .02%	16 µV	16 µV	16 µV	16 µV	46 µV
2 V	± .02%	61 µV	61 µV	61 µV	61 µV	188 µV

Test Conditions:

23°C ± 1°C with *CAL? done after a one-hour warmup, A/D Zero done within 5 minutes before the measurement, autoranging OFF, and A/D Filter ON. Temperature coefficients: Gain - 15 ppm/°C after *CAL?. Offset - Add tempco + fixed offset to offset above.

* = 6.3 µV when temperature ≥ 40°C.

Temp	Tempco	2 Hz	10 Hz	100 Hz	Filt OFF
0-30°C	0.16 µV/°C	0 µV	0 µV	0 µV	0 µV
30-40°C	0.18 µV/°C	4.3 µV	2.7 µV	1.0 µV	0.2 µV
40-55°C	0.39 µV/°C	13 µV	10 µV	6.2 µV	0.8 µV

Table A-5. Scanning A/D - DCV Accuracy (Option 13 SCP Gain X64, 1-year)

Range ± FS	Linearity % of rdg	Offset Error				Noise 3 sigma
		2 Hz	10 Hz	100 Hz	Filter OFF	
.0039V	± .02%	2.9 µV	2.3 µV	2.1 µV	2.1 µV	1.3 µV*
.0156V	± .02%	3 µV	2.4 µV	2.2 µV	2.2 µV	1.9 µV**
.0625V	± .02%	3.5 µV	3 µV	2.9 µV	2.9 µV	5.7 µV
.25V	± .02%	8.2 µV	8 µV	8 µV	8 µV	23 µV

Test Conditions:

23°C ± 1°C with *CAL? done after a one-hour warmup, A/D Zero done within 5 minutes before the measurement, autoranging OFF, and A/D Filter ON. Temperature coefficients: Gain - 15 ppm/°C after *CAL?. Offset - Add tempco + fixed offset to offset above.

* = 1.7 µV for 100 Hz filter , ** = 2.2 µV when temperature ≥ 40°C.

Temp	Tempco	2 Hz	10 Hz	100 Hz	Filt OFF
0-30 °C	0.16 µV/°C	0 µV	0 µV	0 µV	0 µV
30-40°C	0.18 µV/°C	1.1µV	0.2 µV	0.1µV	0.1 µV
40-55°C	0.39 µV/°C	6 µV	1.4 µV	0.6 µV	0.6 µV

**Example: Calculate
DC Voltage
Accuracy**

From Table A-1, for a 3.2 Vdc input to the scanning A/D using the 4.0 V range, scanning A/D accuracy (1-year) for the Option 11 SCP = ± (.02% of reading + 122 µV offset error +366 µV noise) = ± (.0002 x 3.2 + 122 x 10⁻⁶ + 366 x 10⁻⁶) = ± 0.0011 Vdc. Thus, for a 3.2 Vdc input the Minimum value for the Option 11 SCP test in Table 2-1 = 3.1989 Vdc and the Maximum value = 3.2011 Vdc.

**Measurement
Uncertainty
Calculations**

Measurement uncertainties for the Datron 4708 source are calculated using the 90-day accuracy specifications in the *Datron 4708 User's Handbook*. Measurement Uncertainty = Datron Accuracy + Calibration Uncertainty, where Datron Accuracy (ppm) = Accuracy Relative to Calibration Standards = ± (ppm OUTPUT + ppm FS) and FS = 2 x range for all ranges. The assumed test conditions are:

- Temperature of 23°C ± 1°C
- 90 days since calibration
- At least one hour warmup time

**Calculate DCV
Measurement
Uncertainty**

From Section 6 - Specifications of the *Datron 4708 User's Handbook*, DC Voltage (Option 10) Accuracy follows, where Datron Accuracy = ± (ppm OUTPUT + ppm FS).

Table A-6. Datron 4708 DC Voltage Specifications (Option 10, 90-day)

Datron Range (Volts)	Datron Accuracy (ppm)	Calibration Uncertainty (ppm)	Total Measurement Uncertainty (μV)
100.00000 mV	3 + 0.4 μV	4	± [7.0 * OUTPUT + 0.4]
1.0000000 V	2 + 0.4	2	± [4.0 * OUTPUT + 0.8]
10.000000 V	1 + 0.15	1.5	± [2.5 * OUTPUT + 3.0]
100.00000 V	2 + 0.25	2	± [4.0 * OUTPUT + 50.0]

Example: Calculate DC Voltage Measurement Uncertainty

Since Measurement Uncertainty = Datron Accuracy + Calibration Uncertainty, for a 3.2 Vdc OUTPUT and 10.000000 V range Measurement Uncertainty (μV) = ± [(1.0 x 3.2) + (2 x 0.15 x 10) + (1.5 x 3.2)] = ± 11 μV = ± 1.1E-5 V. Or, from Table A-6, Measurement Uncertainty (μV) = ± [(2.5 x 3.2) + 3.0] = ± 11 μV = ± 1.1E-5 V.

Test Accuracy Ratio (TAR) Calculations

For the HP E1413A Scanning A/D, DCV Test Accuracy Ratio (TAR) is:

$$TAR = \frac{\text{Maximum} - \text{Input}}{\text{Measurement Uncertainty}}$$

where Maximum, Input, and Measurement Uncertainty are all in Vdc.

Example: Calculate DC Voltage Accuracy TAR

For a 3.2 Vdc measurement (Input), the Maximum value = 3.2011 Vdc and the Measurement Uncertainty = 1.1E-5 Vdc, so

$$TAR = \frac{(3.2011 - 3.2000)}{1.1E-5} = 100:1$$

Since this value is >10:1, the entry in Table 2-1 is ">10:1".

B

Error Messages

Table B-1. HP E1413A Error Messages

Code	Description	Comments
-108	Parameter not allowed	
-160	Block data error	
-211	Trigger ignored	
-212	Arm ignored	
-213	INIT ignored	
-221	Settings conflict	
-222	Data out of range	
-224	Illegal parameter value	
-240	Hardware error. Execute *TST?	
-253	Corrupt media	
-281	Cannot create program	
-282	Illegal program name	
-310	System error	
-410	Query INTERRUPTED	
2001	Invalid channel number	
2003	Invalid word address	
2007	Bus error	
2008	Scan list not initialized	
2009	Too many channels in channel list	
2016	Byte count is not a multiple of two	
3000	Illegal while initiated	
3001	Illegal while continuous	
3004	Illegal command. CAL:CONF not sent.	Incorrect sequence of calibration commands. Send CAL:CONF command before CAL:VAL command.
3005	Illegal command. Send CAL:VAL:RES.	The only command accepted after a CAL:CONF: RES is a CAL:VAL:RES command.
3006	Illegal command. Send CAL:VAL:VOLT.	The only command accepted after a CAL:CONF:VOLT is a CAL:VAL:VOLT command.
3007	Invalid signal conditioning module	The command sent to an SCP was illegal for its type.
3008	Too few channels in scan list	A Scan List must have at least two channels.
3012	Trigger too fast	Scan List not completed before another trigger event occurs.
3015	Channel modifier not permitted here	
3019	TRIG:TIM interval too small for SAMP:TIM interval and scan list size	TRIG:TIM interval must allow for completion of entire scan list at currently set SAMP:TIM interval.

Table B-1. HP E1413A Error Messages (cont'd)

Code	Description	Comments
3020	Input overvoltage	Calibration relays opened (if JM2202 not cut) to protect module inputs, and Questionable Data Status bit 11 set. Execute *RST to close relays and/or reset status bit.
3021	FIFO overflow	
3026	Calibration failed	
3027	Unable to map A24 VXI memory	
3028	Incorrect range value.	Range value sent is not supported by instrument.
3030	Command not yet implemented!!.	
3032	0x1: DSP-Unrecognized command code	
3033	0x2: DSP-Parameter out of range.	
3034	0x4: DSP-Flash ROM erase failure	Check that SCP is seated or replace SCP. Channel numbers are in FIFO.
3035	0x8: DSP-Programming voltage not present	
3036	0x10: DSP-Invalid SCP gain value	
3037	0x20: DSP-Invalid *CAL? constant or checksum. *CAL? required.	
3038	0x40: DSP- Could not cal some channels	Check that SCP is seated or replace SCP. Channel numbers are in FIFO.
3039	0x80: DSP-Re-Zero of ADC failed.	
3040	0x100: DSP-Invalid Tare CAL constant or checksum.	Perform CAL:TARE - CAL:TARE? procedure.
3041	0x200: DSP-Invalid Factory CAL constant or checksum.	Perform A/D Cal procedure.
3042	0x400: DSP-DAC adjustment went to limit.	Execute *TST?
3043	0x800: DSP Status—Do *CAL?	
3044	0x1000: DSP-Overvoltage on input	
3045	0x2000: DSP-reserved error condition	
3046	0x4000: DSP-ADC hardware failure	
3047	0x8000: DSP-reserved error condition	
3048	Calibration or Test in Process	
3049	Calibration not in Process	

Table B-1. HP E1413A Error Messages (cont'd)

Code	Description	Comments
3050	ZERO must be sent before FSCale	Perform A/D Cal sequence as shown in CAL:CONF:VOLT
3051	Memory size must be multiple of 4.	From MEM:VME:SIZE. Each HP E1413 reading requires 4 bytes.
3052	Self test failed. Test info in FIFO.	A value of 1 through 99 is a failed test number. A value of 100 through 163 is a channel number for the failed test. A value of 200 through 204 is an A/D range number for the failed test where 200 = .0625V, 201 = .25V, 202 = 1V, 203 = 4V, and 204 = 16V range. For example, if DATA:FIFO? returns the values 72 and 108, this indicates that test number 72 failed on channel 8. Test numbers 20, 30-37, 72, 74-76 may indicate a problem with a Signal Conditioning Plug-on. For tests 20 and 30-37, remove all SCPs and see if *TST? passes. If so, replace SCPs one at a time until you find the one causing the problem. For tests 72, and 74-76, try to re-seat the SCP that the channel number(s) points to, or move the SCP and see if the failure(s) follow the SCP. If the problems move with the SCP, replace the SCP. Refer to the *TST? command for a list of module functions tested. NOTE During the first 5 minutes after power is applied, *TST? may fail. Allow the module to warm up before executing *TST?.
3053	Corrupt on board Flash memory	
3056	Custom EU not loaded	May have erased custom EU conversion table with *RST. May have linked channel with standard EU after loading custom EU, this erases the custom EU for this channel. Reload custom EU table using DIAG:CUST:LIN or DIAG:CUST:PIEC.

Command Reference

Introduction

This appendix describes the Standard Commands for Programmable Instruments (SCPI) CALibration commands and IEEE-488.2 Common Commands for the HP E1413A. Commands are listed alphabetically within each subsystem. See *Chapter 5 - Command Reference* in the *HP E1413 User's Manual* for command fundamentals.

CALibration Commands

The CALibration subsystem commands provide two major categories of calibration: A/D Calibration and Working Calibration.

A/D Calibration

For this procedure, an external multimeter is used to determine the actual voltage and resistance values of the Scanning A/D's internal calibration sources. The known values are then sent to the Scanning A/D where they are stored and used to perform internal A/D calibration.

A/D calibration requires a series of CALibration commands (**CAL:CONF...**, **CAL:VAL...**, and **CAL:STORE ADC**). See *Chapter 3 - Adjustments* for the procedure. Always execute ***CAL?** or a **CAL:TARE** operation after A/D calibration.

Working Calibration

As shown in Figure C-1, there are three levels of HP E1413A "working calibration": A/D Zero, Channel Calibration, and Channel Tare.

A/D Zero (CAL:ZERO?): This function quickly compensates for any short term A/D converter offset drift (the autozero function in a conventional voltmeter).

Channel Calibration (*CAL? or CAL:SETup): This function corrects for offset and gain errors, thermal offsets, and component drift for each channel out to the input side of the SCP.

Channel Tare (CAL:TARE): This function corrects for voltage offsets in external (user) system wiring. The user places a short across the transducer wiring and the voltage that the Scanning A/D measures is now considered the new "zero" value for that channel. The new offset can be stored in non-volatile calibration memory (with **CAL:STOR TARE**) but is in effect whether stored or not. **CAL:TARE** automatically executes a ***CAL?** command.




Figure C-1. HP E1413A Working Calibration Levels

CALibration Command Syntax

```

CALibration
:CONFigure
:RESistance
:VOLTage <range>, ZERO | FS
:SETup
:SETup?
:STORE ADC | TARE
:TARE (@<ch_list>)
:RESet
:TARE?
:VALue
:RESistance <ref_ohms>
:VOLTage <ref_volts>
:ZERO?

```

CALibration: CONFigure: RESistance

CALibration:CONFigure:RESistance connects the on-board reference resistor to the Calibration Bus. A four-wire measurement of the resistor can be made with an external multimeter connected to the H_{CAL}, L_{CAL}, H_{OHM}, and L_{OHM} terminals on the terminal module or to the V_H, V_L, Ω H, and Ω L terminals on the Cal Bus connector.

Comments

- **Related Commands:** CAL:VAL:RES, CAL:STOR ADC

Command Sequence

CAL:CONF:RES *connect reference resistor to Calibration Bus*

*OPC? or SYST:ERR? *must wait for CAL:CONF:RES to complete*

(now measure ref resistor with external DMM)

CAL:VAL:RES <measured value> *Send measured value to module*

CAL:STORE ADC *Store cal constants in non-volatile memory (used only at end of complete cal sequence)*

CALibration: CONFigure: VOLTage

CALibration:CONFigure:VOLTage <range>,<zero_fs> connects the on-board voltage reference to the Calibration Bus. A measurement of the source voltage can be made with an external multimeter connected to the H_{CAL} and L_{CAL} terminals on the terminal module or to the V_H and V_L terminals on the Cal Bus connector. The *range* parameter controls the voltage level available when the *zero_fs* parameter is FSCale (full scale).

Parameters

Parameter Name	Parameter Type	Range of Values	Default Units
range	numeric (float32)	see comments	volts
zero_fs	discrete (string)	ZERO FSCale	none

Comments

- The *range* parameter must be within 5% of one of the 5 following values: .0625VDC, .25VDC, 1VDC, 4VDC, 16VDC. Range may be specified in millivolts (mV).
- The FSCALE output voltage of the calibration source should be greater than 90% of the nominal value for each range, except the 16V range where the output is 10V.
- **Related Commands:** CAL:VAL:VOLT, CAL:STOR ADC

Usage

CAL:CONF:VOLT .25, ZERO	<i>Voltage reference set to .25V range and zero output</i>
CAL:CONF:VOLT .25, FSCALE	<i>Set same range but full-scale output</i>

Command Sequence

CAL:CONF:VOLTAGE .0625, ZERO	<i>connect voltage reference to Calibration Bus</i>
*OPC? or SYST:ERR?	<i>Wait for CAL:CONF:VOLT to complete</i>
<i>(now measure voltage with external DMM)</i>	
CAL:VAL:VOLT <measured value>	<i>Send measured value to module</i>
repeat above sequence for full-scale	
repeat zero and full-scale for remaining ranges (.25, 1, 4, 16)	
CAL:STORE ADC	<i>Store cal constants in non-volatile memory (used only at end of cal seq)</i>

CALibration:SETup

CALibration:SETup causes the Channel Calibration function to be performed for every module channel. The Channel Calibration function calibrates the A/D Offset and the Gain/Offset for all 64 channels. This calibration is accomplished using internal calibration references. Since this is time-consuming, you may want to run many at once rather than one at a time.

CAL:SET performs the same operation as the *CAL? command except that since it is not a query command it does not tie up the C-SCPI driver waiting for response data from the instrument. If you have multiple HP E1413s in your system, you can start a CAL:SET operation on each and then execute a CAL:SET? command to complete the operation on each instrument.

- **Related Commands:** CAL:SETup?, *CAL?

Usage

CAL:SET	<i>start SCP Calibration on 1st HP E1413</i>
:	<i>start SCP Calibration on more HP E1413s</i>
CAL:SET	<i>start SCP Calibration on last HP E1413</i>
CAL:SET?	<i>query for results from 1st HP E1413</i>
:	<i>query for results from more HP E1413s</i>
CAL:SET?	<i>query for results from last HP E1413</i>

CALibration:SETup?

CALibration:SETup? returns a value to indicate the success of the last CAL:SETup or *CAL? operation. CAL:SETup? returns the value only after the CAL:SETup operation is complete.

Comments

- **Returned Value:**

Value	Meaning	Further Action
0	Cal OK	None
-1	Cal Error	Query the Error Queue (SYST:ERR?) See Appendix B. Also run *TST?
-2	No results available	No *CAL? or CAL:SETUP done

The C-SCPI type for this returned value is int16.

- **Related Commands:** CAL:SETup, *CAL?

Usage see CAL:SETup

CALibration:STORe

CALibration:STORe <type> stores the most recently measured calibration constants into Flash Memory (Electrically Erasable Programmable Read Only Memory). When *type* = ADC, the module sets its Analog-to-Digital Converter calibration using the most recently measured CAL:VALues for voltage and resistance, and stores these to Flash Memory. When *type* = TARE, the module stores the most recently measured CAL:TARE channel offsets into Flash Memory.

NOTE

The HP E1413's Flash Memory has a finite lifetime of approximately ten thousand write cycles (unlimited read cycles). While executing CAL:STOR once every day would not exceed the lifetime of the Flash Memory for approximately 27 years, an application that stored constants many times each day would unnecessarily shorten the Flash Memory's lifetime. See Comments below.

Parameters

Parameter Name	Parameter Type	Range of Values	Default Units
type	discrete (string)	ADC TARE	none

- Comments**
- The Flash Memory Enable jumper (JM 2201) must be set to the enable position before executing this command (See *Chapter 3 - Adjustments*).
 - Channel offsets are compensated by the CAL:TARE command even when not stored in the Flash Memory. There is no need to use the CAL:STORE TARE command for channels which are re-calibrated frequently.
 - **Related Commands:** CAL:VAL:RES, CAL:VAL:VOLT
 - ***RST Condition:** Stored calibration constants are unchanged.

Usage

CAL:STORE ADC

Store cal constants in non-volatile memory after A/D calibration

CAL:STORE TARE

Store channel offsets in non-volatile memory after channel tare

Command Sequence

Storing A/D cal constants

perform complete A/D calibration, then...

CAL:STORE ADC

Storing channel tare (offset) values

CAL:TARE <ch_list>

to correct channel offsets

CAL:STORE TARE

Optional - depends on long term storage req

CALibration:TARE

CALibration:TARE (@<ch_list>) measures the voltage present on the channels specified and stores the value in on-board RAM as a calibration constant for those channels. Future measurements made with the channels will be compensated by the amount of the tare value.

Use CAL:TARE to compensate for voltage offsets in transducer wiring. Where tare values need to be retained for long periods, they can be stored in the module's Flash Memory (Electrically Erasable Programmable Read Only Memory) by executing the CAL:STORE TARE command.

NOTE

The HP E1413's Flash Memory has a finite lifetime of approximately ten thousand write cycles (unlimited read cycles). While executing CAL:STORE once every day would not exceed the lifetime of the Flash Memory for approximately 27 years, an application that stored constants many times each day would unnecessarily shorten the Flash Memory's lifetime.

NOTE

If Open Transducer Detect (OTD) is enabled when CAL:TARE is executed, the module will disable OTD, wait 1 minute to allow channels to settle, perform the calibration, and then re-enable OTD. If your program turns off OTD before executing CAL:TARE, it should also wait 1 minute for settling.

Parameters

Parameter Name	Parameter Type	Range of Values	Default Units
ch_list	channel list (string)	100 - 163	none

Comments

- Channel offsets are compensated by the CAL:TARE command even when not stored in the Flash Memory. There is no need to use the CAL:STORE TARE command for channels which are re-calibrated frequently.
- Set Amplifier/Filter SCP gain before CAL:TARE. For best accuracy, choose the gain that will be used during measurements.
- Executing CAL:TARE sets the Calibrating bit (bit 0) in Operation Status Group. Executing CAL:TARE? resets the bit.
- **Related Commands:** CAL:TARE?, CAL:STORE TARE
- ***RST Condition:** Channel offsets are not affected by *RST.

Command Sequence

CAL:TARE <ch_list>

to correct channel offsets

CAL:TARE?

to return the success flag from the CAL:TARE operation

CAL:STORE TARE

Optional - depends on long term storage req

CALibration: TARE:RESet

CALibration:TARE:RESet resets the tare calibration constants to zero for all 64 channels. Executing CAL:TARE:RES affects the tare cal constants in RAM only. To reset the tare cal constants in Flash Memory, execute CAL:TARE:RES and then execute CAL:STORE TARE.

Command Sequence

CAL:TARE:RESET

to reset channel offsets

CAL:STORE TARE

Optional if necessary to reset tare cal constants in Flash Memory.

CALibration:TARE?

CALibration:TARE? Returns a value to indicate the success of the last CAL:TARE operation. CAL:TARE? returns the value only after the CAL:TARE operation is complete.

- **Returned Value:**

Value	Meaning	Further Action
0	Cal OK	None
-1	Cal Error	Query the Error Queue (SYST:ERR?) See Error Messages in <i>Appendix B - Error Messages</i> . Also run *TST?
-2	No results available	No CAL:TARE done

The C-SCPI type for this returned value is **int16**.

- Executing CAL:TARE sets the Calibrating bit (bit 0) in Operation Status Group. Executing CAL:TARE? resets the bit.
- **Related Commands:** CAL:STOR TARE

Command Sequence

CAL:TARE <ch_list>

to correct channel offsets

CAL:TARE?

*to return the success flag
from the CAL:TARE
operation*

CAL:STORE TARE

*Optional depending on
necessity of long term
storage*

CALibration: VALue:RESistance

CALibration:VALue:RESistance <ref_ohms> sends the value of the on-board reference resistor to the module for A/D calibration.

Parameters

Parameter Name	Parameter Type	Range of Values	Default Units
ref_ohms	numeric (float 32)	5%	ohms

Comments

- *ref_ohms* must be within 5% of the nominal resistor value and may be specified in Kohm.

- A four-wire measurement of the resistor can be made with an external multimeter connected to the **HCAL**, **LCAL**, **HOHM**, and **LOHM** terminals on the terminal module or to the **VH**, **VL**, Ω **H**, and Ω **L** terminals on the Cal Bus connector.
- Use the **CAL:CONF:RES** command to configure the reference resistor for measurement at the Calibration Bus connector.
- **Related Commands:** **CAL:CONF:RES**, **CAL:STORE ADC**

Usage

CAL:VALUE:RESISTANCE <measured value>

Command Sequence

CAL:CONF:RES

(now measure ref resistor with external DMM)

CAL:VAL:RES <measured value> *Send measured value to module*

CALibration: VALue:VOLTage

CALibration:VALue:VOLTage <ref_volts> sends the value of the DC reference source to the module for A/D calibration.

Parameters

Parameter Name	Parameter Type	Range of Values	Default Units
ref_volts	numeric (float 32)	must be within 10% of range nominal	volts

Comments

- *ref_volts* may be specified in millivolts (mV).
- A measurement of the source voltage can be made with an external multimeter connected to the **HCAL** and **LCAL** terminals on the terminal module or to the **VH** and **VL** terminals on the Cal Bus connector.
- Use the **CAL:CONF:VOLT** command to configure the on-board voltage source for measurement at the Calibration Bus connector.
- The value sent must be for the currently configured range and output (zero or full scale) as set by the previous **CAL:CONF:VOLT** <range>, **ZERO** | **FSCale** command.
- **Related Commands:** **CAL:CONF:VOLT**, **CAL:STORE ADC**

Usage

CAL:VALUE:VOLTAGE <measured value>

Command Sequence

CAL:CONF:VOLTAGE 4,FSCALE

*OPC?

Wait for operation to complete

ENTER statement

(now measure voltage with external DMM)

CAL:VAL:VOLT <measured value>

Send measured value to module

CALibration:ZERO?

CALibration:ZERO? corrects Analog to Digital converter offset for any drift since the last *CAL? or CAL:ZERO? command was executed.

Comments

- The CAL:ZERO? command only corrects for A/D offset drift (zero). Use the *CAL? common command to perform on-line calibration of channels as well as A/D offset. *CAL? performs gain and offset correction of the A/D and each channel out to the field wiring connector.

Returned Value:

Value	Meaning	Further Action
0	Cal OK	None
-1	Cal Error	Query the Error Queue (SYST:ERR?) See Error Messages in <i>Appendix B - Error Messages</i>

The C-SCPI type for this returned value is **int16**.

- Executing this command **does not** alter the module's programmed state (function, range, etc.).
- **Related Commands:** *CAL?
- ***RST Condition:** A/D offset performed

Usage

CAL:ZERO?

enter statement here

returns 0 or -1

Common Commands

This section describes IEEE-488.2 Common commands. See *Chapter 5 - HP E1413 Command Reference* in the *HP E1413A User's Manual* for Common Command fundamentals.

***CAL?** **Calibration Command.** The calibration command causes the Channel Calibration function to be performed for every module channel. The Channel Calibration function includes calibration of A/D Offset, and Gain and Offset for all 64 channels. This calibration is accomplished using internal calibration references.

- **Returned Value:**

Value	Meaning	Further Action
0	Cal OK	None
-1	Cal Error	Query the Error Queue (SYST?ERR?). See Error Messages in <i>Appendix B - Error Messages</i>

The C-SCPI type for this returned value is **int16**.

- **Related Commands:** CALibration:SETup, CALibration:SETup?
- Executing this command **does not** alter the module's programmed state (function, range etc.).

NOTE

*If Open Transducer Detect (OTD) is enabled when *CAL? is executed, the module will disable OTD, wait 1 minute to allow channels to settle, perform the calibration, and then re-enable OTD. If your program turns off OTD before executing *CAL?, it should also wait 1 minute for settling.*

***CLS** **Clear Status Command.** The *CLS command clears all status event registers (Standard Event Status Event Register, Standard Operation Status Event Register, Questionable Data Event Register) and the instrument's error queue. This clears the corresponding summary bits (bits 3, 5, & 7) in the Status Byte Register.

*CLS does not affect the enable bits in any of the status register groups. (The SCPI command STATUS:PRESet *does* clear the Operation Status Enable and Questionable Data Enable registers.) *CLS disables the Operation Complete function (*OPC command) and the Operation Complete Query function (*OPC? command).

***ESE <mask>** **Standard Event Status Enable Register Command.** Enables one or more events in the Standard Event Status Register to be reported in bit 5 (the Standard Event Status Summary Bit) of the Status Byte Register. You enable an event by specifying its decimal weight for <mask>. To enable more than one event (bit), specify the sum of the decimal weights. The C-SCPI type for <mask> is **int16**.

Bit #	7	6	5	4	3	2	1	0
Weighted Value	128	64	32	16	8	4	2	1
Event	Power-On	User Request	Command Error	Execution Error	Device Dependent Error	Query Error	Request Control	Operation Complete

***ESE?** **Standard Event Status Enable Query.** Returns the weighted sum of all enabled (unmasked) bits in the Standard Event Status Register. The C-SCPI type for this returned value is **int16**.

***ESR?** **Standard Event Status Register Query.** Returns the weighted sum of all set bits in the Standard Event Status Register. After reading the register, *ESR? clears the register. The events recorded in the Standard Event Status Register are independent of whether or not those events are enabled with the *ESE command to set the Standard Event Summary Bit in the Status Byte Register. The Standard Event bits are described in the *ESE command. The C-SCPI type for this returned value is **int16**.

***IDN?** **Identity.** Returns the device identity. The response consists of the following four fields (fields are separated by commas):

- Manufacturer
- Model Number
- Serial Number (returns 0 if not available)
- Firmware Revision (returns 0 if not available)

The *IDN? command returns the following command string for the HPE1413:

HEWLETT-PACKARD,E1413,<serial number>,<revision number>
The C-SCPI type for this returned value is string.

NOTE

The revision will vary with the revision of the firmware installed in the instrument. This is the only indication of which version of the firmware is installed.

***OPC**

Operation Complete. Causes an instrument to set bit 0 (Operation Complete Message) in the Standard Event Status Register when all pending operations have been completed. By enabling this bit to be reflected in the Status Byte Register (*ESE 1 command), you can ensure synchronization between the instrument and an external computer or between multiple instruments.

NOTE

*Do not use *OPC to determine when the CAL:SETUP or CAL:TARE commands have completed. Instead, use their query forms CAL:SETUP? or CAL:TARE?*

***OPC?**

Operation Complete Query. Causes an instrument to place a 1 into the instrument's output queue when all pending instrument operations are finished. By requiring your computer to read this response before continuing program execution, you can ensure synchronization between one or more instruments and the computer. The C-SCPI type for this returned value is int16.

NOTE

*Do not use *OPC? to determine when the CAL:SETUP or CAL:TARE commands have completed. Instead, use their query forms CAL:SETUP? or CAL:TARE?*

***RST** **Reset Command.** Resets the HPE1413 as follows:

- Sets all four scan lists to their default states:
 - Scan List 1 = ROUT:SEQ:DEF (@100:163)
 - Scan List 2 through 4 are zero length (*undefined*)
 - SENSE:FUNC:VOLT AUTO,(@100:163)
(all channels DCV, autorange)
- Sets the trigger system as follows:
 - TRIGGER:SOURCE HOLD
 - TRIGGER:TIMER 1E-4
 - TRIGGER:COUNT 1
 - ARM:SOURCE IMMEDIATE
- SAMPLE:TIMER 10E-6
- Aborts all pending operations, returns to Trigger Idle state
- Disables the *OPC and *OPC? modes
- MEMORY:VME:ADDRESS 240000;
MEMORY:VME:STATE OFF; MEMORY:VME:SIZE 0

*RST does not affect:

- Calibration data
- The output queue
- The Service Request Enable (SRE) register
- The Event Status Enable (ESE) register

***SRE <mask>**

Service Request Enable. When a service request event occurs, it sets a corresponding bit in the Status Byte Register (this happens whether or not the event has been enabled (unmasked) by *SRE). The *SRE command allows you to identify which of these events will assert an HP-IB service request (SRQ).

When an event is enabled by *SRE and that event occurs, it sets a bit in the Status Byte Register and issues an SRQ to the computer (sets the HP-IB SRQ line true). You enable an event by specifying its decimal weight for <mask>. To enable more than one event, specify the sum of the decimal weights. The C-SCPI type for <mask> is int16.

Bit #	7	6	5	4	3	2	1	0
Weighted Value	128	64	32	16	8	4	2	1
Event	Operation Status	Request Service	Standard Event	Message Available	Questionable Status	not used	not used	not used

- *SRE?** **Status Register Enable Query.** Returns the weighted sum of all enabled (unmasked) events (those enabled to assert SRQ) in the Status Byte Register. The C-SCPI type for this returned value is **int16**.
- *STB?** **Status Byte Register Query.** Returns the weighted sum of all set bits in the Status Byte Register. Refer to the ***ESE** command earlier in this chapter for a table showing the contents of the Status Byte Register. ***STB?** does not clear bit 6 (Service Request). The Message Available bit (bit 4) may be cleared as a result of reading the response to ***STB?**. The C-SCPI type for this returned value is **int16**.
- *TRG** **Trigger.** Triggers an instrument when the trigger source is set to bus (TRIG:SOUR BUS command) and the instrument is in the Wait for Trigger state.
- *TST?** **Self-Test.** Causes an instrument to execute extensive internal self-tests and returns a response showing the results of the self-test.

NOTE

*During the first 5 minutes after power is applied, *TST? may fail. Allow the module to warm-up before executing *TST?*

Comments

- **Returned Value:**

The C-SCPI type for this returned value is **int16**.

- Following ***TST?**, the module is placed in the ***RST** state.
- ***TST?** performs the following tests on the HP E1413 and installed Signal Conditioning Plug-ons (SCPs):

DIGITAL TESTS:

Test#	Description
1-3:	Writes and reads patterns to registers via A16 & A24
4-5:	Checks FIFO and CVT
6:	Checks measurement complete (Measuring) status bit
7:	Checks operation of FIFO half and FIFO full IRQ generation
8-9:	Checks trigger operation

ANALOG FRONT END DIGITAL TESTS:

Test#	Description
20:	Checks that SCP ID makes sense
30-32:	Checks relay driver and fet mux interface with EU CPU
33,71:	Checks opening of all relays on power down or input overvoltage
34-37:	Check fet mux interface with A/D digital

ANALOG TESTS:

Test#	Description
40-42:	Checks internal voltage reference
43-44:	Checks zero of A/D, internal cal source and relay drives
45-46:	Checks fine offset calibration DAC
47-48:	Checks coarse offset calibration DAC
49:	Checks internal + and -15V supplies
50-53:	Checks internal calibration source
54-55:	Checks gain calibration DAC
56-57:	Checks that autorange works
58-58:	Checks internal current source
60-63:	Checks front end and A/D noise and A/D filter
64:	Checks zeroing of coarse and fine offset calibration DACs
65-70:	Checks current source and CAL BUS relay and relay drives and OHM relay drive
71:	See 33
72-73:	Checks continuity through SCPs, bank relays and relay drivers
74:	Checks open transducer detect
75:	Checks current leakage of the SCPs
76:	Checks voltage offset of the SCPs

***WAI** **Wait-to-Continue.** Prevents an instrument from executing another command until the operation begun by the previous command is finished (sequential operation).

NOTE

*Do not use *WAI to determine when the CAL:SETUP or CAL:TARE commands have completed. Instead, use their query forms CAL:SETUP? or CAL:TARE?. CAL:SETUP? and CAL:TARE? return a value only after the CAL:SETUP or CAL:TARE operations are complete.*

HEADQUARTERS OFFICES

If there is no sales office listed for your area, contact one of these headquarters offices.

NORTH/CENTRAL AFRICA

Hewlett-Packard S.A.
7, rue du Bois-du-Lan
CH-1217 MEYRIN 1, Switzerland
Tel: (022) 83 12 12
Telex: 27835 hmea
Cable: HEWPACKSA Geneva

ASIA

Hewlett-Packard Asia Ltd.
47/F, 26 Harbour Rd.,
Wanchai, HONG KONG
G.P.O. Box 863, Hong Kong
Tel: 5-8330833
Telex: 76793 HPA HX
Cable: HPASIAL TD

EASTERN EUROPE

Hewlett-Packard Ges.m.b.h.
Liebigasse 1
P.O.Box 72
A-1222 VIENNA, Austria
Tel: (222) 2500-0
Telex: 13 4425 HEPA A

NORTHERN EUROPE

Hewlett-Packard S.A.
V. D. Hooplaan 241
P.O.Box 999
NL-1183 AG AMSTELVEEN
The Netherlands
Tel: 20 547999
Telex: 18 919 hpner

SOUTH EAST EUROPE

Hewlett-Packard S.A.
World Trade Center
110 Avenue Louis Casai
1215 Cointin, GENEVA, Switzerland
Tel: (022) 98 96 51
Telex: 27225 hpser

EASTERN USA

Hewlett-Packard Co.
4 Choke Cherry Road
ROCKVILLE, MD 20850
Tel: (301) 948-6370

MIDWESTERN USA

Hewlett-Packard Co.
5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800

SOUTHERN USA

Hewlett-Packard Co.
2000 South Park Place
ATLANTA, GA 30339
Tel: (404) 955-1500

WESTERN USA

Hewlett-Packard Co.
5161 Lankershim Blvd.
NORTH HOLLYWOOD, CA 91601
Tel: (818) 505-5600

MEDITERRANEAN AND MIDDLE EAST

Hewlett-Packard S.A.
Mediterranean and Middle East
Operations
Atrina Centre
32 Kifissias Ave.
Paradissos-Amarousion, ATHENS
Greece
Tel: 682 88 11
Telex: 21-6588 HPAT GR
Cable: HEWPACKSA Athens

OTHER INTERNATIONAL AREAS

Hewlett-Packard Co.
Intercontinental Headquarters
3495 Deer Creek Road
PALO ALTO, CA 94304
Tel: (415) 857-1501
Telex: 034-8300
Cable: HEWPACK

ARGENTINA

Hewlett-Packard Argentina S.A.
Montaneses 2140/50
1428 BUENOS AIRES
Tel: 781-4059/69
Cable: HEWPACKARG

AUSTRALIA

Hewlett-Packard Australia Ltd.
31-41 Joseph Street
P.O. Box 221
BLACKBURN, Victoria 3130
Tel: 895-2895
Telex: 31-024
Cable: HEWPARD Melbourne

Hewlett-Packard Australia Ltd.
17-23 Talavera Road
P.O. Box 308
NORTH RYDE, N.S.W. 2113
Tel: 888-4444
Telex: 21561
Cable: HEWPARD Sydney

AUSTRIA

Hewlett-Packard Ges.m.b.h.
Liebigasse 1
P.O. Box 72
A-1222 VIENNA
Tel: (222) 2500-0
Telex: 134425 HEPA A

BELGIUM

Hewlett-Packard Belgium S.A./N.V.
Blvd de la Woluwe, 100
Woluwedel
B-1200 BRUSSELS
Tel: (02) 762-32-00
Telex: 23-494 paloben bru

BRAZIL

Hewlett-Packard do Brasil
I.e.C. Ltda.
Alameda Rio Negro, 750
ALPHAVILLE
06400 Barueri SP
Tel: (011) 421.1311
Telex: (011) 33872 HPBR-BR
Cable: HEWPACK Sao Paulo

Hewlett-Packard do Brasil
I.e.C. Ltda.
Praia de Botafogo 228
6° Andar-conj 614
Edificio Argentina - Ala A
22250 RIO DE JANEIRO, RJ
Tel: (021) 552-6422
Telex: 21905 HPBR-BR
Cable: HEWPACK Rio de Janeiro

CANADA

Hewlett-Packard (Canada) Ltd.
11120-178th Street
EDMONTON, Alberta T5S 1P2
Tel: (403) 486-6666

Hewlett-Packard (Canada) Ltd.
17500 Trans Canada Highway
South Service Road
KIRKLAND, Quebec H9J 2X8
Tel: (514) 697-4232
Telex: 058-21521

Hewlett-Packard (Canada) Ltd.
6877 Goreway Drive
MISSISSAUGA, Ontario L4V 1M8
Tel: (416) 678-9430
Telex: 069-8644

Hewlett-Packard (Canada) Ltd.
2670 Queensview Dr.
OTTAWA, Ontario K2B 8K1
Tel: (613) 820-6483

CHINA, People's Republic of

China Hewlett-Packard Co., Ltd.
P.O. Box 9610, Beijing
4th Floor, 2nd Watch Factory Main
Bldg.
Shuang Yu Shou, Bei San Huan Road
Hai Dian District
BEIJING
Tel: 28-0567
Telex: 22601 CTSHP CN
Cable: 1920 Beijing

DENMARK

Hewlett-Packard A/S
Kongevejen 25
DK-3460 BIRKERØD
Tel: (02) 81-66-40
Telex: 37409 hpas dk

FINLAND

Hewlett-Packard Oy
Piispankalliontie 17
02200 ESPOO
Tel: 00358-0-88721
Telex: 121563 HEWPA SF

FRANCE

Hewlett-Packard France
Chemin des Mouilles
Boite Postale 162
69131 ECULLY Cedex (Lyon)
Tel: (78) 133-81-25
Telex: 310617F

Hewlett-Packard France
Parc d'activités du Bois Briard
Avenue du Lac
91040 EVRY Cedex
Tel: (60) 77-83-83
Telex: 692315F

Hewlett-Packard France
Zone Industrielle de Courtaboeuf
Avenue des Tropiques
91947 LES ULIS Cedex (Orsay)
Tel: (69) 07-78-25
Telex: 600048F

GERMAN FEDERAL REPUBLIC

Hewlett-Packard GmbH
Vertriebszentrum Mitte
Hewlett-Packard-Strasse
D-6380 BAD HOMBURG
Tel: (06172) 16-0
Fax: (06172) 16-1309

Hewlett-Packard GmbH
Vertriebszentrum Südwest
Schickardstrasse 2
D-7030 BOBLINGEN
Tel: (07031) 14-0
Fax: (07031) 14-6429

Hewlett-Packard GmbH
Vertriebszentrum Süd
Eschenstrasse 5
D-8028 TAUFKIRCHEN
Tel: (089) 61207-0
Fax: (089) 61207-300

GREECE

Hewlett-Packard A.E.
178, Kifissias Avenue
6th Floor
Halandri-ATHENS
Greece
Tel: 6471543, 6471673, 6472971
Telex: 221 286 HPHLGR

HONG KONG

Hewlett-Packard Hong Kong, Ltd.
G.P.O. Box 795
5th Floor, Sun Hung Kai Centre
30 Harbour Road
HONG KONG
Tel: 5-8323211
Telex: 66678 HEWPA HX
Cable: HEWPACK HONG KONG

ICELAND

Hewlett-Packard Iceland
Hoefdabakka 9
110 REYKJAVIK
Tel: (1) 67 1000

INDIA

Blue Star Ltd.
13 Community Center
New Friends Colony
NEW DELHI 110 065
Tel: 633182, 636674
Telex: 031-61120
Cable: BLUEFROST

INDONESIA

BERCA Indonesia P.T.
P.O.Box 2497/Jkt
Antara Bldg., 11th Floor
Jl. Medan Merdeka Selatan 17
JAKARTA-PUSAT
Tel: 343989
Telex: 46748 BERSAL IA

IRELAND

Hewlett-Packard Ireland Ltd.
82/83 Lower Leeson Street
DUBLIN 2
Tel: 0001 608800
Telex: 30439

ISRAEL

Computation and Measurement
Systems (CMS) Ltd.
11 Masad Street
67060
TEL-AVIV
Tel: 388 388
Telex: 33569 Motil IL

ITALY

Hewlett-Packard Italiana S.p.A.
Via G. di Vittorio 9
I-20063 CERNUSCO SUL
NAVIGLIO
(Milano)
Tel: (02) 923691
Telex: 334632

Hewlett-Packard Italiana S.p.A.
Viale C. Pavese 340
I-00144 ROMA EUR
Tel: (06) 54831
Telex: 610514

JAPAN

Yokogawa-Hewlett-Packard Ltd.
Chuo Bldg.,
4-20 Nishinakajima, 5 Chome
Yodogawa-ku
OSAKA, 532
Tel: (06) 304-6021
Telex: YHPOSA 523-3624

Yokogawa-Hewlett-Packard Ltd.
29-21 Takaido-Higashi, 3 Chome
Suginami-ku TOKYO 168
Tel: (03) 331-6111
Telex: 232-2024 YHPTOK

Yokogawa-Hewlett-Packard Ltd.
Yasuda Seimei Nishiguchi Bldg.
30-4 Tsuruya-cho, 3 Chome
Kanagawa-ku, YOKOHAMA 221
Tel: (045) 312-1252

SALES & SUPPORT OFFICES

Arranged alphabetically by country

KOREA

Samsung Hewlett-Packard Co. Ltd.
Dongbang Yeeouido Building
12-16th Floors
36-1 Yeeouido-Dong
Youngdeungpo-Ku
SEOUL
Tel: 784-4666, 784-2666
Telex: 25166 SAMSAN K

MALAYSIA

Hewlett-Packard Sales (Malaysia)
Sdn. Bhd.
9th Floor
Chung Khia Bank Building
46, Jalan Raja Laut
50350 KUALA LUMPUR
Tel: 2986555
Telex: 31011 HPSM MA

MEXICO

Hewlett-Packard de Mexico,
S.A. de C.V.
Monte Pelvoux No. 111
Lomas de Chapultepec
11000 MEXICO, D.F.
Tel: 5-40-62-28, 72-66, 50-25
Telex: 17-74-507 HEWPACK MEX

NETHERLANDS

Hewlett-Packard Nederland B.V.
Startbaan 16
NL-1187 XR AMSTELVEEN
P.O. Box 667
NL-1180 AR AMSTELVEEN
Tel: (020) 547-6911
Telex: 13 216 HEPAN NL

NORWAY

Hewlett-Packard Norge A/S
Osterdalen 16-18
P.O. Box 34
N-1345 OESTERAAS
Tel: 0047/2/24 60 90
Telex: 76621 hpnas n

PUERTO RICO

Hewlett-Packard Puerto Rico
101 Muñoz Rivera Av
Esu. Calle Ochoa
HATO REY, Puerto Rico 00918
Tel: (809) 754-7800

SAUDI ARABIA

Modern Electronics Establishment
Hewlett-Packard Division
P.O. Box 1228
Redec Plaza, 6th Floor
JEDDAH
Tel: 644 96 28
Telex: 4027 12 FARNAS SJ
Cable: ELECTA JEDDAH

SINGAPORE

Hewlett-Packard Singapore (Sales)
Pte. Ltd.
#08-00 Inchcape House
450-2 Alexandra Road
Alexandra P.O. Box 58
SINGAPORE, 9115
Tel: 4731788
Telex: 34209 HPSGSO RS
Cable: HEWPACK, Singapore

SOUTH AFRICA

Hewlett-Packard So Africa (Pty.) Ltd.
9 Eastern Service Road
Eastgate Ext. 3
SANDTON 2144
Tel: 802-5111, 802-5125
Telex: 4-20877 SA
Cable: HEWPACK Johannesburg

SPAIN

Hewlett-Packard Española, S.A.
Crt. de la Coruña, Km. 16, 400
Las Rozas
E-MADRID
Tel: (1) 637.00.11
Telex: 23515 HPE

SWEDEN

Hewlett-Packard Sverige AB
Skalholtsgatan 9, Kista
Box 19
S-16393 SPÅNGA
Tel: (08) 750-2000
Telex: (854) 17886
Telefax: (08) 7527781

SWITZERLAND

Hewlett-Packard (Schweiz) AG
7, rue du Bois-du-Lan
Case postale 365
CH-1217 MEYRIN 1
Tel: (0041) 22-83-11-11
Telex: 27333 HPAG CH

TAIWAN

Hewlett-Packard Taiwan Ltd.
8th Floor, Hewlett-Packard Building
337 Fu Hsing North Road
TAIPEI
Tel: (02) 712-0404
Telex: 24439 HEWPACK
Cable: HEWPACK Taipei

TURKEY

Teknim Company Ltd.
Iran Caddesi No. 7
Karakiidere

ANKARA

Tel: 275800
Telex: 42155 TKNM TR

UNITED KINGDOM

ENGLAND

Hewlett-Packard Ltd.
Heathside Park Road
Cheadle Heath
STOCKPORT
Cheshire
SK3 0RB
Tel: 061-428-0828
Telex: 668068

Hewlett-Packard Ltd.
King Street Lane
Winnersh, WOKINGHAM
Berkshire RG11 5AR
Tel: 0734 784774
Telex: 847178

SCOTLAND

Hewlett-Packard Ltd.
SOUTH QUEENSFERRY
West Lothian, EH30 9TG
Tel: 031 331 1188
Telex: 72682

UNITED STATES

Alabama

Hewlett-Packard Co.
420 Wynn Drive
HUNTSVILLE, AL 35805
Tel: (205) 830-2000

Arizona

Hewlett-Packard Co.
8080 Pointe Parkway West
PHOENIX, AZ 85044
Tel: (602) 273-8000

California

Hewlett-Packard Co.
1421 S. Manhattan Av.
FULLERTON, CA 92631
Tel: (714) 999-6700

Hewlett-Packard Co.
5651 West Manchester Ave.
LOS ANGELES, CA 90045
Tel: (213) 337-8000
Telex: 910-325-6608

Hewlett-Packard Co.
9606 Aero Drive
SAN DIEGO, CA 92123
Tel: (619) 279-3200

Hewlett-Packard Co.
3003 Scott Boulevard
SANTA CLARA, CA 95054
Tel: (408) 988-7000
Telex: 910-338-0586

Colorado

Hewlett-Packard Co.
24 Inverness Place, East
ENGLEWOOD, CO 80112
Tel: (303) 649-5000

Connecticut

Hewlett-Packard Co.
47 Barnes Industrial Road South
WALLINGFORD, CT 06492
Tel: (203) 265-7801

Florida

Hewlett-Packard Co.
2901 N.W. 62nd Street
FORT LAUDERDALE, FL 33309
Tel: (305) 973-2600

Hewlett-Packard Co.
6177 Lake Ellenor Drive
ORLANDO, FL 32809
Tel: (305) 859-2900

Georgia

Hewlett-Packard Co.
2000 South Park Place
ATLANTA, GA 30339
Tel: (404) 955-1500
Telex: 810-766-4890

Illinois

Hewlett-Packard Co.
5201 Tollview Drive
ROLLING MEADOWS, IL 60008
Tel: (312) 255-9800
Telex: 910-687-1066

Indiana

Hewlett-Packard Co.
11911 N. Meridian St.
CARMEL, IN 46032
Tel: (317) 844-4100

Louisiana

Hewlett-Packard Co.
160 James Drive East
ST. ROSE, LA 70087
P.O. Box 1449
KENNER, LA 70063
Tel: (504) 467-4100

Maryland

Hewlett-Packard Co.
3701 Koppers Street
BALTIMORE, MD 21227
Tel: (301) 644-5800
Telex: 710-862-1943

Hewlett-Packard Co.
2 Choke Cherry Road
ROCKVILLE, MD 20850
Tel: (301) 948-6370

Massachusetts

Hewlett-Packard Co.
1775 Minuteman Road
ANDOVER, MA 01810
Tel: (617) 682-1500

Michigan

Hewlett-Packard Co.
39550 Orchard Hill Place Drive
NOVI, MI 48050
Tel: (313) 349-9200

Minnesota

Hewlett-Packard Co.
2025 W. Larpenteur Ave.
ST. PAUL, MN 55113
Tel: (612) 644-1100

Missouri

Hewlett-Packard Co.
1001 E. 101st Terrace Suite 120
KANSAS CITY, MO 64131-3368
Tel: (816) 941-0411

Hewlett-Packard Co.
13001 Hollenberg Drive
BRIDGETON, MO 63044
Tel: (314) 344-5100

New Jersey

Hewlett-Packard Co.
120 W. Century Road
PARAMUS, NJ 07653
Tel: (201) 265-5000

New Mexico

Hewlett-Packard Co.
7801 Jefferson N.E.
ALBUQUERQUE, NM 87109
Tel: (505) 823-6100

New York

Hewlett-Packard Co.
9600 Main Street
CLARENCE, NY 14031
Tel: (716) 759-8621

Hewlett-Packard Co.
7641 Henry Clay Blvd.
LIVERPOOL, NY 13088
Tel: (315) 451-1820

Hewlett-Packard Co.
3 Crossways Park West
WOODBURY, NY 11797
Tel: (516) 682-7800

North Carolina

Hewlett-Packard Co.
5605 Roanne Way
GREENSBORO, NC 27420
Tel: (919) 852-1800

Ohio

Hewlett-Packard Co.
15885 Sprague Road
CLEVELAND, OH 44136
Tel: (216) 243-7300

Hewlett-Packard Co.
9080 Springboro Pike
MIAMISBURG, OH 45342
Tel: (513) 433-2223

Hewlett-Packard Co.
675 Brooksedge Blvd.
WESTERVILLE, OH 43081
Tel: (614) 891-3344

Oklahoma

Hewlett-Packard Co.
3525 N.W. 56th St.
Suite C-100
OKLAHOMA CITY, OK 73112
Tel: (405) 946-9499

Oregon

Hewlett-Packard Co.
9255 S. W. Pioneer Court
WILSONVILLE, OR 97070
Tel: (503) 682-8000

Pennsylvania

Hewlett-Packard Co.
111 Zeta Drive
PITTSBURGH, PA 15238
Tel: (412) 782-0400

Hewlett-Packard Co.
2750 Monroe Boulevard
VALLEY FORGE, PA 19482
Tel: (215) 666-9000

Texas

Hewlett-Packard Co.
1826-P Kramer Lane
AUSTIN, TX 78758
Tel: (512) 835-6771

Hewlett-Packard Co.
10535 Harwin Drive
HOUSTON, TX 77036
Tel: (713) 776-6400

Hewlett-Packard Co.
930 E. Campbell Rd.
RICHARDSON, TX 75081
Tel: (214) 231-6101

Hewlett-Packard Co.
1020 Central Parkway South
SAN ANTONIO, TX 78232
Tel: (512) 494-9336

Utah

Hewlett-Packard Co.
3530 W. 2100 South St.
SALT LAKE CITY, UT 84119
Tel: (801) 974-1700

Virginia

Hewlett-Packard Co.
4305 Cox Road
GLEN ALLEN, VA 23060
Tel: (804) 747-7750

Washington

Hewlett-Packard Co.
15815 S.E. 37th Street
BELLEVUE, WA 98006
Tel: (206) 643-4000

Wisconsin

Hewlett-Packard Co.
275 N. Corporate Dr.
BROOKFIELD, WI 53005
Tel: (414) 794-8800

VENEZUELA

Hewlett-Packard de Venezuela C.A.
3A Transversal Los Ruices Norte
Edificio Segre 2 & 3
Apartado 50933
CARACAS 1050
Tel: (582) 239-4133
Telex: 251046 HEWPACK

YUGOSLAVIA

Do Hermes
General Zdanova 4
YU-11000 BEOGRAD
Tel: (011) 342 641
Telex: 11433