



***F u G Elektronik GmbH
Rosenheim - Germany***

Technische Unterlagen / Technical Manual

**F u G Elektronik GmbH
Florianstr. 2
D - 83024 Rosenheim**

GERMANY

Tel. :
+49 (0) 8031 2851-0

Fax:
+49 (0) 8031 81099

email:
info@fug-elektronik.de

Internet:
www.fug-elektronik.de

ISO 9001 : 2000

Typ /Type

HCE 7 - 125 NEG

Fabrik-Nr. / Serial No.

14803-01-01

2007/03

High Voltage Power Supplies HCE - Series

power class 7W and 35W

certified according to
DIN EN ISO 9001

Operating Instructions

This instruction is only dedicated to electrical experts and people with a suitable technical education, which are familiar with electrical risks and can keep the risk for themselves and other people as low as possible.

For the operation of this unit only a.m. persons are admitted.

1. Sicherheitshinweise



Diese Betriebsanleitung richtet sich ausschließlich an Elektrofachkräfte und Personen mit einer geeigneten technischen Ausbildung, die sich der Gefahren bewußt sind und die Gefährdung für sich und andere möglichst gering halten können. Für die Bedienung des Netzgerätes sind nur o.g. Personen zugelassen.

Die Netzgeräte liefern je nach Typ sehr hohe Spannungen und / oder sehr hohe Leistungen! Überzeugen Sie sich vor Inbetriebnahme davon, daß nichts und niemand durch diese Spannung gefährdet wird!

Vor Inbetriebnahme

Lesen Sie unbedingt die ganze Betriebsanleitung! Beachten Sie alle darin enthaltenen Hinweise und Warnungen. Das Nichtbefolgen dieser Betriebsanleitung verletzt die Sicherheitsbestimmungen beim Betrieb der Geräte. Für Folgen, die aus der Nichtbeachtung der Sicherheitshinweise entstehen, kann FuG keine Haftung übernehmen.

Netzspannung

Überprüfen Sie, ob die auf dem Typenschild angegebene Netzspannung und Frequenz mit Ihrer örtlichen Netzspannung übereinstimmt.

Ausgang

Die Ausgangsanschlüsse sind abhängig von Spannung und Leistung steckbar oder klemmbar. Hohe Leistungen sind nur klemmbar. Sorgen Sie für spannungs- und leistungsgerechte Verbindungen. Für Hochspannung verwenden Sie nur die mitgelieferten Stecker.

Erdung

Das Gerät ist mit einer Schutz Erde ausgestattet (Schutzklasse 1). Zum Schutz gegen die Gefahr elektrischer Schläge muß das Gerät über ein Netzkabel mit Schutzleiter angeschlossen werden. Zum Potentialausgleich mit dem Verbraucher und zur Sternpunktterdung einer Anlage muß der Erdungsbolzen verwendet werden.

Betriebsräume

Die Geräte dürfen nur in sauberen und trockenen Räumen betrieben werden. Stellen Sie sicher, daß durch die Lüftungsschlitze keine Gegenstände oder Flüssigkeiten in das Gehäuse gelangen können. Wegen der Gefahr der Funkenbildung darf das Gerät nicht in der Nähe von brennbaren Gasen und Dämpfen betrieben werden.

Kühlung

Die im Gerät entstehende Verlustwärme wird durch Konvektion bzw. Zwangsbelüftung abgeführt. Es muß ein Luftaustausch mit der Umgebungsluft möglich sein (siehe Abschnitt 2.1.)

Gerät öffnen

Das Gerät darf vom Bedienungspersonal nur geöffnet werden, um interne Schalter umzuschalten, die in der Bedienungsanleitung beschrieben sind (z.B. Adreßschalter IEEE 488-Bus, ist bei manchen Geräten inseitig). Vor dem Öffnen muß das Gerät vom Netz getrennt werden!

ACHTUNG!

Im Gerät befinden sich Kondensatoren, die sich nur langsam entladen (typische Entladezeit 5min) oder sich im Fehlerfall gar nicht entladen. Benutzen Sie nur isoliertes Werkzeug. Wartungs- und Reparaturarbeiten dürfen nur von geschultem Servicepersonal ausgeführt werden.

Symbole



Beachten Sie unbedingt die Betriebsanleitung, bevor Sie Schalter oder Buchsen mit diesem Kennzeichen betätigen bzw. beschalten!



Kennzeichen für Hochspannung führende Ausgänge



Kennzeichen für Gehäusemasse auf Schutzleiterpotential

1. Safety Instructions



This instruction is dedicated only to electrical experts and people with a suitable technical education, are familiar with electrical risks and can keep the risk for themselves and for others as low as possible. Only authorized personnel as mentioned above should be allowed to operate the power supplies.

The power supplies, depending on type, create very high voltages and / or very high power! Convince yourself first, that nothing and nobody can be endangered by this voltage, before operating the unit!

Before operating the unit

Make sure that you have read and understood the operating instruction manual! Ensure that you observe all the hints and warnings contained within it. In not following the operating instructions, you contravene the safety regulations for operating units of this type. FuG accepts no liability for consequences arising from the failure to follow these safety instructions.

Input voltage

Check whether the input voltage and frequency for your power supply noted on the label corresponds with your actual input voltage.

Output

The output terminals depend on the voltage and power with plugs or clamps. Take care for adequate voltage and power connections. For high voltage use only the enclosed connectors.

Ground

The unit is provided with a safety ground (German safety class 1). For protection against electric shocks the unit must be connected to mains via a cable with non-fused earthed conductor. For electrical potential equalization to the load and to the center of the AC-net the earth stud must be used.

Operating environment

The units may only be operated in a clean, dry environment. Ensure that no objects or liquids can get into the case through the ventilation slits. Because of the risk of sparks the unit should not be operated in the vicinity of flammable gases or fumes.

Cooling

The units are air cooled by convection or forced ventilation. Therefore, ensure that an adequate air-flow is available, (pay attention to section 2.1.)

Opening the unit

The unit may be opened by operating personnel only to operate internal switches as described in the operating instructions, (e.g. address switch IEEE 488 interface, which is inside the case in some types). Before opening, ensure that the unit is unplugged from the mains!

ATTENTION!

The unit contains capacitors, which discharge themselves only very slowly (typical discharge time 5 min) or, in worst case, do not discharge at all. For switch over use insulated tools only. Maintenance or repair of this units should only be carried out by trained service personnel who are aware of the inherent dangers of such equipments.

Symbols



Strictly follow the operating instructions before you either change switches, or connect sockets, marked with this symbol!



Symbol for High Voltage outputs



Symbol for chassis earth, potential safety earth.

Content:

- 1. Safety Instructions**
- 2. General**
 - 2.1. Setup Information
 - 2.2. Preparation for Installation
 - 2.3. Description
 - 2.4. Assembly
 - 2.5. Mode of Operation
- 3. Operation**
 - 3.1. Analog Programming
 - 3.2. Maintenance
- 4. Technical Data**
 - 4.1. Calibration
 - 4.2. Certificate of Conformity
- 5. Options**
- 6. Accessories**
 - 6.1. Connectors, Cables
 - 6.2. Mounting Instructions
- 7. Warranty, Repair**
- 8. Special Models**
- 9. Appendix**
 - Circuit Diagrams

1. Safety Instructions

**The units of the series HCE deliver dangerously High Voltages!
Ensure that nothing, and nobody, will be endangered by this High Voltage
before putting the unit into operation!**

Attention !	The full dielectric strength of the high voltage connectors is only realized when fully mated together.
Before putting into operation	Make sure that you have read and understood the operating instruction manual! Ensure that you observe all the hints and warnings contained within it. In not following the operating instructions, you contravene the safety regulations for operating units of this type. FuG accepts no liability for consequences arising from the failure to follow these safety instructions.
Mains voltage	Check whether the input voltage for your power supply, noted on the type label, corresponds to your actual mains voltage.
Earth	The unit is provided with a safety earth (German safety class I). For protection against electric shocks, the unit must be connected to the mains via a suitable 3 or 5-pole cable with a non-fused earth conductor. For electrical potential equalization to the load, and to the center of the AC-supply, the earth stud must be used.
Operating environment	The units may only be operated in a clean, dry environment. Please make sure that no objects or liquids can enter the casing through the ventilating aperture. Because of the risk of sparks, the unit should not be operated in the vicinity of flammable gases or fumes.
Cooling	To ensure a adequate cooling, the ambient temperature should not exceed 40°C . This unit is air cooled by convection. Therefore , please ensure an adequate air-flow is available, and ensure that nothing is placed either above or below the unit which may impede this air-flow. Do not expose the unit directly to solar radiation. If the unit is used as a plug-in component, sufficient air-flow must be provided.
Opening the unit	Before opening, ensure that the unit is disconnected from the mains! The unit may be opened by operating personnel only for the purpose of operating switches as described in the operating instructions.
<u>ATTENTION!</u>	The unit contains capacitors, which discharge only very slowly (typical discharge time 5 min -<50V) or, in worst case, do not discharge at all. For switch over use isolated tools only. Maintenance or repair of this unit should only be carried out by trained service personnel who are aware of the inherent dangers of such equipment.

Symbols		Adhere strictly to the operating instructions before you either change switches, or connect sockets, marked with this symbol!
		Symbol for HIGH VOLTAGE OUTPUTS
		Symbol for chassis earth, potential safety earth.

2. General

High Voltage Output

Polarity

The units of the series HCE (High Voltage Chopper Power Supplies in EURO-size) are high stable DC- power supplies with low ripple.

ATTENTION. The units supply dangerously HIGH VOLTAGE!

The power supplies have a fixed polarity, **positive or negative**.
The wanted polarity can only be fixed in the factory. One pole lies on the HV terminal, the other pole on the "0V" terminal and is inside the unit connected to earth by a wire bridge.

Short-circuit Protection

All units are short-circuit proof. The maximum current can be supplied for all output voltages, even into a short-circuit.

ATTENTION! During short-circuit or flash over, the internal filter-capacitors will be discharged very fast. The output current is only limited by internal safety resistors, and can reach a value 500 x nominal value.

Load Types

The type of load is not critical. All passive bipolar loads can be connected.

Series Connection

Power supplies of the series HCE may be connected in series, even if they have different nominal voltages, but than the center point must be connected to earth.

Parallel Connection

Parallel connection is supported.

Type Number

From the type number you can see both the power class and the maximum output voltage of the unit.

Example: **HCE 35 - 20 000** = Power class 35W / Nominal voltage 20 000V

Modified types with differing electrical or mechanical data are indicated by a "M" within the type number, or are marked with a sticker "**modifiziert**" (e.g. HCE 35**M** - 20 000).
(In this case pay attention to the description in section 8. "Special Models")

Serial Number

The label on the rear of the unit, the technical manual and the circuit diagrams show the serial number.
It has the following content:

Serial.- No.: KKKKK-PP-NN YYYY/MM



Delivery Year / Month
Consecutive number out of this item
Item number
Internal order number

IMPORTANT

Please indicate on all further enquiries for warranty, service or spare parts orders the serial number, as well as the model number, of the unit.

2.1. Setup Information

Operating position	The units may only be operated in horizontal position.
Class of pollution	The units are conceived for the pollution class 2 (normal, not conductive pollution).
EMC	The units are built according to the current standards.
Transport	If the power supply is equipped with lifting appliances or handles, the weight of the unit must be shared to these points.

2.2. Preparation for Installation

Mains Voltage	Check whether the input voltage for your power supply, noted on the type label, corresponds to your actual mains voltage. Use only the enclosed delivered mains cable.
Earth, Safety Conductor	The unit is provided with a safety earth (German safety class I). For protection against electric shocks, the unit must be connected to the mains via a suitable 3 or 5-pole cable with a non-fused earth conductor. For electrical potential equalization to the load, and to the center of the AC-supply, the earth stud must be used.
Fuses	Internal: See type label. External: On mains side next higher size, characteristics <u>delay-action</u> or if automatic cut-out is used, characteristics " <u>G</u> " or " <u>K</u> ".
Load connection	The load has to be connected on the HV terminal of the power supply. The return current may flow back via the screen of the HV-cable or via a separate line to the "0V" terminal. The output current must not flow back via mains earth! The screen of the HV-cable always must be connected to earth. On load side a suitable overvoltage arrestor or earthing) must be provided to ensure, that due to a mistakenly opened 0V back connection on the power supply, the voltage does not exceed the max. permissible earthy potential of the load with respect to earth. (see also "Output Isolation", section 4. Technical Data)

2.3. Description

The power supplies series HCE are 3HU EURO-cassettes, different width 14PU, 21PU or 28PU, depending on type.

19" chassis for 84PU are available as accessories.

All controls and displays are on the front panel.

The AC-Input, the HV-output and the programming terminal are on the rear.

2.4. Assembly

The unit mainly consists of 3 function subunits:

- Mains source and oscillating unit.
- HV-transformer, HV-rectifier with filter, HV-divider and current measuring shunt.
- Control unit with measuring and control amplifier, reference voltage generator, pulse width modulator to trigger the oscillator unit, source for the control unit from the mains transformer and a ± 15 V voltage stabilizer.



2.5. Operating Mode

	The rectified mains voltage feeds the rectangular push-pull oscillator stage. For the regulation, the rectangular voltage is pulse width modulated.
High voltage	This rectangular voltage is transformed by a HV-transformer and, dependent on type or nominal voltage, rectified by a bridge, a multiplier cascade or a Diode splitting configuration.
Filtering	The High Voltage so generated is filtered by a R-C- filter and fed to the output via a protection resistor.
Voltage measurement	A precision HV-divider feeds the measured voltage to the control circuit. For a better performance, a voltage derived from a capacitive divider on the end of the rectifier is added. The divided voltage is normalized by an integrated amplifier to +10V = V_{nominal}.
Voltage control	The normalized voltage forms the actual value for the control amplifier. The measuring socket and the V-monitor are also supplied from this voltage. The voltage control amplifier compares this voltage with the setting voltage (reference voltage divided by the setting potentiometer or an external programming voltage). The difference is amplified and fed, as control signal, to the input of the PWM-circuit, which drives the oscillator unit.
Current measurement	The current in the earthy pole of the HV-rectifier flows through a current measuring resistor. The voltage drop on this resistor is also normalized by an integrated amplifier, (+10V = nominal current).
Current control	The ±15 V source of the control electronics is monitored. Runs it below a minimum value, the input of the integrated PWM device is inhibited.

3. Operation



The unit delivers dangerously High Voltage!

Did you follow the safety instructions in Section 1.

Please notice in particular point 2.2 Load connection.

Mains switch ON/OFF

The mains switch "POWER" is placed on the front panel left side down.
In on condition the switch lights red.

Internal operation

Set the switch for the programming to "INT".

Regulation

Voltage constant or current constant operation possible.
The operating mode is indicated by a LED
The transition occurs automatically.

Voltage Adjustment

Voltage adjustment by screwdriver on a multiturn potentiometer
"ADJUST VOLTAGE" on the front panel

Current Adjustment

Current adjustment by screwdriver on a multiturn potentiometer
"ADJUST CURRENT" on the front panel

Voltage Control

To operate the power supply in voltage constant mode, the current potentiometer must be set to a value higher than the present load current.
The LED MODE VOLTAGE (V-Reg) is on.

Current Limitation

To operate the power supply in current **Limitation** mode, the voltage potentiometer must be set to a value higher than the present output voltage.
The LED MODE CURRENT (C-Limit) is on.

Wrong Adjustment

Not following these instructions the power supply will not deliver output voltage or it jumps into another control mode.

Remarks:

no LED lights up = disturbed operation. Internal fuse defective?
or programming switch set to extern and no enable signal appears
both LEDs on = possible, when one of the voltage or current potentiometers is set to zero.

Monitor Outputs

The monitor outputs, 2mm sockets on the frontpanel, provide the possibility to measure the output voltage and the output current. The monitor voltages 0 - 10 V correspond to 0 - nominal value.

The monitor voltages are always positive, independent of the polarity of the output voltage. The monitor outputs are short circuit proof.

Polarity

The power supply has a fixed polarity. The polarity is indicated by a sticker on the handle. (positive = red ; negative = blue).

ATTENTION!

If the unit is switched off or mains fails eventually existing output figures will **not** be displayed.

! Please pay attention on the discharging time !

3.1. Analog Programming

Extern Operation

Select the operation mode on the programming switch on the front panel.
For external control of the unit by analog programming set the toggle switch ADJUST on the front panel to "EXT".

Programming via Sub-D15 connector on the rear is active.

Analog Programming


On the rear you will find the terminal for the external control of the power supply. Voltage and current can be adjusted by standardized analog signals (0 to 10 V) or by external potentiometers. A special connection allows a combination of internal / external operation.

ATTENTION!

The reference point "0V" (Pins 6 or9) for all external programming voltages is **always connected to the output "0V", independent of the output polarity.**
At an open connection to "0V" - earth, the programming can float up to ± 125 V.
Please note, that the connection cable of the programming and the following equipment must have a dielectric strength of min. 125 V with respect to earth (screen).
A programming connector with 500 V dielectric strength is enclosed.

Cable Screening

The connection lines to the interface terminals must be screened. The screen has to be connected to the earth point of the connector. The mounting studs of the programming sockets lie on earth.









Pin configuration:

Solder side of the plug

1) C-LIMIT	(I-Begr) Status report "Current control"	Regulating active • apx. +15V	.
2) V-REG	(U-Reg) Status report "Voltage control"	Regulating active • apx. +15V	.
3) C-MON	(I-MON) Monitor output current 0.. nominal • 0..+10V. Ri = 10kΩ	(always positive, independent of the output polarity).	.
4) VPS	(UPS) Slider of the potentiometer "voltage adjustment"	(not with "floating analog programming").	.
5) IPS	(IPS) Slider of the potentiometer "current adjustment"	(not with "floating analog programming").	.
6) 0V	(0V-dig) Reference for digital signals		.
7) n.c.			.
8) V-SET	(U-Soll) Rated value for voltage adjustment (Input) 0..+10V • 0..nominal		.
9) 0VR	(0VR) Reference for analog signals		.
10) +10VR	Reference voltage +10V	(against Pin 9 max. 2mA loadable).	.
11) V-MON	(U-Mon) Monitor voltage (Output) 0.. nominal • 0..+10V. Ri = 10kΩ	(always positive, independent of the output polarity)	.
12) UNIT-ON	(Ger.Ein) Power supply ON Bridge to Pin 6 • ON	(Attention! Only Output-Voltage ON/OFF => No mains disconnection!).	.
13) n.c.			.
14) n.c.			.
15) C-SET	(I-Soll) Rated value for current limitation (Input) 0..+10V • 0..nominal		.

Examples for Voltage Programming or Current Programming

An external voltage adjustment implicitly requires the wiring of the current control and vice versa. The ON/OFF (Trigger) command (12-6)must implicitly be connected.



The reference voltage of +10 V or the set values may also be alternatively delivered from other external voltage sources (connect 0V). No LED on: Perhaps ON-command (pin 12-6) not connected.

ATTENTION!

If the unit is switched off or mains fails eventually existing output figures will not be displayed on the monitor terminals.

3.2. Maintenance

HCE series needs no maintenance.

4. Technical Data

All here stated data are valid for voltage and current control in internal operation.

Changes of the technical data with the options analog and digital programming see section 5.1.

AC - Input	230V $\pm 10\%$ 47 - 63 Hz Overvoltage category II according to IEC664. N-connection and PE (non fused earth) always necessary!
EMC Standards	for single phase systems EN 50 081 - 1 EN 50 082 - 1 Length of signal- and control lines $\leq 3\text{m}$
Safety	The units are in accordance with EN 61010 (VDE 0411)
Environment Conditions	Operating room : Only for indoor usage (see section 2.1.) Temperature : 0 °C to 40 °C Air humidity : Max. relative humidity 80% until 31 °C, linear decreasing until 50% relative humidity with 40 °C Atm press : Height until 2000 m over NN Contamination : 2, according to IEC664
Protection Class	IP20
Output Voltage / Current	See handle front panel of the power supply.
Output Polarity	Positive or negative, see indication on the unit.
Output Isolation	The "0V"- terminal in the factory was connected to earth by a bridge, it can be changed to earthy by the customer. For that the wire bridge between "0V" and earth must be removed from the floating power supply. In this mode the "0V" terminal is protected by an overvoltage arrestor (150 V) which must not be stressed $> \pm 125\text{V}$ for a longer time. The return current must flow back in this case via the "0V" terminal.
Setting Range Voltage	with potentiometer ADJUST VOLTAGE appr. 0,1% to 100% from nominal value
Setting Current Limitation	with potentiometer ADJUST CURRENT appr. 0,1% to 100% from nominal value
Reproducibility	$\pm 1 \times 10^{-3}$ from nominal value,
Setting Resolution	With trimming potentiometer on the front panel $\pm 1 \times 10^{-4}$ from nominal value
Residual Ripple	$< 1 \times 10^{-4}_{ss} + 50\text{mV}_{ss}$ from nominal value typ. $5 \times 10^{-5}_{ss}$
Deviation	$< \pm 1 \times 10^{-5}$ from nominal value, for $\pm 10\%$ mains voltage variation $< 2 \times 10^{-4}$ from nominal value, for 0 to 100% load variation $< \pm 1 \times 10^{-4}$ from nominal value, over 8 hours $< \pm 1,5 \times 10^{-4}/K$ from nominal value
Recovery Time	
voltage control	$< 1\text{ms}$ for load variations from 10% to 100% or 100% to 10%
current control	$< 10\text{ms}$ for load variations causing an output voltage variation less than 10% of the nominal voltage.
Discharging Time Constant	at unloaded output 0,5 sec to 5 sec, depending on type
Discharging Time down to $< 50\text{V}$	max. one minute
Display	LEDs for status report MODE VOTAGE for voltage control / MODE CURRENT for current limitation.
ATTENTION!	If the unit is switched off or mains fails eventually existing output figures will <u>not be displayed.</u>
Mechanics	EURO-cassettes, widths: 14PU, 21PU and 28PU Depending on type, changes reserved.

4.1. Calibration

Calibration Certificate

All guaranteed data for our power supplies are tested in the factory and documented in an internal test protocol. Furthermore we offer within the scope of our DIN ISO 9001 certified quality system a calibration in our plant.
The customer receives a calibration certificate. We certify the output data and the compliance with our catalog data.

The blue calibration sticker refers to the next recommended date of calibration.

Subsequent Calibration

Generally we recommend an annual subsequent calibration.

4.2. Certificate of Conformity

CE

The power supplies carry the **CE**-sign. The EU-conformity declaration certifies, that the unit is in accordance with the regulations of the Board of the European Union for the adjustment of laws of the member states about electromagnetic sociability. (89/336/EEC revised according to the relevant issue)
Conformity is proven by compliance with the following standards: EN 50081-1; EN 50082-1 or EN 50081-2; EN 50082-2.

Further more the accordance with the low voltage guide lines (Electrical equipment's for use within defined voltage limits, 73/23/EWG revised by 93/68/EWG) is confirmed by the compliance with EN 61010.

5. Options

For power supplies of the series HCE no options are provided

6. Accessories

19"- chassis for HCE-cassettes, 84PU width.

6.1. Connectors, Cables

Output connectors are on the rear.
At units up to 650 V nominal voltage the outputs are 4mm safety connectors, from 1250 V nominal voltage on the outputs are HV-sockets, mating HV-connectors are included.

Type	Voltage	Connector Type	Mating Cable
HCE 7 .. 35	- 125 .. 650	4mm safety connector	no preferred type
HCE 7 .. 35	- 1250 .. 6500	SHV (R317 005)	RG 58
HCE 7 .. 35	- 12500 .. 20000	F 3415 AG 6,2	LEMO 130 660
HCE 7 .. 35	- 35000	F 3430	RG 11

6.2. Mounting Instructions

see enclosed Mounting Instructions

7. Warranty, Repairs

Your high voltage power supply has been assembled and tested under stringent quality assurance procedures.

We provide a 2 years warranty, commencing with the delivery date stated in the serial number.

This warranty does not cover misuse or attempted repair by untrained personnel.

Enclosed you will find one set of circuit diagrams for service purposes.

In all further enquiries for service or spare parts, please provide both the model and serial number of the unit.

8. Special Models

not applicable for standard units

DEUTSCH	ENGLISCH
Abfallzeit	fall time
Abluft	outgoing air
Abschaltung	switch-off
Abschaltzeit	turn-off time
Abschluß (HV-Steckverbindung)	termination
Achtung	attention
Analog-Programmierung	analog programming
Anpreßkraft	clamping force
Anschluß	line input
Anschlußbuchse (HV-Steckverbindung)	HV socket
Anstiegszeit	rise time
Anzeige	display
Auf / Ab	up / down
Anzeige Spannungsvorwahl	display preselected voltage
Ausgangswiderstand	output resistor
AUS	off
Ausgang	output
Ausgangs isolation	output insulation
Ausgangssteuerung	output control
Ausschaltverlustleistung	turn-off dissipation
Begrenzung	limitation
Bereich	range
Beschreibung	description
Betrieb	operation
Betriebsstundenzähler	elapsed-hour meter
Betriebstemperatur	operating temperature
Breite	width
Buchse	socket
ca.	appr.
Dauergrenzstrom	continuous critical current
Digital-Programmierung	digital programming
dreiphasig	three-phase
Durchlaßspannung	conduction voltage
Durchlaßstrom	forward current
EIN	on
Einschaltstrombegrenzung	starting current limitation
Einschaltverlustleistung	turn-on dissipation
Einschaltzeit	turn-on time
Einstellauflösung	setting resolution
einstellbar	adjustable
Einstellbereich	setting range
Energie	energy
Entladezeit	discharging time
Entladung	discharge
Entwicklung	development
Ersatzwiderstand	equivalent resistance
Fabrik-Nummer	serial number
Feinpöt 99%/1%	fine tune potentiometer 99%/1%
Fernbedienung	remote control
Fertigung	production
flink	fast
Freigabe	release
Frequenz	frequency

DEUTSCH	ENGLISCH
Frontplatte	front panel
Fühler	sense
Fühleranschlüsse	sense terminals
Garantie	warranty
gedrückt	pushed
Gegenstecker	mating connector
Gehäusetemperatur	case temperature
Gerät bereit	stand by
Gesamtverlustleistung	total power dissipation
Gewicht	weight
gezogen	pulled
Grenzlastintegral	load limit integral
Grenzstrom	critical current
Haltestrom	holding current
Hauptschalter	main switch
Hochspannung	high voltage
Hochspannungs-Behälter	HV-container
Hochspannungsstecker	high voltage plug
Höhe	height
HV-AUS	HV-OFF
HV-EIN	HV-ON
HV-Kabel	HV cable
HV-Relais ein	HV relay on
Induktivität	inductance
Interlock	interlock
Interlock HV-Stecker	interlock HV plug
Interlock-Schleife	interlock loop
Interlockschalter	interlock switch
Isolation	insulation
Isolations-Prüfspannung	insulation test voltage
isoliert	insulated
Istwert	actual value
Kassette	cassette
Klemme	clamp
Kondensator	capacitor
Kühlkörpertemperatur	heatsink temperature
Kühlmitteltemperatur	coolant temperature
Kupferschiene	copper bar
Kurz ab (kurzzeitige Abschaltung)	brief interruption
Kurzschluß	short circuit
kurzschlußfest	short-circuit proof
Kurzzeitbetrieb	short-time operation
Lampen-Test	lamp test
Lampenstrom	lamp current
Leistung	power
Leistung ein/aus	power on/off
Leistungsbegrenzung	power limitation
Leistungsregelung	power regulation
Lichtstrom	luminous flux
linear geregelt	linear regulated
Lüfter	fan
Luftmenge	air quantity
Meldung	message
Modifikation	modification
negativ	negative
Nennlast	nominal load

DEUTSCH	ENGLISCH
Netz	line (alternativ: mains , power)
Netzanschluß	mains connection
Netzeingang	mains input (alternativ: AC power input)
Netzgerät	power supply
Netzfilter	line filter
Netzkabel	main cable
Netzspannung i.O.	mains voltage ok.
nicht zündender Steuerstrom	non-trigger current
Niederspannung	low voltage
NOT-AUS	emergency off
offen	open
Periodendauer	period lenght
periodischer Einschaltstrom	repetitive turn-on current
Phasenfehler	phase failure
Pol	terminal
Polarität	polarity
positiv	positive
potentialfreie Programmierung	floating analog programming
Programmiergeschwindigkeit	programming speed
Programmierung	programming
Puls	pulse
Pulsausgang	pulse output
Qualitätsprüfung	quality control
Regelabweichung	deviation
Regelung	regulation
Regelzeit	regulating time
Reset	reset
Rückplatte	rear panel
Rückseite	rear side
rückseitig	on the rear
Rückwärts-Sperrstrom	reverse current
Schaltverlustleistung	switching dissipation
Schirm	screen
Schleusenspannung	threshold voltage
Schlüsselschalter	key switch
Schrank	rack
Segmenttest	display-segment test
Sicherheit	safety
Sicherung	fuse
Simulation	simulation
Sollwert	set value
Spannung	voltage
Spannung ein	voltage on
Spannung erreicht	charge voltage achieved
Spannung i.O.	voltage ok.
Spannungsmessung	voltage measurement
Spannungsmonitor	voltage monitor
Spannungsregelung	voltage control
Speicherzeit	storage time
Sperrschichttemperatur	junction temperature
Spitzensteuerstrom	peak trigger current
Spitzenstrom	forward current
Spule	coil
Stabilität	stability
Stecker	plug
Steueranschluß	input control

Steuerimpulsdauer	trigger pulse duration
Steuerspannung	trigger voltage
Steuerstrom	trigger current
Steuerung	control
Steuerung extern	external control
Steuerung Netzgerät	power supply control
Störung Gerät	unit fault
Stoßstrom-Grenzwert	surge current limit value
Strom	current
Strom-Effektivwert	RMS current
Strombegrenzung	current limitation
Strommessung	current measurement
Strommonitor	current monitor
Stromregelung	current control
Supraleiter	superconductor
Tantal	tantalum
Thyristor	thyristor
Tiefe	depth
Tischgehäuse	table-top case
träg	slow
Transformator	transformer
Transistor	transistor
Treiber	driver
Trigger / kontinuierlich	trigger / continuous
Überlast	overload
Überschwinger	overshoot
Überspannung	overvoltage
Überstrom	overcurrent
Übertemperatur	overtemperature
Überwachung	monitoring
Umschalter	switchover contact
Umgebungstemperatur	ambient temperature
Unterbrechung	interrupt
Unterspannung	undervoltage
Verlustleistung	power dissipation
verriegeln	lock
Vorheizzeit	preheating time
Vorwahl	pre setting
Vorwärts-Sperrstrom	forward leakage current
Wärmetauscher	heat exchanger
Wärmewiderstand	thermal resistance
Wasserkühlung	water cooling
Wassermenge	water quantity
Welligkeit	ripple
Widerstand	resistor
Wiederholbarkeit (Reproduzierbarkeit)	reproducibility
Wiederholfrequenz	repetition frequency
Wirkungsgrad	efficiency
Zeit	time
Zerhacker	chopper
Zündspannung	ignition voltage
Zündstrom	ignition current
Nur spannungslos stecken / umpolen	Plug-in / pole inversion only at voltage-free output



FuG Elektronik GmbH

Nieder- und Hochspannungs-Netzgeräte

EC- Certificate of Conformity

This is to certify that the

DC-Power Supplies

HCE - Series

**in all power and voltage classes
with single-phase mains connection**

from serial no.: 10080-01-01 to 99999-99-99 **YYYY/MM**
YYYY – Year MM – Month

comply with the provisions of the Directive of the European Union on the approximation of the laws of the Member States

-relating to electrical equipment for use within defined voltage limits
(73/23/EEC revised by 93/68/EEC)

-relating to electromagnetic compatibility
(89/336/EEC revised by 91/263/EEC, 92/31/EEC, 93/68/EEC, 93/97/EEC)

Conformity is proven by compliance with the following standards:

EN 61010 - 1
EN 61000 - 6 - 1
EN 61000 - 6 - 3
EN 61000 - 3 - 2

Rosenheim, 11 May 2005

F.u.G. Elektronik GmbH

Sales & QM

ppa. A. Elsasser



Konf E HCE eph.doc

**zertifiziert nach
DIN EN ISO 9001**

F.u.G. Elektronik GmbH
Florianstraße 2
83024 Rosenheim

Telefon: (08031) 28 51-0

Telefax: (08031) 8 10 99


email:
info@fug-elektronik.de

internet:
<http://www.fug-elektronik.de>

Geschäftsführer:
Gerhard Giebichenstein
Wolfgang Fritz

Registergericht:
Traunstein
HRB 8638

VAT-Nr. DE 16 18 91 071



HCE7-125P
600709_01
14803-01_01

