

# TOSHIBA

## Industrial Inverter (For 3-phase induction motors)

### Instruction Manual

# TOSVERT VF-S15

### <Detailed manual>

|                    |              |
|--------------------|--------------|
| 3-phase 240V class | 0.4 to 15kW  |
| 1-phase 240V class | 0.2 to 2.2kW |
| 3-phase 500V class | 0.4 to 15kW  |

#### NOTICE

1. Make sure that this instruction manual is delivered to the end user of the inverter unit.
2. Read this manual before installing or operating the inverter unit, and store it in a safe place for reference.

Contents

Read first

Connection

Operations

Setting  
parametersMain  
parametersOther  
parametersOperation  
with external  
signalMonitoring the  
operation statusMeasures  
to satisfy the  
standardsPeripheral  
devicesTable of  
parameters  
and data

Specifications

Before making  
a service callInspection and  
maintenance

Warranty

Disposal of the  
inverter

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

# I. Safety precautions

**I**

The items described in these instructions and on the inverter itself are very important so that you can use safely the inverter, prevent injury to yourself and other people around you as well as to prevent damage to property in the area. Thoroughly familiarize yourself with the symbols and indications shown below and then continue to read the manual. Make sure that you observe all warnings given.

## Explanation of markings

| Marking                                                                                          | Meaning of marking                                                                                                                      |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Warning</b> | Indicates that errors in operation will lead to death or serious injury.                                                                |
|  <b>Caution</b> | Indicates that errors in operation will lead to injury (*1) to people or that these errors will cause damage to physical property. (*2) |

(\*1) Such things as injury, burns or shock that will not require hospitalization or long periods of outpatient treatment.

(\*2) Physical property damage refers to wide-ranging damage to assets and materials.

## Meanings of symbols

| Marking                                                                           | Meaning of marking                                                                                                                                                                                                                                    |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Indicates prohibition (Don't do it).<br>What is prohibited will be described in or near the symbol in either text or picture form.                                                                                                                    |
|  | Indicates an instruction that must be followed.<br>Detailed instructions are described in illustrations and text in or near the symbol.                                                                                                               |
|  | -Indicates warning.<br>What is warned will be described in or near the symbol in either text or picture form.<br>-Indicates caution.<br>What the caution should be applied to will be described in or near the symbol in either text or picture form. |

## ■ Limits in purpose

This inverter is used for controlling speeds of three-phase induction motors in general industrial use.

Single-phase input model is output by the inverter as three-phase output and cannot drive a single-phase motor.



### Safety precautions

- ▼ This product is intended for general purpose uses in industrial application. It cannot be used applications where may cause big impact on public uses, such as power plant and railway, and equipment which endanger human life or injury, such as nuclear power control, aviation, space flight control, traffic, safety device, amusement, or medical.  
It may be considerable whether to apply, under the special condition or an application where strict quality control may not be required. Please contact your Toshiba distributor.
- ▼ Please use our product in applications where do not cause serious accidents or damages even if product is failure, or please use in environment where safety equipment is applicable or a backup circuit device is provided outside the system.
- ▼ Please do not use our product for any load other than three-phase induction motors in general industrial use. (Use in other than properly applied three-phase induction motors may cause an accident.)  
Single-phase input model is output by the inverter as three-phase output and cannot drive a single-phase motor.

## ■ Handling

| <b>Warning</b>             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Reference section     |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|
| <br>Disassembly prohibited | <ul style="list-style-type: none"> <li>Never disassemble, modify or repair.<br/>This can result in electric shock, fire and injury. Call your Toshiba distributor for repairs.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 2.                    |
| <br>Prohibited             | <ul style="list-style-type: none"> <li>Never remove the terminal block cover when power is on.<br/>The unit contains many high voltage parts and contact with them will result in electric shock.</li> <li>Do not stick your fingers into openings such as cable wiring holes and cooling fan covers.<br/>This can result in electric shock or other injury.</li> <li>Do not place or insert any kind of object (electrical wire cuttings, rods, wires etc.) into the inverter.<br/>This can result in electric shock or fire.</li> <li>Do not allow water or any other fluid to come in contact with the inverter.<br/>This can result in electric shock or fire.</li> </ul>                                                                | 2.1<br>2.<br>2.<br>2. |
| <br>Mandatory action       | <ul style="list-style-type: none"> <li>Turn the power on only after attaching the terminal block cover.<br/>If the power is turned on without the terminal block cover attached, this can result in electric shock or other injury.</li> <li>If the inverter begins to emit smoke or an unusual odor, or unusual sounds, immediately turn the power off.<br/>Continuous use of the inverter in such a state will cause fire. Call your Toshiba distributor for repairs.</li> <li>Always turn the power off if the inverter is not used for long periods of time since there is a possibility of malfunction caused by leaks, dust and other material. If power is left on with the inverter in that state, it can result in fire.</li> </ul> | 2.1<br>3.<br>3.       |

|  Caution               |                                                                                                                                                                                                                                                                                                                                                                                  | Reference section |
|---------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Contact prohibited | <ul style="list-style-type: none"> <li>Do not touch heat radiating fins or discharge resistors. These devices are hot, and you'll get burned if you touch them.</li> </ul>                                                                                                                                                                                                       | 3.                |
| <br>Mandatory action   | <ul style="list-style-type: none"> <li>Use an inverter that conforms to the specifications of power supply and three-phase induction motor being used. If the inverter being used does not conform to those specifications, not only will the three-phase induction motor not rotate correctly, but it can also cause serious accidents through overheating and fire.</li> </ul> | 1.1<br>1.4.1      |

## ■ Transportation & installation

|  Warning             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Reference section                               |
|-------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Do not install or operate the inverter if it is damaged or any component is missing. This can result in electric shock or fire. Call your Toshiba distributor for repairs.</li> <li>Do not place any inflammable objects near the inverter. If an accident occurs in which flame is emitted, this could lead to fire.</li> <li>Do not install in any location where the inverter could come into contact with water or other fluids.<br/><i>This can result in electric shock or fire.</i></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 1.4.4<br><br>1.4.4<br>1.4.4                     |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Operate under the environmental conditions prescribed in the instruction manual. Operations under any other conditions can result in malfunction.</li> <li>Mount the inverter on a metal plate.<br/>The rear panel gets very hot. Do not install in an inflammable object, this can result in fire.</li> <li>Do not operate with the terminal block cover removed. This can result in electric shock. Failure to do so can lead to risk of electric shock and can result in death or serious injury.</li> <li>An emergency stop device must be installed that fits with system specifications (e.g. shut off input power then engage mechanical brake). Operation cannot be stopped immediately by the inverter alone, thus resulting in an accident or injury.</li> <li>All options used must be those specified by Toshiba.<br/>The use of any other option will result in an accident.</li> <li>When using switchgear for the inverter, it must be installed in a cabinet.<br/>Failure to do so can lead to risk of electric shock.</li> </ul> | 1.4.4<br>1.4.4<br>1.4.4<br>1.4.4<br>1.4.4<br>10 |

|  Caution       |                                                                                                                                                                                                                                                                                                                                                                 | Reference section |
|-------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Prohibited | <ul style="list-style-type: none"> <li>When transporting or carrying, do not hold by the front panel covers. The covers will come off and the unit will drop, resulting in injury.</li> <li>Do not install in any area where the unit would be subject to large amounts of vibration. This could cause the unit to fall, resulting in bodily injury.</li> </ul> | 2.<br>1.4.4       |

|  <b>Caution</b>      |                                                                                                                                                                                                                                                         | Reference section |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>When removing and installing the terminal cover with a screwdriver, be sure not to scratch your hand as these results in injury.</li> </ul>                                                                      | 1.3.2             |
|                                                                                                       | <ul style="list-style-type: none"> <li>Pressing too hard on the screwdriver can scratch the inverter.</li> </ul>                                                                                                                                        | 1.3.2             |
|                                                                                                       | <ul style="list-style-type: none"> <li>Always turn the power off when removing the wiring cover.</li> </ul>                                                                                                                                             | 1.3.2             |
|                                                                                                       | <ul style="list-style-type: none"> <li>After wiring is complete, be sure to replace the terminal cover.</li> </ul>                                                                                                                                      | 1.3.2             |
|                                                                                                       | <ul style="list-style-type: none"> <li>The main unit must be installed on a base that can bear the unit's weight.</li> <li>If the unit is installed on a base that cannot withstand that weight, the unit can fall, resulting in injury.</li> </ul>     | 1.4.4             |
|                                                                                                       | <ul style="list-style-type: none"> <li>If braking is necessary (to hold motor shaft), install a mechanical brake.</li> </ul> <p>The brake on the inverter will not function as a mechanical hold, and if used for that purpose, injury will result.</p> | 1.4.4             |

## ■ Wiring

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Reference section |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Do not connect input power to the output (motor side) terminals (U/T1, V/T2, W/T3). Connecting input power to the output could destroy the inverter or cause a fire.</li> </ul>                                                                                                                                                                                                                                                                                                                                        | 2.2               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Do not insert a braking resistor between DC terminals (between PA/+ and PC/- or PO and PC/-). It could cause a fire.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                        | 2.2               |
|                                                                                                       | <ul style="list-style-type: none"> <li>First shut off input power and wait at least 15 minutes before touching terminals and wires on equipment (MCCB) that is connected to inverter power side.</li> </ul>                                                                                                                                                                                                                                                                                                                                                   | 2.2               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Touching the terminals and wires before that time could result in electric shock.</li> <li>Do not shut down the external power supply on ahead when VIA terminal is used as logic input terminal by external power supply.</li> </ul> <p>It could cause unexpected result as VIA terminal is ON status.</p>                                                                                                                                                                                                            | 2.2               |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Electrical construction work must be done by a qualified expert.</li> </ul> <p>Connection of input power by someone who does not have that expert knowledge can result in fire or electric shock.</p>                                                                                                                                                                                                                                                                                                                  | 2.1               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Connect output terminals (motor side) correctly.</li> </ul> <p>If the phase sequence is incorrect, the motor will operate in reverse and that can result in injury.</p>                                                                                                                                                                                                                                                                                                                                                | 2.1               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Wiring must be done after installation.</li> </ul> <p>If wiring is done prior to installation, that can result in injury or electric shock.</p>                                                                                                                                                                                                                                                                                                                                                                        | 2.1               |
|                                                                                                       | <ul style="list-style-type: none"> <li>The following steps must be performed before wiring.</li> </ul> <ol style="list-style-type: none"> <li>Turn off all input power.</li> <li>Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.</li> <li>Use a tester that can measure DC voltage (400VDC or 800VDC or more), and check to make sure that the voltage to the DC main circuits (across PA/+ - PC/-) is 45V or less.</li> </ol> <p>If these steps are not properly performed, the wiring will cause electric shock.</p> | 2.1               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Tighten the screws on the terminal block to specified torque.</li> </ul> <p>If the screws are not tightened to the specified torque, it can lead to fire.</p>                                                                                                                                                                                                                                                                                                                                                          | 2.1               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Check to make sure that the input power voltage is +10%, -15% of the rated power voltage (±10% when the load is 100% in continuous operation) written on the name plate.</li> </ul> <p>If the input power voltage is not +10%, -15% of the rated power voltage (±10% when the load is 100% in continuous operation), this can result in fire.</p>                                                                                                                                                                      | 1.4.4             |
|                                                                                                       | <ul style="list-style-type: none"> <li>Set a parameter <math>F109</math> when VIA or VIB terminals are used as logic input terminal.</li> </ul> <p>If it is not set, it could result in malfunction.</p>                                                                                                                                                                                                                                                                                                                                                      | 2.2               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Set a parameter <math>F147</math> when S3 terminal is used as PTC input terminal.</li> </ul> <p>If it is not set, it could result in malfunction.</p>                                                                                                                                                                                                                                                                                                                                                                  | 2.2               |

|  <b>Warning</b> |                                                                                                                                                                        | Reference section |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Be Grounded | <ul style="list-style-type: none"> <li>Ground must be connected securely. If the ground is not securely connected, it could lead to electric shock or fire.</li> </ul> | 2.1<br>2.2<br>10. |

|  <b>Caution</b> |                                                                                                                                                                                                            | Reference section |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Prohibited  | <ul style="list-style-type: none"> <li>Do not attach devices with built-in capacitors (such as noise filters or surge absorbers) to the output (motor side) terminals. This could cause a fire.</li> </ul> | 2.1               |

## **■ Operations**

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Reference section       |
|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Never touch the internal connector while the upper terminal cover of control panel is opened. There is a risk of electrical shock because it carries a high voltage.</li> <li>Do not touch inverter terminals when electrical power is going to the inverter even if the motor is stopped. Touching the inverter terminals while power is connected to it will result in electric shock.</li> <li>Do not touch switches when the hands are wet and do not try to clean the inverter with a damp cloth. Such practices will result in electric shock.</li> <li>Do not go near the motor in alarm-stop status when the retry function is selected. The motor will suddenly restart and that could result in injury. Take measures for safety, e.g. attaching a cover to the motor, against accidents when the motor unexpectedly restarts.</li> </ul> | 1.3.2<br>3.<br>3.<br>3. |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Turn the input power on only after attaching the terminal block cover. When enclosed inside a cabinet and used with the terminal block cover removed, always close the cabinet doors first and then turn the power on. If the power is turned on with the terminal block cover or cabinet doors open can result in electric shock.</li> <li>Make sure that operation signals are off before resetting the inverter after malfunction. If the inverter is reset before turning off the operating signal, the motor can restart suddenly, resulting in injury.</li> <li>If incorrect setting, the drive will have some damage or unexpected movement. Be sure to set the setup menu correctly.</li> </ul>                                                                                                                                             | 3.<br>3.<br>3.1         |

|  <b>Caution</b>  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Reference section |
|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Prohibited | <ul style="list-style-type: none"> <li>Observe all permissible operating ranges of motors and mechanical equipment. (Refer to the motor's instruction manual.) Not observing these ranges will result in injury.</li> <li>Do not set the stall prevention level (<math>F 60 \ t</math>) extremely low. If the stall prevention level parameter (<math>F 60 \ t</math>) is set at or below the no-load current of the motor, the stall preventive function will be always active and increase the frequency when it judges that regenerative braking is taking place. Do not set the stall prevention level parameter (<math>F 60 \ t</math>) below 30% under normal use conditions.</li> </ul> | 3.<br>6.29.2      |

|  Caution             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Reference section |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Use an inverter that conforms to the specifications of power supply and three-phase induction motor being operated. If the inverter being used does not conform to those specifications, not only will the three-phase induction motor not rotate correctly, but it will cause serious accidents through overheating and fire.</li> </ul>                                                                                                                                                                                                             | 1.4.1             |
|                                                                                                       | <ul style="list-style-type: none"> <li>The leakage current through the input/output power cables of inverter and capacitance of motor can affect to peripheral devices.<br/>The value of leakage current is increased under the condition of the PWM carrier frequency and the length of the input/output power cables. In case the total cable length (total of length between an inverter and motors) is more than 100m, overcurrent trip can occur even the motor no-load current.<br/>Make enough space among each phase cable or install the filter (MSF) as countermeasure.</li> </ul> | 1.4.3             |

## ■ When operation by using remote keypad is selected

|  Warning             |                                                                                                                                                                                                                                                                                                                                                                                  | Reference section |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Set the parameter Communication time-out time (<i>F803</i>), Communication time-out action (<i>F804</i>) and Disconnection detection of extension panel (<i>F731</i>).<br/>If these are not properly set, the inverter can not be stopped immediately in breaking communication and this could result in injury and accidents.</li> </ul> | 6.38.1            |
|                                                                                                       | <ul style="list-style-type: none"> <li>An emergency stop device and the interlock that fit with system specifications must be installed.<br/>If these are not properly installed, the inverter can not be stopped immediately and this could result in injury and accidents.</li> </ul>                                                                                          | 6.38.1            |

## ■ When sequence for restart after a momentary failure is selected (inverter)

|  Caution             |                                                                                                                                                                                                                                                               | Reference section |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Stand clear of motors and mechanical equipment.<br/>If the motor stops due to a momentary power failure, the equipment will start suddenly after power is restored. This could result in unexpected injury.</li> </ul> | 5.9               |
|                                                                                                       | <ul style="list-style-type: none"> <li>Attach caution label about sudden restart after a momentary power failure on inverters, motors and equipment for prevention of accidents in advance.</li> </ul>                                                        | 5.9               |

## ■ When retry function is selected (inverter)

|  Caution              |                                                                                                                                                                                                                                                                                              | Reference section |
|--------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Stand clear of motors and equipment.<br/>If the motor and equipment stop when the alarm is given, selection of the retry function will restart them suddenly after the specified time has elapsed. This could result in unexpected injury.</li> </ul> | 6.19.3            |
|                                                                                                        | <ul style="list-style-type: none"> <li>Attach caution label about sudden restart in retry function on inverters, motors and equipment for prevention of accidents in advance.</li> </ul>                                                                                                     | 6.19.3            |

## ■ Maintenance and inspection

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Reference section  |
|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Do not replace parts. This could be a cause of electric shock, fire and bodily injury. To replace parts, call your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | 14.2               |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>The equipment must be inspected daily. If the equipment is not inspected and maintained, errors and malfunctions can not be discovered and that could result in accidents.</li> <li>Before inspection, perform the following steps.               <ol style="list-style-type: none"> <li>Turn off all input power to the inverter.</li> <li>Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.</li> <li>Use a tester that can measure DC voltages (400V/800V DC or more), and check that the voltage to the DC main circuits (across PA/+ - PC/-) is 45V or less.</li> </ol> </li> </ul> <p>Performing an inspection without carrying out these steps first could lead to electric shock.</p> | 14.<br>14.<br>14.2 |

## ■ Disposal

|  <b>Caution</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Reference section |
|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>If you dispose of the inverter, have it done by a specialist in industry waste disposal (*). If you dispose of the inverter by yourself, this can result in explosion of capacitor or produce noxious gases, resulting in injury.</li> </ul> <p>(*) Persons who specialize in the processing of waste and known as "industrial waste product collectors and transporters" or "industrial waste disposal persons". Please observe any applicable law, regulation, rule or ordinance for industrial waste disposal.</p> | 16.               |

## ■ Attach caution labels

Shown here are examples of caution labels to prevent, in advance, accidents in relation to inverters, motors and other equipment. Be sure to affix the caution label where it is easily visible when selecting the auto-restart function (5.9) or the retry function (6.19.3).

|                                                                                                                                                                                            |                                                   |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| If the inverter has been programmed for restart sequence of momentary power failure, place warning labels in a place where they can be easily seen and read.<br>(Example of caution label) |                                                   |
|                                                                                                           | <b>Caution (Functions programmed for restart)</b> |
| Do not go near motors and equipment.<br>Motors and equipment that have stopped temporarily after momentary power failure will restart suddenly after recovery.                             |                                                   |

|                                                                                                                                                                       |                                                 |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|
| If the retry function has been selected, place warning labels in a location where they can be easily seen and read.<br>(Example of caution label)                     |                                                 |
|                                                                                      | <b>Caution (Functions programmed for retry)</b> |
| Do not go near motors and equipment.<br>Motors and equipment that have stopped temporarily after an alarm will restart suddenly after the specified time has elapsed. |                                                 |

## Contents

|      |                                                                                    |      |
|------|------------------------------------------------------------------------------------|------|
| I    | Safety precautions.....                                                            | 1    |
| 1.   | Read first.....                                                                    | A-1  |
| 1.1  | Check product purchase.....                                                        | A-1  |
| 1.2  | Contents of the product.....                                                       | A-2  |
| 1.3  | Names and functions.....                                                           | A-3  |
| 1.4  | Notes on the application.....                                                      | A-22 |
| 2.   | Connection.....                                                                    | B-1  |
| 2.1  | Cautions on wiring.....                                                            | B-1  |
| 2.2  | Standard connections.....                                                          | B-3  |
| 2.3  | Description of terminals.....                                                      | B-6  |
| 3.   | Operations.....                                                                    | C-1  |
| 3.1  | How to Set the Setup Menu.....                                                     | C-2  |
| 3.2  | Simplified Operation of the VF-S15.....                                            | C-4  |
| 3.3  | How to operate the VF- S15.....                                                    | C-8  |
| 4.   | Setting parameters.....                                                            | D-1  |
| 4.1  | Setting and Display Modes.....                                                     | D-1  |
| 4.2  | How to set parameters.....                                                         | D-3  |
| 4.3  | Functions useful in searching for a parameter or changing a parameter setting..... | D-7  |
| 4.4  | Checking the region settings selection.....                                        | D-13 |
| 4.5  | EASY key function.....                                                             | D-14 |
| 5.   | Main parameters.....                                                               | E-1  |
| 5.1  | Meter setting and adjustment.....                                                  | E-1  |
| 5.2  | Setting acceleration/deceleration time.....                                        | E-4  |
| 5.3  | Maximum frequency.....                                                             | E-5  |
| 5.4  | Upper limit and lower limit frequencies.....                                       | E-6  |
| 5.5  | Base frequency.....                                                                | E-7  |
| 5.6  | Setting the electronic thermal.....                                                | E-8  |
| 5.7  | Preset-speed operation (speeds in 15 steps).....                                   | E-16 |
| 5.8  | Switching between two frequency commands.....                                      | E-19 |
| 5.9  | Auto-restart (Restart of coasting motor).....                                      | E-21 |
| 5.10 | Changing operation panel display.....                                              | E-23 |
| 6.   | Other parameters.....                                                              | F-1  |
| 6.1  | Parameters useful for setting and adjustments.....                                 | F-2  |
| 6.2  | Selection of operation mode.....                                                   | F-12 |
| 6.3  | Selecting control mode.....                                                        | F-17 |

|      |                                                                               |       |
|------|-------------------------------------------------------------------------------|-------|
| 6.4  | Manual torque boost - increasing torque boost at low speeds .....             | F-24  |
| 6.5  | Signal output .....                                                           | F-25  |
| 6.6  | Input signal selection.....                                                   | F-28  |
| 6.7  | Terminal function selection.....                                              | F-31  |
| 6.8  | Basic parameters 2 .....                                                      | F-33  |
| 6.9  | V/f 5-point setting .....                                                     | F-35  |
| 6.10 | Frequency priority selection .....                                            | F-35  |
| 6.11 | Operation frequency.....                                                      | F-44  |
| 6.12 | DC braking .....                                                              | F-46  |
| 6.13 | Stop at lower-limit frequency operation (sleep function).....                 | F-48  |
| 6.14 | Jog run mode .....                                                            | F-49  |
| 6.15 | Jump frequency - avoiding resonant frequencies.....                           | F-51  |
| 6.16 | Bumpless operation .....                                                      | F-52  |
| 6.17 | Low voltage operation .....                                                   | F-54  |
| 6.18 | PWM carrier frequency .....                                                   | F-54  |
| 6.19 | Trip-less intensification.....                                                | F-60  |
| 6.20 | Drooping control.....                                                         | F-73  |
| 6.21 | Light-load high-speed operation function .....                                | F-75  |
| 6.22 | Braking function .....                                                        | F-75  |
| 6.23 | Acceleration/deceleration suspend function (Dwell function) .....             | F-76  |
| 6.24 | PID control .....                                                             | F-78  |
| 6.25 | Setting motor constants.....                                                  | F-85  |
| 6.26 | Torque limit.....                                                             | F-91  |
| 6.27 | Acceleration/deceleration time 2 and 3 .....                                  | F-96  |
| 6.28 | Shock monitoring function .....                                               | F-100 |
| 6.29 | Protection functions.....                                                     | F-101 |
| 6.30 | Forced fire-speed control function.....                                       | F-115 |
| 6.31 | Override .....                                                                | F-116 |
| 6.32 | Analog input terminal function selection.....                                 | F-119 |
| 6.33 | Adjustment parameters .....                                                   | F-120 |
| 6.34 | Operation panel parameter .....                                               | F-124 |
| 6.35 | Tracing functions .....                                                       | F-134 |
| 6.36 | Integrating wattmeter .....                                                   | F-134 |
| 6.37 | Parameter registration to easy setting mode.....                              | F-134 |
| 6.38 | Communication function.....                                                   | F-135 |
| 6.39 | Permanent magnet motors.....                                                  | F-143 |
| 6.40 | Traverse function .....                                                       | F-144 |
| 7.   | Operations with external signal .....                                         | G-1   |
| 7.1  | Operating external signals .....                                              | G-1   |
| 7.2  | Applied operations by an I/O signal (operation from the terminal block) ..... | G-2   |
| 7.3  | Speed instruction (analog signal) settings from external devices.....         | G-12  |

|                                                                         |      |
|-------------------------------------------------------------------------|------|
| 8. Monitoring the operation status .....                                | H-1  |
| 8.1 Flow of status monitor mode .....                                   | H-1  |
| 8.2 Status monitor mode .....                                           | H-2  |
| 8.3 Display of trip information .....                                   | H-6  |
| 9. Measures to satisfy the standards .....                              | I-1  |
| 9.1 How to cope with the CE Marking Directive .....                     | I-1  |
| 9.2 Compliance with UL Standard and CSA Standard .....                  | I-6  |
| 10. Peripheral devices .....                                            | J-1  |
| 10.1 Selection of wiring materials and devices .....                    | J-1  |
| 10.2 Installation of a magnetic contactor .....                         | J-4  |
| 10.3 Installation of an overload relay .....                            | J-5  |
| 10.4 Optional external devices .....                                    | J-6  |
| 11. Table of parameters and data .....                                  | K-1  |
| 11.1 Frequency setting parameter .....                                  | K-1  |
| 11.2 Basic parameters .....                                             | K-1  |
| 11.3 Extended parameters .....                                          | K-5  |
| 11.4 Default settings by inverter rating .....                          | K-28 |
| 11.5 Default settings by setup menu .....                               | K-29 |
| 11.6 Input Terminal Function .....                                      | K-30 |
| 11.7 Output Terminal Function .....                                     | K-34 |
| 11.8 Application easy setting .....                                     | K-38 |
| 11.9 Unchangeable parameters in running .....                           | K-39 |
| 12. Specifications .....                                                | L-1  |
| 12.1 Models and their standard specifications .....                     | L-1  |
| 12.2 Outside dimensions and mass .....                                  | L-4  |
| 13. Before making a service call - Trip information and remedies .....  | M-1  |
| 13.1 Trip/Alarm causes and remedies .....                               | M-1  |
| 13.2 Restoring the inverter from a trip .....                           | M-7  |
| 13.3 If the motor does not run while no trip message is displayed ..... | M-8  |
| 13.4 How to determine the causes of other problems .....                | M-9  |
| 14. Inspection and maintenance .....                                    | N-1  |
| 14.1 Regular inspection .....                                           | N-1  |
| 14.2 Periodical inspection .....                                        | N-2  |
| 14.3 Making a call for servicing .....                                  | N-5  |
| 14.4 Keeping the inverter in storage .....                              | N-5  |

15. Warranty.....O-1

16. Disposal of the inverter .....P-1



### 1.1 Check product purchase

 Caution




Use an inverter that conforms to the specifications of power supply and three-phase induction motor being used. If the inverter being used does not conform to those specifications, not only will the three-phase induction motor not rotate correctly, but it can also cause serious accidents through overheating and fire.

Inverter main unit


### Motor capacity

**VF-S15**  
1PH-200/240V-0.2kW/0.25HP




Name plate

Danger label



Type indication label

## Setup sheet



Danger label



Name plate

**TOSHIBA**  
TRANSISTOR INVERTER

FS15S-2002PL-W

0.2kW-0.6kVA-0.25HP (0)

| INPUT       | OUTPUT      |
|-------------|-------------|
| 1PH 200 240 | 3PH 200 240 |

|       |           |
|-------|-----------|
| 50/60 | 0.1...500 |
|-------|-----------|

CP : fermenting and protection

refer to User Manual

al No. 8118 18021202 0001 (1)


Made in Indonesia

---

\_\_\_\_\_

OSHIBA INDUSTRIAL  
PRODUCTS SALES CO. TSU

## Quick start manual



## CD-ROM

Contains the instruction manual in digital form



## Danger label kit


Danger labels for sticking in 6 languages.



- English
- Germany / English
- Italian / English
- Spanish / English
- Chinese / English
- France / English

## 1.2 Contents of the product

Explanation of the name plate label





Note 1) Always shut power off first then check the ratings label of inverter held in a cabinet.

Note 2) ID label is stuck for special specification product.

This instruction manual is for the "Ver. 102" or "Ver104" CPU version of the inverter.  
 The function in this manual may not be partially realized in the previous CPU version.  
 Please be informed that CPU version will be frequently upgraded.


## 1.3 Names and functions

### 1.3.1 Outside view




Note 1) Remove the protective label as shown on the next page when installing the inverter side by side with other inverters and using the inverter in locations with temperatures above 40°C.

Example of the protective label on the top of the inverter



[Opening the cover]



Insert a small screw driver  
and slide the door lock to  
upside for unlock.  
(Slide it to downside for lock.)

## ★About the monitor display

The LED on the operation panel uses the following symbols to indicate parameters and operations.


### LED display (numbers)

|   |   |   |   |   |   |   |   |   |   |   |
|---|---|---|---|---|---|---|---|---|---|---|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | - |
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | - |

### LED display (letters)

|    |    |   |   |    |    |    |    |    |    |    |    |    |    |    |
|----|----|---|---|----|----|----|----|----|----|----|----|----|----|----|
| Aa | Bb | C | c | Dd | Ee | Ff | Gg | H  | h  | I  | i  | Jj | Kk | Ll |
| A  | b  | C | c | d  | E  | F  | G  | H  | h  | I  | i  | J  | K  | L  |
| Mm | Nn | O | o | Pp | Qq | Rr | Ss | Tt | Uu | Vv | Ww | Xx | Yy | Zz |
| M  | n  | O | o | P  | q  | r  | S  | t  | U  | v  | W  | X  | Y  | Z  |

## [Operation panel]



1

### 1.3.2 Opening terminal cover and terminal block



Prohibited



#### Warning

- Never touch the internal connector while the upper cover of control panel is opened. There is a risk of electrical shock because it carries a high voltage.

Mandatory  
action

#### Caution


- When removing and mounting the terminal cover or the terminal block with a screwdriver, be sure not to scratch your hand as these results in injury.
- Pressing too hard on the screwdriver can scratch the inverter.
- Always turn the power off when removing the wiring cover.
- After wiring is complete, be sure to replace the terminal cover.

Use the following procedure to open the terminal cover and pull the power terminal block.

| Inverter type                                                                         | Procedure                                                  | Reference number |
|---------------------------------------------------------------------------------------|------------------------------------------------------------|------------------|
| VFS15-2004PM-W to 2007PM-W<br>VFS15S-2002PL-W to 2007PL-W                             | In the beginning, remove the outside terminal block cover. | (1)              |
|                                                                                       | Next, remove the inside terminal block cover.              | (2)              |
| VFS15-2015PM-W to 2037PM-W<br>VFS15S-2015PL-W, 2022PL-W<br>VFS15-4004PL-W to 4015PL-W | In the beginning, remove the outside terminal block cover. | (3)              |
|                                                                                       | Next, remove the inside terminal block cover.              | (4)              |
| VFS15-4022PL-W, 4037PL-W                                                              | In the beginning, remove the outside terminal block cover. | (3)              |
|                                                                                       | Next, remove the inside terminal block cover.              | (5)              |
| VFS15-2055PM-W to 2150PM-W<br>VFS15-4055PL-W to 4150PL-W                              | Follow a procedure and remove the power terminal cover.    | (6)              |


(1) Removing the outside terminal block cover (VFS15-2004PM-W to 2007PM-W, VFS15S-2002PL-W to 2007PL-W)

1)




Insert a screwdriver or other thin object into the hole indicated with the □ mark.

2)




Press in on the screwdriver.

3)



While pressing on the screwdriver, rotate the terminal cover downward to remove it.

4)




Pull the terminal cover up at an angle.

- After wiring is complete, be sure to restore the terminal cover to its original position.


(2) Removing the inside terminal block cover (VFS15-2004PM-W to 2007PM-W, VFS15S-2002PL-W to 2007PL-W)

1)




The finger is put on to the tab part of the terminal block cover.

2)



While pressing on the screwdriver, rotate the terminal cover downward to remove it.

3)




Pull the terminal cover up at an angle.

- After wiring is complete, be sure to restore the terminal cover to its original position.


(3) Removing the outside terminal block cover (VFS15-2015PM-W to 2037PM-W, VFS15S-2015PL-W, 2022PL-W, VFS15-4004PL-W to 4037PL-W)

1)




Insert a screwdriver or other thin object into the hole indicated with the ◻ mark.

2)



Press in on the screwdriver.

3)




While pressing on the screwdriver, slides the terminal cover downward to remove it.

- After wiring is complete, be sure to restore the terminal cover to its original position.


- (4) Removing the inside terminal block cover (VFS15-2015PM-W to 2037PM-W, VFS15S-2015PL-W, 2022PL-W, VFS15-4004PL-W to 4015PL-W)

1)




The finger is put on to the tab part of the terminal block cover.

2)



While pressing on the screwdriver, rotate the terminal cover downward to remove it.

3)




Pull the terminal cover up at an angle.

- After wiring is complete, be sure to restore the terminal cover to its original position.


(5) Removing the inside terminal block cover (VFS15-4022PL-W, 4037PL-W)

1)




The finger is put on to the tab part of the terminal block cover.

2)



While pressing on the screwdriver, rotate the terminal cover downward to remove it.

3)




Pull the terminal cover up at an angle.

- After wiring is complete, be sure to restore the terminal cover to its original position.


(6) Removing the power terminal cover (VFS15-2055PM-W to 2150PM-W, VFS15-4055PL-W to 4150PL-W)

1)




Insert a screwdriver or other thin object into the hole indicated with the  mark.

2)



Press in on the screwdriver.

3)



While pressing on the screwdriver, slide the terminal cover downward to remove it.

- After wiring is complete, be sure to restore the terminal cover to its original position.

### 1.3.3 Power circuit and control circuit terminal blocks

#### 1) Power circuit terminal

In case of the lug connector, cover the lug connector with insulated tube, or use the insulated lug connector.

(Recommended Lug connectors and Insulated Tubes)


| Screw Size | Wire Size<br>(mm <sup>2</sup> ) | Manufacturer and Type-Form |                 |
|------------|---------------------------------|----------------------------|-----------------|
|            |                                 | Lug connector              | Insulated Tube  |
|            |                                 | JST                        | SHINAGAWA SHOKO |
| M3.5 screw | 1.5-2.5                         | V2-M3                      |                 |
| M4 screw   | 1.5-2.5                         | V2-4                       |                 |
|            | 3.5-5.5                         | V5.5-4                     |                 |
| M5 screw   | 1.5-2.5                         | V2-5                       |                 |
|            | 3.5-6.0                         | V5.5-5                     |                 |
|            | 8.0-10                          | R8-5                       | TCM-81          |
|            | 14-16                           | R14-5                      | TCM-141         |
| M6 screw   | 1.5-2.5                         | V2-6                       |                 |
|            | 3.5-6.0                         | R5.5-6                     | TCM-53          |
|            | 8.0-10                          | R8-6                       | TCM-81          |
|            | 14-16                           | R14-6                      | TCM-141         |
|            | 22-25                           | R22-6                      | TCM-221         |

Use a plus or minus screwdriver to loose or tighten screws.

| Screw size                    | Tightening torque |            |
|-------------------------------|-------------------|------------|
| M3.5 screw                    | 1.0 N·m           | 8.9 lb·in  |
| M4 screw                      | 1.4 N·m           | 12.4 lb·in |
| M5 screw                      | 2.4 N·m           | 20.8 lb·in |
| M6 screw                      | 4.5 N·m           | 40.0 lb·in |
| M4 screw (grounding terminal) | 1.4 N·m           | 12.4 lb·in |
| M5 screw (grounding terminal) | 2.8 N·m           | 24.8 lb·in |

Refer to section 2.3.1 for details about terminal functions.


VFS15-2004PM-W to 2007PM-W




Note1) Bend the clips on the wiring port of the terminal cover to connect the PB, PO, PA/+, and PC/- terminals.

Note2) Be careful to insert all wires into the cage of terminal block.

VFS15-2015PM-W, 2022PM-W




VFS15-2037PM-W




Note1) Bend the clips on the wiring port of the terminal cover to connect the PB, PO, PA/+, and PC/- terminals.

Note2) Be careful to insert all wires into the cage of terminal block.

## VFS15S-2002PL-W to 2007PL-W




## VFS15S-2015PL-W, 2022PL-W




Note1) Bend the clips on the wiring port of the terminal cover to connect the PB, PO, PA+, and PC- terminals.  
 Note2) Be careful to insert all wires into the cage of terminal block.

## VFS15-4004PL-W to 4015PL-W




## VFS15-4022PL-W, 4037PL-W




- Note1) Bend the clips on the wiring port of the terminal cover to connect the PB, PO, PA/+, and PC/- terminals.  
 Note2) Be careful to insert all wires into the cage of terminal block.

VFS15-2055PM-W, 2075PM-W  
VFS15-4055PL-W, 4075PL-W




VFS15-2110PM-W, 2150PM-W



Note1) Bend the clips on the wiring port of the terminal cover to connect the PB, PO, PA/+, and PC/+ terminals.  
Note2) Be careful to insert all wires into the cage of terminal block.

VFS15-4110PL-W, 4150PL-W



Note1) Bend the clips on the wiring port of the terminal cover to connect the PB, PO, PA/+, and PC/- terminals.


Note2) Be careful to insert all wires into the cage of terminal block.

## 2) Grounding capacitor switch

Single-phase 240V model and three-phase 500V model have a built-in high-attenuation noise filter and is grounded via a capacitor.


A switch makes for easy switching to reduce leakage current from the inverter and the load on the capacitor. However, be careful, as reducing the load means non-conformity with the EMC standard on the inverter itself. Always do switching with the power off.

Note) In case of three phase 500V-4.0kW model, if you disconnect the capacitor from ground, set the parameter of carrier frequency  $F_{CU}$  to 4kHz or less with motor cable length 30m or less.  
In case of three phase 500V-4.0kW model, don't disconnect the capacitor from the ground, if you set the overload characteristic selection  $RUL$  to 2.



## 3) Control circuit terminal block

The control circuit terminal block is common to all equipment.



| Screw size | Recommended tightening torque |
|------------|-------------------------------|
| M3 screw   | 0.5 N·m                       |
|            | 4.4 lb·in                     |

Stripping length: 6 (mm)

Screwdriver: Small-sized flat-blade screwdriver  
(Blade thickness: 0.5 mm, blade width: 3.5 mm)

Refer to section 2.3.2 for details about all terminal functions.

### Wire size

| Conductor | 1 wire                             | 2 wires of same size                |
|-----------|------------------------------------|-------------------------------------|
| Solid     | 0.3-1.5mm <sup>2</sup> (AWG 22-16) | 0.3-0.75mm <sup>2</sup> (AWG 22-18) |
| Stranded  |                                    |                                     |

### Recommended ferrule

Using ferrule to be improved efficiency and reliability of wiring is recommended.

| Wire size<br>mm <sup>2</sup> (AWG) | Type                |                           |
|------------------------------------|---------------------|---------------------------|
|                                    | PHOENIX CONTACT     | Dinkle International.,Ltd |
| 0.34 (22)                          | AI 0.34-6TQ         | DN00306                   |
| 0.5 (20)                           | AI 0.5-6WH          | DN00506                   |
| 0.75 (18)                          | AI 0.75-6GY         | DN00706                   |
| 1 (16)                             | AI 1-6RD            | DN01006                   |
| 1.5 (16)                           | AI 1.5-8BK          | DN01508                   |
| *2 2 X 0.5 (-)                     | AI TWIN2 X 0.5-8WH  | DTE00508                  |
| *2 2 X 0.75 (-)                    | AI TWIN2 X 0.75-8GY | DTE00708                  |

\*1: Crimping pliers CRIMPFOX ZA3 (PHOENIX CONTACT)  
CT1 (Dinkle International.,Ltd)

\*2: These ferrules enable practical crimping of two wires in a ferrule.

1.4 Notes on the application

1.4.1 Motors

When this inverter and the motor are used in conjunction, pay attention to the following items.

|                                                                                                          |                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Caution</b>         |                                                                                                                                                                                                                                                                                                                                |
| <br>Mandatory<br>action | Use an inverter that conforms to the specifications of power supply and three-phase induction motor being operated. If the inverter being used does not conform to those specifications, not only will the three-phase induction motor not rotate correctly, but it will cause serious accidents through overheating and fire. |

Comparisons with commercial power operation

This inverter employs the sinusoidal PWM system. However, the output voltage and output current are not perfect sine waves, they have a distorted wave that is close to sinusoidal waveform. This is why compared to operation with a commercial power there will be a slight increase in motor temperature, noise and vibration.

Operation in the low-speed area

When running continuously at low speed in conjunction with a general purpose motor, there may be a decline in that motor's cooling effect. If this happens, operate with the output decreased from rated load. To carry out low-speed operation continuously at the rated torque, we recommend to use a inverter rated motor or a forced cooled motor designed for use with an inverter. When operating in conjunction with an inverter rated motor, you must change the inverter's motor overload protection level  $\overline{U}_L$  to VF motor use.

Adjusting the overload protection level

This inverter protects against overloads with its overload detection circuits (electronic thermal). The electronic thermal's reference current is set to the inverter's rated current, so it must be adjusted in line with the rated current of the motor being used in combination.

High speed operation at and above 60Hz

Operating at frequencies greater than 60Hz will increase noise and vibration. There is also a possibility this will exceed the motor's mechanical strength limits and the bearing limits so you should inquire to the motor's manufacturer about such operation.

Method of lubricating load mechanisms

Operating an oil-lubricated reduction gear and gear motor in the low-speed areas will worsen the lubricating effect. Check with the manufacturer of the reduction gear to find out about operable gearing area.

## Low loads and low inertia loads

The motor may demonstrate instability such as abnormal vibrations or overcurrent trips at light loads of 50% or under of the load percentage, or when the load's inertia moment is extremely small. If that happens reduce the carrier frequency.

## Occurrence of instability

Unstable phenomena may occur with the load and motor combinations shown below.

- Combined with a motor that exceeds applicable motor ratings for the inverter
- Combine with a much smaller motor according to the applicable motor rating of the inverter.
- Combined with special motors

To deal with the above lower the settings of inverter carrier frequency.

- Combined with couplings between load devices and motors with high backlash

When using the inverter in the above combination, use the S-pattern acceleration/deceleration function, or when vector control is selected, adjust the load inertia moment ratio or switch to V/f control mode.

- Combined with loads that have sharp fluctuations in rotation such as piston movements

In this case, adjust the load inertia moment ratio during vector control or switch to V/f control.

## Braking a motor when cutting off power supply


A motor with its power cut off goes into free-run, and does not stop immediately. To stop the motor quickly as soon as the power is cut off install an auxiliary brake. There are different kinds of brake devices, both electrical and mechanical. Select the brake that is best for the system.

## Load that produces regenerative torque

When combined with a load that produces regenerative torque, the overvoltage or overcurrent protection function may be activated to trip the inverter.

## Motors with a brake


When motors with a brake are directly connected to the inverter's output, the brake cannot be released at startup because of low voltage. Wire the brake circuit separately from the main circuit.



In circuit diagram 1, the brake is turned on and off through MC2 and MC3. If you do not wire it as shown in diagram 1, an over-current trip may occur because of a bound current during brake operation.  
(Example of standby ST assigned to terminal S2.)

In circuit diagram 2, the brake is turned on and off by using low-speed signal RY-RC.

In some situations, such as with elevators, turning the brake on and off with a low-speed signal may be appropriate. Be sure to contact us before designing your system.



## Measures to protect motors against surge voltages

In a system in which a 500V-class inverter is used to control the operation of a motor, very high surge voltages may be produced. When applied to the motor coils repeatedly for a long time, may cause deterioration of their insulation, depending on the cable length, cable routing and types of cables used. Here are some examples of measures against surge voltages.

- (1) Lower the inverter's carrier frequency.
- (2) Set the parameter  $F \ 3 \ 15$  (Carrier frequency control mode selection) to 2 or 3.
- (3) Use a motor with high insulation strength.
- (4) Insert an AC reactor or a surge voltage suppression filter between the inverter and the motor.

## 1.4.2 Inverters

### Protecting inverters from overcurrent


The inverter has an overcurrent protection function. The programmed current level is set to the inverter's maximum applicable motor. If the motor used has a small capacity, the overcurrent level and the electronic thermal protection must be readjusted. If adjustment is necessary, refer to section 5.6, and make adjustments as directed.

### Inverter capacity

Do not use a small-capacity (kVA) inverter to control the operation of a large-capacity motor (two-class or more larger motor), no matter how light the load is. Current ripple will raise the output peak current making it easier to set off the overcurrent trip.

### Power factor correction capacitor


Power factor correction capacitors cannot be installed on the output side of the inverter. When a motor is run that has a power factor correction capacitor attached to it, remove the capacitors. This can cause inverter malfunction and capacitor destruction.



### Operating at other than rated voltage

Connections to voltages other than the rated voltage described in the rating label cannot be made. If a connection must be made to a power supply other than one with rated voltage, use a transformer to raise or lower the voltage to the rated voltage.

## Circuit breaking when two or more inverters are used on the same power line



There is no fuse in the inverter's main circuit. Thus, as the diagram above shows, when more than one inverter is used on the same power line, you must select interrupting characteristics so that only MCCB2 to MCCBn+1 will trip and the MCCB1 will not trip when a short occurs in the inverter (INV1). When you cannot select the proper characteristics install a circuit interrupting fuse behind MCCB2 to MCCBn+1.

### If power supply distortion is not negligible

If the power supply distortion is not negligible because the inverter shares a power distribution line with other systems causing distorted waves, such as systems with thyristors or large-capacity inverters, install an input AC reactor to improve the input power factor, to reduce higher harmonics, or to suppress external surges.

### If multiple inverters are connected with common DC bus link

When inverters are fed by AC power supply and connected with common DC bus link, ground fault trip protection may operate. In that case, set ground fault detection selection ( $F 5 1 4$ ) to  $\square$  "Disabled".

## ■ Disposal

Refer to chapter 16.


## 1.4.3 What to do about the leakage current

|                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br><b>Mandatory action</b> | <div style="text-align: center;">  <b>Caution</b> </div> <ul style="list-style-type: none"> <li>The leakage current through the input/output power cables of inverter and capacitance of motor can affect to peripheral devices.<br/>The value of leakage current is increased under the condition of the PWM carrier frequency and the length of the input/output power cables. In case the total cable length (total of length between an inverter and motors) is more than 100m, overcurrent trip can occur even the motor no-load current. Make enough space among each phase cable or install the filter (MSF) as countermeasure.</li> </ul> |
|--------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

1

### (1) Influence of leakage current across ground


Leakage current may flow not just through the inverter system but also through ground wires to other systems. Leakage current will cause earth leakage breakers, leakage current relays, ground relays, fire alarms and sensors to operate improperly, and it will cause superimposed noise on the TV screen or display of incorrect current detection with the CT.



#### Remedies:

- If there is no radio-frequency interference or similar problem, detach the built-in noise filter capacitor, using the grounding capacitor switch.
- Reduce PWM carrier frequency.  
The setting of PWM carrier frequency is done with the parameter *F300*.  
Although the electromagnetic noise level is reduced, the motor acoustic noise is increased.
- Use high frequency remedial products for earth leakage breakers

## (2) Influence of leakage current across lines



### (1) Thermal relays

The high frequency component of current leaking into electrostatic capacity between inverter output wires will increase the effective current values and make externally connected thermal relays operate improperly. If the wires are more than 50 meters long, it will be easy for the external thermal relay to operate improperly with models having motors of low rated current (several A (ampere) or less), because the leakage current will increase in proportion to the motor rating.

### Remedies:


1. Use the electronic thermal built into the inverter. (Refer to section 5.6)

The setting of the electronic thermal is done using parameter  $\text{OLP}, \text{tHr}$ .

2. Reduce the inverter's PWM carrier frequency. However, that will increase the motor's magnetic noise.

The setting of PWM carrier frequency is done with the parameter  $F\text{SC}$ . (Refer to section 6.18)

3. This can be improved by installing 0.1 $\mu$  to 0.5 $\mu$ F - 1000V film capacitor to the input/output terminals of each phase in the thermal relay.



### (2) CT and ammeter

If a CT and ammeter are connected externally to detect inverter output current, the leak current's high frequency component may destroy the ammeter. If the wires are more than 50 meters long, it will be easy for the high frequency component to pass through the externally connected CT and be superimposed on and burn the ammeter with models having motors of low rated current (several A (ampere) or less), especially the 500V class low capacity (4.0kW or less) models, because the leakage current will increase in proportion to the motor's rated current.

Be sure to set the inverter's PWM carrier frequency to 5 kHz or less. However, that will increase the

motor's magnetic noise. The setting of PWM carrier frequency is done with the parameter *F300*  
(Refer to section 6.18).

#### Remedies:

1. Use a meter output terminal in the inverter control circuit.  
The load current can be output on the meter output terminal (FM). If the meter is connected, use an ammeter of 1mAdc full scale or a voltmeter of 10V full scale.  
0-20mAdc (4-20mAdc) can be also output. (Refer to section 5.1)
2. Use the monitor functions built into the inverter.  
Use the monitor functions on the panel built into the inverter to check current values. (Refer to section 8.2.1)

1

### 1.4.4 Installation

#### ■ Installation environment

This inverter is an electronic control instrument. Take full consideration to installing it in the proper operating environment.

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>• Do not place any inflammable substances near the inverter.<br/>If an accident occurs in which flame is emitted, this could lead to fire.</li> <li>• Do not install in any location where the inverter could come into contact with water or other fluids.<br/>This can result in electric shock or fire.</li> </ul>                                                                                                                                                                                             |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>• Operate under the environmental conditions prescribed in the instruction manual.<br/>Operations under any other conditions can result in malfunction.</li> <li>• Check to make sure that the input power voltage is +10%, -15% of the rated power voltage (±10% when the load is 100% in continuous operation) written on the name plate.<br/>If the input power voltage is not +10%, -15% of the rated power voltage (±10% when the load is 100% in continuous operation), this can result in fire.</li> </ul> |

|  <b>Caution</b> |                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited  | <ul style="list-style-type: none"> <li>• Do not install the inverter in any location subject to large amounts of vibration.<br/>This could cause the unit to fail, resulting in bodily injury.</li> </ul> |




- Do not install in any location of high temperature, high humidity, moisture condensation and freezing and avoid locations where there is exposure to water and/or where there may be large amounts of dust, metallic fragments and oil mist.
- Do not install in any location where corrosive gases or grinding fluids are present.

1

- Operate in areas where ambient temperature ranges from  $-10^{\circ}\text{C}$  to  $60^{\circ}\text{C}$ .  
When using the inverter in locations with temperatures above  $40^{\circ}\text{C}$ , remove the protective label on the top of the inverter and use the inverter with the output current reduced according to section 6.18.



[Position for measuring ambient temperature]




Note: The inverter is a heat-emitting body. Make sure proper space and ventilation is provided when installing in the cabinet.

- Do not install in any location that is subject to large amounts of vibration.



Note: If the inverter is installed in a location that is subject to vibration, anti-vibration measures are required. Please consult with Toshiba about these measures.

- If the inverter is installed near any of the equipment listed below, provide measures to insure against errors in operation.



|                      |                                   |
|----------------------|-----------------------------------|
| Solenoids:           | Attach surge suppressor on coil.  |
| Brakes:              | Attach surge suppressor on coil.  |
| Magnetic contactors: | Attach surge suppressor on coil.  |
| Fluorescent lights:  | Attach surge suppressor on coil.  |
| Resistors:           | Place far away from the inverter. |

## ■ How to install

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Do not install or operate the inverter if it is damaged or any component is missing. This can result in electric shock or fire. Call your Toshiba distributor for repairs.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Mount the inverter on a metal plate. The rear panel gets very hot. Do not install in an inflammable object, this can result in fire.</li> <li>Do not operate with the terminal block cover removed. This can result in electric shock.</li> <li>An emergency stop device must be installed that fits with system specifications (e.g. shut off input power then engage mechanical brake). Operation cannot be stopped immediately by the inverter alone, thus, resulting in an accident or injury.</li> <li>All options used must be those specified by Toshiba. The use of any other option will result in an accident.</li> </ul> |

1

|  <b>Caution</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>The main unit must be installed on a base that can bear the unit's weight. If the unit is installed on a base that cannot withstand that weight, the unit can fall, resulting in injury.</li> <li>If braking is necessary (to hold motor shaft), install a mechanical brake. The brake on the inverter will not function as a mechanical hold, and if used for that purpose, injury will result.</li> </ul> |

### (1) Normal installation

Select an indoor location with good ventilation, and then install it upright on a flat metal plate.


When installing multiple inverters, leave at least 3 cm of space between each inverter and install them aligned horizontally.

When using the inverter in locations with temperatures above 40°C, remove the protective label on the top of the inverter and use the inverter with the output current reduced according to section 6.18.


### (2) Side-by-side installation

To align the inverters side-by-side horizontally, remove the protective label on the top of the inverter before use. When using the inverter in locations with temperatures above 40°C, use the inverter with the output current reduced.

If the door is opened 90° or more, please open the door with the left side inverter's door open when the same capacity inverters are installed with side-by-side.



Normal installation



Side-by-side installation

The space shown in the diagram is the minimum allowable space. Because air cooled equipment has cooling fans built in on the top or bottom surfaces, make the space on top and bottom as large as possible to allow for air passage.

Note: Do not install in any location where there is high humidity or high temperatures and where there are large amounts of dust, metallic fragments and oil mist.

1

## ■ Calorific values of the inverter and the required ventilation

About 5% of the rated power of the inverter will be lost as a result of conversion from AC to DC or from DC to AC. In order to suppress the rise in temperature inside the cabinet when this loss becomes heat loss, the interior of the cabinet must be ventilated and cooled.

The amount of forcible air-cooling ventilation required and the necessary heat discharge surface quantity when operating in a sealed cabinet according to motor capacity are as follows.

| Voltage class              | Inverter type |          | Calorific values (W)<br>Note 1) |       | Amount of forcible air<br>cooling ventilation<br>required (m³/min) |       | Heat discharge<br>surface area required<br>for sealed storage<br>cabinet (m²) |       | Standby power<br>requirement<br>(W)<br>Note 2) |
|----------------------------|---------------|----------|---------------------------------|-------|--------------------------------------------------------------------|-------|-------------------------------------------------------------------------------|-------|------------------------------------------------|
|                            |               |          | 4kHz                            | 12kHz | 4kHz                                                               | 12kHz | 4kHz                                                                          | 12kHz |                                                |
| Three-phase<br>240V class  | VFS15-        | 2004PM-W | 35                              | 40    | 0.20                                                               | 0.23  | 0.70                                                                          | 0.80  | 6                                              |
|                            |               | 2007PM-W | 45.6                            | 50    | 0.26                                                               | 0.28  | 0.91                                                                          | 0.99  | 6                                              |
|                            |               | 2015PM-W | 81                              | 92    | 0.46                                                               | 0.52  | 1.61                                                                          | 1.85  | 10                                             |
|                            |               | 2022PM-W | 94.9                            | 104   | 0.54                                                               | 0.59  | 1.90                                                                          | 2.07  | 10                                             |
|                            |               | 2037PM-W | 139                             | 154   | 0.79                                                               | 0.87  | 2.77                                                                          | 3.08  | 11                                             |
|                            |               | 2055PM-W | 256                             | 283   | 1.45                                                               | 1.61  | 5.12                                                                          | 5.66  | 22                                             |
|                            |               | 2075PM-W | 305                             | 367   | 1.73                                                               | 2.08  | 6.10                                                                          | 7.34  | 22                                             |
|                            |               | 2110PM-W | 475                             | 538   | 2.70                                                               | 3.05  | 9.50                                                                          | 10.76 | 31                                             |
|                            |               | 2150PM-W | 557                             | 628   | 3.16                                                               | 3.56  | 11.14                                                                         | 12.56 | 31                                             |
| Single-phase<br>240V class | VFS15S-       | 2002PL-W | 23                              | 24.8  | 0.13                                                               | 0.14  | 0.46                                                                          | 0.50  | 5                                              |
|                            |               | 2004PL-W | 37                              | 42.2  | 0.21                                                               | 0.24  | 0.74                                                                          | 0.84  | 5                                              |
|                            |               | 2007PL-W | 46                              | 50    | 0.26                                                               | 0.28  | 0.92                                                                          | 1.00  | 5                                              |
|                            |               | 2015PL-W | 79                              | 90    | 0.45                                                               | 0.51  | 1.57                                                                          | 1.80  | 8                                              |
|                            |               | 2022PL-W | 101                             | 110   | 0.58                                                               | 0.62  | 2.03                                                                          | 2.20  | 8                                              |
| Three-phase<br>500V class  | VFS15-        | 4004PL-W | 30                              | 39    | 0.17                                                               | 0.22  | 0.61                                                                          | 0.78  | 12                                             |
|                            |               | 4007PL-W | 39                              | 50    | 0.22                                                               | 0.28  | 0.78                                                                          | 1.00  | 12                                             |
|                            |               | 4015PL-W | 58                              | 76    | 0.33                                                               | 0.43  | 1.15                                                                          | 1.53  | 12                                             |
|                            |               | 4022PL-W | 77                              | 102   | 0.44                                                               | 0.58  | 1.53                                                                          | 2.04  | 13                                             |
|                            |               | 4037PL-W | 131                             | 156   | 0.75                                                               | 0.88  | 2.63                                                                          | 3.12  | 13                                             |
|                            |               | 4055PL-W | 211                             | 263   | 1.20                                                               | 1.49  | 4.22                                                                          | 5.26  | 22                                             |
|                            |               | 4075PL-W | 254                             | 346   | 1.44                                                               | 1.96  | 5.08                                                                          | 6.92  | 22                                             |
|                            |               | 4110PL-W | 387                             | 470   | 2.20                                                               | 2.67  | 7.74                                                                          | 9.40  | 31                                             |
|                            |               | 4150PL-W | 466                             | 572   | 2.65                                                               | 3.25  | 9.32                                                                          | 11.44 | 31                                             |


Note 1) Case of 100% Load Continuation operation. The heat loss for the optional external devices (input AC reactor, radio noise reduction filters, etc.) is not included in the calorific values in the table

Note 2) It is power consumption when power is on but is not output (0Hz), and cooling fan is activated (model with cooling fan).

## ■ Panel designing taking into consideration the effects of noise

The inverter generates high frequency noise. When designing the control panel setup, consideration must be given to that noise. Examples of measures are given below.


- Wire so that the main circuit wires and the control circuit wires are separated. Do not place them in the same conduit, do not run them parallel, and do not bundle them.
- Provide shielding and twisted wire for control circuit wiring.
- Separate the input (power) and output (motor) wires of the main circuit. Do not place them in the same conduit, do not run them parallel, and do not bundle them.
- Ground the inverter grounding terminals ( $\perp$ ).
- Install surge suppressor on any magnetic contactor and relay coils used around the inverter.
- Install noise filters if necessary.
- To comply with the EMC directives, install the optional EMC plate and fix the shield to it.
- Install EMC plate and use shielded wires.



## ■ Installing more than one unit in a cabinet

When two or more inverters are installed in one cabinet, pay attention to the followings.

- Inverters may be installed side by side with each other with no space left between them.  
When installing inverters side by side, remove the protective label on the top of the inverter.  
When using the inverter in locations with temperatures above 40°C, use the inverter with the output current reduced.
- Ensure a space of at least 20 centimeters on the top and bottom of the inverters.
- Install an air deflecting plate so that the heat rising up from the inverter on the bottom does not affect the inverter on the top.



## 2. Connection

|  <b>Warning</b>            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Disassembly prohibited | <ul style="list-style-type: none"> <li>• Never disassemble, modify or repair.<br/>This can result in electric shock, fire and injury. Call your Toshiba distributor for repairs.</li> </ul>                                                                                                                                                                                                                                                                                                            |
| <br>Prohibited             | <ul style="list-style-type: none"> <li>• Do not stick your fingers into openings such as cable wiring holes and cooling fan covers.<br/>This can result in electric shock or other injury.</li> <li>• Do not place or insert any kind of object (electrical wire cuttings, rods, wires) into the inverter. This can result in electric shock or fire.</li> <li>• Do not allow water or any other fluid to come in contact with the inverter.<br/>This can result in electric shock or fire.</li> </ul> |

2

|  <b>Caution</b> |                                                                                                                                                                                                     |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited  | <ul style="list-style-type: none"> <li>• When transporting or carrying, do not hold by the front panel covers.<br/>The covers will come off and the unit will drop, resulting in injury.</li> </ul> |

### 2.1 Cautions on wiring

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>• Never remove the terminal cover when power is on.<br/>The unit contains many high voltage parts and contact with them will result in electric shock.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>• Turn the power on only after attaching the terminal block cover.<br/>If the power is turned on without the terminal block cover attached, this can result in electric shock or other injury.</li> <li>• Electrical construction work must be done by a qualified expert.<br/>Connection of input power by someone who does not have that expert knowledge can result in fire or electric shock.</li> <li>• Connect output terminals (motor side) correctly.<br/>If the phase sequence is incorrect, the motor will operate in reverse and that can result in injury.</li> <li>• Wiring must be done after installation.<br/>If wiring is done prior to installation, that can result in injury or electric shock.</li> <li>• The following steps must be performed before wiring.               <ol style="list-style-type: none"> <li>(1) Shut off all input power.</li> <li>(2) Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.</li> <li>(3) Use a tester that can measure DC voltage (400VDC or 800VDC or more), and check to make sure that the voltage to the DC main circuits (across PA/+ - PC/-) is 45V or less.<br/>If these steps are not properly performed, the wiring will cause electric shock.</li> </ol> </li> <li>• Tighten the screws on the terminal block to specified torque.<br/>If the screws are not tightened to the specified torque, it can lead to fire.</li> </ul> |

|                                                                                                  |                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Warning</b> |                                                                                                                                                                              |
| <br>Be Grounded | <ul style="list-style-type: none"> <li>• Ground must be connected securely.<br/>If the ground is not securely connected, it could lead to electric shock or fire.</li> </ul> |

|                                                                                                  |                                                                                                                                                                                                                |
|--------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Caution</b> |                                                                                                                                                                                                                |
| <br>Prohibited  | <ul style="list-style-type: none"> <li>• Do not attach devices with built-in capacitors (such as noise filters or surge absorber) to the output (motor side) terminal.<br/>This could cause a fire.</li> </ul> |

2

### ■ Preventing radio noise

To prevent electrical interference such as radio noise, separately bundle wires to the main circuit's power terminals (3-phase models: R/L1, S/L2, T/L3, single-phase models: R/L1, S/L2/N) and wires to the motor terminals (U/T1, V/T2, W/T3).

### ■ Control and main power supply

The control power supply and the main circuit power supply for this inverter are the same.

If a malfunction or trip causes the main circuit to be shut off, control power will also be shut off. When checking the cause of the malfunction or the trip, use the trip holding retention selection parameter.

In addition, please use an optional control power supply backup unit when only control power supply operates, even if the main circuit is shut off due to trouble or tripping.

### ■ Wiring

- Because the space between the main circuit terminals is small, use sleeved crimp-style terminals for the connections. Connect the terminals so that adjacent terminals do not touch each other.
- For grounding terminal  use wires of the size that is equivalent to or larger than those given in table 10.1 and always ground the inverter (240V voltage class: D type ground, 500V voltage class: C type ground).  
Use as large and short a grounding wire as possible and wire it as close as possible to the inverter.
- For the sizes of electric wires used in the main circuit, refer to the table in section 10.1.
- The length of each wire does not exceed 30 meters. If the wire is longer than 30 meters, the wire size (diameter) must be increased.

## 2.2 Standard connections

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Do not connect input power to the output (motor side) terminals (U/T1, V/T2, W/T3). Connecting input power to the output could destroy the inverter or cause a fire.</li> <li>Do not insert a braking resistor between DC terminals (between PA/+ and PC/- or PO and PC/-). It could cause a fire.</li> <li>First shut off input power and wait at least 15 minutes before touching terminals and wires on equipment (MCCB) that is connected to inverter power side. Touching the terminals and wires before that time could result in electric shock.</li> <li>Do not shut down the external power supply on ahead when VIA terminal is used as logic input terminal by external power supply. It could cause unexpected result as VIA terminal is ON status.</li> </ul> |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>Set a parameter <math>F_{109}</math> when VIA or VIB terminals are used as logic input terminal. If it is not set, it could result in malfunction.</li> <li>Set a parameter <math>F_{147}</math> when S3 terminal is used as PTC input terminal. If it is not set, it could result in malfunction.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <br>Be Grounded      | <ul style="list-style-type: none"> <li>Ground must be connected securely. If the ground is not securely connected, it could lead to electric shock or fire.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |


## 2

Standard connection diagram - SINK (Negative) (common:CC)



## 2.2.2 Standard connection diagram 2


Standard connection diagram - SOURCE (Positive) (common:P24)



## 2.3 Description of terminals

### 2.3.1 Power circuit terminals

#### ■ Connections with peripheral equipment



Note 1: The T/L3 terminal is not provided for any single-phase models. So if you are using single-phase models, use the R/L1 and S/L2/N terminals to connect power cables.

#### ■ Power circuit

| Terminal symbol | Terminal function                                                                                                                                                                          |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | Grounding terminal for connecting inverter. There are 3 terminals in cooling fin or mounting part of EMC plate.                                                                            |
| R/L1,S/L2,T/L3  | 240V class : Three-phase 200 to 240V-50/60Hz<br>: Single-phase 200 to 240V-50/60Hz<br>500V class : Three-phase 380 to 500V-50/60Hz<br>* Single-phase inputs are R/L1 and S/L2/N terminals. |
| U/T1,V/T2,W/T3  | Connect to three-phase motor.                                                                                                                                                              |
| PA/+, PB        | Connect to braking resistors.<br>Change parameters <i>F304, F305, F308, F309</i> if necessary.                                                                                             |
| PA/+            | This is a positive potential terminal in the internal DC main circuit.<br>DC common power can be input between PA/- terminal and PC/- terminal.                                            |
| PC/-            | This is a negative potential terminal in the internal DC main circuit.<br>DC common power can be input between PC/- terminal and PA/+ terminal.                                            |
| PO, PA/+        | Terminals for connecting a DC reactor (DCL: optional external device). Shorted by a Shorting-bar when shipped from the factory. Before installing DCL, remove the shorting-bar.            |

The arrangements of power circuit terminals are different from each range.

Refer to section 1.3.3.1) for details.

## 2.3.2 Control circuit terminals

The control circuit terminal block is common to all equipment.

Regarding to the function and specification of each terminal, please refer to the following table.

Refer to section 1.3.3.3) about the arrangement of control circuit terminals.

### ■ Control circuit terminals

| Terminal symbol | Input / output | Function                                                                                                                                                                                                  | Electrical specifications                                                                                                                                                                                                                                             | Inverter internal circuits |
|-----------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| F               | Input          | Shorting across F-CC or P24-F causes forward rotation; open causes deceleration stop. (When Standby ST is always ON) 3 different functions can be assigned.                                               | No voltage logic input<br>24Vdc-5mA or less<br><br>Sink/Source and PLC selectable using slide switch SW1 (Default setting is PLC side)<br><br>Pulse train input (S2 terminal)<br>Pulse frequency range:<br>10pps~2kpps<br>Duty: 50±10%<br><br>PTC input (S3 terminal) |                            |
| R               | Input          | Shorting across R-CC or P24-R causes reverse rotation; open causes deceleration stop. (When Standby ST is always ON) 3 different functions can be assigned.                                               |                                                                                                                                                                                                                                                                       |                            |
| RES             | Input          | This inverter protective function is reset if RES-CC or P24-RES is connected. Shorting RES-CC or P24-RES has no effect when the inverter is in a normal condition. 2 different functions can be assigned. |                                                                                                                                                                                                                                                                       |                            |
| S1              | Input          | Shorting across S1-CC or P24-S1 causes preset speed operation. 2 different functions can be assigned.                                                                                                     |                                                                                                                                                                                                                                                                       |                            |
| S2              | Input          | Shorting across S2-CC or P24-S2 causes preset speed operation. By changing parameter F 145 setting, this terminal can also be used as a pulse train input terminal.                                       |                                                                                                                                                                                                                                                                       |                            |
| S3              | Input          | Shorting across S3-CC or P24-S3 causes preset speed operation. By changing slide switch SW2 and parameter F 147 setting, this terminal can also be used as a PTC input terminal.                          |                                                                                                                                                                                                                                                                       |                            |

2

| Terminal symbol  | Input / output           | Function                                                                                                                                                                                                                                                                                                                                                                                   | Electrical specifications                             | Inverter internal circuits |
|------------------|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|----------------------------|
| CC               | Common to Input / output | Control circuit's equipotential terminal (3 terminals)                                                                                                                                                                                                                                                                                                                                     |                                                       |                            |
| PP               | Output                   | Analog power supply output                                                                                                                                                                                                                                                                                                                                                                 | 10Vdc (permissible load current: 10mA <sub>dc</sub> ) |                            |
| V I A<br>Note 1) | Input                    | Multifunction programmable analog input.<br>Default setting: 0-10Vdc (1/1000 resolution) and 0-60Hz (0-50Hz) frequency input (1/2000 resolution).<br><br>By changing parameter $F I O 9$ , this terminal can also be used as a multifunction programmable logic input terminal.                                                                                                            | 10Vdc (internal impedance: 30k $\Omega$ )             |                            |
| V I B<br>Note 1) | Input                    | Multifunction programmable analog input.<br>Default setting: 0-10Vdc (1/1000 resolution) and 0-60Hz (0-50Hz) frequency input.<br><br>The function can be changed to -10-+10V input by parameter $F I O 7 = 1$ setting.<br><br>By switching slide switch SW2 and changing parameter $F I O 9$ setting, this terminal can also be used as a multifunction programmable logic input terminal. | 10Vdc (internal impedance: 30k $\Omega$ )             |                            |
| V I C            | Input                    | Multifunction programmable analog input.<br>4-20mA (0-20mA) input.                                                                                                                                                                                                                                                                                                                         | 4-20mA (internal impedance: 250 $\Omega$ )            |                            |

| Terminal symbol | Input / output | Function                                                                                                                                                                                                                                  | Electrical specifications                                                                                                                                                                        | Inverter internal circuits |
|-----------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| FM              | Output         | Multifunction programmable analog output. Default setting: output frequency. The function can be changed to meter option (0-1mA), 0-10Vdc voltage, or 0-20mA (4-20mA) current output by parameter $F5B1$ setting. Resolution Max. 1/1000. | 1mA dc full-scale ammeter or QS60T(option)<br><br>0-20mA (4-20mA) DC ammeter<br>Permissible load resistance: 600Ω or less<br><br>0-10V DC volt meter<br>Permissible load resistance: 1kΩ or more |                            |
| P24             | Output         | 24Vdc power output                                                                                                                                                                                                                        | 24Vdc-100mA<br>Note 2)                                                                                                                                                                           |                            |
|                 | Input          | This terminal can be used as a common terminal when an external power supply is used by changing SW1 to PLC side.                                                                                                                         | -                                                                                                                                                                                                |                            |
| +24             | Output         | 24Vdc power output                                                                                                                                                                                                                        | 24Vdc-100mA<br>Note 2)                                                                                                                                                                           |                            |
| +SU             | Input          | DC power input terminal for operating the control circuit. Connect a control power backup device (option or 24Vdc power supply) between +SU and CC.                                                                                       | Voltage: 24Vdc±10%<br>Current: 1A or more                                                                                                                                                        |                            |

| Terminal symbol                  | Input / output | Function                                                                                                                                                                                                                                                                                                                                                                                                                          | Electrical specifications                                                                                                                                   | Inverter internal circuits |
|----------------------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| OUT<br>NO                        | Output         | Multifunction programmable open collector output. Default setting detect and output speed reach signal.<br>Multifunction output terminals to which two different functions can be assigned. The NO terminal is an equipotential terminal. It is isolated from the CC terminal.<br><br>By changing parameter <i>F 5 5 9</i> settings, these terminals can also be used as multifunction programmable pulse train output terminals. | Open collector output<br>24Vdc-100mA<br><br>To output pulse trains, a current of 10mA or more needs to be passed.<br><br>Pulse frequency range:<br>10~2kpps |                            |
| FLA<br>FLB<br>FLC<br><br>Note 3) | Output         | Multifunction programmable relay contact output.<br>Detects the operation of the inverter's protection function.<br>Contact across FLA-FLC is closed and FLB-FLC is opened during protection function operation.                                                                                                                                                                                                                  | Max. switching capacity<br>250Vac-2A,<br>30Vdc-2A<br>(cosφ=1)<br>: at resistive load<br><br>250Vac-1A<br>(cosφ=0.4)                                         |                            |
| RY<br>RC<br><br>Note 3)          | Output         | Multifunction programmable relay contact output.<br>Default settings detect and output low-speed signal output frequencies.<br>Multifunction output terminals to which two different functions can be assigned.                                                                                                                                                                                                                   | 30Vdc-1A<br>(L/R=7ms)<br><br>Min. permissible load<br>5Vdc-100mA<br>24Vdc-5mA                                                                               |                            |

Note 1) When VIA terminal is used as logic input terminal, be sure to connect a resistor between P24 and VIA in case of sink logic, between VIA and CC in case of source logic. (Recommended resistance: 4.7kΩ-1/2W)

It is not needed for VIB terminal.

Note 2) 100mA is the sum of P24 and +24.

Note 3) A chattering (momentary ON/OFF of contact) is generated by external factors of the vibration and the impact, etc. In particular, please set the filter of 10ms or more, or timer for measures when connecting it directly with input unit terminal of programmable controller. Please use the OUT terminal as much as possible when the programmable controller is connected.

## ■ Connection of SINK (Negative) logic/SOURCE (Positive) logic (When the inverter's internal power supply is used)


Current flowing out turns control input terminals on. These are called sink logic terminals. The general used method in Europe is source logic in which current flowing into the input terminal turns it on.

Sink logic is sometimes referred to as negative logic, and source logic is referred to as positive logic. Each logic is supplied with electricity from either the inverter's internal power supply or an external power supply, and its connections vary depending on the power supply used.

Sink/source logic can be switched by slide switch SW1.

2

<Examples of connections when the inverter's internal power supply is used>




Note 4: Be sure to connect NO and CC terminals for Sink logic.

Be sure to connect P24 and OUT terminals for Source logic.

## ■ SINK (Negative)/ SOURCE (Positive) logic connection (When an external power supply is used)

The P24 terminal is used to connect to an external power supply or to separate a terminal from other input or output terminals.

<Examples of connections when an external power supply is used>



## ■ Switching of slide switch

Refer to section 1.3.3.3) about location of slide switch.

### (1) Switching of sink/source logic: SW1 (Default setting : PLC side)

Setting of sink/source logic for F, R, RES, S1, S2, and S3 terminals are switched by slide switch SW1.

When an external power supply is used for sink logic, set the slide switch SW1 to PLC side.

Set the sink/source logic switching before turn on power supply.

After confirming the right for sink/source setting, turn on power supply.

### (2) Switching of VIB terminal function: Upper SW2 (Default setting: VIB side)

Setting of analog input/ logic input for VIB terminal is switched by upper slide switch SW2 and parameter  $F109$ .

When using VIB terminal as an analog input terminal, set the slide switch to VIB side and set the parameter  $F109=0$ .

When using VIB terminal as a logic input terminal, set the slide switch to S4 side and set the parameter any value to  $F109=1,3$ , or  $4$ . Sink/ source logic depends on the slide switch SW1. Match the setting of upper slide switch SW2 and parameter  $F109$  surely.

If it is not, this can result in malfunction.

### (3) Switching of S3 terminal function: Lower SW2 (Default setting: S3 side)

Setting of logic input/ PTC input for S3 terminal is switched by lower slide switch SW2 and parameter  $F147$ .

When using S3 terminal as a logic input terminal, set the slide switch to S3 side and set the parameter  $F147=0$ .

When using S3 terminal as a PTC input terminal, set the slide switch to PTC side and set the parameter  $F147=1$ .

Match the setting of lower slide switch SW2 and parameter  $F147$  surely.

If it is not, this can result in malfunction.

### 3. Operations

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited       | <ul style="list-style-type: none"> <li>Do not touch inverter terminals when electrical power is going to the inverter even if the motor is stopped.<br/>Touching the inverter terminals while power is connected to it will result in electric shock.</li> <li>Do not touch switches when the hands are wet and do not try to clean the inverter with a damp cloth. Such practices will result in electric shock.</li> <li>Do not go near the motor in alarm-stop status when the retry function is selected.<br/>The motor will suddenly restart and that could result in injury.<br/>Take measures for safety, e.g. attaching a cover to the motor, against accidents when the motor unexpectedly restarts.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                       |
| <br>Mandatory action | <ul style="list-style-type: none"> <li>If the inverter begins to emit smoke or an unusual odor, or unusual sounds, immediately turn the power off.<br/>Continuous use of the inverter in such a state will cause fire. Call your Toshiba distributor for repairs.</li> <li>Always turn the power off if the inverter is not used for long periods of time since there is a possibility of malfunction caused by leaks, dust and other material. If power is left on with the inverter in that state, it can result in fire.</li> <li>Turn the input power on only after attaching the terminal block cover.<br/>When enclosed inside a cabinet and used with the terminal block cover removed, always close the cabinet doors first and then turn the power on. If the power is turned on with the terminal block cover or the cabinet doors open, this can result in electric shock.</li> <li>Make sure that operation signals are off before resetting the inverter after malfunction.<br/>If the inverter is reset before turning off the operating signal, the motor can restart suddenly, resulting in injury.</li> </ul> |

|  <b>Caution</b>        |                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Contact prohibited | <ul style="list-style-type: none"> <li>Do not touch heat radiating fins or discharge resistors.<br/>These devices are hot, and you'll get burned if you touch them.</li> </ul>                                                  |
| <br>Prohibited         | <ul style="list-style-type: none"> <li>Observe all permissible operating ranges of motors and mechanical equipment. (Refer to the motor's instruction manual.)<br/>Not observing these ranges will result in injury.</li> </ul> |

### 3.1 How to Set the Setup Menu



#### Warning



Mandatory  
action

- If incorrect setting, the drive will have some damage or unexpected movement. Be sure to set the setup menu correctly.

Set the setup menu according to the base frequency and the base frequency voltage of the motor connected. (If you are not sure which region code of setup menu should be selected and what values should be specified, consult your Toshiba distributor.)

Each setup menu automatically sets all parameters relating to the base frequency and the base frequency voltage of the motor connected. (See the table on the following page.)

Follow these steps to change the setup menu [Example: Selecting a region code to *EU*]

| Panel operated | LED display                                                                            | Operation                                                             |
|----------------|----------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
|                | <i>SEt</i>                                                                             | <i>SEt</i> is blinking                                                |
|                | <div><i>EU</i></div> <div><i>JP</i></div> <div><i>ASIA</i></div> <div><i>USA</i></div> | Turn the setting dial, and select region code " <i>EU</i> " (Europe). |
|                | <i>EU ↔ In It</i>                                                                      | Press the center of the setting dial to determine the region.         |
|                | <i>0.0</i>                                                                             | The operation frequency is displayed (Standby).                       |

- If you want to change the selected region by the setup menu, the setup menu will appear by the following settings. Please note, however, that all setting parameters return to status of default setting and the trip history data is cleared.
  - Set parameter *SEt* to "*0*".
  - Set parameter *tYp* to "*13*".
- The parameter settings in the table on the following page can be changed individually even after they are selected in the setup menu.

■ Values set by each setup parameter

| Title                                              | Function                                              |            | EU<br>(Mainly in Europe) | USA<br>(Mainly in North America) | ASIA<br>(Mainly in Asia, Oceania)<br>Note 1) | JP<br>(Mainly in Japan)  |
|----------------------------------------------------|-------------------------------------------------------|------------|--------------------------|----------------------------------|----------------------------------------------|--------------------------|
| ULUL1170/<br>F204/F213/<br>F219/F330/<br>F367/F814 | Frequency                                             |            | 50.0(Hz)                 | 60.0(Hz)                         | 50.0(Hz)                                     | 60.0(Hz)                 |
| ULU/<br>F171                                       | Base frequency voltage<br>1, 2                        | 240V class | 230(V)                   | 230(V)                           | 230(V)                                       | 200(V)                   |
|                                                    |                                                       | 500V class | 400(V)                   | 460(V)                           | 400(V)                                       | 400(V)                   |
| PE                                                 | V/F control mode selection                            |            | 0                        | 0                                | 0                                            | 2                        |
| F307                                               | Supply voltage correction (output voltage limitation) |            | 2                        | 2                                | 2                                            | 3                        |
| F319                                               | Regenerative over-excitation upper limit              |            | 120                      | 120                              | 120                                          | 140                      |
| F417                                               | Motor rated speed                                     |            | 1410(min <sup>-1</sup> ) | 1710(min <sup>-1</sup> )         | 1410(min <sup>-1</sup> )                     | 1710(min <sup>-1</sup> ) |

Note 1) Excludes Japan.

Note 2) Slide switch SW1 is set to PLC side at default setting. Set it appropriately according to the logic used.

Refer to page B-11 to 13 for details.

## 3.2 Simplified Operation of the VF-S15

Operation command and Operation frequency command are necessary to operate the inverter.

Operation method and operation frequency setting can be selected from the following.

At default setting, the inverter runs and stops with RUN/STOP key on the panel keypad, and frequency can be set with the setting dial.

Run / Stop

- : (1) Run and stop using the panel keypad  
(2) Run and stop using external signals

Setting the frequency

- : (1) Setting using setting dial  
(2) Setting using external signals  
(0-10Vdc, 4-20mAdc, -10-+10Vdc)

Use the basic parameters  $Cn0d$  (command mode selection) and  $Fn0d$  (frequency setting mode selection) for selection.

[Parameter setting]

| Title  | Function                           | Adjustment range                                                                                                                                                                                                                                                                                                                             | Default setting |
|--------|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| $Cn0d$ | Command mode selection             | 0: Terminal block<br>1: Panel keypad (including extension panel)<br>2: RS485 communication<br>3: CANopen communication<br>4: Communication option                                                                                                                                                                                            | 1               |
| $Fn0d$ | Frequency setting mode selection 1 | 0: Setting dial 1(save even if power is off)<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Setting dial 2(press in center to save)<br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input<br>12, 13: -<br>14: $ScrQ$ | 0               |

- $Fn0d=0$  (setting dial 1) is the mode that after the frequency is set by the setting dial or an extension panel, the frequency is saved even if the power is turned off. The usage of this setting dial is similar to that of potentiometer.
- Refer to section 6.2.1 for details about  $Fn0d=4$  to 7, 11, and 14.

### 3.2.1 How to run and stop

[Example of  $\text{CnCd}$  setting procedure]

| Panel operation                                                                   | LED display              | Operation                                                                                                                              |
|-----------------------------------------------------------------------------------|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                   | 0.0                      | Displays the output frequency (operation stopped).<br>(When standard monitor display selection $F \ 7 \ 1 \ 0 = 0$ [output frequency]) |
|  | RUH                      | Displays the first basic parameter [History (RUH)].                                                                                    |
|  | CnCd                     | Turn the setting dial, and select "CnCd".                                                                                              |
|  | 1                        | Press the center of the setting dial to read the parameter value.<br>(Standard default: 1).                                            |
|  | 0                        | Turn the setting dial to change the parameter value to 0 (terminal block).                                                             |
|  | 0 $\leftrightarrow$ CnCd | Press the center of the setting dial to save the changed parameter.<br>CnCd and the parameter set value are displayed alternately.     |

3

#### (1) Run and stop using the panel keypad ( $\text{CnCd} = 1$ )

Use the  and  keys on the panel keypad to start and stop the motor.

 : Motor runs.  : Motor stops.


- The direction of rotation is determined by the setting of parameter  $F \ r$  (forward run, reverse run selection).  
(0: forward run, 1: reverse run)
- Forward run and reverse run are switchable with the extension panel (option). Set the parameter  $F \ r$  (forward run, reverse run selection) to 2 or 3. (Refer to section 5.8)

#### (2) RUN and STOP using external signals ( $\text{CnCd} = 0$ ): Sink (Negative) logic

Use external signals to the inverter terminal block to start and stop the motor.

Short  and  terminals: run forward


Open  and  terminals: slow down and stop



## (3) Coast stop

Assign parameters as described below in case of Coast stop. Inverter will display  $\text{FFF}$  at Coast stop.

- 1) Assign " $\text{S}$  (ST)" to an input terminal. Set parameter  $\text{F} \cdot \text{I} \cdot \text{O} = \text{O}$ . Open the ST-CC for coast stop (see the status described on the right).
- 2) Assign " $\text{S}$  (FRR)" to an input terminal. Coast stop is done by shorting FRR and CC.



### 3.2.2 How to set the frequency

[Example of  $FND$  setting procedure]  $FND=1$ : Setting the frequency by the terminal VIA

| Panel operation                                                                   | LED display         | Operation                                                                                                                   |
|-----------------------------------------------------------------------------------|---------------------|-----------------------------------------------------------------------------------------------------------------------------|
|                                                                                   | 0.0                 | Displays the output frequency (operation stopped).<br>(When standard monitor display selection $F710=0$ [output frequency]) |
|  | RUH                 | Displays the first basic parameter [History (RUH)].                                                                         |
|  | $FND$               | Turn the setting dial, and select " $FND$ ".                                                                                |
|  | 0                   | Press the center of the setting dial to read the parameter value.<br>(Standard default: 0).                                 |
|  | 1                   | Turn the setting dial to change the parameter value to 1 (terminal block VIA).                                              |
|  | $1 \Rightarrow FND$ | The parameter value is written. $FND$ and the parameter value are displayed alternately several times.                      |

\* Pressing the MODE key twice returns the display to standard monitor mode (displaying output frequency).

(1) Setting using the keypad (including extension panel option) ( $FND=0$  or 3)



: Moves the frequency up



: Moves the frequency down

■ Example of operating from the panel ( $FND=3$ : press in center to save)

| Panel operation                                                                   | LED display           | Operation                                                                                               |
|-----------------------------------------------------------------------------------|-----------------------|---------------------------------------------------------------------------------------------------------|
|                                                                                   | 0.0                   | Displays the output frequency.<br>(When standard monitor display selection $F710=0$ [output frequency]) |
|  | 50.0                  | Set the output frequency. (The frequency will not be saved if the power is turned off in this state.)   |
|  | $50.0 \Rightarrow FL$ | Save the output frequency. $FL$ and the frequency are displayed alternately.                            |

■ Example of operating from the panel ( $FND=0$ : save even if power is off)

| Panel operation                                                                    | LED display | Operation                                                                                                        |
|------------------------------------------------------------------------------------|-------------|------------------------------------------------------------------------------------------------------------------|
|                                                                                    | 0.0         | Display the output frequency.<br>(When standard monitor display selection is set as $F710=0$ [output frequency]) |
|  | 60.0        | Set the output frequency.                                                                                        |
| -                                                                                  | 60.0        | The frequency will be saved when the power is turned off in this state.                                          |

(2) Setting of frequency using external signals to terminal block ( $FND=1, 2$  or 8)  
⇒ Refer to section 7.3 for details.


(3) Switching two frequency commands ⇒ Refer to section 5.8 for details.

3.3 How to operate the VF-S15

Overview of how to operate the inverter with simple examples

Ex.1      Operation Command: Panel Operation  
Frequency Command: Setting Dial 1

(1) Wiring



(2) Parameter setting (default setting)

| Title      | Function                           | Setting value |
|------------|------------------------------------|---------------|
| <i>Fnn</i> | Command mode selection             | <i>1</i>      |
| <i>Fnn</i> | Frequency setting mode selection 1 | <i>0</i>      |

(3) Operation


Run/stop: Press the  and  keys on the panel.

Frequency setting: Turn the setting dial to set the frequency. The frequency setting is saved just by turning the setting dial.

\*1: Single-phase models are R/L1 and S/L2/N.

**Ex.2**
**Operation Command : Panel Operation**  
**Frequency Command: Setting Dial 2**

## (1) Wiring



## (2) Parameter setting

| Title       | Function                           | Setting value |
|-------------|------------------------------------|---------------|
| <i>Fn0d</i> | Command mode selection             | <i>1</i>      |
| <i>Fn0d</i> | Frequency setting mode selection 1 | <i>3</i>      |

## (3) Operation

Run/stop: Press the **RUN** and **STOP** keys on the panel.

Frequency setting: Turn the setting dial to set the frequency.

To save the frequency setting, press the center of the setting dial.

*F* *Σ* and the set frequency will flash on and off alternately, then set frequency will be retained.


The set frequency will be retained even if power supply is cut.

\*1: Single-phase models are R/L1 and S/L2/N.

### Ex.3

Operation Command: External Signal  
Frequency Command: Setting Dial

#### (1) Wiring



#### (2) Parameter setting

| Title                                                 | Function                           | Setting value                    |
|-------------------------------------------------------|------------------------------------|----------------------------------|
| $\overline{C} \overline{0} \overline{0} \overline{d}$ | Command mode selection             | $\overline{0}$                   |
| $\overline{F} \overline{0} \overline{0} \overline{d}$ | Frequency setting mode selection 1 | $\overline{0}$ or $\overline{3}$ |

#### (3) Operation

Run/stop: ON/OFF input to F-CC, R-CC. (with sink logic)

F is for forward run signal and R is for reverse run signal (default setting)


Frequency setting: Turn the setting dial to set the frequency.

\*1: Single-phase models are R/L1 and S/L2/N.

# Ex.4

Operation Command: External Signal  
Frequency Command: External Analog Signal

## (1) Wiring



## (2) Parameter setting

| Title      | Function                           | Setting value |
|------------|------------------------------------|---------------|
| <i>Fnd</i> | Command mode selection             | 0             |
| <i>Fnd</i> | Frequency setting mode selection 1 | 1, 2 or 8     |

## (3) Operation

Run/stop: ON/OFF input to F-CC, R-CC. (with sink logic)

F is for forward run signal and R is for reverse run signal (default setting)

Frequency setting: VIA: Input 0~+10V (external potentiometer), VIB: Input 0~+10V (or -10~+10Vdc) or VIC: 4(0)~20mA to set the frequency.

Set the selection of VIA, VIB or VIC in parameter *Fnd*.

VIA : *Fnd* = 1

VIB : *Fnd* = 2

VIC : *Fnd* = 8

Refer to section 7.3 for the setting of analog input characteristics.

\*1: Single-phase models are R/L1 and S/L2/N.

## 4. Setting parameters

### 4.1 Setting and Display Modes

This inverter has the following three display modes.

#### Standard monitor mode

**The standard inverter mode. This mode is enabled when inverter power goes on.**

This mode is for monitoring the output frequency and setting the frequency reference value. It also displays information about status alarms during running and trips.

- Display of output frequency, etc.  
*F 7 1 0* Initial panel display selection  
*(F 7 2 0* Initial extension panel display selection)  
*F 7 0 2* Free unit display scale

- Setting frequency reference values.
- Status alarm

If there is an error in the inverter, the alarm signal and the frequency will flash alternately in the LED display.

*C* : When a current flows at or higher than the overcurrent stall prevention level.

*P* : When a voltage is generated at or higher than the over voltage stall prevention level.

*L* : When the cumulative amount of overload reaches 50% or more of the overload trip value, or when the main circuit element temperature reaches the overload alarm level

*H* : When the overheat protection alarm level is reached

#### Setting monitor mode

**The mode for setting inverter parameters.**

⇒ How to set parameters, refer to section 4.2.

There are two parameter read modes. Refer to section 4.2 for details about selection and switching of modes.

**Easy setting mode** : Only the ten most frequently used parameters are displayed.  
 Parameters can be registered as necessary.  
 (max. 32 parameters)

**Standard setting mode** : Both basic and extended all parameters are displayed.

- Each press of the EASY key switches between the Easy setting mode and the Standard setting mode.


## Status monitor mode

**The mode for monitoring all inverter status.**

Allows monitoring of frequency command value, output current/voltage and terminal information.

⇒ Refer to chapter 8.

The inverter can be moved through each of the modes by pressing the MODE key.



## 4.2 How to set parameters

There are two types of setting monitor modes: Easy mode and Standard setting mode. The mode active when power is turned on can be selected at *PSEL* (EASY key mode selection), and the mode can be switched by the EASY key. Note, however, that the switching method differs when only the Easy mode is selected. Refer to section 4.5 for details.

Setting dial and panel key operations are as follows:



Turning the setting dial  
Used to select items and changing  
setting values. (Note)



Pressing the center of the setting dial  
Used for executing operations and determining  
setting values. (Note)

MODE

Used to select the mode and return to  
the previous menu

EASY

Used to switch between the Easy and Standard  
setting modes.

### Easy setting mode

: The mode changes to the Easy setting mode when the EASY key is pressed at the standard monitor mode and "EASY" is displayed. In the Easy setting mode, the EASY lamp lights.

Only the most frequently used 10 basic parameters are displayed at default setting.

Easy setting mode

| Title       | Function                                    |
|-------------|---------------------------------------------|
| <i>ENDD</i> | Command mode selection                      |
| <i>FREQ</i> | Frequency setting mode selection 1          |
| <i>ACC</i>  | Acceleration time 1                         |
| <i>DEC</i>  | Deceleration time 1                         |
| <i>UL</i>   | Upper limit frequency                       |
| <i>LL</i>   | Lower limit frequency                       |
| <i>ETCR</i> | Motor electronic-thermal protection level 1 |
| <i>FA</i>   | Meter adjustment gain                       |
| <i>F701</i> | Current/voltage unit selection              |
| <i>PSEL</i> | EASY key mode selection                     |

- If the EASY key is pressed while the setting dial is being turned, values continue to be incremented or decremented even if you release your finger from the setting dial. This feature is handy when setting large values.

Note) Of the available parameters, number value parameters (*ACC* etc.) are reflected in actual operation when the setting dial is turned. Note, however, that the center of the setting dial must be pressed to save values even when the power is turned off.

Note, also, that item selection parameters (*FREQ* etc.) are not reflected in actual operation by just turning the setting dial. To reflect these parameters, press the center of the setting dial.

**Standard setting mode**

: The mode changes to the Standard setting mode when the EASY key is pressed and "5 1 d" is displayed.  
Both basic and extended all parameters are displayed.

**Basic parameters**

: This parameter is a basic parameter for the operation of the inverter.

⇒ Refer to chapter 5 for details.

⇒ Refer to section 11.2 for parameter tables.

**Extended parameters**

: The parameters for detailed and special setting.

⇒ Refer to chapter 6 for details.

⇒ Refer to section 11.3 for parameter tables.


Note) There are the parameters that cannot be changed during inverter running for reasons of safety. Refer to section 11.9.

## 4.2.1 Settings in the Easy setting mode

The inverter enters this mode by pressing the MODE key when the Easy setting mode is selected

When you are unsure of something during operation:  
You can return to the Standard monitor mode by pressing the MODE key several times.

Standard monitor mode



### ■ Setting parameters in the Easy setting mode

- (1) Select parameter to be changed. (Turn the setting dial.)
- (2) Read the programmed parameter setting. (Press the center of the setting dial.)
- (3) Change the parameter value. (Turn the setting dial.)
- (4) Press this key to save the parameter value. (Press the center of the setting dial.)

- To switch to the Standard setting mode, press the EASY key in the Standard monitor mode. "5 & d" is displayed, and the mode is switched.


## 4.2.2 Settings in the Standard setting mode

The inverter enters this mode by pressing the MODE key when the Standard setting mode is selected.

When you are unsure of something during operation:  
You can return to the Standard monitor mode by pressing the MODE key several times.

### ■ How to set basic parameters

- (1) Select parameter to be changed. (Turn the setting dial.)
- (2) Read the programmed parameter setting. (Press the center of the setting dial.)
- (3) Change the parameter value. (Turn the setting dial.)
- (4) Press this key to save the parameter value. (Press the center of the setting dial.)



- To switch to the Easy setting mode, press the EASY key in the Standard monitor mode.  $ER5Y$  is displayed, and the mode is switched.

#### ■ How to set extended parameters

Each extended parameter is composed of an "F", "R" or "L" suffixed with a 3-digit figure, so first select and read out the heading of the parameter you want "F 1 - -" to "F 9 - -", "R - - -", "L - - -" ("F 1 - -": Parameter starting point is 100, "R - - -": Parameter starting point is A.)

- (5) Select the title of the parameter you want to change. (Turn the setting dial.)
- (6) Read the extended parameter. (Press the center of the setting dial.)
- (7) Select parameter to be changed. (Turn the setting dial.)
- (8) Read the programmed parameter setting. (Press the center of the setting dial.)
- (9) Change the parameter value. (Turn the setting dial.)
- (10) Press this key to save the parameter value. (Press the center of the setting dial.)

#### ■ Adjustment range and display of parameter setting value

**H** : An attempt has been made to assign a value that is higher than the programmable range.

**L** : An attempt has been made to assign a value that is lower than the programmable range.

If the above alarm is flashing on and off, values that exceed **H** or are equal or lower than **L** cannot be set.

\* A setting value of the presently-selected parameter might exceed the upper limit or the lower limit by changing other parameters.

4

## 4.3 Functions useful in searching for a parameter or changing a parameter setting

This section explains functions useful in searching for a parameter or changing a parameter setting.

Changed parameters history search (History function) **RUH**

This function automatically searches for the last five parameters whose settings have been changed. To use this function, select the **RUH** parameter. (The changed parameters are displayed regardless of difference with the default settings.)

⇒ Refer to section 6.1.1 for details.

Easy setting parameters according to application (Application easy setting) **RUH**

The necessary parameter for your machine can be easily set.

Select the machine by parameter **RUH** and set by using the easy setting mode.

⇒ Refer to section 6.1.2 for details.

Set parameters by purpose (Guidance function) **RUF**

Only parameters required for a special purpose can be called up and set.

To use this function, select parameter **RUF**.

⇒ Refer to section 6.1.3 for details.

Reset parameters to default settings **LYP**

Use the **LYP** parameter to reset all parameters back to the default settings. To use this function, set parameter **LYP = 3** or **13**.

⇒ Refer to section 4.3.2 for details.

Call saved customer settings **LYP**

Customer settings can be batch-saved and batch-called.

These settings can be used as customer-exclusive default settings.

To use this function, set parameter **LYP = 7** or **8**.

⇒ Refer to section 4.3.2 for details.

Search changed parameters **GRU**

Automatically searches for only those parameters that are programmed with values different from the default setting.

To use this function, select the **GRU** parameter.

⇒ Refer to section 4.3.1 for details.

## 4.3.1 Searching for and resetting changed parameters

**GRU**: Automatic edit function

### • Function

Automatically searches for only those parameters that are programmed with values different from the default setting and displays them in the **GRU**. Parameter setting value can also be changed while searching.

Note 1: If you reset a parameter to its factory default, the parameter will no longer appear in **GRU**.

Note 2: It may take several seconds to display changed parameters because all data stored in **GRU** is checked against the default settings. To cancel a parameter search, press the MODE key.

Note 3: Parameters which cannot be reset to the default setting after setting **LYP** to **3** are not displayed.

⇒ Refer to section 4.3.2 for details.

■ How to search and reprogram parameters

| Panel operation                                                                                                                                                                                                                                             | LED display                                                                                | Operation                                                                                                                                                                                                                                                                                                             |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                                                                             | 0.0                                                                                        | Displays the output frequency (operation stopped).<br>(When standard monitor display selection is set as $F \nabla 10=0$ [output frequency])                                                                                                                                                                          |
|                                                                                                                                                                            | RUH                                                                                        | Displays the first basic parameter "History function (RUH)."                                                                                                                                                                                                                                                          |
|                                                                                                                                                                            | CUU                                                                                        | Turn the setting dial, and select CUU.                                                                                                                                                                                                                                                                                |
|                                                                                                                                                                            | U - -                                                                                      | Press the center of the setting dial to enter the user parameter setting change search mode.                                                                                                                                                                                                                          |
|  or                                                                                       | ACC                                                                                        | Searches for and displays parameters different to the default settings. Parameters are changed by either pressing the center of the setting dial or turning it to the right. (Turning the setting dial to the left searches for parameter in the reverse direction.)                                                  |
|                                                                                                                                                                            | 8.0                                                                                        | Press the center of the setting dial to display set values.                                                                                                                                                                                                                                                           |
|                                                                                                                                                                            | 5.0                                                                                        | Turn the setting dial, and change set values.                                                                                                                                                                                                                                                                         |
|                                                                                                                                                                            | 5.0 $\leftrightarrow$ ACC                                                                  | Press the center of the setting dial to set values. The parameter name and set value light alternately and are written.                                                                                                                                                                                               |
|                                                                                                                                                                            | U - - F<br>(U - - r)                                                                       | Use the same steps as those above and turn the setting dial to display parameters to search for or whose settings must be changed, and check or change the parameter settings.                                                                                                                                        |
|                                                                                                                                                                            | CUU                                                                                        | When CUU appears again, the search is ended.                                                                                                                                                                                                                                                                          |
| <br><br> | Parameter display<br>$\downarrow$<br>CUU<br>$\downarrow$<br>F r - F<br>$\downarrow$<br>0.0 | A search can be canceled by pressing the MODE key. Press the key once while the search is underway to return to the display of parameter setting mode. Returns to the CUU display.<br>After that press the MODE key and return to the status monitor mode or the standard monitor mode (display of output frequency). |

### 4.3.2 Return to default settings

#### **Ⓕ Ⓙ Ⓟ**: Default setting

- Function

It is possible to return groups of parameters to their defaults, clear run times, and record/recall set parameters.

[Parameter setting]

| Title | Function        | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                   | Default setting |
|-------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Ⓕ Ⓙ Ⓟ | Default setting | 0: -<br>1: 50Hz default setting<br>2: 60Hz default setting<br>3: Default setting 1 (Initialization)<br>4: Trip record clear<br>5: Cumulative operation time clear<br>6: Initialization of type information<br>7: Save user setting parameters<br>8: Load user setting parameters<br>9: Cumulative fan operation time record clears<br>10, 11: -<br>12: Number of starting clear<br>13: Default setting 2 (complete initialization) | 0               |

- This function will be displayed as 0 during reading on the right. This previous setting is displayed **on the left**.

Example: **3 0**

- Ⓕ Ⓙ Ⓟ cannot be set during the inverter operating. Always stop the inverter first and then program.

#### Programmed value

50 Hz default setting (Ⓕ Ⓙ Ⓟ = 1)

Setting Ⓕ Ⓙ Ⓟ to 1 sets the following parameters for base frequency 50 Hz use.

(The setting values of other parameters are not changed.)

- |                                                        |                                                                        |
|--------------------------------------------------------|------------------------------------------------------------------------|
| • Maximum frequency (F H) : 50Hz                       | • Upper limit frequency (U L) : 50Hz                                   |
| • Base frequency 1 (u L) : 50Hz                        | • Base frequency 2 (F 1 7 0) : 50Hz                                    |
| • VIA input point 2 frequency (F 2 0 4) : 50Hz         | • VIB input point 2 frequency (F 2 1 3) : 50Hz                         |
| • VIC input point 2 frequency (F 2 1 9) : 50Hz         | • Automatic light-load high-speed operation frequency (F 3 3 0) : 50Hz |
| • Process upper limit (F 3 5 7) : 50Hz                 | • Communication command point 2 frequency (F 8 1 4) : 50Hz             |
| • Motor rated speed (F 4 1 7) : 1410 min <sup>-1</sup> |                                                                        |

60 Hz default setting ( $\text{tYP} = 2$ )

Setting  $\text{tYP}$  to 2 sets the following parameters for base frequency 60 Hz use.

(The setting values of other parameters are not changed.)

- |                                          |                          |                                                                  |        |
|------------------------------------------|--------------------------|------------------------------------------------------------------|--------|
| • Maximum frequency ( $FH$ )             | : 60Hz                   | • Upper limit frequency ( $UL$ )                                 | : 60Hz |
| • Base frequency 1 ( $\omega L$ )        | : 60Hz                   | • Base frequency 2 ( $F170$ )                                    | : 60Hz |
| • VIA input point 2 frequency ( $F204$ ) | : 60Hz                   | • VIB input point 2 frequency ( $F213$ )                         | : 60Hz |
| • VIC input point 2 frequency ( $F219$ ) | : 60Hz                   | • Automatic light-load high-speed operation frequency ( $F330$ ) | : 60Hz |
| • Process upper limit ( $F367$ )         | : 60Hz                   | • Communication command point 2 frequency ( $F814$ )             | : 60Hz |
| • Motor rated speed ( $F417$ )           | : 1710 $\text{min}^{-1}$ |                                                                  |        |

Default setting 1 ( $\text{tYP} = 3$ )

Setting  $\text{tYP}$  to 3 will return parameters to the default settings (exclusive of some parameters).

- When 3 is set,  $\text{tn1L}$  is displayed for a short time after the settings are configured, and then disappears. Then the inverter is in standard motor mode. In this case, the trip history data is cleared.

Be aware that the following parameters do not return to the default settings even if  $\text{tYP} = 3$  is set for maintainability. (To initialize all parameters, set  $\text{tYP} = 13$ )

- |                                                   |                                                        |
|---------------------------------------------------|--------------------------------------------------------|
| • $RU L$ : Overload characteristic selection      | • $F470 \sim F475$ : VIA/VIB/VIC input bias / gain     |
| • $FAS L$ : Meter selection                       | • $F669$ : Logic output/pulse train output selection   |
| • $FAN$ : Meter adjustment gain                   | • $F681$ : Analog output signal selection              |
| • $SEL$ : Checking the region setting             | • $F691$ : Inclination characteristic of analog output |
| • $F107$ : Analog input terminal selection        | • $F692$ : Analog output bias                          |
| • $F109$ : Analog/logic input selection (VIA/VIB) | • $F880$ : Free notes                                  |

\* Refer to "Communication manual" about parameter  $\text{Cxxx}$ .

Trip record clear ( $\text{tYP} = 4$ )

Setting  $\text{tYP}$  to 4 initializes the past eight sets of recorded error history data.

- The parameter does not change.

Cumulative operation time clear ( $\text{tYP} = 5$ )

Setting  $\text{tYP}$  to 5 resets the cumulative operation time to the initial value (zero).

Initialization of type information ( $\text{tYP} = 6$ )

Setting  $\text{tYP}$  to 6 clears the trips when an  $E\text{tYP}$  format error occurs. But if the  $E\text{tYP}$  displayed, contact your Toshiba distributor.

**Save user setting parameters (t Y P = 7)**

Setting t Y P to 7 saves the current settings of all parameters.

**Load user setting parameters (t Y P = 8)**

Setting t Y P to 8 loads parameter settings to (calls up) those saved by setting t Y P to 7.

\* By setting t Y P to 7 or 8, you can use parameters as your own default parameters.

**Cumulative fan operation time record clear (t Y P = 9)**

Setting t Y P to 9 resets the cumulative operation time to the initial value (zero).

Set this parameter when replacing the cooling fan, and so on

**Number of starting clear (t Y P = 12)**

Setting t Y P to 12 resets the number of starting to the initial value (zero).

**Default setting 2 (t Y P = 13)**

Set t Y P to 13 to return all parameters to their default settings.

When 13 is set, **13 13** is displayed for a short time after the settings are configured, and then disappears. Then setup menu **5 E t** is displayed. After reviewing the setup menu items, make a setup menu selection. In this case, all parameters are returned to their defaults, and the trip history data is cleared. (Refer to section 3.1)

## 4.4 Checking the region settings selection

**SET**: Checking the region setting

- Function

The region selected on the setup menu can be checked.

Also, the setup menu starts and can be changed to a different region.

[Parameter setting]

| Title | Function                    | Adjustment range                                                                                                            | Default setting |
|-------|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------|-----------------|
| SET   | Checking the region setting | 0: Start setup menu<br>1: Japan (read only)<br>2: North America (read only)<br>3: Asia (read only)<br>4: Europe (read only) | 1 *             |

\* Default setting values vary depending on the setup menu setting. 1 to 4 are displayed.

### ■ Content of region settings

The number displayed when parameter SET is read indicates which of the following regions was selected on the setup menu.

4: EU (Europe) is selected on the setup menu.

3: ASIA (Asia, Oceania) is selected on the setup menu.

2: USA (North America) is selected on the setup menu.

1: JP (Japan) is selected on the setup menu.

The setup menu is started by setting SET=0.

Refer to section 3.1 for details.

Note: 1 to 4 set to parameter SET are read-only. They cannot be written.

## 4.5 EASY key function

**PSEL** : EASY key mode selection

**F750** : EASY key function selection

**F751** to **F782** : Easy setting mode parameter 1 to 32

### • Function

It is possible to switch between standard mode and easy setting mode using the EASY key. (default setting)  
Up to 32 arbitrary parameters can be registered to easy setting mode.

The EASY key can select following four functions.

- Easy / Standard setting mode switching function
- Shortcut key function
- Local / Remote switching function
- Peak hold function

[Parameter setting]

| Title       | Function                    | Adjustment range                                                                                                                                    | Default setting |
|-------------|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>PSEL</b> | EASY key mode selection     | 0: Standard setting mode at power on<br>1: Easy setting mode at power on<br>2: Easy setting mode only                                               | 0               |
| <b>F750</b> | EASY key function selection | 0: Easy / standard setting mode switching function<br>1: Shortcut key<br>2: Local / remote key<br>3: Monitor peak / minimum hold trigger<br>4, 5: - | 0               |

### ■ Easy / Standard setting mode switching function (**F750=0**): Default setting

It is possible to switch between standard mode and easy setting mode when you push the EASY key while the inverter is stopping.

Standard setting mode is selected when the power is turned on at default setting.

The way parameters are read out and displayed varies according to the mode selected.

### Easy setting mode

Allows pre-registration (easy setting mode parameters) of frequently changed parameters and reading of only registered parameters (maximum of 32 types).

In the Easy setting mode, the EASY key lamp lights.

### Standard setting mode

Standard setting mode in which all parameters are read out.

[How to read out parameters]

Use the EASY key to change between Easy setting mode and Standard setting mode, and then press the MODE key to enter the setting monitor mode.

Turn the setting dial to read the parameter.

The relation between the parameter and the mode selected is shown below.

**PSEL=0**

- \* When the power is turned on, the inverter is in standard mode. Press the EASY key to switch to easy setting mode.

**PSEL=1**

- \* When the power is turned on, the inverter is in easy setting mode. Press the EASY key to switch to standard mode.

**PSEL=2**

- \* Always in easy setting mode.

However, it can be switched to standard setting mode by EASY key if it is set to  $PSEL=0, 1$ . When  $PSEL$  is not displayed in Easy setting mode,  $U_n d Q$  is displayed and it can be temporarily switched to standard setting mode by EASY key after center of the setting dial is pushed for five seconds or more.

[How to select parameters]

Select the desired parameters as easy setting mode parameters 1 to 32 (*F 75 1* to *F 78 2*). Note that parameters should be specified by communication number. For communication numbers, refer to Table of parameters.

In easy setting mode, only parameters registered to parameters 1 to 32 are displayed in order of registration.

The values of the default settings are shown in the table below.

[Parameter setting]

| Title         | Function                       | Adjustment range                               | Default setting             |
|---------------|--------------------------------|------------------------------------------------|-----------------------------|
| <i>F 75 1</i> | Easy setting mode parameter 1  | <i>0-2999</i>                                  | <i>3 (END)</i>              |
| <i>F 75 2</i> | Easy setting mode parameter 2  | <i>0-2999</i>                                  | <i>4 (FND)</i>              |
| <i>F 75 3</i> | Easy setting mode parameter 3  | <i>0-2999</i>                                  | <i>9 (ACC)</i>              |
| <i>F 75 4</i> | Easy setting mode parameter 4  | <i>0-2999</i>                                  | <i>10 (dEC)</i>             |
| <i>F 75 5</i> | Easy setting mode parameter 5  | <i>0-2999</i>                                  | <i>12 (UL)</i>              |
| <i>F 75 6</i> | Easy setting mode parameter 6  | <i>0-2999</i>                                  | <i>13 (LL)</i>              |
| <i>F 75 7</i> | Easy setting mode parameter 7  | <i>0-2999</i>                                  | <i>600 (tHr)</i>            |
| <i>F 75 8</i> | Easy setting mode parameter 8  | <i>0-2999</i>                                  | <i>6 (Fn)</i>               |
| <i>F 75 9</i> | Easy setting mode parameter 9  | <i>0-2999</i><br>(Set by communication number) | <i>999</i><br>(No function) |
| <i>F 76 0</i> | Easy setting mode parameter 10 |                                                |                             |
| <i>F 76 1</i> | Easy setting mode parameter 11 |                                                |                             |
| <i>F 76 2</i> | Easy setting mode parameter 12 |                                                |                             |
| <i>F 76 3</i> | Easy setting mode parameter 13 |                                                |                             |
| <i>F 76 4</i> | Easy setting mode parameter 14 |                                                |                             |
| <i>F 76 5</i> | Easy setting mode parameter 15 |                                                |                             |
| <i>F 76 6</i> | Easy setting mode parameter 16 |                                                |                             |
| <i>F 76 7</i> | Easy setting mode parameter 17 |                                                |                             |
| <i>F 76 8</i> | Easy setting mode parameter 18 |                                                |                             |
| <i>F 76 9</i> | Easy setting mode parameter 19 |                                                |                             |
| <i>F 77 0</i> | Easy setting mode parameter 20 |                                                |                             |
| <i>F 77 1</i> | Easy setting mode parameter 21 |                                                |                             |
| <i>F 77 2</i> | Easy setting mode parameter 22 |                                                |                             |
| <i>F 77 3</i> | Easy setting mode parameter 23 |                                                |                             |
| <i>F 77 4</i> | Easy setting mode parameter 24 |                                                |                             |
| <i>F 77 5</i> | Easy setting mode parameter 25 |                                                |                             |
| <i>F 77 6</i> | Easy setting mode parameter 26 |                                                |                             |
| <i>F 77 7</i> | Easy setting mode parameter 27 |                                                |                             |
| <i>F 77 8</i> | Easy setting mode parameter 28 |                                                |                             |
| <i>F 77 9</i> | Easy setting mode parameter 29 |                                                |                             |
| <i>F 78 0</i> | Easy setting mode parameter 30 |                                                |                             |
| <i>F 78 1</i> | Easy setting mode parameter 31 | <i>0-2999</i>                                  | <i>701 (F 70 1)</i>         |
| <i>F 78 2</i> | Easy setting mode parameter 32 | <i>0-2999</i>                                  | <i>50 (PSEL)</i>            |

Note: If any number other than communication numbers is specified, it is regarded as *999* (no function assigned).

### ■ Shortcut key function ( $F750=1$ )

This function allows you to register, in a shortcut list, parameters whose settings need to be changed frequently so that you can read them out easily in a single operation.

The shortcut is usable in the frequency monitor mode only.

[Operation]

Set  $F750$  to  $1$ , read out the setting of the parameter you want to register, and press and hold down the EASY key for 2 seconds or more. The registration of the parameter in a shortcut list has been completed.

To read out the parameter, just press the EASY key.

### ■ Local / Remote switching ( $F750=2$ )

This function allows you to easily switch between panel operation and external operation.


To switch between control device, set  $F750$  to  $2$ , and then select the desired control device, using the EASY key.

If bumpless operation selection  $F295$  is set to  $1$  (Enabled), it can be switched during operation.

Local means panel operation.

Remote means the operation that is selected by command mode selection:  $ENQd$  and frequency setting mode selection:  $FNQd$  ( $F207$ ).

In the Local mode, the EASY key lamp lights.



Note) Please note that if set the parameter  $F750$  to  $0$  in local mode, the panel operation state holds and it becomes different from setting of  $ENQd$ .

### ■ Peak hold function ( $F750=3$ )

This function allows you to set peak hold and minimum hold triggers for parameters  $F709$ , using the EASY key.

The measurement of the minimum and maximum values set for  $F709$  starts the instant when you press the EASY key after setting  $F750$  to  $3$ .

The peak hold and minimum hold values are displayed in absolute values.

## 5. Main parameters

Here are described main parameters you set before use according to the section 11. Tables of parameters and data.

### 5.1 Meter setting and adjustment

**FN5L**: Meter selection

**FN**: Meter adjustment gain

- Function  
Output of 0 - 1mAdc, 0 (4) - 20mAdc, 0 - 10vdc can be selected for the output signal from the FM terminal, depending on the **FSB** setting. Adjust the scale at **FN**.  
Use an ammeter with a full-scale 0 - 1mAdc meter.  
The **FSG** (analog output bias) needs to be adjusted if output is 4 - 20mAdc.

Parameter setting


| Title       | Function              | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Supposition output at<br><b>FN5L=17</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Default setting |
|-------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>FN5L</b> | Meter selection       | 0: Output frequency<br>1: Output current<br>2: Frequency command value<br>3: Input voltage (DC detection)<br>4: Output voltage (command value)<br>5: Input power<br>6: Output power<br>7: Torque<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency<br>13: VIA input value<br>14: VIB input value<br>15: Fixed output 1<br>(output current 100% equivalent)<br>16: Fixed output 2<br>(output current 50% equivalent)<br>17: Fixed output 3<br>(Other than the output current)<br>18: RS485 communication data<br>19: For adjustments ( <b>FN</b> set value is displayed.)<br>20: VIC input value<br>21, 22: -<br>23: PID feedback value<br>24: Integral input power<br>25: Integral output power | Maximum frequency ( <b>FH</b> )<br>-<br>Maximum frequency ( <b>FH</b> )<br>1.5x rated voltage<br>1.5x rated voltage<br>1.85x rated power<br>1.85x rated power<br>2.5x rated torque<br>-<br>Rated load factor<br>Rated load factor<br>Rated load factor<br>Maximum frequency ( <b>FH</b> )<br>Maximum input value<br>Maximum input value<br>-<br>-<br>-<br>Maximum value (100.0%)<br>-<br>Maximum input value<br>-<br>Maximum frequency ( <b>FH</b> )<br>1000x <b>F749</b><br>1000x <b>F749</b> | 0               |
| <b>FN</b>   | Meter adjustment gain | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | -               |

■ Resolution: All FM terminals have a maximum of 1/1000.

## ■ Adjustment scale with parameter $F\bar{n}$ (Meter adjustment)


Connect meters as shown below.

<Displaying output frequency>



\* Optional QS-60T frequency meter is available.

<Displaying output current>



\* Meter with a maximum scale of 1.5x the inverter's rated output current is recommended.


[Example of how to adjust the FM terminal frequency meter]

\* Use the meter's adjustment screw to pre-adjust zero-point.

\* Adjust  $F691$  and  $F692$  in advance in case of 4-20mA output.

| Operation panel action | LED display                       | Operation                                                                                                                                                                                                |
|------------------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| -                      | 50.0                              | Displays the output frequency.<br>(When standard monitor display selection $F710$ is set to 0)                                                                                                           |
| MODE                   | RUH                               | The first basic parameter "RUH" (history function) is displayed.                                                                                                                                         |
|                        | $F\bar{n}$                        | Turn the setting dial to select $F\bar{n}$ .                                                                                                                                                             |
|                        | 50.0                              | Output frequency can be displayed by pressing the center of the setting dial.                                                                                                                            |
|                        | 50.0                              | Turn the setting dial to adjust the meter.<br><u>The meter's indicator will change by turning setting dial.</u><br>(The inverter displays output frequency and it will not change with the setting dial) |
|                        | 50.0 $\leftrightarrow$ $F\bar{n}$ | Press the center of the setting dial to save the meter's adjustments.<br>$F\bar{n}$ and the frequency are displayed alternately.                                                                         |
| MODE + MODE            | 50.0                              | The display returns to displaying output frequency.<br>(When standard monitor display selection $F710$ is set to 0 [output frequency])                                                                   |

- Example of 4-20mA output adjustment (Refer to section 6.33.3 for details)



Note 1) When using the FM terminal for current output, be sure that the external load resistance is less than 600Ω.

Use over 1kΩ external load resistance for voltage output.

Note 2)  $F\bar{n}5\bar{L} = 1\bar{2}$  is the motor drive frequency.

## Adjusting the meter in inverter stop state

- Adjustment of the meter for output current ( $F\bar{n}5\bar{L} = 1$ )

Adjustment of the meter for output current can be done in inverter stop state.

When setting  $F\bar{n}5\bar{L}$  to  $1\bar{5}$  for fixed output 1 (output current 100% equivalent), a signal assuming that inverter rated current (output current 100% equivalent) passes will be output from the FM terminal.

Adjust the meter with the  $F\bar{n}$  (Meter adjustment) parameter in this state.

Similarly, if you set  $F\bar{n}5\bar{L}$  to  $1\bar{6}$  for fixed output 2 (output current 50% equivalent), a signal assuming that 50% of inverter rated current (output current 50% equivalent) passes will be output from the FM terminal.

After meter adjustment is ended, set  $F\bar{n}5\bar{L}$  to  $1$  (output current).

- Other adjustments ( $F\bar{n}5\bar{L} = 0, 2$  to  $7, 9$  to  $14, 18, 20, 23$  to  $25$ )

$F\bar{n}5\bar{L} = 1\bar{7}$ : When fixed output 3 (other than the output current) is set, a signal of the value for other monitors is fixed at the following values and output through the FM terminal.

100% standard value for each item is the following:

|                                   |                                      |
|-----------------------------------|--------------------------------------|
| $F\bar{n}5\bar{L} = 0, 2, 12, 23$ | : Maximum frequency ( $F\bar{H}$ )   |
| $F\bar{n}5\bar{L} = 3, 4$         | : 1.5 times of rated voltage         |
| $F\bar{n}5\bar{L} = 7$            | : 2.5 times of rated torque          |
| $F\bar{n}5\bar{L} = 9$ to $11$    | : Rated load factor                  |
| $F\bar{n}5\bar{L} = 13, 14, 20$   | : Maximum input value (10V, or 20mA) |
| $F\bar{n}5\bar{L} = 18$           | : Maximum value (100.0%)             |
| $F\bar{n}5\bar{L} = 24, 25$       | : 1000x $F\bar{7}4\bar{9}$           |


## 5.2 Setting acceleration/deceleration time

**ACC**: Acceleration time 1 **F519**: Setting of acceleration/deceleration time unit

**DEC**: Deceleration time 1 **RU1**: Automatic acceleration/deceleration

• Function

- 1) For acceleration time 1 **ACC** programs the time that it takes for the inverter output frequency to go from 0.0Hz to maximum frequency **FH**.
- 2) For deceleration time 1 **DEC** programs the time that it takes for the inverter output frequency to go from maximum frequency **FH** to 0.0Hz.



[Parameter setting]

| Title       | Function                                       | Adjustment range                                                                | Default setting |
|-------------|------------------------------------------------|---------------------------------------------------------------------------------|-----------------|
| <b>ACC</b>  | Acceleration time 1                            | 0.0-3600 (360.0) (s)                                                            | 10.0            |
| <b>DEC</b>  | Deceleration time 1                            | 0.0-3600 (360.0) (s)                                                            | 10.0            |
| <b>F519</b> | Setting of acceleration/deceleration time unit | 0: -<br>1: 0.01s unit (after execution: 0)<br>2: 0.1s unit (after execution: 0) | 0               |

Note1): Setting increment unit can be changed to 0.01 seconds by parameter **F519**.

Note2): **F519=2**: When the acceleration/deceleration time is set to 0.0 seconds, the inverter accelerates and decelerates 0.05 seconds.


**F519=1**: When the acceleration/deceleration time is set to 0.00 seconds, the inverter accelerates and decelerates 0.01 seconds.

- If the programmed value is shorter than the optimum acceleration/deceleration time determined by load conditions, overcurrent stall or overvoltage stall function may make the acceleration/deceleration time longer than the programmed time. If an even shorter acceleration/deceleration time is programmed, there may be an overcurrent trip or overvoltage trip for inverter protection. (Refer to section 13.1 for details)

## 5.3 Maximum frequency

**$FH$** : Maximum frequency

- Function
  - 1) Programs the range of frequencies output by the inverter (maximum output values).
  - 2) This frequency is used as the reference for acceleration/deceleration time.



This function determines the value in line with the ratings of the motor and load.

Maximum frequency cannot be adjusted during operation. To adjust, first stop the inverter.

- If  $FH$  is increased, adjust the upper limit frequency  $UL$  as necessary.

[Parameter setting]

| Title | Function          | Adjustment range | Default setting |
|-------|-------------------|------------------|-----------------|
| $FH$  | Maximum frequency | 30.0-500.0 (Hz)  | 80.0            |


## 5.4 Upper limit and lower limit frequencies

$\overline{UL}$ : Upper limit frequency

$\overline{LL}$ : Lower limit frequency

- Function

Programs the lower limit frequency that determines the lower limit of the output frequency and the upper limit frequency that determines the upper limit of that frequency.



[Parameter setting]

| Title           | Function              | Adjustment range           | Default setting |
|-----------------|-----------------------|----------------------------|-----------------|
| $\overline{UL}$ | Upper limit frequency | 0.5 - F H (Hz)             | *1              |
| $\overline{LL}$ | Lower limit frequency | 0.0 - $\overline{UL}$ (Hz) | 0.0             |

\* 1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

Note1) Do not set a value 10 times larger than  $\overline{UL}$  (base frequency 1) and F 1 7 0 (base frequency 2) for  $\overline{UL}$ .

If a large number is set, the output frequency can only be output at 10 times of minimum value  $\overline{UL}$  and F 1 7 0 and R-0 5 alarm is displayed.

Note2) Output frequency lower than parameter F 2 4 0 (Starting frequency) is not output. Parameter F 2 4 0 setting is needed.


## 5.5 Base frequency

**U L**: Base frequency 1

**U L U**: Base frequency voltage 1

- Function  
Set the base frequency and the base frequency voltage in conformance with load specifications or the base frequency.

Note: This is an important parameter that determines the constant torque control area.



[Parameter setting]

| Title        | Function                | Adjustment range                           | Default setting |
|--------------|-------------------------|--------------------------------------------|-----------------|
| <b>U L</b>   | Base frequency 1        | 20.0-500.0 (Hz)                            | *1              |
| <b>U L U</b> | Base frequency voltage1 | 50-330 (240V class)<br>50-660 (500V class) | *1              |

\* 1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

## 5.6 Setting the electronic thermal

***PUL*** : Overload characteristic selection

***ELr*** : Motor electronic-thermal protection level 1

***OLn*** : Electronic-thermal protection characteristic selection

***F173*** : Motor electronic-thermal protection level 2

***F607*** : Motor 150% overload detection time

***F631*** : Inverter overload detection method

***F632*** : Electronic-thermal memory

***F657*** : Overload alarm level

• Function

This parameter allows selection of the appropriate electronic thermal protection characteristics according to the particular rating and characteristics of the motor.

[Parameter setting]

| Parameter setting |                                                        | Adjustment range                                                                                        |                          |                     |                | Default setting |
|-------------------|--------------------------------------------------------|---------------------------------------------------------------------------------------------------------|--------------------------|---------------------|----------------|-----------------|
| Title             | Function                                               |                                                                                                         |                          |                     |                |                 |
| <i>PUL</i>        | Overload characteristic selection                      | 0: ~ *4<br>1: Constant torque characteristic (150%-60s)<br>2: Variable torque characteristic (120%-60s) |                          |                     |                | 0               |
| <i>ELr</i>        | Motor electronic-thermal protection level 1            | 10 – 100 (%) / (A) *1                                                                                   |                          |                     |                | 100             |
| <i>OLn</i>        | Electronic-thermal protection characteristic selection | Setting value                                                                                           |                          | Overload protection | Overload stall | 0               |
|                   |                                                        | 0                                                                                                       | Standard motor           | valid               | invalid        |                 |
|                   |                                                        | 1                                                                                                       |                          | valid               | valid          |                 |
|                   |                                                        | 2                                                                                                       |                          | invalid             | invalid        |                 |
|                   |                                                        | 3                                                                                                       |                          | invalid             | valid          |                 |
|                   |                                                        | 4                                                                                                       | VF motor (special motor) | valid               | invalid        |                 |
|                   |                                                        | 5                                                                                                       |                          | valid               | valid          |                 |
|                   |                                                        | 6                                                                                                       |                          | invalid             | invalid        |                 |
| 7                 | invalid                                                | valid                                                                                                   |                          |                     |                |                 |
| <i>F173</i>       | Motor electronic-thermal protection level 2            | 10 – 100 (%) / (A) *1                                                                                   |                          |                     |                | 100             |
| <i>F607</i>       | Motor 150% overload detection time                     | 10 – 2400 (s)                                                                                           |                          |                     |                | 300             |
| <i>F631</i>       | Inverter overload detection method                     | 0: 150%-60s (120%-60s)<br>1: Temperature estimation                                                     |                          |                     |                | 0               |

[Parameter setting]

| Title     | Function                  | Adjustment range                                                                                                                                                       | Default setting |
|-----------|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| $F 6 3 2$ | Electronic-thermal memory | 0: Disabled ( $\mathcal{E} H r$ , $F 1 7 3$ )<br>1: Enabled ( $\mathcal{E} H r$ , $F 1 7 3$ )<br>2: Disabled ( $\mathcal{E} H r$ )<br>3: Enabled ( $\mathcal{E} H r$ ) | 0               |
| $F 6 5 7$ | Overload alarm level      | 10-100                                                                                                                                                                 | 50              |

\*1: The inverter's rated current is 100%. When  $F 7 0 1$  (current/voltage unit selection) = 1 (A (amps)/V (volts)) is selected, it can be set at A (amps).

\*2:  $F 6 3 2$  = 1: Electronic-thermal statuses (cumulative overload value) of motor and inverter are saved when power supply is OFF. It is calculated from the saved value when power supply is ON again.

\*3: Parameter  $R U L$  is displayed as "0" during reading after this is set.

Present setting of inverter overload characteristic can be confirmed by status monitor.

Refer to monitor "Overload and region setting" of section 8.2.1.

## 1) Setting the electronic thermal protection characteristics selection $\mathcal{O} L \mathcal{N}$ and motor electronic thermal protection level 1 $\mathcal{E} H r$ , 2 $F 1 7 3$

The electronic thermal protection characteristics selection ( $\mathcal{O} L \mathcal{N}$ ) is used to enable or disable the motor overload trip function ( $\mathcal{O} L 2$ ) and the overload stall function.

While the inverter overload trip ( $\mathcal{O} L 1$ ) will be in constantly detective operation, the motor overload trip ( $\mathcal{O} L 2$ ) can be selected using the parameter  $\mathcal{O} L \mathcal{N}$ .

### Explanation of terms

Overload stall: This is an optimum function for equipment such as fans, pumps and blowers with variable torque characteristics that the load current decreases as the operating speed decreases.

When the inverter detects an overload, this function automatically lowers the output frequency before the motor overload trip ( $\mathcal{O} L 2$ ) is activated. With this function, operation can be continued, without tripping, by operating using a frequency balanced by load current.

Note: Do not use the overload stall function with loads having constant torque characteristics (such as conveyor belts in which load current is fixed with no relation to speed).

## [Using standard motors (other than motors intended for use with inverters)]

When a motor is used in the lower frequency range than the rated frequency, that will decrease the cooling effects for the motor. This speeds up the start of overload detection operations when a standard motor is used in order to prevent overheating.

## ■ Setting of electronic thermal protection characteristics selection $\overline{OL\overline{n}}$


| Setting value  | Overload protection | Overload stall |
|----------------|---------------------|----------------|
| $\overline{0}$ | valid               | invalid        |
| $\overline{1}$ | valid               | valid          |
| $\overline{2}$ | invalid             | invalid        |
| $\overline{3}$ | invalid             | valid          |

## ■ Setting of motor electronic thermal protection level $\overline{1\overline{tHr}}$ (Same as $\overline{F1\overline{t3}}$ )

When the capacity of the motor in use is smaller than the capacity of the inverter, or the rated current of the motor is smaller than the rated current of the inverter, adjust thermal protection level  $\overline{1\overline{tHr}}$  for the motor in accordance with the motor's rated current.

\* When displaying as a percentage, 100% = rated output current (A) of the inverter is displayed.

Output current reduction factor  
[%]/[A]



Note: The motor overload protection start level is fixed at 30Hz.

[Example of setting: When the VFS15-2007PM-W is running with a 0.4kW motor having 2A rated current]

| Operation panel action   | LED display                                    | Operation                                                                                                                                                                             |
|--------------------------|------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                          | $\overline{0.0}$                               | Displays the output frequency. (Perform during operation stopped.) (When standard monitor display selection $\overline{F1\overline{t3}}$ is set to $\overline{0}$ [output frequency]) |
| $\overline{\text{MODE}}$ | $\overline{RUH}$                               | The first basic parameter "RUH" (history function) is displayed.                                                                                                                      |
|                          | $\overline{tHr}$                               | Turn the setting dial to change the parameter to $\overline{tHr}$ .                                                                                                                   |
|                          | $\overline{100}$                               | Parameter values can be read by pressing the center of the setting dial (default setting is 100%).                                                                                    |
|                          | $\overline{42}$                                | Turn the setting dial to change the parameter to $\overline{42\%}$ (= motor rated current/inverter rated output current $\times 100 = 2.0/4.8 \times 100$ )                           |
|                          | $\overline{42} \leftrightarrow \overline{tHr}$ | Press the center of the setting dial to save the changed parameter. $\overline{tHr}$ and the parameter are displayed alternately.                                                     |

Note: The rated output current of the inverter should be calculated from the rated output current for frequencies below 4kHz, regardless of the setting of the PWM carrier frequency parameter ( $\overline{F300}$ ).

[Using a VF motor (motor for use with inverter)]

■ Setting of electronic thermal protection characteristics selection **0 L n**

| Setting value | Overload protection | Overload stall |
|---------------|---------------------|----------------|
| 4             | valid               | invalid        |
| 5             | valid               | valid          |
| 6             | invalid             | invalid        |
| 7             | invalid             | valid          |


VF motors (motors designed for use with inverters) can be used in frequency ranges lower than those for standard motors, but their cooling efficiency decreases at frequencies below 6Hz.

■ Setting of motor electronic thermal protection level 1 **0 H r** (Same as **F 1 7 3**)

If the capacity of the motor is smaller than the capacity of the inverter, or the rated current of the motor is smaller than the rated current of the inverter, adjust the electronic thermal protection level 1 **0 H r** so that it fits the motor's rated current.

\* If the indications are in percentages (%), then 100% equals the inverter's rated output current (A).

Output current reduction factor [%]/[A]



Note) The start level for motor overload reduction is fixed at 6 Hz.

2) Motor 150%-overload detection time **F 6 0 7**

Parameter **F 6 0 7** is used to set the time elapsed before the motor trips under a load of 150% (overload trip **0 L 2**) within a range of 10 to 2400 seconds.

3) Inverter overload detection method **F 6 3 1**

As this function is set to protect the inverter unit, this function cannot be turned off by parameter setting.

The inverter overload detection method can be selected using parameter **F 6 3 1** (Inverter overload detection method).


[Parameter setting]

| Title          | Function                           | Adjustment range                                    | Default setting |
|----------------|------------------------------------|-----------------------------------------------------|-----------------|
| <b>F 6 3 1</b> | Inverter overload detection method | 0: 150%-60s (120%-60s)<br>1: Temperature estimation | 0               |

If the inverter overload trip function (**0 L 1**) is activated frequently, this can be improved by adjusting the stall operation level **F 6 0 1** downward or increasing the acceleration time **R C C** or deceleration time **d E C**.

- $F_{63} I = 0$  (150%-60s),  $R_{UL} = 1$  (Constant torque characteristic)


Protection is given uniformly regardless of temperature, as shown by the 150%-60 sec overload curve in the figure below.



Inverter overload protection characteristics

- $F_{63} I = 1$  (Temperature estimation),  $R_{UL} = 1$  (Constant torque characteristic)

This parameter adjusts automatically overload protection, predicting the inverter internal temperature rise. (diagonally shaded area in the figure below)



Note 1: If the load applied to the inverter 150% or more of its rated load or the operation frequency is 0.1Hz or less, the inverter may trip (OL 1 or OL 1 to OL 3) in a shorter time.

Note 2: The inverter is default setting so that, if the inverter becomes overloaded, it will automatically reduce the carrier frequency to avoid an overload trip (OL 1 or OL 1 to OL 3). A reduction in carrier frequency causes an increase in noise from the motor, but this does not affect the performance of the inverter. If you do not want the inverter to reduce the carrier frequency automatically, set the parameter F316=0.

Note 3: Overload detection level is variable by condition of output frequency and carrier frequency.

Note 4: Regarding to characteristic for RUL=2 setting, refer to section 5.6.5).

## 4) Electronic thermal memory F632

When the power is OFF, it is possible to reset or maintain the overload totaling level.

This parameter's settings are applied both to the motor's electronic thermal memory and the electronic thermal memory for inverter protection.

[Parameters settings]

| Title | Function                  | Adjustment range                                                                           | Default setting |
|-------|---------------------------|--------------------------------------------------------------------------------------------|-----------------|
| F632  | Electronic thermal memory | 0: Disabled (LHr, F173)<br>1: Enabled (LHr, F173)<br>2: Disabled (LHr)<br>3: Enabled (LHr) | 0               |

- F632=1 is a function for complying with the U.S. NEC standards.

### 5) Overload characteristic selection $RUL$

Overload characteristic of inverter can be selected to 150%-60s or 120%-60s.

[Parameters settings]

| Title | Function                          | Adjustment range                                                                                     | Default setting |
|-------|-----------------------------------|------------------------------------------------------------------------------------------------------|-----------------|
| $RUL$ | Overload characteristic selection | 0: -<br>1: Constant torque characteristic (150%-60s)<br>2: Variable torque characteristic (120%-60s) | 0               |


- Regarding to characteristic for  $RUL = 1$  setting, refer to section 5.6.3).

Note 1) In case of  $RUL = 2$  setting, be sure to install the input AC reactor (ACL) between power supply and inverter.

Note 2) In case of  $RUL = 2$  setting in three phase 500V-4.0kW model, be sure to press the grounding capacitor switch and connect the grounding capacitors to the ground.

- $RUL = 2$  (Variable torque characteristic),  $F63 I=0$  (120%-60s)


Inverter overload



Inverter overload protection characteristic

- $RUL = 2$  (Variable torque characteristic),  $F63 = 1$  (Temperature estimation)

This parameter adjusts automatically overload protection, predicting the inverter internal temperature rise. (diagonally shaded area in the figure below)



Note 1: The rated output current of inverter is changed by setting of  $RUL = 1$  or  $2$ .

Refer to page L-1 about each rated output current.

Note 2: Parameter  $RUL$  is displayed as "0" during reading after this is set.

Note 3: Present setting of inverter overload characteristic can be confirmed by status monitor.

Refer to monitor "Overload and region setting" of section 8.2.1.

## 6) Overload alarm level F657

When the motor overload level reaches to  $F657$  setting value (%) of overload trip ( $OL2$ ) level, "L" will be displayed on the left side digit and the "L" and output frequency monitor will be blinking alternately on overload alarm status.

Overload alarm signal can be output from output terminal.

[Parameters settings]

| Title  | Function             | Adjustment range | Default setting |
|--------|----------------------|------------------|-----------------|
| $F657$ | Overload alarm level | 10-100 (%)       | 50              |

[Example of setting]: Assigning the overload alarm to the OUT terminal.

| Title  | Function                           | Adjustment range | Setting |
|--------|------------------------------------|------------------|---------|
| $F131$ | Output terminal selection 2A (OUT) | 0-255            | 16: POL |

17 is reverse signal.

## 5.7 Preset-speed operation (speeds in 15 steps)

**5r0** to **5r7**: Preset-speed frequency 0 to 7

**F287** to **F294**: Preset-speed frequency 8 to 15

**F724**: Operation frequency setting target by setting dial

### •Function

A maximum of 15 speed steps can be selected just by switching an external logic signal. Multi-speed frequencies can be programmed anywhere from the lower limit frequency  $L_L$  to the upper limit frequency  $U_L$ .

[Setting method]

#### 1) Run/stop

The starting and stopping control is done from the terminal block.

| Title       | Function               | Adjustment range                                                                                                                                  | Setting |
|-------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| <b>cn0d</b> | Command mode selection | 0: Terminal block<br>1: Panel keypad (including extension panel)<br>2: RS485 communication<br>3: CANopen communication<br>4: Communication option | 0       |

#### 2) Preset-speed frequency setting

a) Set the speed (frequency) of the number of steps necessary.

[Parameter setting]

Preset-speed 0

| Title       | Function                           | Adjustment range       | Default setting |
|-------------|------------------------------------|------------------------|-----------------|
| <b>5r0</b>  | Preset-speed frequency 0           | $L_L - U_L$ (Hz)       | 0.0             |
| <b>fn0d</b> | Frequency setting mode selection 1 | 0-13<br>14: <b>5r0</b> | 0               |

Frequency command set with **5r0** is valid when **fn0d=14 (5r0)**.

(**5r0** is valid even when the command mode selection is not **cn0d=0**.)

Setting from speed 1 to speed 15

| Title              | Function                    | Adjustment range | Default setting |
|--------------------|-----------------------------|------------------|-----------------|
| <b>5r1 - 5r7</b>   | Preset-speed frequency 1-7  | $L_L - U_L$ (Hz) | 0.0             |
| <b>F287 - F294</b> | Preset-speed frequency 8-15 | $L_L - U_L$ (Hz) | 0.0             |

b) Speed (frequency) can be changed during operation.

| Title       | Function                                           | Adjustment range                                                                         | Default setting |
|-------------|----------------------------------------------------|------------------------------------------------------------------------------------------|-----------------|
| <b>F724</b> | Operation frequency setting target by setting dial | 0: Panel frequency ( $F_L$ )<br>1: Panel frequency ( $F_L$ )<br>+ Preset speed frequency | 1               |

When **F724=1**, speed (frequency) can be changed with the setting dial during operation. Set value of the Preset-speed frequency will change by pressing the center.

Note) When the other preset-speed command is input while adjusting frequency with the setting dial, operation frequency will change but not the inverter display and the subject of adjustment.

Ex) If  $\overline{S1}$  is input when operating under  $\overline{S1}$  and changing frequency with the setting dial, operation frequency will change to  $\overline{S1}$  but inverter display and the subject of adjustment continue to be  $\overline{S1}$ . Press the center or MODE key to display  $\overline{S1}$ .

Preset-speed logic input signal example: Slide switch SW1 = SINK side

O: ON -: OFF (Speed commands other than preset-speed commands are valid when all are OFF)

| CC<br>S1<br>S2<br>S3<br>RES | Terminal | Preset-speed |   |   |   |   |   |   |   |   |    |    |    |    |    |    |
|-----------------------------|----------|--------------|---|---|---|---|---|---|---|---|----|----|----|----|----|----|
|                             |          | 1            | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|                             | S1-CC    | ○            | - | ○ | - | ○ | - | ○ | - | ○ | -  | ○  | -  | ○  | -  | ○  |
|                             | S2-CC    | -            | ○ | ○ | - | - | ○ | - | - | ○ | -  | ○  | -  | -  | ○  | ○  |
|                             | S3-CC    | -            | - | - | ○ | ○ | ○ | ○ | - | - | -  | -  | ○  | ○  | ○  | ○  |
|                             | RES-CC   | -            | - | - | - | - | - | - | ○ | ○ | ○  | ○  | ○  | ○  | ○  | ○  |

- Terminal functions are as follows.

Terminal S1..... Input terminal function selection 4A (S1)

$F \uparrow \downarrow 4 = \uparrow \downarrow$  (Preset-speed command 1: SS1)

Terminal S2..... Input terminal function selection 5 (S2)

$F \uparrow \downarrow 5 = \uparrow \downarrow$  (Preset-speed command 2: SS2)

Terminal S3..... Input terminal function selection 6 (S3)


$F \uparrow \downarrow 6 = \uparrow \downarrow$  (Preset-speed command 3: SS3)

Terminal RES..... Input terminal function selection 3A (RES)

$F \uparrow \downarrow 3 = \uparrow \downarrow$  (preset-speed command 4: SS4)

- In the default settings, SS4 is not assigned. Assign SS4 to RES with input terminal function selection.

[ Example of a connection diagram ]  
(with sink logic settings)



## 3) Using other speed commands with preset-speed command


|                                                 |          |                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------------------------------------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Command mode selection<br><i>Fn0d</i>           |          | 0: Terminal block                                                                                                                                                                                                                                                                                                                                                                                           | 1: Panel keypad (including extension panel)<br>2: RS485 communication<br>3: CANopen communication<br>4: Communication option                                                                                                                                                                                                                                                                                |
| Frequency setting mode selection<br><i>Fn0d</i> |          | 0: Setting dial 1 (including extension panel) (save even if power is off)<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Setting dial 2 (including extension panel) (press in center to save)<br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input<br>12, 13: -<br>14: <i>Scr0</i> | 0: Setting dial 1 (including extension panel) (save even if power is off)<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Setting dial 2 (including extension panel) (press in center to save)<br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input<br>12, 13: -<br>14: <i>Scr0</i> |
| Preset-speed command                            | Active   | Preset-speed command valid (Note)                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                                                                                                                                                             |
|                                                 | Inactive | Command set with <i>Fn0d</i> is valid                                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                             |

**(The inverter doesn't accept Preset-speed command.)**

Note) The preset-speed command is always given priority when other speed commands are input at the same time.

An example of three-speed operation with the default settings is shown below.

(Frequency settings are required for *Scr1* to *3*.)



## 5.8 Switching between two frequency commands

***FND***: Frequency setting mode selection1

***F200***: Frequency priority selection

***F207***: Frequency setting mode selection2

- Function

These parameters are used to switch between two frequency commands automatically or with input terminal signals.

### Parameter setting

| Title              | Function                           | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                 | Default setting |
|--------------------|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b><i>FND</i></b>  | Frequency setting mode selection 1 | 0: Setting dial 1 (including extension panel)<br>(save even if power is off)<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Setting dial 2 (including extension panel)<br>(press in center to save)<br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input<br>12, 13: -<br>14: <i>SCQ</i> | 0               |
| <b><i>F207</i></b> | Frequency setting mode selection 2 | 0: <i>FND</i> (Switchable to <i>F207</i> by terminal input)<br>1: <i>FND</i> (Switchable to <i>F207</i> at 1.0 Hz or less of designated frequency)                                                                                                                                                                                                                                                               | 1               |
| <b><i>F200</i></b> | Frequency priority selection       | 0: <i>FND</i> (Switchable to <i>F207</i> by terminal input)<br>1: <i>FND</i> (Switchable to <i>F207</i> at 1.0 Hz or less of designated frequency)                                                                                                                                                                                                                                                               | 0               |

Note) *FND*/*F207* is set to 0 or 3, when frequency setting is used with an extension panel option.

### 1) Switching with input terminal signals (Input terminal function 104/105: FCHG)

Frequency priority selection parameter ***F200*** = 0

Switch frequency command set with ***FND*** and ***F207*** by the input terminal signals.

Assign frequency setting mode forced switching function (input terminal function selection: 104) to an input terminal.

If an OFF command is entered to the input terminal block: The frequency command set with ***FND***.

If an ON command is entered to the input terminal block: The frequency command set with ***F207***.

Note) Input terminal function 105 is the inverse signal of the above.

## 2) Automatic switching by frequency command

|                                                   |
|---------------------------------------------------|
| Frequency priority selection parameter $F200 = 1$ |
|---------------------------------------------------|

Switch frequency command set with  $F00d$  and  $F207$  automatically according to the frequency command entered.

If the frequency set with  $F00d$  is above 1Hz: The frequency command set with  $F00d$

If the frequency set with  $F00d$  is 1Hz or less: The frequency command set with  $F207$

## 5.9 Auto-restart (Restart of coasting motor)

**F301**: Auto-restart control selection

|                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Caution</b>             |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <br><b>Mandatory action</b> | <ul style="list-style-type: none"> <li>Stand clear of motors and mechanical equipment<br/>If the motor stops due to a momentary power failure, the equipment will start suddenly when power is restored. This could result in unexpected injury.</li> <li>Attach caution label about sudden restart after a momentary power failure on inverters, motors and equipment for prevention of accidents in advance.</li> </ul> |

### • Function

The **F301** parameter detects the rotating speed and rotational direction of the motor during coasting at the event of momentary power failure, and then after power has been restored, restarts the motor smoothly (motor speed search function). This parameter also allows switching from commercial power operation to inverter operation without stopping the motor.


During operation, "rtr 4" is displayed.

### [Parameter setting]

| Title       | Function                       | Adjustment range                                                                                                     | Default setting |
|-------------|--------------------------------|----------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F301</b> | Auto-restart control selection | 0: Disabled<br>1: At auto-restart after momentary stop<br>2: At ST terminal off and on<br>3: 1 + 2<br>4: At start-up | 0               |


\* If the motor is restarted in retry mode, this function will operate, regardless of the setting of this parameter.

### 1) Auto-restart after momentary power failure (Auto-restart function)



Setting **F301** to **1** or **3**: This function operates after power has been restored following detection of an undervoltage by the main circuits and control power.

## 2) Restarting motor during coasting (Motor speed search function)



- Setting  $F30$  to 2 or 3: This function operates after the ST-CC terminal connection has been opened first and then connected again.

Note 1: As the default setting for ST (Standby) is Always ON, change the following settings.

- $F10 = 1$  (no function)
- Assign 6: ST (Standby) to an open input terminal.

## 3) Motor speed search at starting

When  $F30$  is set to 4, a motor speed search is performed each time operation is started.

This function is useful especially when the motor is not operated by the inverter but by the external factor.

### Warning!!

- At restart, it takes about 1 second for the inverter to check the number of revolutions of the motor. For this reason, the start-up takes more time than usual.
- Use this function when operating a system with one motor connected to one inverter. This function may not operate properly in a system configuration when multiple motors are connected to one inverter.
- In case of using this function, do not set the output phase failure detection selection ( $F605 = 1, 2, 4$ ).

### Application to a crane or hoist

The crane or hoist may have its load to be moved downward during the above waiting time. To apply the inverter to such machines, therefore, set the auto-restart control mode selection parameter to " $F30 = 0$ " (Disabled). Do not use the retry function, either.

Note 2: It is not malfunction that abnormal noise might be heard from the motor during the motor speed search at the auto-restart.

## 5.10 Changing operation panel display

### 5.10.1 Changing the unit (A/V) from a percentage of current and voltage

**F701**: Current/voltage unit selection

- Function

These parameters are used to change the unit of monitor display.

%  $\leftrightarrow$  A (ampere)/V (volt)


Current 100% = Rated current of inverter

Voltage 100% = 200Vac (240V class), 400Vac (500V class)


#### ■ Example of setting

During the operation of the VFS15-2015PM-W (rated current: 8.0A) at the rated load (100% load), units are displayed as follows:

##### 1) Display in percentage terms



##### 2) Display in amperes/volts



[Parameter setting]

| Title | Function                       | Adjustment range                 | Default setting |
|-------|--------------------------------|----------------------------------|-----------------|
| F701  | Current/voltage unit selection | 0: %<br>1: A (ampere) / V (volt) | 0               |

\* The **F701** converts the following parameter settings:

- A display : Current monitor display: Load current, torque current

Motor electronic-thermal protection level 1 & 2 **F173**

DC braking current **F251**

Stall prevention level 1 & 2 **F601, F185**

Small current detection current **F611**

Brake releasing small current detection level **F326**

- V display : Voltage monitor display: Input voltage, output voltage

V/f 5-point setting VF1-5 voltage **F191, F193, F195, F197, F199**

Note) Base frequency voltage 1 & 2 (**F171**) always displayed in the unit of V.

## 5.10.2 Displaying the motor or the line speed

**F702**: Frequency free unit display magnification

**F703**: Frequency free unit coverage selection

**F705**: Inclination characteristic of free unit display

**F706**: Free unit display bias

• Function

The frequency or any other item displayed on the monitor can be converted into the rotational speed of the motor or load device. The unit of the amount of processing or that of feedback can be changed at PID control.

The value obtained by multiplying the displayed frequency by the **F702**-set value will be displayed as follows:

$$\text{Value displayed} = \text{Monitor-displayed or parameter-set frequency} \times \text{F702}$$

1) Displaying the motor speed

To switch the display mode from 60Hz (default setting) to  $1800\text{min}^{-1}$  (the rotating speed of the 4P motor)

$$\begin{array}{ccc} \boxed{60.0} \text{ Hz} & \longrightarrow & \boxed{1800} \\ \text{F702} = 0.00 & & \begin{array}{l} \text{F702} = 30.00 \\ 60 \times 30.00 = 1800 \end{array} \end{array}$$

2) Displaying the speed of the loading unit

To switch the display mode from 60Hz (default setting) to  $6\text{m/min}^{-1}$  (the speed of the conveyor)

$$\begin{array}{ccc} \boxed{60.0} \text{ Hz} & \longrightarrow & \boxed{6.00} \\ \text{F702} = 0.00 & & \begin{array}{l} \text{F702} = 0.10 \\ 60 \times 0.10 = 6.00 \end{array} \end{array}$$

Note: This parameter displays the inverter output frequency as the value obtained by multiplying it by a positive number. This does not mean that the actual motor speed or line speed are indicated with accuracy.

[Parameter setting]

| Title       | Function                                        | Adjustment range                                                                   | Default setting |
|-------------|-------------------------------------------------|------------------------------------------------------------------------------------|-----------------|
| <b>F702</b> | Frequency free unit display magnification       | 0.00: Disabled (display of frequency)<br>0.01-200.0 (times)                        | 0.00            |
| <b>F703</b> | Frequency free unit coverage selection          | 0: All frequencies display<br>1: PID frequencies display                           | 0               |
| <b>F705</b> | Inclination characteristic of free unit display | 0: Negative inclination (downward slope)<br>1: Positive inclination (upward slope) | 1               |
| <b>F706</b> | Free unit display bias                          | 0.00- $F_H$ (Hz)                                                                   | 0.00            |

\* The  $F702$  converts the following parameter settings:

In case of  $F703=0$

•Free unit Frequency monitor display

Frequency-related parameters

Output frequency, Frequency command value, PID feedback value, Stator frequency, During stop: Frequency command value (During operation: Output frequency)

$FC, FH, UL, LL, 5r0 \sim 5r7,$   
 $F100, F101, F102, F167, F190, F192,$   
 $F194, F196, F198, F202, F204, F211,$   
 $F213, F217, F219$   
 $F240, F241, F242, F250, F260, F265,$   
 $F267, F268, F270$  to  $F275,$   
 $F287 \sim F294, F330, F331, F346, F350,$   
 $F367, F368, F383,$   
 $F390$  to  $F393, F505, F513, F649, F812,$   
 $F814, A923$  to  $A927$

In case of  $F703=1$


• Free unit PID control -related parameters  $FP1d, F367, F368$

Note) The unit of the Base frequency 1 and 2 are always Hz.


5

■ An example of setting when  $FH$  is 80 and  $F702$  is 10.00


$F705=1, F706=0.00$



$F705=1, F706=20.00$



$F705=0, F706=80.00$



## 6. Other parameters

Extended parameters are provided for sophisticated operation, fine adjustment and other special purposes. Modify parameter settings as required. Refer to section 11. tables of parameters.

Refer to the corresponding sections regarding the following parameters.

| Title            | Function                                               | Reference |
|------------------|--------------------------------------------------------|-----------|
| <i>RUU</i>       | Overload characteristic selection                      | 5.6, 6.18 |
| <i>FNSL</i>      | Meter selection                                        | 5.1       |
| <i>FN</i>        | Meter adjustment gain                                  |           |
| <i>ACC</i>       | Acceleration time 1                                    | 5.2       |
| <i>DEC</i>       | Deceleration time 1                                    |           |
| <i>FH</i>        | Maximum frequency                                      | 5.3       |
| <i>UL</i>        | Upper limit frequency                                  | 5.4       |
| <i>LL</i>        | Lower limit frequency                                  |           |
| <i>uL</i>        | Base frequency 1                                       | 5.5       |
| <i>uLv</i>       | Base frequency voltage 1                               |           |
| <i>tHr</i>       | Motor electronic-thermal protection level 1            | 5.6       |
| <i>OLN</i>       | Electronic-thermal protection characteristic selection |           |
| <i>SP0-SP7</i>   | Preset-speed frequency 0-7                             | 5.7       |
| <i>FPId</i>      | Process input value of PID control                     | 6.24      |
| <i>LYP</i>       | Default setting                                        | 4.3.2     |
| <i>SEt</i>       | Checking the region setting                            | 4.4       |
| <i>PSEL</i>      | EASY key mode selection                                | 4.5       |
| <i>GU</i>        | Automatic edit function                                | 4.3.1     |
| <i>F200</i>      | Frequency priority selection                           | 5.8       |
| <i>F207</i>      | Frequency setting mode selection 2                     |           |
| <i>F287-F294</i> | Preset-speed frequency 8-15                            | 5.7       |
| <i>F301</i>      | Auto-restart control selection                         | 5.9       |
| <i>F519</i>      | Setting of acceleration/deceleration time unit         | 5.2       |
| <i>F607</i>      | Motor 150% overload detection time                     | 5.6       |
| <i>F631</i>      | Inverter overload detection method                     |           |
| <i>F632</i>      | Electronic-thermal memory                              |           |
| <i>F657</i>      | Overload alarm level                                   |           |
| <i>F701</i>      | Current/voltage unit selection                         | 5.10.1    |
| <i>F702</i>      | Frequency free unit display magnification              | 5.10.2    |
| <i>F703</i>      | Frequency free unit coverage selection                 |           |
| <i>F705</i>      | Inclination characteristic of free unit display        |           |
| <i>F706</i>      | Free unit display bias                                 |           |
| <i>F724</i>      | Operation frequency setting target by setting dial     | 5.7       |
| <i>F750</i>      | EASY key function selection                            | 4.5       |
| <i>F751-F782</i> | Easy setting mode parameter 1-32                       |           |

## 6.1 Parameters useful for settings and adjustments

### 6.1.1 Searching for changes using the history function (*RUH*)

***RUH*** : History function

History function (*RUH*):

Automatically searches for 5 latest parameters that are programmed with values different from the default setting and displays them in the *RUH*. Parameter setting can also be changed within this group *RUH*.

#### How to use the history function

| Operation panel action                                                                                                                                                                                                                                       | LED display                                                             | Operation                                                                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                                                                              | 0.0                                                                     | Displays the output frequency (operation stopped).<br>(When standard monitor display selection <i>F 1 10</i> =0 [output frequency])                                                                                  |
|                                                                                                                                                                             | <i>RUH</i>                                                              | The first basic parameter " <i>RUH</i> " (history function) is displayed.                                                                                                                                            |
|                                                                                                                                                                             | <i>ACC</i>                                                              | The parameter that was set or changed last is displayed.                                                                                                                                                             |
|                                                                                                                                                                             | 8.0                                                                     | Press the center of the setting dial to display the set value.                                                                                                                                                       |
|                                                                                                                                                                             | 5.0                                                                     | Turn the setting dial to change the set value.                                                                                                                                                                       |
|                                                                                                                                                                             | 5.0 ↔ <i>ACC</i>                                                        | Press the center of the setting dial to save the changed value. The parameter name and the programmed value will flash on and off alternately.                                                                       |
|                                                                                                                                                                             | ****                                                                    | Turn the dial as described above to search for and display changed parameters to check and change the settings.                                                                                                      |
|                                                                                                                                                                             | <i>HERd</i><br>( <i>End</i> )                                           | <i>HERd</i> : First historic record<br><i>End</i> : Last historic record                                                                                                                                             |
| <br><br> | Parameter display<br>↓<br><i>RUH</i><br>↓<br><i>F r - F</i><br>↓<br>0.0 | Press the MODE key to return to the parameter setting mode " <i>RUH</i> ."<br>After that you can press the MODE key to return to the status monitor mode or the standard monitor mode (display of output frequency). |

## Notes on operation

- If no history information is stored, this parameter is skipped and the next parameter "*RUH*" is displayed.
- *HERd* and *ERd* are added respectively to the first and last parameters in a history of changes.

Note: The following parameters are not displayed in this *RUH*, even if they are the most recent changes.

*FL* (Operation frequency of operation panel),

*RU F* (Guidance function),

*RU L* (Overload characteristic selection),

*RU I* (Automatic acceleration/deceleration),

*RU 2* (Torque boost setting macro function),

*LP* (Default setting),

*SEL* (Checking the region setting),

*F 00* (Parameter protection selection),

*F 73 7* (All key operation prohibition),

*F 73 B* (Password setting (*F 700*)),

*F 73 9* (Password verification)

## 6.1.2 Application easy setting (*RUH*)

***RUH*** : Application easy setting

Application easy setting (*RUH*):

Parameters necessary to your machine can be set easily using the application easy setting.

The parameters necessary to the machine is set to easy setting mode parameters 1-32 (*F 75 1-F 78 2*). Set the parameters using the easy setting mode. (Refer to section 4.5.)

6

[Parameter setting]

| Title      | Function                 | Adjustment range                                                                                                           | Default setting |
|------------|--------------------------|----------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>RUH</i> | Application easy setting | 0:-<br>1: Initial easy setting<br>2: Conveyor<br>3: Material handling<br>4: Hoisting<br>5: Fan<br>6: Pump<br>7: Compressor | 0               |

## ■ How to use the Application easy setting

- 1) Choose the machine

| Operation panel action                                                            | LED display             | Operation                                                                                                                     |
|-----------------------------------------------------------------------------------|-------------------------|-------------------------------------------------------------------------------------------------------------------------------|
|                                                                                   | 0.0                     | Displays the output frequency.<br>(When standard monitor display selection <i>F 7 10</i> is set to 0 [output frequency])      |
|  | <i>R U H</i>            | The first basic parameter " <i>R U H</i> " (history function) is displayed.                                                   |
|  | <i>R U R</i>            | Turn the setting dial to the right to change the parameter to <i>R U R</i> .                                                  |
|  | 0                       | Set values are displayed by pressing the center of the setting dial.                                                          |
|  | 2                       | Turn the setting dial to the right to select 1 or 2.                                                                          |
|  | <i>2</i> ⇌ <i>R U R</i> | Press the center of the setting dial to save the changed set value. <i>R U R</i> and the set value are displayed alternately. |

- 2) The parameters necessary to the machine are set to easy setting mode parameter 1-32. (Refer to the chart below)
- 3) Set the parameters using easy setting mode. Refer to section 4.5 for easy setting mode.

Table of parameters that can be set using *R U R*

| <i>R U R</i>   | 1: Initial easy setting | 2: Conveyor    | 3: Material handling | 4: Hoisting    | 5: Fan         | 6: Pump        | 7: Compressor  |
|----------------|-------------------------|----------------|----------------------|----------------|----------------|----------------|----------------|
| <i>F 7 5 1</i> | <i>C 0 0 d</i>          | <i>C 0 0 d</i> | <i>C 0 0 d</i>       | <i>C 0 0 d</i> | <i>C 0 0 d</i> | <i>C 0 0 d</i> | <i>C 0 0 d</i> |
| <i>F 7 5 2</i> | <i>F 0 0 d</i>          | <i>F 0 0 d</i> | <i>F 0 0 d</i>       | <i>F 0 0 d</i> | <i>F 0 0 d</i> | <i>F 0 0 d</i> | <i>F 0 0 d</i> |
| <i>F 7 5 3</i> | <i>A C C</i>            | <i>A C C</i>   | <i>A C C</i>         | <i>A C C</i>   | <i>A C C</i>   | <i>A C C</i>   | <i>A C C</i>   |
| <i>F 7 5 4</i> | <i>d E C</i>            | <i>d E C</i>   | <i>d E C</i>         | <i>d E C</i>   | <i>d E C</i>   | <i>d E C</i>   | <i>d E C</i>   |
| <i>F 7 5 5</i> | <i>U L</i>              | <i>U L</i>     | <i>U L</i>           | <i>U L</i>     | <i>F H</i>     | <i>F H</i>     | <i>F H</i>     |
| <i>F 7 5 6</i> | <i>L L</i>              | <i>L L</i>     | <i>L L</i>           | <i>L L</i>     | <i>U L</i>     | <i>U L</i>     | <i>U L</i>     |
| <i>F 7 5 7</i> | <i>t H r</i>            | <i>t H r</i>   | <i>t H r</i>         | <i>t H r</i>   | <i>L L</i>     | <i>L L</i>     | <i>L L</i>     |
| <i>F 7 5 8</i> | <i>F 0</i>              | <i>F 0</i>     | <i>F 0</i>           | <i>F 0</i>     | <i>t H r</i>   | <i>t H r</i>   | <i>t H r</i>   |
| <i>F 7 5 9</i> | -                       | <i>P t</i>     | <i>P t</i>           | <i>P t</i>     | <i>F 0</i>     | <i>F 0</i>     | <i>F 0</i>     |
| <i>F 7 6 0</i> | -                       | <i>0 L 0</i>   | <i>0 L 0</i>         | <i>0 L 0</i>   | <i>P t</i>     | <i>P t</i>     | <i>P t</i>     |
| <i>F 7 6 1</i> | -                       | <i>S r 1</i>   | <i>S r 1</i>         | <i>F 3 0 4</i> | <i>F 2 0 1</i> | <i>F 2 0 1</i> | <i>F 2 1 6</i> |
| <i>F 7 6 2</i> | -                       | <i>S r 2</i>   | <i>S r 2</i>         | <i>F 3 0 8</i> | <i>F 2 0 2</i> | <i>F 2 0 2</i> | <i>F 2 1 7</i> |
| <i>F 7 6 3</i> | -                       | <i>S r 3</i>   | <i>S r 3</i>         | <i>F 3 0 9</i> | <i>F 2 0 3</i> | <i>F 2 0 3</i> | <i>F 2 1 8</i> |
| <i>F 7 6 4</i> | -                       | <i>S r 4</i>   | <i>S r 4</i>         | <i>F 3 2 8</i> | <i>F 2 0 4</i> | <i>F 2 0 4</i> | <i>F 2 1 9</i> |
| <i>F 7 6 5</i> | -                       | <i>S r 5</i>   | <i>S r 5</i>         | <i>F 3 2 9</i> | <i>F 2 0 7</i> | <i>F 2 0 7</i> | <i>F P 1 d</i> |
| <i>F 7 6 6</i> | -                       | <i>S r 6</i>   | <i>S r 6</i>         | <i>F 3 3 0</i> | <i>F 2 1 6</i> | <i>F 2 1 6</i> | <i>F 3 5 9</i> |
| <i>F 7 6 7</i> | -                       | <i>S r 7</i>   | <i>S r 7</i>         | <i>F 3 3 1</i> | <i>F 2 1 7</i> | <i>F 2 1 7</i> | <i>F 3 6 0</i> |

|      |      |      |      |      |      |      |      |
|------|------|------|------|------|------|------|------|
| F168 | -    | F201 | F240 | F332 | F218 | F218 | F361 |
| F169 | -    | F202 | F243 | F333 | F219 | F219 | F362 |
| F170 | -    | F203 | F250 | F334 | F295 | F295 | F363 |
| F171 | -    | F204 | F251 | F340 | F301 | F301 | F366 |
| F172 | -    | F240 | F252 | F341 | F302 | F302 | F367 |
| F173 | -    | F243 | F304 | F345 | F303 | F303 | F368 |
| F174 | -    | F250 | F308 | F346 | F633 | F610 | F369 |
| F175 | -    | F251 | F309 | F347 | F667 | F611 | F372 |
| F176 | -    | F252 | F502 | F400 | F668 | F612 | F373 |
| F177 | -    | F304 | F506 | F405 | -    | F633 | F380 |
| F178 | -    | F308 | F507 | F415 | -    | F667 | F389 |
| F179 | -    | F309 | F701 | F417 | -    | F668 | F391 |
| F180 | -    | F701 | -    | F648 | -    | -    | F621 |
| F181 | F701 | F702 | -    | F701 | -    | -    | -    |
| F182 | P5EL | P5EL | P5EL | P5EL | P5EL | P5EL | P5EL |

### 6.1.3 Setting a parameter using the guidance function (*RUF*)

***RUF***: Guidance function

6

Guidance function (*RUF*):

The guidance function refers to the special function of calling up only functions necessary to set up the inverter in response to the user's needs. When a purpose-specific guidance is selected, a group of parameters needed for the specified application (function) is formed and the inverter is switched automatically to the mode of setting the group of parameters selected. You can set up the inverter easily by simply setting the parameters in the group one after another. The guidance function (*RUF*) provides five purpose-specific guidance.

[Parameter setting]

| Title      | Function          | Adjustment range                                                                                                                                                | Default setting |
|------------|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>RUF</i> | Guidance function | 0:-<br>1: - Note 1<br>2: Preset speed guidance<br>3: - Note 1<br>4: Motor 1&2 switching operation guidance<br>5: Motor constant setting guidance<br>6: - Note 1 | 0               |

Note1) 1, 3, and 6 are for manufacturer's settings. Do not change the settings.

■ How to use the guidance function

Here are the steps to follow to set parameters, using the guidance function. (When the Preset speed guidance  $RUF = 2$ )

| Operation panel action                                                            | LED display                                                                                        | Operation                                                                                                                                                             |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                   | $0.0$                                                                                              | Displays the operation frequency (output stopped).<br>(When standard monitor display selection $F710=0$ is set to 0 [output frequency]).                              |
|  | $RUH$                                                                                              | The first basic parameter "History ( $RUH$ )" is displayed.                                                                                                           |
|  | $RUF$                                                                                              | Turn the setting dial to select the guidance function ( $RUF$ ).                                                                                                      |
|  | $0$                                                                                                | Press the center of the setting dial to display $0$ .                                                                                                                 |
|  | $2$                                                                                                | Turn the setting dial to change to the setting value "2".                                                                                                             |
|  | $End$                                                                                              | Press the center of the setting dial to display the purpose-specific guidance parameter group (refer to following table).                                             |
|  | ***                                                                                                | After moving to the purpose-specific guidance parameter group, use the setting dial to change the parameters.                                                         |
|  | $End$                                                                                              | $End$ is displayed on completion of the setting of the guidance parameter group.                                                                                      |
|  | Display of parameter<br>$\downarrow$<br>$RUF$<br>$\downarrow$<br>$F7 - F$<br>$\downarrow$<br>$0.0$ | Press the MODE key to exit the guidance parameter group.<br>Thereafter, return to the default monitoring mode (display of output frequency) by pressing the MODE key. |

If there is anything you do not understand during this operation, press the MODE key several times to start over from the step of  $RUH$  display.

$HERd$  or  $END$  is affixed respectively to the first or last parameter in each guidance wizard parameter group.

Table of parameters that can be changed using the guidance function

| Preset-speed setting<br><i>RUF=2</i> | Motor 1&2 switching operation<br><i>RUF=4</i> | Motor constant setting guidance<br><i>RUF=5</i> |
|--------------------------------------|-----------------------------------------------|-------------------------------------------------|
| <i>EN0d</i>                          | <i>F111</i>                                   | <i>Pl</i>                                       |
| <i>FN0d</i>                          | <i>F112</i>                                   | <i>UL</i>                                       |
| <i>RLC</i>                           | <i>F113</i>                                   | <i>ULU</i>                                      |
| <i>dEC</i>                           | <i>F114</i>                                   | <i>F405</i>                                     |
| <i>FH</i>                            | <i>F115</i>                                   | <i>F415</i>                                     |
| <i>UL</i>                            | <i>F116</i>                                   | <i>F417</i>                                     |
| <i>F111</i>                          | <i>UL</i>                                     | <i>F400</i>                                     |
| <i>F112</i>                          | <i>ULU</i>                                    |                                                 |
| <i>F113</i>                          | <i>Ub</i>                                     |                                                 |
| <i>F114</i>                          | <i>F415</i>                                   |                                                 |
| <i>F115</i>                          | <i>tHr</i>                                    |                                                 |
| <i>F116</i>                          | <i>F501</i>                                   |                                                 |
| <i>sr1</i>                           | <i>RLC</i>                                    |                                                 |
| <i>sr2</i>                           | <i>dEC</i>                                    |                                                 |
| <i>sr3</i>                           | <i>F170</i>                                   |                                                 |
| <i>sr4</i>                           | <i>F171</i>                                   |                                                 |
| <i>sr5</i>                           | <i>F172</i>                                   |                                                 |
| <i>sr6</i>                           | <i>F173</i>                                   |                                                 |
| <i>sr7</i>                           | <i>F185</i>                                   |                                                 |
| <i>F287</i>                          | <i>F500</i>                                   |                                                 |
| <i>F288</i>                          | <i>F501</i>                                   |                                                 |
| <i>F289</i>                          |                                               |                                                 |
| <i>F290</i>                          |                                               |                                                 |
| <i>F291</i>                          |                                               |                                                 |
| <i>F292</i>                          |                                               |                                                 |
| <i>F293</i>                          |                                               |                                                 |
| <i>F294</i>                          |                                               |                                                 |

## 6.1.4 Automatically adjusting acceleration/deceleration time

### ***RU1***: Automatic acceleration/deceleration

- Function

This automatically adjusts acceleration and deceleration time in line with load.


Refer to section 5.2 for setting acceleration/ deceleration time manually.

***RU1*** = 1

\* Adjusts the acceleration/deceleration time automatically within the range of 1/8 to 8 times as long as the time set with the *RLC* or *dEC*, depending on the current rating of the inverter.

***RU1*** = 2

\* Automatically adjusts speed during acceleration only. During deceleration, speed is not adjusted automatically but reduced at the rate set with *dEC*.



Set  $RU1$  (automatic acceleration/deceleration) to  $1$  or  $2$

[Parameter setting]

| Title | Function                            | Adjustment range                                                                    | Default setting |
|-------|-------------------------------------|-------------------------------------------------------------------------------------|-----------------|
| $RU1$ | Automatic acceleration/deceleration | 0: Disabled (manual setting)<br>1: Automatic<br>2: Automatic (only at acceleration) | 0               |

- When automatically setting acceleration/deceleration time, always change the acceleration/deceleration time so that it conforms to the load. For inverters that require a fixed acceleration/deceleration time, use the manual settings ( $RLC$ ,  $dEL$ ).
- Setting acceleration/deceleration time ( $RLC$ ,  $dEL$ ) in conformance with mean load allows optimum setting that conforms to further changes in load.
- Use this parameter after actually connecting the motor.
- When the inverter is used with a load that fluctuates considerably, it may fail to adjust the acceleration or deceleration time in time, and therefore may be tripped.
- Do not set  $RU1 = 1$  when using a dynamic braking resistor (optional).

[Methods of setting automatic acceleration/deceleration]

| Operation panel action | LED display         | Operation                                                                                                                 |
|------------------------|---------------------|---------------------------------------------------------------------------------------------------------------------------|
|                        | 0.0                 | Displays the output frequency.<br>(When standard monitor display selection $F710$ is set to 0 [output frequency])         |
|                        | $RUH$               | The first basic parameter " $RUH$ " (history function) is displayed.                                                      |
|                        | $RU1$               | Turn the setting dial to the right to change the parameter to $RU1$ .                                                     |
|                        | 0                   | Set values are displayed by pressing the center of the setting dial.                                                      |
|                        | 1                   | Turn the setting dial to the right to switch $1$ or $2$ .                                                                 |
|                        | $1 \rightarrow RU1$ | Press the center of the setting dial to save the changed set value.<br>$RU1$ and the set value are displayed alternately. |

- Assigning the fast stop command 2 (function number 122/123) to any logic input terminal, it can be changed automatic deceleration by compulsion.

## 6.1.5 Increasing starting torque

### ***RU2***: Torque boost setting macro function

- Function

Simultaneously switches inverter output (V/F) control and programs motor constants automatically (On-line automatic-tuning function) to improve torque generated by the motor. This parameter integrates the selection of function including vector control and setting of auto-tuning.

#### [Parameter setting]

| Title      | Function                            | Adjustment range                                                                                                     | Default setting |
|------------|-------------------------------------|----------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>RU2</i> | Torque boost setting macro function | 0: -<br>1: Automatic torque boost + auto-tuning<br>2: Vector control + auto-tuning<br>3: Energy saving + auto-tuning | 0               |

Note1) Parameter displays on the right always return to 0 after setting. The previous setting is displayed on the left.

Ex. ***1 0***

Note2) Auto-tuning is performed at the start of the motor.

#### Caution:

When the torque boost setting macro function *RU2* is set, look at the motor's name plate and set the following parameters.

- UL* : Base frequency 1 (rated frequency)
- ULV* : Base frequency voltage 1 (rated voltage)
- F405* : Motor rated capacity
- F415* : Motor rated current
- F417* : Motor rated speed

Set the other motor constants as necessary.

### 1) Increasing torque automatically according to the load

*RU2* is set to 1 (Automatic torque boost + auto-tuning)

When torque boost setting macro function control *RU2* is set to 1 (automatic torque boost + auto-tuning), the inverter keeps track of the load current in any speed range and automatically adjusts the output voltage to ensure enough torque and stable operation.

Note 1: The same characteristic can be obtained by setting the V/F control mode selection parameter *PL* to 2 (automatic torque boost control) and the auto-tuning parameter *F400* to 2 (auto-tuning).

⇒ Refer to section 6.25

Note 2: Setting *RU2* to 1 automatically programs *PL* to 2.

## 2) When using vector control (increasing starting torque and high-precision operations)

$R U \bar{2}$  is set to  $\bar{2}$  (Vector control + auto-tuning)

Setting torque boost setting macro function control  $R U \bar{2}$  to  $\bar{2}$  (vector control + auto-tuning) provides high starting torque bringing out the maximum in motor characteristics from the low-speed range. This suppresses changes in motor speed caused by fluctuations in load to provide high precision operation. This is an optimum feature for elevators and other load transporting machinery.

Note 3: The same characteristic can be obtained by setting the V/F control mode selection parameter  $P \bar{L}$  to  $\bar{3}$  (vector control) and the auto-tuning parameter  $F 4 \bar{0} \bar{0}$  to  $\bar{2}$  (auto-tuning).

⇒ Refer to section 6. 25

Note 4: Setting  $R U \bar{2}$  to  $\bar{2}$  automatically programs  $P \bar{L}$  to  $\bar{3}$ .

## 3) Energy-saving operation

$R U \bar{2}$  is set to  $\bar{3}$  (Energy saving + auto-tuning)

When torque boost setting macro function control  $R U \bar{2}$  is set to  $\bar{3}$  (energy saving + auto-tuning), the inverter always passes a current appropriate to the load for energy saving.

Note 5: The same characteristic can be obtained by setting the V/F control mode selection parameter  $P \bar{L}$  to  $\bar{4}$  (automatic energy saving) and the auto-tuning parameter  $F 4 \bar{0} \bar{0}$  to  $\bar{2}$  (auto-tuning).

⇒ Refer to section 6. 25

Note 6: Setting  $R U \bar{2}$  to  $\bar{3}$  automatically programs  $P \bar{L}$  to  $\bar{4}$ .

[Example of parameter setting]

| Operation panel action                                                              | LED display                                 | Operation                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                     | $\bar{0} \ \bar{0}$                         | Displays the output frequency. (Perform during operation stopped.)<br>(When standard monitor display selection $F 7 \ \bar{1} \bar{0}$ is set to $\bar{0}$ [output frequency])              |
|    | $R U H$                                     | The first basic parameter " $R U H$ " (history function) is displayed.                                                                                                                      |
|    | $R U \bar{2}$                               | Turn the setting dial to the right to change the parameter to $R U \bar{2}$ (torque boost setting macro function).                                                                          |
|    | $\bar{0} \ \bar{0}$                         | Set values are displayed by pressing the center of the setting dial.                                                                                                                        |
|   | $\bar{0} \ \bar{3}$                         | Turn the setting dial to the right to change the parameter to $\bar{3}$ (energy saving + auto-tuning). (Right side is the setting value, left side is the history of the previous setting.) |
|  | $\bar{0} \ \bar{3} \Rightarrow R U \bar{2}$ | Press the center of the setting dial to save the changed parameter. $R U \bar{2}$ and the parameter are displayed alternately.                                                              |

If vector control cannot be programmed....

First read the precautions about vector control in section 6.3.9).

- 1) If the desired torque cannot be obtained  $\Rightarrow$  Refer to section 6.25 selection 2
- 2) If auto-tuning error "E t n t" appears  $\Rightarrow$  Refer to section 6.25 selection 4

## ■ $RU2$ (Torque boost setting macro function) and $Pt$ (V/F control mode selection)

Automatic torque boost is the parameter for setting V/F control mode selection ( $Pt$ ) and auto-tuning ( $F400$ ) together. That is why all parameters related to change automatically when  $RU2$  is changed.

|       |                                      | Automatically programmed parameters |                                           |
|-------|--------------------------------------|-------------------------------------|-------------------------------------------|
| $RU2$ |                                      | $Pt$                                | $F400$                                    |
| $0$   | Displays $0$ after resetting         | -                                   | -                                         |
| $1$   | Automatic torque boost + auto-tuning | $2$                                 | Automatic torque boost control            |
| $2$   | Vector control + auto-tuning         | $3$                                 | Vector control                            |
| $3$   | Energy saving + auto-tuning          | $4$                                 | Energy-saving                             |
|       |                                      |                                     | Auto-tuning executed (after execution: 0) |
|       |                                      |                                     | Auto-tuning executed (after execution: 0) |
|       |                                      |                                     | Auto-tuning executed (after execution: 0) |

6

## 4) Increasing torque manually (V/F constant control)

This is the setting of constant torque characteristics that are suited for such things as conveyors. It can also be used to manually increase starting torque.

If V/F constant control is programmed after changing  $RU2$ ,

Set V/F control mode selection  $Pt = 0$  (V/F constant).

$\Rightarrow$  Refer to section 6.3

Note 7: To further increase torque, increase the torque boost value  $1(b)$ .

How to set the torque boost value  $1(b)$

$\Rightarrow$  Refer to section 6.4

Note 8: V/F control selection  $Pt = 1$  (variable torque) is an effective setting for load such as fans and pumps.

$\Rightarrow$  Refer to section 6.3

## 6.2 Selection of operation mode

### 6.2.1 Selection of start/stop and frequency settings

**CMOD**: Command mode selection

**FMOD**: Frequency setting mode selection

- Function

These parameters are used to specify which input device (panel keypad, terminal block, or communication) takes priority in entering an operation stop command or frequency setting mode (terminal VIA/VIB/VIC, setting dial, communication, or UP/DOWN from external logic).

<Command mode selection>

[Parameter setting]

| Title | Function               | Adjustment range                                                                                                                                  | Default setting |
|-------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| CMOD  | Command mode selection | 0: Terminal block<br>1: Panel keypad (including extension panel)<br>2: RS485 communication<br>3: CANopen communication<br>4: Communication option | 1               |

[Programmed value]

- 0: Terminal block operation ON and OFF of an external signal run and stop operation.
- 1: Panel keypad operation Press the **RUN** and **STOP** keys on the panel keypad to run and stop. Operation can also be done from the extension panel.
- 2: RS485 communication Run/stop operations by RS485 communication from an external device.  
⇒ Refer to section 6.38.
- 3: CANopen communication Run/stop operations by CANopen communication from an external device.  
⇒ Refer to "CANopen communication Instruction Manual E6581911".
- 4: Communication option Run/stop operations by commands from a communication option.  
⇒ Refer to each Instruction Manual of option.

\* Operation command selected by **CMOD** and the operation commands from the terminal block can be switched alternately with ON/ OFF of input terminal. (input terminal function number 108, 109) See the table of input terminal function selection in section 11.6.

\* When priority is given to commands from a linked computer or terminal block, they have priority over the setting of **CMOD**.

## &lt;Frequency setting mode selection&gt;

[Parameter setting]

| Title          | Function                           | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                           | Default setting |
|----------------|------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F r e q</i> | Frequency setting mode selection 1 | 0: Setting dial 1 (including extension panel option) (save even if power is off)<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Setting dial 2 (including extension panel option) (press in center to save)<br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input<br>12, 13: -<br>14: <i>S r d</i> | 0               |

[Programmed value]

- 0:** Setting dial 1 Frequencies are set by rotating the setting dial on the inverter and an extension panel option. Like the position of notches in a volume knob, the frequency setting value at the position of the notch is saved.  
⇒ Refer to section 3.2.2
- 1:** Terminal VIA A frequency command is set by means of external analog signals. (VIA terminal: 0 –10Vdc)  
⇒ Refer to section 3.2.2 and 7.3
- 2:** Terminal VIB A frequency command is set by means of external analog signals. (VIB terminal: 0 - +10Vdc or -10 - +10Vdc)  
⇒ Refer to section 3.2.2 and 7.3
- 3:** Setting dial 2 Frequencies are set by rotating the setting dial on the inverter and an extension panel option. Press the center of the setting dial to save the frequency setting value.  
⇒ Refer to section 3.2.2
- 4:** RS485 communication Frequencies are set by RS485 communication from an external device.  
⇒ Refer to section 6.38
- 5:** UP/DOWN from external logic input Frequencies are set by up/down commands from a terminal.  
⇒ Refer to section 6.10.4
- 6:** CANopen communication Frequencies are set by CANopen communication from an external device.  
⇒ Refer to “CANopen communication Instruction Manual E6581911”.

- 7: Communication option Frequencies are set by commands from a communication option.  
⇒ Refer to each Instruction Manual of option.
- 8: Terminal VIC A frequency command is set by means of external analog signals.  
(VIC terminal: 0 (4) - 20mAdc)  
⇒ Refer to section 3.2.2 and 7.3
- 11: Pulse train input A frequency command is set by means of external pulse train signals.  
(S2 terminal: 10pps - 2kpps)  
⇒ Refer to section 6.10.5
- 14: 5r0 Frequencies are set by 5r0 parameter.  
⇒ Refer to section 5.7.

- The control input terminal in which the following functions are set is always valid regardless of the setting of  $\text{CND}$  and  $\text{FND}$ .
  - Reset (valid only for tripping)
  - Standby
  - External input tripping stop command
  - Coast stop command terminal
- To make changes in the command mode selection  $\text{CND}$  and the frequency setting mode selection 1  $\text{FND}$ , first stop the inverter temporarily.  
(Can be changed while in operation when  $\text{F735}$  is set to 0.)
- Priority commands from communications or terminal blocks are given priority over  $\text{FND}$ .

## ■ Preset-speed operation

$\text{CND}$ : Set to 0 (Terminal block operation)

$\text{FND}$ : Valid in all setting values.

## ■ Input terminal settings


Assign the following functions to the input terminal to allow switching of the frequency command by turning the terminal ON/OFF.

| Input terminal function |                                       | ON                                                                              | OFF                     |
|-------------------------|---------------------------------------|---------------------------------------------------------------------------------|-------------------------|
| 48                      | Forced local from communication       | Enabled during communication<br>Local (Setting of $\text{CND}$ , $\text{FND}$ ) | Communication           |
| 106                     | Frequency setting mode terminal block | Terminal block (VIA) enabled                                                    | setting of $\text{FND}$ |

Each of the following numbers (49, 107) are reverse signals.

# ■ Example of run and frequency command switching

## Command mode and frequency setting mode switching



## 6.2.2 Forward/reverse run selection (Panel keypad)

**$F_r$** : Forward/reverse run selection (Panel keypad)

- **Function**  
Program the direction of rotation of the motor when the running and stopping are made using the RUN key and STOP key on the operation panel.  
Valid when  $\mathcal{L} \mathcal{R} \mathcal{Q} \mathcal{d}$  (command mode) is set to  $\mathcal{I}$  (operation panel).

[Parameter setting]

| Title | Function                                        | Adjustment range                                                                                                                           | Default setting |
|-------|-------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| $F_r$ | Forward/reverse run selection<br>(Panel keypad) | 0: Forward run<br>1: Reverse run<br>2: Forward run (F/R switching on extension panel)<br>3: Reverse run (F/R switching on extension panel) | 0               |

- Using extension panel RKP007Z (option) : When  $F_r$  is set to  $\mathcal{Q}$  and the standard monitor is displayed, pressing the FWD/REV key changes the direction of rotation from forward to reverse after displaying the message  $F_r - r$ .  
Pressing the FWD/REV key again changes the direction of rotation from reverse to forward after displaying the message  $F_r - F$ .
- Using extension panel RKP002Z (option) : When  $F_r$  is set to  $\mathcal{Q}$  and the standard monitor is displayed, pressing the DOWN key while pressing the ENT key changes the direction of rotation from forward to reverse after displaying the message  $F_r - r$ .  
Pressing the UP key while pressing the ENT key again changes the direction of rotation from reverse to forward after displaying the message  $F_r - F$ .
- Check the direction of rotation on the status monitor. Refer to section 8.1 for details about monitor.  
 $F_r - F$  : Forward run  
 $F_r - r$  : Reverse run
- When the F and R terminals are used for switching between forward and reverse rotation from the terminal block, the  $F_r$  forward/reverse run selection parameter is rendered invalid.  
Short across the F-CC (Sink logic) or P24-F (Source logic) terminals: forward rotation  
Short across the R-CC (Sink logic) or P24-R (Source logic) terminals: reverse rotation
- You can use the parameter  $F \mathcal{I} \mathcal{Q} \mathcal{S}$  to select deceleration stop or reverse run for the action when both forward and reverse run signals from terminal block are ON simultaneously. The motor will decelerate to stop when the inverter was factory-configured by default.

## 6.3 Selecting control mode

**P<sub>7</sub>**: V/F control mode selection

- Function

The V/F controls shown below can be selected.

- ☐ V/F constant
- ☐ Variable torque
- ☐ Automatic torque boost control \*1
- ☐ Vector control \*1
- ☐ Energy saving \*1
- ☐ Dynamic energy-saving (For fan and pump)
- ☐ PM motor control
- ☐ V/F 5-point setting

\*1 Parameter setting macro torque boost: **PU2** parameter can automatically set this parameter and auto-tuning at a time. (Refer to section 6.1.5)

[Parameter setting]

| Title          | Function                   | Adjustment range                                                                                                                                                                                                                  | Default setting |
|----------------|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| P <sub>7</sub> | V/F control mode selection | 0: V/F constant<br>1: Variable torque<br>2: Automatic torque boost control<br>3: Vector control<br>4: Energy-saving<br>5: Dynamic energy-saving<br>(For fan and pump)<br>6: PM motor control<br>7: V/F 5-point setting<br>8: - *3 | *2              |

\*2: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*3: 8 is manufacturer setting parameter. Do not change the value of this parameter.

Note: P<sub>7</sub> (V/F control mode selection) is valid only for the first motor.

Changes to "V/F constant control" when switching to the second motor, regardless of the P<sub>7</sub> setting.

Steps in setting are as follows

(In this example, the V/F control mode selection parameter  $P\text{L}$  is set to  $3$  (Vector control).)

[Setting V/F control mode selection to  $3$  (sensorless vector control)]

| Operation panel action                                                            | LED display                   | Operation                                                                                                                                                   |
|-----------------------------------------------------------------------------------|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                   | 0.0                           | Displays the output frequency. (Perform during operation stopped.)<br>(When standard monitor display selection $F\ 7\ 10$ is set to $0$ [output frequency]) |
|  | RUH                           | The first basic parameter "RUH" (history function) is displayed.                                                                                            |
|  | $P\text{L}$                   | Rotate the setting dial to the right, and change the parameter to $P\text{L}$ (V/F control mode selection).                                                 |
|  | 2                             | Set values are displayed by pressing the center of the setting dial.                                                                                        |
|  | 3                             | Rotate the setting dial to the right, and change the parameter to $3$ (vector control).                                                                     |
|  | $3 \leftrightarrow P\text{L}$ | Press the center of the setting dial to save the changed set value. $P\text{L}$ and the set value " $3$ " are displayed alternately.                        |

6

**Caution:**

When the V/F control mode selection  $P\text{L}$  is set to  $2$ : Automatic torque boost control,  $3$ : Vector control,  $4$ : Energy-saving,  $5$ : Dynamic energy-saving, or  $6$ : PM motor control, be sure to set the following parameters according to the motor's name plate.


- $\omega L$  : Base frequency 1 (rated frequency)
- $\omega L \omega$  : Base frequency voltage 1 (rated voltage)
- $F\ 4\ 0\ 5$  : Motor rated capacity
- $F\ 4\ 1\ 5$  : Motor rated current
- $F\ 4\ 1\ 7$  : Motor rated speed

Set the other motor constants as necessary

## 1) Constant torque characteristics

Setting of V/F control mode selection  $P_{L1}$  to  $\vec{G}$  (V/F constant)

This is applied to loads with equipment like conveyors and cranes that require the same torque at low speeds as at rated speeds.




\* To increase the torque further, increase the setting value of the manual torque boost value 1 ( $uL$ ).

⇒ Refer to section 6.4 for details.

## 2) Setting for fans and pumps

Setting of V/F control mode selection  $P_{L1}$  to  $\vec{I}$  (variable torque)


This is appropriate for load characteristics of such things as fans, pumps and blowers in which the torque is proportional to the square of load rotation speed.



### 3) Increasing starting torque

Setting of V/F control mode selection  $P\text{L} \rightarrow 2$  (automatic torque boost control)

Detects load current in all speed ranges and automatically adjusts voltage output (torque boost) from inverter. This gives steady torque for stable runs.



Note: This control system can oscillate and destabilize runs depending on the load. In this case, set V/F mode selection  $P\text{L} = 0$  (V/F constant) and increase manual torque boost  $\alpha b$ .

- Motor constant must be set

If the motor you are using is a 4P Toshiba standard motor which has the same capacity as the inverter, there is basically no need to set the motor constant. There are three setting methods as mentioned below. In any method, set the following parameters according to the motor's name plate.

$\omega L$  (Base frequency 1),  $\omega L \omega$  (Base frequency voltage 1),  $F 4 0 5$  (Motor rated capacity),  $F 4 1 5$  (Motor rated current),  $F 4 1 7$  (Motor rated speed)

1) Simultaneous setting of auto torque boost and auto-tuning ( $F 4 0 0 = 2$ )

Set the basic parameter  $R U 2$  (Torque boost setting macro function) to 1.

⇒ Refer to section 6.1.5 for details.

2) Automatic setting

Set the extended parameter  $F 4 0 0$  (auto-tuning) to 5. ⇒ Refer to section 6.25 selection 2 for details.

3) Manual setting

Set each motor constant. ⇒ Refer to section 6.25 selection 4 for details.

### 4) Vector control - increasing starting torque and achieving high-precision operation.

Setting of V/F control mode selection  $P\text{L} \rightarrow 3$  (Vector control)

Using sensorless vector control will provide the highest torque at the low speed ranges.

(1) Provides large starting torque.

(2) Effective when stable operation is required to move smoothly up from the low speeds.

(3) Effective in elimination of load fluctuations caused by motor slippage.

- Motor constant must be set

If the motor you are using is a 4P Toshiba standard motor which has the same capacity as the inverter, there is basically no need to set the motor constant. There are three setting methods as mentioned below. In any method, set the following parameters according to the motor's name plate.

$\omega L$  (Base frequency 1),  $\omega L \omega$  (Base frequency voltage 1),  $F 4 0 5$  (Motor rated capacity),  $F 4 1 5$  (Motor rated current),  $F 4 1 7$  (Motor rated speed)

- 1) Simultaneous setting of vector control and auto-tuning ( $F400=2$ )  
Set the basic parameter  $R12$  (Torque boost setting macro function) to 2  
⇒ Refer to section 6.1.5 for details.
- 2) Automatic setting  
Set the extended parameter  $F400$  (auto-tuning) to 5. ⇒ Refer to section 6.25 selection 2 for details.
- 3) Manual setting  
Set each motor constant. ⇒ Refer to section 6.25 selection 4 for details.

## 5) Energy-saving

Setting of V/F control mode selection  $P1$  to 4 (Energy-saving)

Energy can be saved in all speed areas by detecting load current and flowing the optimum current that fits the load.

If the motor you are using is a 4P Toshiba standard motor which has the same capacity as the inverter, there is basically no need to set the motor constant. There are three setting methods as mentioned below. In any method, set the following parameters according to the motor's name plate.

$\omega L$  (Base frequency 1),  $\omega L \omega$  (Base frequency voltage 1),  $F405$  (Motor rated capacity),  $F415$  (Motor rated current),  $F417$  (Motor rated speed)

- 1) Simultaneous setting of energy-saving and auto-tuning ( $F400=2$ )  
Set the basic parameter  $R12$  (Torque boost setting macro function) to 3  
⇒ Refer to section 6.1.5 for details.
- 2) Automatic setting  
Set the extended parameter  $F400$  (auto-tuning) to 5. ⇒ Refer to section 6.25 selection 2 for details.
- 3) Manual setting  
Set each motor constant. ⇒ Refer to section 6.25 selection 4 for details.

## 6) Achieving further energy savings

Setting of V/F control mode selection  $P1$  to 5 (Dynamic energy-saving)

More substantial energy savings than those provided by setting  $P1$  to 4 can be achieved in any speed range by keeping track of the load current and passing a current appropriate to the load. The inverter cannot respond to rapid load fluctuations, so that this feature should be used only for loads, such as fans and pumps, that are free of violent load fluctuations.

### • Motor constant must be set

If the motor you are using is a 4P Toshiba standard motor which has the same capacity as the inverter, there is basically no need to set the motor constant. There are two setting methods as mentioned below. In any method, set the following parameters according to the motor's name plate.

$\omega L$  (Base frequency 1),  $\omega L \omega$  (Base frequency voltage 1),  $F405$  (Motor rated capacity),  $F415$  (Motor rated current),  $F417$  (Motor rated speed)

- 1) Automatic setting  
Set the extended parameter  $F400$  (auto-tuning) to 5. ⇒ Refer to section 6.25 selection 2 for details.
- 2) Manual setting  
Set each motor constant. ⇒ Refer to section 6.25 selection 4 for details.

## 7) Operating a permanent magnet motor

Setting of V/f control mode selection  $P\bar{k}$  to  $\bar{6}$  (PM motor control)

Permanent magnet motors (PM motors) that are light, small in size and highly efficient, as compared to induction motors, can be operated in sensor-less operation mode.

Note that this feature can be used only for specific motors. For more information, contact your Toshiba distributor.

## 8) Setting of V/f characteristic arbitrarily


Setting of V/f control mode selection  $P\bar{k}$  to  $\bar{7}$  (V/f 5-point setting)

In this mode, the base frequency and the base frequency voltage for the V/f control need to be set to operate the motor while switching a maximum of 5 different V/f characteristics.

[Parameter setting]

| Title    | Function                          | Adjustment range             | Default setting |
|----------|-----------------------------------|------------------------------|-----------------|
| $F\ 190$ | V/f 5-point setting VF1 frequency | $0.0 \sim F\ H$ (Hz)         | $0.0$           |
| $F\ 191$ | V/f 5-point setting VF1 voltage   | $0.0 \sim 125.0$ (%) / (V) * | $0.0$           |
| $F\ 192$ | V/f 5-point setting VF2 frequency | $0.0 \sim F\ H$ (Hz)         | $0.0$           |
| $F\ 193$ | V/f 5-point setting VF2 voltage   | $0.0 \sim 125.0$ (%) / (V) * | $0.0$           |
| $F\ 194$ | V/f 5-point setting VF3 frequency | $0.0 \sim F\ H$ (Hz)         | $0.0$           |
| $F\ 195$ | V/f 5-point setting VF3 voltage   | $0.0 \sim 125.0$ (%) / (V) * | $0.0$           |
| $F\ 196$ | V/f 5-point setting VF4 frequency | $0.0 \sim F\ H$ (Hz)         | $0.0$           |
| $F\ 197$ | V/f 5-point setting VF4 voltage   | $0.0 \sim 125.0$ (%) / (V) * | $0.0$           |
| $F\ 198$ | V/f 5-point setting VF5 frequency | $0.0 \sim F\ H$ (Hz)         | $0.0$           |
| $F\ 199$ | V/f 5-point setting VF5 voltage   | $0.0 \sim 125.0$ (%) / (V) * | $0.0$           |

\* 100% value is 200V for 240V class, and 400V for 500V class.



Note 1: Restrict the value of torque to boost ( $u\ b$ ) to 3% or so. Boosting the torque too much may impair the linearity between points.

Note 2: Please note if the inclination of each V/f is too high (exceeding 8.25%/Hz),  $R\ 02$  (Points setting alarm 2) will occur.


## 9) Cautions for vector control

- 1) When performing vector control, look at the motor's name plate and set the following parameters.  
 $\omega_L$  (Base frequency 1),  $\omega_L \omega$  (Base frequency voltage 1),  $F_{405}$  (Motor rated capacity),  $F_{415}$  (Motor rated current),  $F_{417}$  (Motor rated speed)
- 2) The sensorless vector control exerts its characteristics effectively in frequency areas below the base frequency ( $\omega_L$ ). The same characteristics will not be obtained in areas above the base frequency.
- 3) Set the base frequency to anywhere from 40 to 120Hz during vector control ( $P_{12} = 3$ ).
- 4) Use a general purpose squirrel-cage motor with a capacity that is the same as the inverter's rated capacity or one rank below. The minimum applicable motor capacity is 0.1kW.
- 5) Use a motor that has 2-8 P.
- 6) Always operate the motor in combination of one motor for one inverter. Sensorless vector control cannot be used when one inverter is operated with more than one motor.  
 When using a combination of several motors, set the V/F constant ( $P_{12} = 0$ ).
- 7) The maximum length of wires between the inverter and motor is 30 meters. If the wires are longer than 30 meters, set standard auto-tuning with the wires connected to improve low-speed torque during sensorless vector control.  
 However the effects of voltage drop cause motor-generated torque in the vicinity of rated frequency to be somewhat lower.
- 8) When a reactor is connected between the inverter and a motor, the motor's generated torque may fall. Setting auto-tuning may also cause a trip ( $E_{12n}$ ) rendering sensorless vector control unusable.

# 6.4 Manual torque boost - increasing torque boost at low speeds

**u b**: Torque boost value 1

- Function  
If torque is inadequate at low speeds, increase torque by raising the torque boost rate with this parameter.



[Parameter setting]

| Title      | Function             | Adjustment range | Default setting                               |
|------------|----------------------|------------------|-----------------------------------------------|
| <b>u b</b> | Torque boost value 1 | 0.0 - 30.0 (%)   | According to model<br>(Refer to section 11.4) |

- Valid when **P 5** is set to 0 (V/F constant), 1 (Variable torque), or 7 (V/F 5-point setting).

Note 1: The optimum value is programmed for each inverter capacity by default setting. Be careful not to increase the torque boost rate too much because it could cause an overcurrent trip at startup.

## 6.5 Signal Output

### 6.5.1 Output running signal and braking signal (Low-speed signal)

Refer to section 7.2.2 for output terminal function.

**$F 100$** : Low-speed signal output frequency

- Function


When the output frequency exceeds the setting of  $F 100$ , an ON signal will be generated. This signal can be used as an operation signal when  $F 100$  is set to 0.0Hz, because an ON signal is put out if the output frequency exceeds 0.0Hz. This signal can also be used as an electromagnetic brake excitation/release signal.

- Output from the relay output terminal RY-RC. (Default)

Output from the terminal FLA-FLB-FLC and OUT are possible by the parameter settings.

[Parameter setting]

| Title   | Function                          | Adjustment range | Default setting |
|---------|-----------------------------------|------------------|-----------------|
| $F 100$ | Low-speed signal output frequency | 0.0 - $F H$ (Hz) | 0.0             |



- Output terminal setting

Low-speed signal (ON signal) is output from RY-RC terminal by default setting.

Change this setting to invert the polarity of the signal.

[Parameter setting]

| Title   | Function                             | Adjustment range                 | Default setting                     |
|---------|--------------------------------------|----------------------------------|-------------------------------------|
| $F 130$ | Output terminal selection 1A (RY-RC) | 0-255<br>(Refer to section 11.7) | 4: LOW (Low-speed detection signal) |

Setting value 5 is reverse signal.

Note) Set  $F 132$  to output to FLA-FLC-FLB terminals and  $F 131$  to OUT terminal.

## 6.5.2 Output of designated frequency reach signal

### $F102$ : Speed reach detection band

- Function

When the output frequency becomes equal to the setting by designated frequency  $\pm F102$ , an ON or OFF signal is generated.

[Parameter setting]

#### ■Parameter setting of designated frequency and detection band


| Title  | Function                   | Adjustment range | Default setting |
|--------|----------------------------|------------------|-----------------|
| $F102$ | Speed reach detection band | 0.0- $FH$ (Hz)   | 2.5             |

#### ■Parameter setting of output terminal selection

| Title  | Function                           | Adjustment range                  | Default setting                                                                      |
|--------|------------------------------------|-----------------------------------|--------------------------------------------------------------------------------------|
| $F131$ | Output terminal selection 2A (OUT) | 0-255<br>(Refer to section 11.7.) | 6: RCH (Output frequency attainment signal<br>(acceleration/deceleration completed)) |

Setting value 7 is reverse signal.

Note: Set  $F132$  to output to FLA-FLC-FLB terminals and  $F130$  to RY-RC terminal.



## 6.5.3 Output of set frequency speed reach signal

**F101**: Speed reach setting frequency

**F102**: Speed reach detection band

- Function

When the output frequency becomes equal to the frequency set by **F101**  $\pm$  **F102, an ON or OFF signal is generated.**

[Parameter setting]

■Parameter setting of frequency and detection band

| Title       | Function                      | Adjustment range               | Default setting |
|-------------|-------------------------------|--------------------------------|-----------------|
| <b>F101</b> | Speed reach setting frequency | 0.0- <i>F<sub>H</sub></i> (Hz) | 0.0             |
| <b>F102</b> | Speed reach detection band    | 0.0- <i>F<sub>H</sub></i> (Hz) | 2.5             |


■Parameter setting of output terminal selection

| Title       | Function                           | Adjustment range                  | Setting                                   |
|-------------|------------------------------------|-----------------------------------|-------------------------------------------|
| <b>F131</b> | Output terminal selection 2A (OUT) | 0-255<br>(Refer to section 11.7.) | 8: RCHF (Set frequency attainment signal) |

Setting value 9 is reverse signal.

Note: Set **F132** to assign to FLA-FLC-FLB terminals and **F130** to RY-RC terminal.

If the detection band value + the set frequency is less than the designated frequency



6.6 Input signal selection

6.6.1 Priority selection (Both F and R are ON)

**F 105**: Priority selection (Both F and R are ON)


- Function  
This parameter allows you to select the direction in which the motor runs when a forward run (F) command and a reverse run (R) command are entered simultaneously.  
1) Reverse  
2) Deceleration stop

[Parameter setting]


| Title        | Function                                    | Adjustment range                   | Default setting |
|--------------|---------------------------------------------|------------------------------------|-----------------|
| <b>F 105</b> | Priority selection<br>(Both F and R are ON) | 0: Reverse<br>1: Deceleration stop | 1               |

6

(1) [**F 105** = 0 (Reverse)]: If an F command and an R command are entered simultaneously, **the motor will run in the reverse direction.**



- (2) [ $F105 = 1$  (Stop)]: If an F command and an R command are entered simultaneously, **the motor will deceleration stop.**



## 6.6.2 Changing the voltage range of VIB terminal

**[ $F107$ ]**: Analog input terminal selection (VIB)

- Function  
This parameter allows you to choose the voltage signal input for the VIB terminal.

[Parameter setting]

| Title  | Function                              | Adjustment range         | Default setting |
|--------|---------------------------------------|--------------------------|-----------------|
| $F107$ | Analog input terminal selection (VIB) | 0: 0-+10V<br>1: -10-+10V | 0               |

- $F107=0$ : Input 0 to +10Vdc to VIB-CC terminals.  
Resolution is maximum 1/1000 between 0 to +10Vdc.
- $F107=1$ : Input -10 to +10Vdc to VIB-CC terminals.  
Resolution is maximum 1/2000 between -10 to +10Vdc.

6.6.3 Changing the functions of VIA and VIB terminals

**F 109**: Analog/logic input selection (VIA/VIB)

- Function  
This parameter allows you to choose between analog signal input and contact signal input for the VIA and VIB terminals.

| [Parameter setting] |                                        |                                                        |                 |
|---------------------|----------------------------------------|--------------------------------------------------------|-----------------|
| Title               | Function                               | Adjustment range                                       | Default setting |
| F 109               | Analog/logic input selection (VIA/VIB) | 0: VIA - analog input<br>VIB - analog input            | 0               |
|                     |                                        | 1: VIA - analog input<br>VIB - contact input           |                 |
|                     |                                        | 2: -                                                   |                 |
|                     |                                        | 3: VIA - contact input (Sink)<br>VIB - contact input   |                 |
|                     |                                        | 4: VIA - contact input (Source)<br>VIB - contact input |                 |

Note) When using VIA terminal as contact input terminals, be sure to insert a resistor between P24 terminal and VIA terminal in sink logic connection, and insert a resistor between VIA terminal and CC terminal in source logic connection. (Recommended resistance: 4.7kΩ-1/2W)

When using VIB terminal as contact input terminals, set the upper side of slide switch SW2 to S4 side and then set **F 109**.

## 6.7 Terminal function selection

### 6.7.1 Keeping an input terminal function always active (ON)

**F104**: Always active function selection 1

**F108**: Always active function selection 2

**F110**: Always active function selection 3

- Function

This parameter specifies an input terminal function that is always to be kept active (ON).

[Parameter setting]

| Title       | Function                           | Adjustment range                              | Default setting |
|-------------|------------------------------------|-----------------------------------------------|-----------------|
| <b>F104</b> | Always active function selection 1 | 0-7, 10-153: Refer to section 11.6.<br>8,9: - | 0 (No function) |
| <b>F108</b> | Always active function selection 2 | 0-7, 10-153: Refer to section 11.6.<br>8,9: - | 0 (No function) |
| <b>F110</b> | Always active function selection 3 | 0-7, 10-153: Refer to section 11.6.<br>8,9: - | 6 (ST)          |




#### Explanation of the coast stop function

When ST (Standby) is OFF, coast stops.  
The default setting for ST (Standby) is ON. Please change the following settings:

- **F110=0** (no function)
- Assign open input terminal 6: ST (Standby).

Coast stops if terminal set for ST (Standby) is set to OFF. The monitor on the inverter at this time displays

**OFF**



Note1) Input terminal function 8, 9 (Reset command and its inversion) cannot be assigned.

## 6.7.2 Modifying input terminal functions

|                                                      |                                                       |
|------------------------------------------------------|-------------------------------------------------------|
| <b>F111</b> : Input terminal selection 1A (F)        | <b>F151</b> : Input terminal selection 1B (F)         |
| <b>F112</b> : Input terminal selection 2A (R)        | <b>F152</b> : Input terminal selection 2B (R)         |
| <b>F113</b> : Input terminal selection 3A (RES)      | <b>F153</b> : Input terminal selection 3B (RES)       |
| <b>F114</b> : Input terminal selection 4A (S1)       | <b>F154</b> : Input terminal selection 4B (S1)        |
| <b>F115</b> : Input terminal selection 5 (S2)        | <b>F155</b> : Input terminal selection 1C (F)         |
| <b>F116</b> : Input terminal selection 6 (S3)        | <b>F156</b> : Input terminal selection 2C (R)         |
| <b>F109</b> : Analog/logic input selection (VIA/VIB) | <b>F144</b> : Input terminal response time            |
| <b>F117</b> : Input terminal selection 7 (VIB)       | <b>F146</b> : Logic input/ pulse input selection (S2) |
| <b>F118</b> : Input terminal selection 8 (VIA)       | <b>F147</b> : Logic input/ PTC input selection (S3)   |

⇒ Refer to section 7.2.1 for details about input terminal functions.

## 6.7.3 Modifying output terminal functions

|                                                            |
|------------------------------------------------------------|
| <b>F130</b> : Output terminal selection 1A (RY-RC)         |
| <b>F131</b> : Output terminal selection 2A (OUT)           |
| <b>F132</b> : Output terminal selection 3 (FL)             |
| <b>F137</b> : Output terminal selection 1B (RY-RC)         |
| <b>F138</b> : Output terminal selection 2B (OUT)           |
| <b>F139</b> : Output terminal logic selection (RY-RC, OUT) |

⇒ Refer to section 7.2.2 for details about output terminal functions.

## 6.8 Basic parameters 2

### 6.8.1 Switching motor characteristics via terminal input

**F170**: Base frequency 2

**F171**: Base frequency voltage 2

**F172**: Torque boost value 2

**F173**: Motor electronic-thermal protection level 2

**F185**: Stall prevention level 2

- Function

Use the above parameters to switch the operation of two motors with a single inverter and to select motor V/F characteristics (two types) according to the particular needs or operation mode.

Note: The  $P_L$  (V/F control mode selection) parameter is enabled only for motor 1.

If motor 2 is selected, V/F control will be given constant torque characteristics.

6

[Parameter setting]

| Title       | Function                                    | Adjustment range                                   | Default setting                               |
|-------------|---------------------------------------------|----------------------------------------------------|-----------------------------------------------|
| <b>F170</b> | Base frequency 2                            | 20.0-500.0                                         | *1                                            |
| <b>F171</b> | Base frequency voltage 2                    | 50-330 (V) (240V class)<br>50-660 (V) (500V class) | *1                                            |
| <b>F172</b> | Torque boost value 2                        | 0.0-30.0 (%)                                       | Depending on model<br>(Refer to section 11.4) |
| <b>F173</b> | Motor electronic-thermal protection level 2 | 10-100 (%) / (A) *2                                | 100                                           |
| <b>F185</b> | Stall prevention level 2                    | 10-199 (%) / (A),<br>200 : Disabled *2             | 150                                           |

\*1: Default setting values vary depending on the setup menu. Refer to section 11.5.

\*2: The inverter's rated current is 100%. When  $F173$  : (current and voltage unit selection)

= I (A (amps)/V (volts)) is set, it can be set at A (amps).

## ■ Setting of switching terminals

To switch to motor 2, assign the following functions to a terminal not being used. It is also possible to switch to acceleration/deceleration 2 (AD2). Refer to section 6.27 for details.

It is possible to set 3 functions for terminal F and R, and 2 functions for terminal S1 and RES.

| Input terminal function number |           |           |            |             | Parameters changed from applicable parameters and default standards                                                                                                                                                                          |
|--------------------------------|-----------|-----------|------------|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 24<br>AD2                      | 26<br>AD3 | 28<br>VF2 | 32<br>OCS2 | 152<br>MOT2 |                                                                                                                                                                                                                                              |
| OFF                            | OFF       | OFF       | OFF        | OFF         | Default setting : $Pt, uL, uLv, ub, tHr, ACC, dEC, F502, F601$                                                                                                                                                                               |
| ON                             | OFF       | OFF       | OFF        | OFF         | $ACC \rightarrow F500, dEC \rightarrow F501, F502 \rightarrow F503$                                                                                                                                                                          |
| OFF                            | ON        | OFF       | OFF        | OFF         | $ACC \rightarrow F510, dEC \rightarrow F511, F502 \rightarrow F512$                                                                                                                                                                          |
| OFF                            | OFF       | ON        | OFF        | OFF         | During stop : $Pt \rightarrow V/F$ constant, $uL \rightarrow F170, uLv \rightarrow F171, ub \rightarrow F172, tHr \rightarrow F173$<br>During run : $uL \rightarrow F170, uLv \rightarrow F171, ub \rightarrow F172$                         |
| OFF                            | OFF       | OFF       | ON         | OFF         | $F601 \rightarrow F185$                                                                                                                                                                                                                      |
| -                              | OFF       | -         | -          | ON          | $Pt \rightarrow 0, uL \rightarrow F170, uLv \rightarrow F171, ub \rightarrow F172, tHr \rightarrow F173$ ( $tHr$ is fixed when $F632=2$ or $3$ ), $F601 \rightarrow F185, ACC \rightarrow F500, dEC \rightarrow F501, F502 \rightarrow F503$ |

Note 1: Each of the following numbers (25, 27, 29, 33, 153) are reverse signals.

Note 2:  $Pt$  and "V/F constant" cannot be switched while running. Stop the motor before switching.


It is necessary to wait to start the motor for 0.2 seconds or more after switching it.

$uL$  and  $F170$ ,  $uLv$  and  $F171$ ,  $ub$  and  $F172$  can be switched while running.

Note 3: If motor is switched, the setting to retain and subtract an integral value of motor electronic thermal is possible.

Refer to section 5.6 for details.

## ■ Example of setting a terminal for switching: Sink logic



## 6.9 V/f 5-point setting

---

**F190** : V/f5-point setting VF1 frequency

**F191** : V/f 5-point setting VF1 voltage

**F192** : V/f 5-point setting VF2 frequency

**F193** : V/f 5-point setting VF2 voltage

**F194** : V/f 5-point setting VF3 frequency

**F195** : V/f 5-point setting VF3 voltage

**F196** : V/f 5-point setting VF4 frequency

**F197** : V/f 5-point setting VF4 voltage

**F198** : V/f 5-point setting VF5 frequency

**F199** : V/f 5-point setting VF5 voltage

⇒ For details, refer to 8) of section 6.3.

## 6.10 Frequency priority selection

---

### 6.10.1 Using two frequency commands according to the particular situation

**F00d** : Frequency setting mode selection 1

**F200** : Frequency priority selection

**F201** : Frequency setting mode selection 2

⇒ For details, refer to section 5.8.

## 6.10.2 Setting frequency command characteristics

|             |                                         |
|-------------|-----------------------------------------|
| <b>F107</b> | Analog input terminal selection(VIB)    |
| <b>F109</b> | Analog/logic input selection (VIA/VIB)  |
| <b>F201</b> | VIA input point 1 setting               |
| <b>F202</b> | VIA Input point 1 frequency             |
| <b>F203</b> | VIA Input point 2 setting               |
| <b>F204</b> | VIA Input point 2 frequency             |
| <b>F209</b> | Analog input filter                     |
| <b>F210</b> | VIB input point 1 setting               |
| <b>F211</b> | VIB input point 1 frequency             |
| <b>F212</b> | VIB input point 2 setting               |
| <b>F213</b> | VIB input point 2 frequency             |
| <b>F216</b> | VIC input point 1 setting               |
| <b>F217</b> | VIC input point 1 frequency             |
| <b>F218</b> | VIC input point 2 setting               |
| <b>F219</b> | VIC input point 2 frequency             |
| <b>F810</b> | Communication command point selection   |
| <b>F811</b> | Communication command point 1 setting   |
| <b>F812</b> | Communication command point 1 frequency |
| <b>F813</b> | Communication command point 2 setting   |
| <b>F814</b> | Communication command point 2 frequency |

- Function

Output frequency is adjusted in relation to frequency command according to external analog signals.  
VIA and VIB terminals are set to analog input.

**F209** analog input filter is effective for eliminating noise from frequency setting circuit. Increase the value if operation cannot be done because noise effects stability.

- To fine adjust the frequency command characteristics for analog input, use the parameters **F470** to **F475**. (Refer to section 6.10.3)

[Parameter setting]


| Title        | Function                                | Adjustment range                                                                                                                                                                                                      | Default setting |
|--------------|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F 107</i> | Analog input terminal selection (VIB)   | 0: 0-+10V<br>1: -10-+10V                                                                                                                                                                                              | 0               |
| <i>F 109</i> | Analog/logic input selection (VIA/VIB)  | 0: VIA - analog input<br>VIB - analog input<br>1: VIA - analog input<br>VIB - contact input<br>2: -<br>3: VIA - contact input (Sink)<br>VIB - contact input<br>4: VIA - contact input (Source)<br>VIB - contact input | 0               |
| <i>F 201</i> | VIA input point 1 setting               | 0-100 (%)                                                                                                                                                                                                             | 0               |
| <i>F 202</i> | VIA input point 1 frequency             | 0.0-500.0 (Hz)                                                                                                                                                                                                        | 0.0             |
| <i>F 203</i> | VIA input point 2 setting               | 0-100 (%)                                                                                                                                                                                                             | 100             |
| <i>F 204</i> | VIA input point 2 frequency             | 0.0-500.0 (Hz)                                                                                                                                                                                                        | *1              |
| <i>F 209</i> | Analog input filter                     | 2-1000 (ms)                                                                                                                                                                                                           | 64              |
| <i>F 210</i> | VIB input point 1 setting               | -100-+100 (%)                                                                                                                                                                                                         | 0               |
| <i>F 211</i> | VIB input point 1 frequency             | 0.0-500.0 (Hz)                                                                                                                                                                                                        | 0.0             |
| <i>F 212</i> | VIB input point 2 setting               | -100-+100 (%)                                                                                                                                                                                                         | 100             |
| <i>F 213</i> | VIB input point 2 frequency             | 0.0-500.0 (Hz)                                                                                                                                                                                                        | *1              |
| <i>F 216</i> | VIC input point 1 setting               | 0-100 (%)                                                                                                                                                                                                             | 0               |
| <i>F 217</i> | VIC input point 1 frequency             | 0.0-500.0 (Hz)                                                                                                                                                                                                        | 0               |
| <i>F 218</i> | VIC input point 2 setting               | 0-100 (%)                                                                                                                                                                                                             | 100             |
| <i>F 219</i> | VIC input point 2 frequency             | 0.0-500.0 (Hz)                                                                                                                                                                                                        | *1              |
| <i>F 810</i> | Communication command point selection   | 0: Disabled<br>1: Enabled                                                                                                                                                                                             | 0               |
| <i>F 811</i> | Communication command point 1 setting   | 0-100 (%)                                                                                                                                                                                                             | 0               |
| <i>F 812</i> | Communication command point 1 frequency | 0.0- <i>F H</i> (Hz)                                                                                                                                                                                                  | 0               |
| <i>F 813</i> | Communication command point 2 setting   | 0-100 (%)                                                                                                                                                                                                             | 100             |
| <i>F 814</i> | Communication command point 2 frequency | 0.0- <i>F H</i> (Hz)                                                                                                                                                                                                  | *1              |

\*1: Default setting values vary depending on the setup menu. Refer to section 11.5.


Note 1: Do not set point 1 and 2 to the same value. If they are set to the same value, *E r r i* is displayed.

For details about analog signal setting, refer to section 7.3.


1) 0-10Vdc voltage input adjustment (VIA, VIB terminals)



2) 4-20mA current input adjustment (VIC terminal)



3) -10-+10 Vdc voltage input adjustment (VIB terminal)



### 6.10.3 Fine adjustment of analog frequency command

**F470**: VIA input bias

**F473**: VIB input gain

**F471**: VIA input gain

**F474**: VIC input bias

**F472**: VIB input bias


**F475**: VIC input gain

- Function

These parameters are used to fine adjust the relation between the frequency command input through the analog input terminal VIA, VIB, VIC and the output frequency.

Use these parameters to make fine adjustments after making rough adjustments using the parameters *F201* to *F204*, *F210* to *F213*, *F216* to *F219*.

The figure below shows the characteristic of the frequency command input through the VI terminal and that of the output frequency.



- \* Bias adjustment of analog input terminal (*F470*, *F472*, *F474*)

Decrease the value in case frequency is output even though the frequency command is 0 (zero) Hz.

- \* Gain adjustment of analog input terminal (*F471*, *F473*, *F475*)

Increase the value in case the output frequency doesn't reach the maximum frequency even though the maximum voltage and current are applied.

## 6.10.4 Setting of frequency with the input from an external logic

**F254**: External logic input - UP response time

**F255**: External logic input - UP frequency steps

**F256**: External logic input - DOWN response time

**F257**: External logic input - DOWN frequency steps

**F258**: Initial value of UP/DOWN frequency

**F259**: Change of the initial value of UP/DOWN frequency

- Function

These parameters are used to set an output frequency by means of a signal from an external device.

Parameter setting

| Title       | Function                                         | Adjustment range                                                             | Default setting |
|-------------|--------------------------------------------------|------------------------------------------------------------------------------|-----------------|
| <b>F254</b> | External logic input - UP response time          | 0.0 - 10.0 (s)                                                               | 0.1             |
| <b>F255</b> | External logic input - UP frequency steps        | 0.0 - $F_H$ (Hz)                                                             | 0.1             |
| <b>F256</b> | External logic input - DOWN response time        | 0.0 - 10.0 (s)                                                               | 0.1             |
| <b>F257</b> | External logic input - DOWN frequency steps      | 0.0 - $F_H$ (Hz)                                                             | 0.1             |
| <b>F258</b> | Initial value of UP/DOWN frequency               | $L_L - U_L$ (Hz)                                                             | 0.0             |
| <b>F259</b> | Change of the initial value of UP/DOWN frequency | 0: Not changed<br>1: Setting of <b>F258</b> changed when power is turned off | 1               |

- This function is valid when the parameter **F00d** (Frequency setting mode selection 1) = 5 is set.

### Input terminal settings

Assigning the following functions to the input terminal will allow you to change (up/down) or clear the output frequency by using the terminal's ON/OFF.

| Input terminal function |                         | ON                                                        | OFF                  |
|-------------------------|-------------------------|-----------------------------------------------------------|----------------------|
| 88                      | Frequency UP            | Frequency setting increase                                | Clear                |
| 90                      | Frequency DOWN          | Frequency setting decrease                                | Clear                |
| 92                      | Clear frequency UP/DOWN | OFF → ON: External logic up/down frequency clear settings | <b>F258</b> settings |

Each of the following numbers (89, 91, 93) are reverse signals.

### ■ Adjustment with continuous signals (Operation example 1)

Set parameters as follows to adjust the output frequency up or down in proportion to the frequency adjustment signal input time:

External logic input up/down frequency incremental gradient =  $F265/F264$  setting time

External logic input up/down frequency decremental gradient =  $F267/F266$  setting time


Set parameters as follows to adjust the output frequency up or down almost synchronously with the adjustment by the external logic input up/down frequency command:

$F264 = F266 = 0.1$

$(FHIRC) \geq (F265/F264 \text{ setting time})$

$(FHIDE) \geq (F267/F266 \text{ setting time})$

<<Sample sequence diagram 1: Adjustment with continuous signals>>



6

### ■ Adjustment with pulse signals (Operation example 2)


Set parameters as follows to stepwise adjust the frequency by one pulse:

$F264, F266 \leq$  Pulse On time

$F265, F267 =$  Frequency obtained with each pulse

\* The inverter does not respond to any pulses with an ON time shorter than that set with  $F264$  or  $F266$ . 12ms or more of clearing signal is allowed.

&lt;&lt;Sample sequence diagram 2: Adjustment with pulse signals&gt;&gt;



#### ■ If two signals are impressed simultaneously

- If a clear single and an up or down signal are impressed simultaneously, priority will be given to the clear signal.
- If up and down signals are impressed simultaneously, the frequency will change at the specified up or down rate.

#### ■ The setting of the initial up/down frequency

To adjust the frequency starting at a specified frequency other than 0.0 Hz (default initial frequency) after turning on the inverter, specify the desired frequency by setting the parameter  $F268$  (initial up/down frequency). Also, set  $F269$  (change of initial up/down frequency) to 0 (Not changed).

#### ■ The change of the initial up/down frequency

To make the inverter automatically save the frequency immediately before the power is off and start operation at that frequency next time power is on, set  $F269$  (change of initial up/down frequency) to 1 (which changes the setting of  $F268$  when power is turned off). Keep in mind that the setting of  $F268$  is changed each time power is turned off.

#### ■ Frequency adjustment range

The frequency can be set from  $L_L$  (lower limit frequency) to  $F_H$  (Maximum frequency). The lower-limit frequency will be set as soon as the set frequency clearing function (function number 92, 93) is entered from the input terminal.

#### ■ Minimum unit of frequency adjustment

If  $F702$  (Frequency free unit magnification) is set to 1.00, the output frequency can be adjusted in steps of 0.01Hz.

## 6.10.5 Setting of frequency with the pulse train input

**F146**: Logic input / pulse train input selection (S2)

**F378**: Number of pulse train input

**F679**: Pulse train input filter

- Function

These parameters are used to set output frequency by means of pulse train input signal of S2 terminal.

[Parameter setting]

| Title       | Function                                       | Adjustment range                       | Default setting |
|-------------|------------------------------------------------|----------------------------------------|-----------------|
| <b>F146</b> | Logic input / pulse train input selection (S2) | 0: Logic input<br>1: Pulse train input | 0               |
| <b>F378</b> | Number of pulse train input                    | 10-500 (pps)                           | 25              |
| <b>F679</b> | Pulse train input filter                       | 2-1000 (ms)                            | 2               |

- This function is valid when the parameter **F00d = 11** (Pulse train input) and **F146 = 1** (Pulse train input) are set.
- Number of pulses per 1Hz of output frequency is set by parameter **F378**.
- Example of setting

|                          |                          |                                |
|--------------------------|--------------------------|--------------------------------|
| <b>F378</b> = 25 (pps) : | Input signal = 25 (pps)  | ⇒ Output frequency = 1.0 (Hz)  |
|                          | Input signal = 100 (pps) | ⇒ Output frequency = 4.0 (Hz)  |
|                          | Input signal = 2k (pps)  | ⇒ Output frequency = 80.0 (Hz) |
| <b>F378</b> = 50 (pps) : | Input signal = 50 (pps)  | ⇒ Output frequency = 1.0 (Hz)  |
|                          | Input signal = 100 (pps) | ⇒ Output frequency = 2.0 (Hz)  |
|                          | Input signal = 2k (pps)  | ⇒ Output frequency = 40.0 (Hz) |

Note 1) Minimum number of pulses to inputting S2 terminal is 10 pps, and Maximum is 2 kpps.  
Duty is 50 ± 10%.

Note 2) The maximum frequency output by this function is 200Hz.

## 6.11 Operation frequency

### 6.11.1 Starting frequency/ Stop frequency

**F240**: Starting frequency

**F243**: Stop frequency setting

- Function

The frequency set with **F240** is put out instantly when operation is started.


Use the **F240** parameter when a delay in response of starting torque due to the acceleration/deceleration time may affect the operation. Setting the starting frequency to a value from 0.5 to 3.0Hz is recommended. The occurrence of an overcurrent can be avoided by setting this frequency below the rated slippage of the motor.

When starting: Frequency set with **F240** is output instantly.

When stopping: Output frequency turns to be 0Hz instantly with the frequency set with **F243**.

[Parameter setting]

| Title       | Function               | Adjustment range                          | Default setting |
|-------------|------------------------|-------------------------------------------|-----------------|
| <b>F240</b> | Starting frequency     | 0.1-10.0 (Hz)                             | 0.5             |
| <b>F243</b> | Stop frequency setting | 0.0: Same as <b>F240</b><br>0.1-30.0 (Hz) | 0.0             |



Note: Set these parameters so that the starting frequency **F240** is higher than the stopping frequency **F243**.

If the **F240**-set frequency is lower than the **F243**-set frequency, the inverter doesn't start when the frequency command is **F243**-set frequency or less.

## 6.11.2 Run/stop control with frequency command


**F241**: Operation starting frequency

**F242**: Operation starting frequency hysteresis

- Function  
The Run/stop of operation can be controlled simply with frequency command.

[Parameter setting]

| Title       | Function                                | Adjustment range | Default setting |
|-------------|-----------------------------------------|------------------|-----------------|
| <b>F241</b> | Operation starting frequency            | 0.0- $F_H$ (Hz)  | 0.0             |
| <b>F242</b> | Operation starting frequency hysteresis | 0.0- $F_H$ (Hz)  | 0.0             |



## 6.12 DC braking

### 6.12.1 DC braking

**F249**: PWM carrier frequency during DC braking

**F250**: DC braking starting frequency

**F251**: DC braking current


**F252**: DC braking time

- Function

A large braking torque can be obtained by applying a direct current to the motor. These parameters set the direct current to be applied to the motor, the application time and the starting frequency.

[Parameter setting]

| Title       | Function                                | Adjustment range  | Default setting |
|-------------|-----------------------------------------|-------------------|-----------------|
| <b>F249</b> | PWM carrier frequency during DC braking | 2.0-16.0 (kHz)    | 4.0             |
| <b>F250</b> | DC braking starting frequency           | 0.0- $F_H$ (Hz)   | 0.0             |
| <b>F251</b> | DC braking current                      | 0.0-100 (%) / (A) | 50              |
| <b>F252</b> | DC braking time                         | 0.0-25.5 (s)      | 1.0             |



Note1: During DC braking, the overload protection sensitivity of the inverter increases. The DC braking current may be adjusted automatically to prevent tripping.

Note 2: During DC braking, the carrier frequency becomes the setting of whichever is lower parameter **F249** or **F300**.

Note 3: DC braking can be done by using the signal at an input terminal. Input terminal 22: Assign DC braking command (23 is reverse). DC braking is applied while the terminal is ON regardless of the **F250**, **F252** settings. Even if the terminal is OFF, DC braking is applied only for the **F252** time. The amount of DC braking depends on the **F251** settings.

## 6.12.2 Motor shaft fixing control

### **F254**: Motor shaft fixing control


- Function

This function is used to preheat the motor or to prevent the motor from running unexpectedly when its shaft is not restrained.

#### [Parameter setting]

| Title       | Function                   | Adjustment range        | Default setting |
|-------------|----------------------------|-------------------------|-----------------|
| <b>F254</b> | Motor shaft fixing control | 0: Disabled, 1: Enabled | 0               |

If the motor shaft fixing control **F254** is set to 1, half amount of the braking force set with **F251** (DC braking rate) will make the motor continue DC braking even after the completion of ordinary DC braking. To stop motor shaft fixing control, turn off the standby command (ST signal).



As the default setting for ST (Standby) is Always ON, change the following settings:

- **F110** = 0 (no function)
- Assign 6: ST (Standby) to an open input terminal.

Note1: Nearly the same motor shaft fixing control can be exercised when entering a DC braking command with the signal at an input terminal.

Note2: If a power failure occurs during motor shaft fixing control and the motor starts to coast, motor shaft fixing control will be canceled.

Also, if the inverter trips during motor shaft fixing control and is restored to working order by the retry

function, motor shaft fixing control will be canceled.

Note 3: During shaft fixing control, the carrier frequency becomes the setting of whichever is lower parameter,  $F249$  or  $F300$ .

## 6.13 Stop at lower-limit frequency operation (sleep function)

**F256**: Time limit for lower-limit frequency operation

**F259**: Lower limit frequency reach time limit at start-up

**F391**: Hysteresis for lower-limit frequency operation

- Function


If operation at the lower-limit frequency ( $LL$ ) is carried out for the time set with  $F256$ , the inverter will automatically decelerate the motor to stop for the purpose of energy-saving. At that time, " $LSLP$ " is displayed (alternately) on the operation panel.

Stop by this function will be canceled if a frequency command value exceeds the lower-limit frequency ( $LL$ ) +  $F391$  (Hz), or if the operation command is OFF. This function will not work until the output frequency reaches  $LL$  at the start of operation.

If the output frequency doesn't reach  $LL$  at the start of operation for malfunction of load, the inverter will automatically stop after the time set with  $F259$  elapses.

[Parameter setting]

| Title  | Function                                           | Adjustment range                 | Default setting |
|--------|----------------------------------------------------|----------------------------------|-----------------|
| $F256$ | Time limit for lower-limit frequency operation     | 0.0: Disabled<br>0.1 - 600.0 (s) | 0.0             |
| $F259$ | Lower limit frequency reach time limit at start-up | 0.0: Disabled<br>0.1 - 600.0 (s) | 0.0             |
| $F391$ | Hysteresis for lower-limit frequency operation     | 0.0- $LL$ (Hz)                   | 0.2             |



Note: This function is valid when doing forward/reverse switching.

When starting operation,  $F256$  function will not work until output frequency reaches  $LL$ .

When the output frequency exceeds  $LL$ ,  $F259$  function will be invalid until operation signal is OFF.

## 6.14 Jog run mode

**F260**: Jog run frequency

**F261**: Jog run stopping pattern

**F262**: Panel jog run mode

- Function

Use the jog run parameters to operate the motor in jog mode. Input of a jog run signal immediately generates a jog run frequency output irrespective of the designated acceleration time.  
Also, you can choose the jog run start/stop mode from the panel.

Assign 18: jog run mode to an input terminal.

Ex) When assigning it to the RES terminal: **F113** to **18**.

The motor can be operated in jog mode while the assigned input terminals are connected (RES-CC ON).

[Parameter setting]

| Title       | Function                 | Adjustment range                                       | Default setting |
|-------------|--------------------------|--------------------------------------------------------|-----------------|
| <b>F260</b> | Jog run frequency        | <b>F240</b> -20.0 (Hz)                                 | 5.0             |
| <b>F261</b> | Jog run stopping pattern | 0: Deceleration stop<br>1: Coast stop<br>2: DC braking | 0               |
| <b>F262</b> | Panel jog run mode       | 0: Invalid<br>1: Valid                                 | 0               |

[Setting of jog run mode (RES-CC)]

Ex) Assign jog run mode to control terminal RES.

| Title       | Function                       | Adjustment range | Setting              |
|-------------|--------------------------------|------------------|----------------------|
| <b>F113</b> | Input terminal selection (RES) | 0-203            | 18<br>(Jog run mode) |

Note 1: During the jog run mode, low speed detection signal (LOW) is output but designated frequency reach signal (RCH) is not output, and PID control does not work.


Note 2: When only the operation panel is used for operation in jog run mode, the jog run function does not need to be assigned to any input terminal.

<Examples of jog run>

RES (JOG): ON + F:ON: Forward jog run

RES(JOG): ON + R: ON: Reverse jog run

(Frequency command + F: ON: Forward run , Frequency command + R: ON: Reverse run)




- The jog run setting terminal (RES-CC) is enabled when the value of operation frequency is that of the jog run frequency and below.  
This connection does not function when operation frequency exceeds the jog run frequency.
- The motor can be operated in jog mode while the jog run setting terminals are connected (RES-CC).
- Jog run has priority to new operation command given during operation.
- Even for  $F 2 5 2 = 0$  or  $1$ , an emergency DC braking ( $F 6 0 3 = 2$ ) is prior to the setting.
- No limits are imposed to the jog run frequency by the upper-limit frequency (parameter  $U L$ ).

#### ■ Panel jog mode (if $F 2 5 2$ is set to $1$ )

- The direction of rotation can change by using extension panel.  
Using RKP007Z : Display switches to  $F 0 0 0$  and  $r 0 0 0$  by every pressing the FWD/REV key.  
Using RKP002Z : Pressing the UP key changes display to  $F 0 0 0$  and pressing the DOWN key changes display to  $r 0 0 0$ .
- When  $F 0 0 0$  is displayed, the inverter will be placed in forward jog run mode as long as the key is pressed.
- When  $r 0 0 0$  is displayed, the inverter will be placed in reverse jog run mode as long as the RUN key is pressed.
- If you press and hold down the RUN key for 20 seconds or more, the key failure alarm " $E - 1 7$ " will be displayed.

Here is the sequence in which modes change each time you press the MODE key.



Note: When the inverter is in operation (RUN lamp is blinking) or when an operation command is issued (RUN lamp is lighting), the inverter cannot be switched to panel jog mode.

## 6.15 Jump frequency - avoiding resonant frequencies

**F270**: Jump frequency 1

**F271**: Jumping width 1

**F272**: Jump frequency 2


**F273**: Jumping width 2

**F274**: Jump frequency 3

**F275**: Jumping width 3

- Function

Resonance due to the natural frequency of the mechanical system can be avoided by jumping the resonant frequency during operation. During jumping, hysteresis characteristics with respect to the jump frequency are given to the motor.



[Parameter setting]

| Title       | Function         | Adjustment range | Default setting |
|-------------|------------------|------------------|-----------------|
| <b>F270</b> | Jump frequency 1 | 0.0- $F_H$ (Hz)  | 0.0             |
| <b>F271</b> | Jumping width 1  | 0.0-30.0 (Hz)    | 0.0             |
| <b>F272</b> | Jump frequency 2 | 0.0- $F_H$ (Hz)  | 0.0             |
| <b>F273</b> | Jumping width 2  | 0.0-30.0 (Hz)    | 0.0             |
| <b>F274</b> | Jump frequency 3 | 0.0- $F_H$ (Hz)  | 0.0             |
| <b>F275</b> | Jumping width 3  | 0.0-30.0 (Hz)    | 0.0             |

Note 1: Do not set the jump parameters, if multiple jump frequency setting width overlap.

Note 2: During acceleration or deceleration, the jumping function doesn't work for the operation frequency.

## 6.16 Bumpless operation

**F295**: Bumpless operation selection

**F732**: Local/remote key prohibition of extension panel

**F750**: Easy key function selection



- Function  
When switching from Remote mode to Local mode, the status of start and stop, and operating frequency at Remote mode are moved to Local mode.  
Running status of Local mode will not moved to Remote mode when switching from Local mode to Remote mode.

[Parameter setting]

| Title       | Function                                        | Adjustment range                                                                                                                                         | Default setting |
|-------------|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F295</b> | Bumpless operation selection                    | 0: Disabled<br>1: Enabled                                                                                                                                | 0               |
| <b>F732</b> | Local/remote key prohibition of extension panel | 0: Permitted<br>1: Prohibited                                                                                                                            | 1               |
| <b>F750</b> | EASY key function selection                     | 0: Easy / standard setting mode switching function<br>1: Shortcut key<br>2: Local / remote key<br>3: Monitor peak / minimum hold trigger<br>4: -<br>5: - | 0               |

- Set Local/remote function to **EASY** key.  
**F750** (EASY key function selection) = 2 (Local / remote key).  
EASY lamp is lighting during local mode.
- Local mode is the operation using operation panel.  
Remote mode is the operation method selected by the command mode selection: **COMMAND** and Frequency setting mode selection: **FREQ**
- LOC/REM key of extension panel option (RKP007Z) is available.  
In this case, set parameter **F732** (Local/remote key prohibition of extension panel) = 0 (Permitted).

Operation example : Remote mode (  $\overline{F255} = \overline{0}$  : (Terminal block))



- To prevent from moving the setting frequency and start/stop status of Remote mode to Local mode, set  $\overline{F255}$  to "0" (Disabled). In this case, EASY key is effective only while stopping.

## 6.17 Low voltage operation

**F297**: Low voltage operation upper limit frequency

**F298**: Low voltage operation DC voltage

⇒ Refer to "Low voltage operation instruction manual: E6581918" for details.

## 6.18 PWM carrier frequency

**AVL**: Overload characteristic selection

**F300**: PWM carrier frequency

**F312**: Random mode

**F316**: PWM carrier frequency control mode selection

• Function

- 1) With the **F300** parameter, the tone of the magnetic noise from the motor can be changed by switching the PWM carrier frequency. This parameter is also effective in preventing the motor from resonating with its load machine or its fan cover.
- 2) In addition, the **F300** parameter reduces the electromagnetic noise generated by the inverter. Reduce the carrier frequency to reduce electromagnetic noise. Note: The electromagnetic noise level is reduced, but the acoustic noise of the motor is increased.
- 3) The random mode improves hearing impression by changing the pattern of the low carrier frequency.
- 4) To set the parameter **F316** to 2 or 3 has the effect of suppressing voltage surge to the motor. Reduce the carrier frequency to 4kHz or less if the wiring between the inverter and motor is long (20 to 100m as a guide).

[Parameter setting]

| Title       | Function                                     | Adjustment range                                                                                                                                                                                                                       | Default setting |
|-------------|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>AVL</b>  | Overload characteristic selection            | 0: -<br>1: Constant torque characteristic (150%-60s)<br>2: Variable torque characteristic (120%-60s)                                                                                                                                   | 0               |
| <b>F300</b> | PWM carrier frequency                        | 2.0-16.0 (kHz)                                                                                                                                                                                                                         | 12.0            |
| <b>F312</b> | Random mode                                  | 0: Disabled<br>1: Random mode 1<br>2: Random mode 2<br>3: Random mode 3                                                                                                                                                                | 0               |
| <b>F316</b> | PWM carrier frequency control mode selection | 0: Carrier frequency without reduction<br>1: Carrier frequency with automatic reduction<br>2: Carrier frequency without reduction (Support for 500V models)<br>3: Carrier frequency with automatic reduction (Support for 500V models) | 1               |

- Note 1: Some models need reduced current ratings, depending on  $F300$  settings and ambient temperature. Refer to the table on the following pages.
- Note 2: Random mode is exercised when the motor is operated in a low-frequency range where it produces annoying acoustic noise.  
As the three kinds of timbre mode ( $F312=1, 2, 3$ ) are prepared, the proper mode can be selected to fit the load condition.  
If  $F300$  is set to 8.0 kHz or more, the random mode function will not be performed, because the level of motor magnetic noise is low at high carrier frequencies.
- Note 3: When the PWM carrier frequency is high, selecting "Carrier frequency without reduction" causes the inverter to be tripped more easily than selecting "Carrier frequency with automatic reduction."
- Note 4: If the motor becomes overloaded when  $F316$  is set to 0 or 2 (carrier frequency not decreased automatically), an overload trip occurs.
- Note 5: For the setting  $F316=2$  or 3 to take effect, power needs to be turned off and then turned back on.
- Note 6: When setting  $F316$  to 2 or 3, be sure to set  $F300$  at 4.0kHz or less.

## ■ De-rating of rated current

[240V class]

In case of  $RUL=1$  (Constant torque characteristic (150%-60s)) setting.

| VFS15-<br>VFS15S- | Ambient temperature | PWM carrier frequency |              |               |
|-------------------|---------------------|-----------------------|--------------|---------------|
|                   |                     | 2.0k~4.0kHz           | 4.1k~12.0kHz | 12.1k~16.0kHz |
| 2002PL-W          | 40°C or less        | 1.5 A                 | 1.5 A        | 1.5 A         |
|                   | Above 40 to 50°C    | 1.5 A                 | 1.2 A        | 1.2 A         |
|                   | Above 50 to 60°C    | 1.2 A                 | 1.1 A        | 1.1 A         |
| 2004 PM/L-W       | 40°C or less        | 3.3 A                 | 3.3 A        | 3.3 A         |
|                   | Above 40 to 50°C    | 3.3 A                 | 2.6 A        | 2.6 A         |
|                   | Above 50 to 60°C    | 2.6 A                 | 2.5 A        | 2.5 A         |
| 2007 PM/L-W       | 40°C or less        | 4.8 A                 | 4.4 A        | 4.2 A         |
|                   | Above 40 to 50°C    | 4.8 A                 | 3.5 A        | 3.4 A         |
|                   | Above 50 to 60°C    | 3.8 A                 | 3.3 A        | 3.2 A         |
| 2015 PM/L-W       | 40°C or less        | 8.0 A                 | 7.9 A        | 7.1 A         |
|                   | Above 40 to 50°C    | 8.0 A                 | 7.9 A        | 7.1 A         |
|                   | Above 50 to 60°C    | 7.6 A                 | 6.3 A        | 5.7 A         |
| 2022 PM/L-W       | 40°C or less        | 11.0 A                | 10.0 A       | 9.1 A         |
|                   | Above 40 to 50°C    | 11.0 A                | 10.0 A       | 9.1 A         |
|                   | Above 50 to 60°C    | 10.5 A                | 8.0 A        | 7.3 A         |
| 2037PM-W          | 40°C or less        | 17.5 A                | 16.4 A       | 14.6 A        |
|                   | Above 40 to 50°C    | 17.5 A                | 16.4 A       | 14.6 A        |
|                   | Above 50 to 60°C    | 16.6 A                | 13.1 A       | 11.7 A        |
| 2055PM-W          | 40°C or less        | 27.5 A                | 25.0 A       | 25.0 A        |
|                   | Above 40 to 50°C    | 27.5 A                | 25.0 A       | 25.0 A        |
|                   | Above 50 to 60°C    | 26.1 A                | 20.0 A       | 20.0 A        |
| 2075PM-W          | 40°C or less        | 33.0 A                | 33.0 A       | 29.8 A        |
|                   | Above 40 to 50°C    | 33.0 A                | 33.0 A       | 29.8 A        |
|                   | Above 50 to 60°C    | 31.4 A                | 26.4 A       | 23.8 A        |

| VFS15-   | Ambient temperature | PWM carrier frequency |              |               |
|----------|---------------------|-----------------------|--------------|---------------|
|          |                     | 2.0k~4.0kHz           | 4.1k~12.0kHz | 12.1k~16.0kHz |
| 2110PM-W | 40°C or less        | 54.0 A                | 49.0 A       | 49.0 A        |
|          | Above 40 to 50°C    | 54.0 A                | 49.0 A       | 49.0 A        |
|          | Above 50 to 60°C    | 51.3 A                | 39.2 A       | 39.2 A        |
| 2150PM-W | 40°C or less        | 66.0 A                | 60.0 A       | 54.0 A        |
|          | Above 40 to 50°C    | 66.0 A                | 60.0 A       | 54.0 A        |
|          | Above 50 to 60°C    | 62.7 A                | 48.0 A       | 43.2 A        |

In case of  $R/L = 2$  (Variable torque characteristic (120%-60s)) setting.

| VFS15-    | Ambient temperature | PWM carrier frequency |
|-----------|---------------------|-----------------------|
|           |                     | 2.0k~4.0kHz           |
| 2004 PM-W | 40°C or less        | 3.5 A                 |
| 2007 PM-W | 40°C or less        | 6.0 A                 |
| 2015 PM-W | 40°C or less        | 9.6 A                 |
| 2022 PM-W | 40°C or less        | 12.0 A                |
| 2037PM-W  | 40°C or less        | 19.6 A                |
| 2055PM-W  | 40°C or less        | 30.0 A                |
| 2075PM-W  | 40°C or less        | 38.6 A                |
| 2110PM-W  | 40°C or less        | 56.0 A                |
| 2150PM-W  | 40°C or less        | 69.0 A                |

| VFS15S-   | Ambient temperature | PWM carrier frequency |
|-----------|---------------------|-----------------------|
|           |                     | 2.0k~4.0kHz           |
| 2002 PL-W | 40°C or less        | 1.9 A                 |
| 2004 PL-W | 40°C or less        | 4.1 A                 |
| 2007 PL-W | 40°C or less        | 5.5 A                 |
| 2015 PL-W | 40°C or less        | 10.0 A                |
| 2022 PL-W | 40°C or less        | 12.0 A                |

[500V class]

In case of  $RUL = 1$  (constant torque characteristic (150%-60s) setting)

(480V or less)

| VFS15-    | Ambient temperature | PWM carrier frequency |              |               |
|-----------|---------------------|-----------------------|--------------|---------------|
|           |                     | 2.0k~4.0kHz           | 4.1k~12.0kHz | 12.1k~16.0kHz |
| 4004 PL-W | 40°C or less        | 1.5 A                 | 1.5 A        | 1.5 A         |
|           | Above 40 to 50°C    | 1.5 A                 | 1.5 A        | 1.5 A         |
|           | Above 50 to 60°C    | 1.4 A                 | 1.2 A        | 1.2 A         |
| 4007 PL-W | 40°C or less        | 2.3 A                 | 2.1 A        | 2.1 A         |
|           | Above 40 to 50°C    | 2.3 A                 | 2.1 A        | 2.1 A         |
|           | Above 50 to 60°C    | 2.2 A                 | 1.7 A        | 1.7 A         |
| 4015 PL-W | 40°C or less        | 4.1 A                 | 3.7 A        | 3.3 A         |
|           | Above 40 to 50°C    | 4.1 A                 | 3.7 A        | 3.3 A         |
|           | Above 50 to 60°C    | 3.9 A                 | 3.0 A        | 2.6 A         |
| 4022 PL-W | 40°C or less        | 5.5 A                 | 5.0 A        | 4.5 A         |
|           | Above 40 to 50°C    | 5.5 A                 | 5.0 A        | 4.5 A         |
|           | Above 50 to 60°C    | 5.2 A                 | 4.0 A        | 3.6 A         |
| 4037 PL-W | 40°C or less        | 9.5 A                 | 8.6 A        | 7.5 A         |
|           | Above 40 to 50°C    | 9.5 A                 | 8.6 A        | 7.5 A         |
|           | Above 50 to 60°C    | 9.0 A                 | 6.9 A        | 6.0 A         |
| 4055 PL-W | 40°C or less        | 14.3 A                | 13.0 A       | 13.0 A        |
|           | Above 40 to 50°C    | 14.3 A                | 13.0 A       | 13.0 A        |
|           | Above 50 to 60°C    | 13.6 A                | 10.4 A       | 10.4 A        |
| 4075 PL-W | 40°C or less        | 17.0 A                | 17.0 A       | 14.8 A        |
|           | Above 40 to 50°C    | 17.0 A                | 17.0 A       | 14.8 A        |
|           | Above 50 to 60°C    | 16.2 A                | 13.6 A       | 11.8 A        |
| 4110 PL-W | 40°C or less        | 27.7 A                | 25.0 A       | 25.0 A        |
|           | Above 40 to 50°C    | 27.7 A                | 25.0 A       | 25.0 A        |
|           | Above 50 to 60°C    | 26.3 A                | 20.0 A       | 20.0 A        |
| 4150 PL-W | 40°C or less        | 33.0 A                | 30.0 A       | 26.0 A        |
|           | Above 40 to 50°C    | 33.0 A                | 30.0 A       | 26.0 A        |
|           | Above 50 to 60°C    | 31.4 A                | 24.0 A       | 20.8 A        |

(over 480V)

| VFS15-    | Ambient temperature | PWM carrier frequency |              |               |
|-----------|---------------------|-----------------------|--------------|---------------|
|           |                     | 2.0k~4.0kHz           | 4.1k~12.0kHz | 12.1k~16.0kHz |
| 4004 PL-W | 40°C or less        | 1.5 A                 | 1.5 A        | 1.2 A         |
|           | Above 40 to 50°C    | 1.5 A                 | 1.5 A        | 1.2 A         |
|           | Above 50 to 60°C    | 1.4 A                 | 1.2 A        | 1.0 A         |
| 4007 PL-W | 40°C or less        | 2.1 A                 | 1.9 A        | 1.9 A         |
|           | Above 40 to 50°C    | 2.1 A                 | 1.9 A        | 1.9 A         |
|           | Above 50 to 60°C    | 2.0 A                 | 1.5 A        | 1.5 A         |
| 4015 PL-W | 40°C or less        | 3.8 A                 | 3.4 A        | 3.1 A         |
|           | Above 40 to 50°C    | 3.8 A                 | 3.4 A        | 3.1 A         |
|           | Above 50 to 60°C    | 3.6 A                 | 2.7 A        | 2.5 A         |
| 4022 PL-W | 40°C or less        | 5.1 A                 | 4.6 A        | 4.2 A         |
|           | Above 40 to 50°C    | 5.1 A                 | 4.6 A        | 4.2 A         |
|           | Above 50 to 60°C    | 4.8 A                 | 3.7 A        | 3.4 A         |
| 4037 PL-W | 40°C or less        | 8.7 A                 | 7.9 A        | 6.9 A         |
|           | Above 40 to 50°C    | 8.7 A                 | 7.9 A        | 6.9 A         |
|           | Above 50 to 60°C    | 8.3 A                 | 6.3 A        | 5.5 A         |
| 4055 PL-W | 40°C or less        | 13.2 A                | 12.0 A       | 12.0 A        |
|           | Above 40 to 50°C    | 13.2 A                | 12.0 A       | 12.0 A        |
|           | Above 50 to 60°C    | 12.5 A                | 9.6 A        | 9.6 A         |
| 4075 PL-W | 40°C or less        | 15.6 A                | 14.2 A       | 12.4 A        |
|           | Above 40 to 50°C    | 15.6 A                | 14.2 A       | 12.4 A        |
|           | Above 50 to 60°C    | 14.8 A                | 11.4 A       | 9.9 A         |
| 4110 PL-W | 40°C or less        | 25.5 A                | 23.0 A       | 23.0 A        |
|           | Above 40 to 50°C    | 25.5 A                | 23.0 A       | 23.0 A        |
|           | Above 50 to 60°C    | 24.2 A                | 18.4 A       | 18.4 A        |
| 4150 PL-W | 40°C or less        | 30.4 A                | 27.6 A       | 24.0 A        |
|           | Above 40 to 50°C    | 30.4 A                | 27.6 A       | 24.0 A        |
|           | Above 50 to 60°C    | 28.9 A                | 22.1 A       | 19.2 A        |

In case of  $RUL = 2$  (Variable torque characteristic (120%-60s)) setting.

| VFS15-    | Ambient temperature | PWM carrier frequency |
|-----------|---------------------|-----------------------|
|           |                     | 2.0k~4.0kHz           |
| 4004 PL-W | 40°C or less        | 2.1 A                 |
| 4007 PL-W | 40°C or less        | 3.0 A                 |
| 4015 PL-W | 40°C or less        | 5.4A                  |
| 4022 PL-W | 40°C or less        | 6.9 A                 |
| 4037 PL-W | 40°C or less        | 11.1 A                |
| 4055 PL-W | 40°C or less        | 17.0A                 |
| 4075 PL-W | 40°C or less        | 23.0 A                |
| 4110 PL-W | 40°C or less        | 31.0A                 |
| 4150 PL-W | 40°C or less        | 38.0A                 |

- \* In case of  $RUL = 2$  setting, be sure to install the input AC reactor (ACL) between power supply and inverter and use at ambient temperature 40°C or less. Set  $F300$  to 4.0 kHz or less.
- \* If parameter  $F315 = 0$  or  $2$  and current is increased to main module overheat level ( $OL3$ ) or to overheat level ( $OH$ ), the  $L$  alarm or  $H$  alarm occurs. If the cumulative amount of overload is increased further,  $OL3$  trip or  $OH$  trip occurs.  
In this case, to avoid such trips, reduce the stall prevention level ( $F601$ ) properly.
- \* If parameter  $F315 = 2$  or  $3$ , setting parameter  $F300$  to 4.0kHz or less is recommended. Output voltage may be reduced.
- \* PWM carrier frequency is increased at high output frequency area for stable operation, even if  $F300$  is set to low PWM carrier frequency.
- \* In case of three phase 500V-4.0kW model with  $RUL = 2$  setting, be sure to press the grounding capacitor switch and connect the grounding capacitor to the ground.

## 6.19 Trip-less intensification

### 6.19.1 Auto-restart (Restart of coasting motor)

**F301**: Auto-restart control selection

⇒ Refer to section 5.9 for details.

### 6.19.2 Regenerative power ride-through control/Deceleration stop during power failure/Synchronized acceleration/deceleration

**F302**: Regenerative power ride-through control (Deceleration stop)

**F317**: Synchronized deceleration time

**F318**: Synchronized acceleration time

#### • Function

- 1) Regenerative power ride-through control: When momentary power failure occurs during operation, this function makes operation continue using the regeneration energy from a motor.
- 2) Deceleration stop during power failure: When momentary power failure occurs during operation, this function stops the motor quickly and compulsorily using the regeneration energy from the motor. (Deceleration time varies according to control.) When operation is stopped, the message "S t P" blinks on the operation panel. After the forced stop, the inverter remains static until you put off the operation command momentarily.
- 3) Synchronized acceleration/deceleration: When the inverter is used with textile machines, this function decelerate the motors synchronously to stop in the event of a momentary power failure and accelerate them to reach the targeted frequency commands synchronously at the recovery from the power failure in order to prevent thread breakage.

[Parameter setting]

| Title       | Function                                                                                                      | Adjustment range                                                                                                                                                                                                                       | Default setting |
|-------------|---------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F302</b> | Regenerative power ride-through control (Deceleration stop)                                                   | 0: Disabled<br>1: Regenerative power ride-through control<br>2: Deceleration stop during power failure<br>3: Synchronized acceleration / deceleration (signal)<br>4: Synchronized acceleration / deceleration (signal + power failure) | 0               |
| <b>F317</b> | Synchronized deceleration time (time elapsed between start of deceleration to stop)                           | 0.0-3600 (360.0) (s)                                                                                                                                                                                                                   | 2.0             |
| <b>F318</b> | Synchronized acceleration time (time elapsed between start of acceleration to achievement of specified speed) | 0.0-3600 (360.0) (s)                                                                                                                                                                                                                   | 2.0             |


Note 1: The deceleration time and the acceleration time when  $F302=3$  or  $4$  depend on the setting of  $F317$  and that of  $F318$ , respectively.

Note 2: Even if these functions are used, a motor may coast according to load conditions.

In this case, use the auto-restart function ( $F301$ ) for the smooth restart after power supply is restored.


Note 3: Jog run function doesn't operate at synchronized acceleration/deceleration.

■ An example of setting when  $F302=1$   
[When power is interrupted]




- The time for which the operation of the motor can be continued depends on the machine inertia and load conditions. Before using this function, therefore, perform verification tests.
- Use with the retry function allows the motor to be restarted automatically without being brought to an abnormal stop.

Note 4: If power is interrupted during deceleration stop, power ride-through control will not be performed.



Note 5: If momentary power failure occurs during deceleration stop, power ride-through control will not be performed.


## ■ An example of setting when $F302=2$



- Even after the recovery from an input power failure, the motor continues deceleration stop. If the voltage in the inverter main circuit falls below a certain level, however, control will be stopped and the motor will coast.
- If the voltage in main circuit falls below main circuit undervoltage ( $UVF$ ) level at Non-stop control during power failure, the motor will coast and inverter displays  $5LGP$  and  $0.0$  alternately. The motor continues coasting even after power supply is restored.

- An example of setting when  $F302=3$  (when the function of receiving power failure synchronized signal is assigned to the input terminal S1)


$F114$  (Input terminal function selection 4A (S1)) =  $62$  (Power failure synchronized signal)



- If the parameters  $F317$ ,  $F318$  are set for same acceleration and deceleration time and if power failure synchronized signal of the input terminal functions ( $62$ ,  $63$ ) are used, multiple motors can be stopped at about the same time or make them reach to each frequency command.
- If a power failure synchronized signal is ON, the synchronized deceleration function decreases the output frequency to 0Hz to decelerate the motor linearly within the time specified with  $F317$ . (The S-pattern operation function or the braking sequence cannot be used along with this function.)  
When the motor comes to a full stop, the message "S t P" appears.
- If the power failure synchronized signal is canceled during synchronized deceleration, the synchronized acceleration function increases the output frequency to the frequency at the start of synchronized deceleration or to the command frequency, whichever is lower, to accelerate the motor linearly within the time specified with  $F318$ . (The S-pattern operation function, the braking sequence or the auto-tuning function cannot be used along with this function.)  
When acceleration is started, the message "S t P" disappears.
- If a forward/reverse switching command or a stop command is issued during synchronized acceleration or deceleration, synchronized acceleration or deceleration will be canceled.
- When the motor is started again after the synchronized deceleration function stop, turn off the power failure synchronized signal.
- In case of using the synchronized deceleration function, make sure that overvoltage limit operation is not working during deceleration.

- An example of setting when  $F302=4$

Synchronized deceleration if a power failure synchronized signal is ON or if a power failure occurs. Synchronized acceleration if the power failure synchronized signal is canceled or power is restored.



## 6.19.3 Retry function

**F303**: Retry selection (number of times)

| Caution                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Mandatory action |                                                                                                                                                                                                                                                                                                                                                                  |
|                                                                                                       | <ul style="list-style-type: none"> <li>Stand clear of motors and equipment.</li> <li>If the motor and equipment stop when the alarm is given, selection of the retry function will restart them suddenly after the specified time has elapsed. This could result in unexpected injury.</li> <li>Attach caution label about sudden restart in retry function on inverters, motors and equipment for prevention of accidents in advance.</li> </ul> |

- Function  
This parameter resets the inverter automatically when the inverter gives an alarm. During the retry mode, the motor speed search function operates automatically when necessary and thus allows smooth motor restarting.

[Parameter setting]

| Title       | Function                          | Adjustment range          | Default setting |
|-------------|-----------------------------------|---------------------------|-----------------|
| <b>F303</b> | Retry selection (number of times) | 0: Disabled, 1-10 (Times) | 0               |

The likely causes of tripping and the corresponding retry processes are listed below.

| Cause of tripping                                                                     | Retry process                                                                                                                                                                                          | Canceling conditions                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Overcurrent<br>Overvoltage<br>Overload<br>Overheating<br>Step-out (for PM motor only) | Up to 10 times in succession<br>1st retry: About 1 sec after tripping<br>2nd retry: About 2 sec after tripping<br>3rd retry: About 3 sec after tripping<br><br>10th retry: About 10 sec after tripping | The retry function will be canceled at once if tripping is caused by an unusual event other than: overcurrent, overvoltage, overload, overheating, or step-out.<br>This function will also be canceled if retrying is not successful within the specified number of times. |

- Retry is done only when the following trips occur.  
*OC 1, OC 2, OC 3, OP 1, OP 2, OP 3, OL 1, OL 2, OL 3, OH, SOU*
- Protective operation detection relay signals (FLA, FLB, FLC terminal signals) are not sent during use of the retry function. (Default setting)
- To allow a signal to be sent to the protective action detection relay (FLA, B and C terminals) even during the retry process, assign function numbers *146* or *147* to *F132*.
- A virtual cooling time is provided for overload tripping (*OL 1, OL 2*).  
In this case, the retry function operates after the virtual cooling time and retry time elapsed.
- In the event of tripping caused by an overvoltage (*OP 1* to *OP 3*), the retry function will not be activated until the voltage in the DC section comes down to a normal level.
- In the event of tripping caused by overheating (*OH*), the retry function will not be activated until the temperature in the inverter is lowered enough for restarting operation.
- During retrying, *r t r Y* and the monitor display specified by Initial panel display selection parameter, *F710*, are displayed alternately.
- The number of retries will be cleared if the inverter is not tripped for the specified period of time after a successful retry.  
"A successful retry" means that the inverter output frequency reaches the command frequency without causing the inverter to re-trip.

## 6.19.4 Dynamic (regenerative) braking - For abrupt motor stop

**F304**: Dynamic braking selection

**F308**: Dynamic braking resistance

**F309**: Dynamic braking resistor capacity

**F626**: Over-voltage stall protection level

- Function

The inverter does not contain a braking resistor. Connect an external braking resistor in the following cases to enable dynamic braking function:

- 1) when decelerating the motor abruptly or if overvoltage tripping ( $\overline{OP}$ ) occurs during deceleration stop
- 2) when a continuous regenerative status occurs during downward movement of a lift or the winding-out operation of a tension control machine
- 3) when the load fluctuates and results in a continuous regenerative status even during constant speed operation of a machine such as a press

[Parameter setting]

| Title       | Function                            | Adjustment range                                                                                                                                                                        | Default setting                           |
|-------------|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------|
| <b>F304</b> | Dynamic braking selection           | 0: Disabled<br>1: Enabled, Resistor overload protection enabled<br>2: Enabled<br>3: Enabled, Resistor overload protection enabled (At ST terminal on)<br>4: Enabled (At ST terminal on) | 0                                         |
| <b>F308</b> | Dynamic braking resistance          | 1.0-1000 ( $\Omega$ )                                                                                                                                                                   | Depending on models<br>(See Section 11.4) |
| <b>F309</b> | Dynamic braking resistor capacity   | 0.01-30.00 (kW)                                                                                                                                                                         |                                           |
| <b>F626</b> | Over-voltage stall protection level | 100-150 (%)                                                                                                                                                                             |                                           |
|             |                                     |                                                                                                                                                                                         | 136 (240V class)<br>141 (500V class)      |


- Overload status of braking resistor can be output by assigning the braking resistor overload pre-alarm (function number : 30,31) to any logic output terminal.

Note 1) The operation level of dynamic braking is defined by parameter **F626**.


Note 2) In case of parameter **F304** = 1 to 4, the inverter will be automatically set as "without overvoltage limit operation" and controlled so that the resistor consumes the regenerative energy from the motor.  
(The same function as **F305** = 1)

## 1) Connecting an external braking resistor (optional)

Separate-optional resistor (with thermal fuse)



Connecting thermal relays and an external braking resistor



Note 1: A TC (Trip coil) is connected as shown in this figure when an MCCB with a trip coil is used instead of an MC. A step-down transformer is needed for every 500V-class inverter, but not for any 240V-class inverter.

Note 2: As a last resort to prevent fire, be sure to connect a thermal relay (THR). Although the inverter has a means of preventing overload and overcurrent to protect the braking resistor, the thermal relay is activated in case the protection function fails to work. Select and connect a thermal relay (THR) appropriately to the capacity (wattage) of the braking resistor.

[Parameter setting]

| Title        | Function                            | Setting              |
|--------------|-------------------------------------|----------------------|
| <i>F 304</i> | Dynamic braking selection           | 1                    |
| <i>F 305</i> | Overvoltage limit operation         | 1                    |
| <i>F 308</i> | Dynamic braking resistance          | Proper value         |
| <i>F 309</i> | Dynamic braking resistor capacity   | Proper value         |
| <i>F 626</i> | Over-voltage stall protection level | 136 (%) (240V class) |
|              |                                     | 141 (%) (500V class) |

- To use this inverter in applications that create a continuously regenerative status (such as downward movement of a lift, a press or a tension control machine), or in applications that require deceleration stopping of a machine with a significant load inertial moment, increase the dynamic braking resistor capacity according to the operation rate required.
- To connect an external dynamic braking resistor, select one with a resultant resistance value greater than the minimum allowable resistance value. Be sure to set the appropriate operation rate in *F 308* and *F 309* to ensure overload protection.
- When using a braking resistor with no thermal fuse, connect and use a thermal relay as a control circuit for cutting the power off.

## 2) Optional dynamic braking resistors

Optional dynamic braking resistors are listed below. All these resistors are 3%ED in operation rate

| Inverter type                                         | Braking resistor |           |                                                    |
|-------------------------------------------------------|------------------|-----------|----------------------------------------------------|
|                                                       | Type-form        | Rating    | Continuous regenerative braking allowable capacity |
| VFS15-2004PM-W, 2007PM-W<br>VFS15S-2002PL-W~2007PL-W  | PBR-2007         | 120W-200Ω | 90W                                                |
| VFS15-2015PM-W, 2022PM-W<br>VFS15S-2015PL-W, 2022PL-W | PBR-2022         | 120W-75Ω  | 90W                                                |
| VFS15-2037PM-W                                        | PBR-2037         | 120W-40Ω  | 90W                                                |
| VFS15-2055PM-W, 2075PM-W                              | PBR7-004W015     | 440W-15Ω  | 130W                                               |
| VFS15-2110PM-W, 2150PM-W                              | PBR7-008W7R5     | 880W-7.5Ω | 270W                                               |
| VFS15-4004PL-W~4022PL-W                               | PBR-2007         | 120W-200Ω | 90W                                                |
| VFS15-4037PL-W                                        | PBR-4037         | 120W-160Ω | 90W                                                |
| VFS15-4055PL-W, 4075PL-W                              | PBR7-004W060     | 440W-60Ω  | 130W                                               |
| VFS15-4110PL-W, 4150PL-W                              | PBR7-008W030     | 880W-30Ω  | 270W                                               |

Note 1: The data in Rating above refer to the resultant resistance capacities (watts) and resultant resistance values (Ω).

Note 2: Braking resistors for frequent regenerative braking are optionally available. For more information, contact your Toshiba distributor.

Note 3: Type-form of "PBR-" indicates the thermal fuse". Type-form of "PBR7-" indicates the thermal fuse and thermal relay.

Note 4: The default setting values of parameter  $F308$  (Dynamic braking resistance) and  $F309$  (Dynamic braking resistor capacity) are applied to braking resistor option.

## 3) Minimum resistances of connectable braking resistors

The minimum allowable resistance values of the externally connectable braking resistors are listed in the table below.

Do not connect braking resistors with smaller resultant resistances than the listed minimum allowable resistance values.

| Inverter rated output capacity (kW) | 240V Class                    |                              | 500V Class                    |                              |
|-------------------------------------|-------------------------------|------------------------------|-------------------------------|------------------------------|
|                                     | Resistance of standard option | Minimum allowable resistance | Resistance of standard option | Minimum allowable resistance |
| 0.2                                 | 200Ω                          | 55Ω                          | -                             | -                            |
| 0.4                                 | 200Ω                          | 55Ω                          | 200Ω                          | 114Ω                         |
| 0.75                                | 200Ω                          | 55Ω                          | 200Ω                          | 114Ω                         |
| 1.5                                 | 75Ω                           | 44Ω                          | 200Ω                          | 67Ω                          |
| 2.2                                 | 75Ω                           | 33Ω                          | 200Ω                          | 67Ω                          |
| 4.0                                 | 40Ω                           | 16Ω                          | 160Ω                          | 54Ω                          |
| 5.5                                 | 15Ω                           | 12Ω                          | 60Ω                           | 43Ω                          |
| 7.5                                 | 15Ω                           | 12Ω                          | 60Ω                           | 28Ω                          |
| 11                                  | 7.5Ω                          | 5Ω                           | 30Ω                           | 16Ω                          |
| 15                                  | 7.5Ω                          | 5Ω                           | 30Ω                           | 16Ω                          |

Note: Be sure to set  $F308$  (Dynamic braking resistance) at the resistance of the dynamic braking resistor connected.

## 6.19.5 Avoiding overvoltage tripping

**F305**: Overvoltage limit operation


**F319**: Regenerative over-excitation upper limit

**F626**: Overvoltage stall protection level

- Function

These parameters are used to keep the output frequency constant or increase it to prevent overvoltage tripping in case the voltage in the DC section rises during deceleration or varying speed operation. The deceleration time during overvoltage limit operation may increase above the designated time.

Overvoltage limit operation level



[Parameter setting]

| Title       | Function                                                          | Adjustment range                                                                                                        | Default setting                      |
|-------------|-------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|--------------------------------------|
| <b>F305</b> | Overvoltage limit operation<br>(Deceleration stop mode selection) | 0: Enabled<br>1: Disabled<br>2: Enabled (Quick deceleration control)<br>3: Enabled (Dynamic quick deceleration control) | 2                                    |
| <b>F319</b> | Regenerative over-excitation upper limit                          | 100-160 (%)                                                                                                             | 120*1                                |
| <b>F626</b> | Overvoltage stall protection level                                | 100-150 (%) *2                                                                                                          | 136 (240V class)<br>141 (500V class) |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*2: 100% corresponds to an input voltage of 200V for 240V models or to an input voltage of 400V for 500V models.

- If **F305** is set to 2 (quick deceleration control), the inverter will increase the voltage to the motor (over-excitation control) to increase the amount of energy consumed by the motor when the voltage reaches the overvoltage protection level during deceleration, and therefore the motor can be decelerated more quickly than normal deceleration.
- If **F305** is set to 3 (dynamic quick deceleration control), the inverter will increase the voltage to the motor (over-excitation control) to increase the amount of energy consumed by the motor as soon as the motor begins to decelerate, and therefore the motor can be decelerated still more quickly than quick deceleration.
- During overvoltage limit operation, the overvoltage pre-alarm (*P* blinks) is displayed.
- The parameter **F319** is used to adjust the maximum energy that the motor consumes during deceleration. Specify a larger value if the inverter trips during deceleration because of an overvoltage. When **F305** is set 2 or 3, this function works.
- Parameter **F626** serves also as a parameter for setting the regenerative braking level.

## 6.19.6 Output voltage adjustment/Supply voltage correction

**ULU** : Base frequency voltage 1

**F307** : Supply voltage correction (output voltage limitation)

• Function

Supply voltage correction: Prevent torque decline during low-speed operation.

Maintains a constant V/F ratio, even when the input voltage fluctuates.

Output voltage limitation: Limits the voltage at frequencies exceeding the base frequency (**ULU**) to prevent outputting the voltage exceeding base frequency voltage (**ULU**).  
Applied when operating a special motor with low induced voltage.


[Parameter setting]

| Title       | Function                                                 | Adjustment range                                           | Default setting |
|-------------|----------------------------------------------------------|------------------------------------------------------------|-----------------|
| <b>ULU</b>  | Base frequency voltage1                                  | 50-330 (240V class)<br>50-660 (500V class)                 | *1              |
| <b>F307</b> | Supply voltage correction<br>(output voltage limitation) | 0: Supply voltage uncorrected,<br>output voltage limited   | *1              |
|             |                                                          | 1: Supply voltage corrected,<br>output voltage limited     |                 |
|             |                                                          | 2: Supply voltage uncorrected,<br>output voltage unlimited |                 |
|             |                                                          | 3: Supply voltage corrected,<br>output voltage unlimited   |                 |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

- If **F307** is set to "0" or "2", the output voltage will change in proportion to the input voltage.
- Even if the base frequency voltage (**ULU** parameter) is set above the input voltage, the output voltage will not exceed the input voltage.
- The ratio of voltage to frequency can be adjusted according to the rated motor voltage and frequency. Setting **F307** to "0" or "1" prevents the output voltage from increasing, even if the input voltage changes when operation frequency exceeds the base frequency.
- When the V/F control mode selection parameter (**P1**) is set to any number between 2 to 6, the supply voltage is corrected regardless of the setting of **F307**.


[F307=0: No voltage compensation/output voltage limited]




\* The above is applied when V/F control mode selection parameter P<sub>L</sub> is set to "0" or "1".

$\frac{u_L}{\text{Rated voltage}} > 1$  the output voltage can be prevented from exceeding the input voltage.

[F307=1: Voltage compensation/output voltage limited]




[F307=2: No voltage compensation/no output voltage limit]



\* The above is applied when V/F control mode selection parameter P<sub>L</sub> is set to "0" or "1".

$\frac{u_L}{\text{Rated voltage}} > 1$  the output voltage can be prevented from exceeding the input voltage.

[F307=3: Voltage compensation/no output voltage control]



\* Note that even if the input voltage is set less than  $u_L$ , an output voltage over  $u_L$  occurs for a base frequency of  $u_L$  or higher output frequency.

Note: Rated voltage is fixed at 200V for 240V class and 400V for 500V class.

## 6.19.7 Reverse-run prohibition

**F311**: Reverse-run prohibition

- Function  
This function prevents the motor from running in the forward or reverse direction when it receives the wrong operation signal.

[Parameter setting]

| Title | Function                | Adjustment range                                                                           | Default setting |
|-------|-------------------------|--------------------------------------------------------------------------------------------|-----------------|
| F311  | Reverse-run prohibition | 0: Forward/reverse run permitted<br>1: Reverse run prohibited<br>2: Forward run prohibited | 0               |

## 6.20 Drooping control

**F320**: Droop gain


**F323**: Droop insensitive torque band

**F324**: Droop output filter

- Function  
Drooping control has the function to prevent loads from concentrating at a specific motor because of a load imbalance when multiple inverters are used to operate one machine.  
These parameters are used to allow the motor to "slip" according to the load torque current. The insensitive torque band and the gain can be adjusted using these parameters.

[Parameter setting]

| Title | Function                      | Adjustment range | Default setting |
|-------|-------------------------------|------------------|-----------------|
| F320  | Droop gain                    | 0.0-100.0 (%)    | 0.0             |
| F323  | Droop insensitive torque band | 0-100 (%)        | 10              |
| F324  | Droop output filter           | 0.1-200.0        | 100.0           |



- The drooping control function is to operate the power-running motor at operating frequency  $f_1$  (Hz), which is lower than command frequency  $f_0$  (Hz) by droop frequency  $\Delta f$  (Hz), when the torque current is  $T_1$  (%). (See the figure above.)
- The droop frequency  $\Delta f$  can be calculated using the following expression.  
Droop frequency  $\Delta f$  (Hz) = base frequency  $\omega_L$   $\times F323 \times (T_1 - F323)$
- When the torque current is above the specified droop insensitive torque band ( $F323$ ), the frequency is reduced during power running or increased during regenerative braking. The figure above shows an example of the operating frequency during power running. During regenerative braking, control is performed to increase the frequency.
- The drooping control function is activated above the torque current set with  $F323$ .
- The amount of droop frequency  $\Delta f$  varies depending on the amount of torque current  $T_1$ .

Note: If the base frequency  $\omega_L$  exceeds 100Hz, count it as 100Hz.

Control is exercised between the starting frequency ( $F240$ ) and the maximum frequency ( $FH$ ).

[An example of calculation]

Parameter setting: Base frequency  $\omega_L$  = 60 (Hz), droop gain  $F323$  = 10 (%)

Droop insensitive torque band  $F323$  = 30 (%)

Droop frequency  $\Delta f$  (Hz) and operating frequency  $f_1$  when command frequency  $f_0$  is 50 (Hz) and torque current  $T_1$  is 100 (%) are as follows;

$$\begin{aligned} \text{Droop frequency } \Delta f \text{ (Hz)} &= \omega_L \times F323 \times (T_1 - F323) \\ &= 60 \text{ (Hz)} \times 10 \text{ (\%)} \times (100 \text{ (\%)} - 30 \text{ (\%)} \\ &= 4.2 \text{ (Hz)} \end{aligned}$$

$$\text{Operation frequency } f_1 \text{ (Hz)} = f_0 - \Delta f = 50 \text{ (Hz)} - 4.2 \text{ (Hz)} = 45.8 \text{ (Hz)}$$

## 6.21 Light-load high-speed operation function

|                                                                               |                                                                 |
|-------------------------------------------------------------------------------|-----------------------------------------------------------------|
| <b>F328</b> : Light-load high-speed operation selection                       | <b>F335</b> : Switching load torque during power running        |
| <b>F329</b> : Light-load high-speed learning function                         | <b>F336</b> : Heavy-load torque during power running            |
| <b>F330</b> : Automatic light-load high-speed operation frequency             | <b>F337</b> : Heavy-load torque during constant power running   |
| <b>F331</b> : Light-load high-speed operation switching lower limit frequency | <b>F338</b> : Switching load torque during regenerative braking |
| <b>F332</b> : Light-load high-speed operation load waiting time               |                                                                 |
| <b>F333</b> : Light-load high-speed operation load detection time             |                                                                 |
| <b>F334</b> : Light-load high-speed operation heavy load detection time       |                                                                 |

⇒ Refer to "Functions for lift application: E6581871" for details.

6

## 6.22 Braking function

### 6.22.1 Brake sequence control

|                                                             |                                               |
|-------------------------------------------------------------|-----------------------------------------------|
| <b>F325</b> : Brake releasing waiting time                  | <b>F344</b> : Lowering torque bias multiplier |
| <b>F326</b> : Brake releasing small current detection level | <b>F345</b> : Brake release time              |
| <b>F340</b> : Creeping time 1                               | <b>F346</b> : Creeping frequency              |
| <b>F341</b> : Braking mode selection                        | <b>F347</b> : Creeping time 2                 |
| <b>F342</b> : Load portion torque input selection           | <b>F348</b> : Braking time learning function  |
| <b>F343</b> : Hoisting torque bias input                    |                                               |

⇒ Refer to "Functions for lift application: E6581871" for details.

## 6.22.2 Hit and stop control

**F382**: Hit and stop control

**F383**: Hit and stop control frequency

⇒ Refer to "Hit & Stop control: E6581873" for details.

## 6.23 Acceleration/deceleration suspend function (Dwell function)

**F349**: Acceleration/deceleration suspend function

**F352**: Deceleration suspend frequency

**F350**: Acceleration suspend frequency

**F353**: Deceleration suspend time

**F351**: Acceleration suspend time

### • Function

This function suspends acceleration and deceleration when starting and stopping during the transportation of heavy load by temporarily running the motor at a constant speed according to the delay in braking. It also prevents the occurrence of overcurrent at starting and slippage at stopping by fixing the timing with brake.

There are two ways to suspend acceleration or deceleration: suspending it automatically by setting the suspend frequency and time using parameters, and suspending it by means of a signal from an external control device.

### [Parameter setting]

| Title       | Function                                   | Adjustment range                                      | Setting value |
|-------------|--------------------------------------------|-------------------------------------------------------|---------------|
| <b>F349</b> | Acceleration/deceleration suspend function | 0:Disabled<br>1:Parameter setting<br>2:Terminal input | 0             |
| <b>F350</b> | Acceleration suspend frequency             | 0.0- <i>F<sub>H</sub></i> (Hz)                        | 0.0           |
| <b>F351</b> | Acceleration suspend time                  | 0.0-10.0 (s)                                          | 0.0           |
| <b>F352</b> | Deceleration suspend frequency             | 0.0- <i>F<sub>H</sub></i> (Hz)                        | 0.0           |
| <b>F353</b> | Deceleration suspend time                  | 0.0-10.0 (s)                                          | 0.0           |


Note1: The acceleration suspend frequency (**F350**) should not be set below the starting frequency (**F240**).

Note2: The deceleration suspend frequency (**F352**) should not be set below the stop frequency (**F243**).

Note3: If the output frequency is lowered by a stall prevention function, the acceleration suspend function may be activated.


## 1) To suspend acceleration or deceleration automatically

Set the frequency with  $F350$  or  $F352$  and the time with  $F351$  or  $F353$ , and then set  $F349$  to 1. When reached the set frequency, the motor stops accelerating or decelerating to run at a constant speed.



## 2) To suspend acceleration or deceleration by means of a signal from an external control device

Set  $50$  for an input terminal. As long as ON signals are inputted, the motor continues to rotate at a constant speed.



Ex.) When setting the acceleration/deceleration suspend signal to S3 terminal


| Title  | Function                        | Adjustment range | Example of setting                             |
|--------|---------------------------------|------------------|------------------------------------------------|
| $F116$ | Input terminal selection 6 (S3) | 0-203            | 60 (Acceleration/ deceleration suspend signal) |

Function No. 61 is the inversion signal.

Note: If the operation signal is ON after Acceleration/ deceleration suspend signal is ON, the inverter will operate at frequency set with  $F240$ .

### ■ If the stall control function is activated during constant-speed rotation

The frequency changes momentarily as a result of stall control, but the time for which the frequency changes is included in the suspend time.



#### ■ Stall control

The inverter will automatically change the operation frequency when it detects an overcurrent, overload or overvoltage. Configure each stall control setting using the following parameters.

Overcurrent stall :  $F501$  (Stall prevention level 1)

Overload stall :  $017$  (Electronic thermal protection characteristic selection)

Overvoltage stall :  $F305$  (Overvoltage limit operation)

Note: When the frequency command value, the acceleration suspend frequency ( $F350$ ), and the deceleration suspend frequency ( $F352$ ) have the same setting, the acceleration/ deceleration suspend function will not work.

## 6.24 PID control

$FP1d$ : Process input value of PID control

$F167$ : Frequency command agreement detection range

$F359$ : PID control waiting time

$F360$ : PID control

$F361$ : Delay filter

$F362$ : Proportional gain

$F363$ : Integral gain

$F366$ : Differential gain

$F367$ : Process upper limit

$F368$ : Process lower limit

$F369$ : PID control feedback signal selection

$F372$ : Process increasing rate (speed type PID control)

$F373$ : Process decreasing rate (speed type PID control)

$F380$ : PID forward/reverse characteristics selection

$F389$ : PID control reference signal selection

- Function

Process control including keeping airflow, pressure, and the amount of flow constant, can be exercised using feedback signals (4 to 20mA, 0 to 10V) from a detector.

Or, it is also possible to always set 0 for integral and differential at terminal input.


⇒ Refer to "PID control instruction manual: E6581879" for details.

[Parameter setting]

| Title          | Function                                         | Adjustment range                                                                                                                                                                                                                                                                        | Default setting |
|----------------|--------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F 3 6 8</i> | Process input value of PID control               | <i>F 3 6 8</i> - <i>F 3 6 7</i> (Hz)                                                                                                                                                                                                                                                    | 0.0             |
| <i>F 3 5 9</i> | PID control waiting time                         | 0-2400 (s)                                                                                                                                                                                                                                                                              | 0               |
| <i>F 3 6 0</i> | PID control                                      | 0: Disabled<br>1: Process type PID control<br>2: Speed type PID control                                                                                                                                                                                                                 | 0               |
| <i>F 3 6 1</i> | Delay filter                                     | 0.0-25.0 (s)                                                                                                                                                                                                                                                                            | 0.1             |
| <i>F 3 6 2</i> | Proportional gain                                | 0.01-100.0                                                                                                                                                                                                                                                                              | 0.30            |
| <i>F 3 6 3</i> | Integral gain                                    | 0.01-100.0                                                                                                                                                                                                                                                                              | 0.20            |
| <i>F 3 6 6</i> | Differential gain                                | 0.00-2.55                                                                                                                                                                                                                                                                               | 0.00            |
| <i>F 3 6 7</i> | Process upper limit                              | 0.0- <i>F 3 6 7</i> (Hz)                                                                                                                                                                                                                                                                | 60.0 *1         |
| <i>F 3 6 8</i> | Process lower limit                              | 0.0- <i>F 3 6 7</i> (Hz)                                                                                                                                                                                                                                                                | 0.0             |
| <i>F 3 6 9</i> | PID control feedback signal selection            | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4 to 6: -                                                                                                                                                                                                       | 0               |
| <i>F 3 7 2</i> | Process increasing rate (speed type PID control) | 0.1-600.0 (s)                                                                                                                                                                                                                                                                           | 10.0            |
| <i>F 3 7 3</i> | Process decreasing rate (speed type PID control) | 0.1-600.0 (s)                                                                                                                                                                                                                                                                           | 10.0            |
| <i>F 3 8 0</i> | PID forward/reverse characteristics selection    | 0: Forward<br>1: Reverse                                                                                                                                                                                                                                                                | 0               |
| <i>F 3 8 9</i> | PID control reference signal selection           | 0: <i>F 3 8 0</i> / <i>F 3 7 2</i> selected<br>1: Terminal VIA<br>2: Terminal VIB<br>3: <i>F 3 6 1</i><br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input | 0               |

\*1: Default setting value vary depending on the setup menu setting. Refer to section 11.5.

## 1) External connection



## 2) Selecting process value and feedback value

Process value (frequency) and feedback value can be combined as follows for the PID control.

| (1) Process value                                                                                                                                                                                                                                                                | (2) Feedback value                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| PID control reference signal selection <i>F 3 8 9</i>                                                                                                                                                                                                                            | PID control feedback signal selection <i>F 3 6 9</i>                              |
| 0: <i>F 0 0 d / F 2 0 7</i> selected<br>1: Terminal VIA<br>2: Terminal VIB<br>3: <i>F P i d</i><br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4 to 6: - |

Note 1: When setting *F 3 8 9*, do not select the same signal used for feedback input.

Note 2: The changing value by setting dial is selected as follows.

- *F C* setting: *F C* setting (*F 0 0 d* or *F 2 0 7*=0 or 3) is valid.

- *F P i d* setting: *fpid* is selected (*F 3 8 9*=3) and *F C* setting is invalid.

Note 3: Signal is put out when the amount of feedback matches to the amount of processing. Assign function number 144 or 145 to an output terminal.

Frequency agreement detection range ( $F\ 15\ 7$ ) can also be set.

### 3) Setting PID control

Set "I" (Process type PID control operation) in the parameter  $F\ 35\ 0$  (PID control).

(1) Set parameters  $R\ 1\ 1$  (acceleration time) and  $d\ 1\ 1$  (deceleration time) to the system fitting values.

(2) Please set the following parameters to place limits to the setting value and the control value.

Placing a limit to the process value : The parameter  $F\ 35\ 7$  (Process upper limit),  $F\ 35\ 8$  (Process lower limit)

Placing a limit to the output frequency : The parameter  $U\ 1$  (Upper limit frequency),  $L\ 1$  (Lower limit frequency)

Note 4: Assigning the function number 36 (PID control prohibition) to an input terminal. PID control function is stopped temporarily while the terminal is ON.

### 4) Adjusting the PID control gain level

Adjust the PID control gain level according to the process quantities, the feedback signals and the object to be controlled.


[Parameter settings]

| Title      | Function              | Adjustment range                   | Default setting |
|------------|-----------------------|------------------------------------|-----------------|
| $F\ 35\ 2$ | Proportional gain (P) | 0.01 - 100.0                       | 0.30            |
| $F\ 35\ 3$ | Integral gain (I)     | 0.01 - 100.0 (1/ s <sup>-1</sup> ) | 0.20            |
| $F\ 35\ 6$ | Derivative gain (D)   | 0.00 - 2.55 (s)                    | 0.00            |

#### $F\ 35\ 2$ (P-gain adjustment parameter)

This parameter adjusts the proportional gain level during PID control. A correction value proportional to the particular deviation (the difference between the process value and the feedback value) is obtained by multiplying this deviation by the parameter setting.


A larger P-gain adjustment value gives faster response. Too large an adjustment value, however, results in an unstable event such as hunting.



### F 3 6 3 (I-gain adjustment parameter)

This parameter adjusts the integral gain level during PID control. Any remaining deviations (residual deviation offset) during proportional action are cleared to zero.


A larger I-gain adjustment value reduces residual deviations. Too large an adjustment value, however, results in an unstable event such as hunting.



- Assign function number 52 (PID integral/derivative clear) to an input terminal. It is possible to calculate integral/derivative amounts always as 0 (zero) while the input terminal is ON.

### F 3 6 6 (D-gain adjustment parameter)

This parameter adjusts the differential gain level during PID control. This gain increases the speed of response to a rapid change in deviation (difference between the process value and the feedback value). Note that setting the gain beyond necessity may cause fluctuations in output frequency, and thus operation to become unstable.




- Assign function number 52 (PID integral/derivative clear) to an input terminal, and it is possible to calculate integral/derivative amounts always as 0 (zero) while the input terminal is ON.


## 5) Adjusting feedback input

Make adjustment by converting input level of the feedback amount into frequency. Refer to section 6.10.2 for details.


Example of 0 - 10 Vdc voltage input setting



Example of 0 - 10 Vdc voltage input setting



Example of 4 - 20 mAdc voltage input setting




## 6) Setting the time elapsed before PID control starts

Waiting time until starting PID control system can be set to avoid PID control until the control system becomes stable.

The inverter ignores feedback input signals, carries out operation at the frequency determined by the frequency command value for the period of time specified with F359, and enters the PID control mode after the elapsed time.

## 7) PID control forward/reverse characteristic switch

PID input characteristics can be reversed.




- When characteristic is reversed according to parameters, set PID calculation reverse selection parameter F380 is 1: Set reverse characteristics.
- When characteristic is reversed using logic input terminal, assign function number 54/55, PID characteristics switching, to an input terminal.

Note) If reverse characteristics is selected for parameter F380 and terminal input at the same time, they become forward characteristic.

## 8) Comparing process quantity and feedback amount

If the frequency command value specified using  $F\ 38\ 9$  and the frequency command value from  $F\ 35\ 9$  match the range of  $\pm F\ 15\ 7$ , an ON or OFF signal will be sent out from the output terminal.



## 6.25 Setting motor constants

### 6.25.1 Setting motor constants for induction motors

|                                            |                                                  |
|--------------------------------------------|--------------------------------------------------|
| <b>F400</b> : Auto-tuning                  | <b>F416</b> : Motor no-load current              |
| <b>F401</b> : Slip frequency gain          | <b>F417</b> : Motor rated speed                  |
| <b>F402</b> : Automatic torque boost value | <b>F459</b> : Load inertia moment ratio          |
| <b>F405</b> : Motor rated capacity         | <b>F462</b> : Speed reference filter coefficient |
| <b>F415</b> : Motor rated current          |                                                  |

To use vector control, automatic torque boost and automatic energy saving, motor constant setting (motor tuning) is required. The following three methods are available to set motor constants.

- 1) Using the torque boost setting macro function (**RU2**) for setting the V/F control mode selection (**P1**) and auto-tuning (**F400=2**) collectively
- 2) Setting V/F control mode selection (**P1**) and auto-tuning (**F400**) independently
- 3) Combining the V/F control mode selection (**P1**) and manual tuning

#### Caution:

If the settings for V/F control mode selections **P1** are **2**: automatic torque boost control, **3**: vector control, **4**: energy-saving, and **5**: Dynamic energy-saving, make sure to confirm the motor's name plate and set the following parameters;

- UL**: Base frequency 1 (rated frequency)
- ULV**: Base frequency voltage 1 (rated voltage)
- F405**: Motor rated capacity
- F415**: Motor rated current
- F417**: Motor rated speed

Set the other motor constants as necessary.

#### [Selection 1: Setting by parameter setting macro torque boost]

This is the easiest among the available methods. It conducts vector control and auto-tuning at the same time. Be sure to set the motor for **UL**, **ULV**, **F405**, **F415**, **F417**.

Set **RU2** to **1** (Automatic torque boost + auto-tuning)

Set **RU2** to **2** (Vector control + auto-tuning)

Set **RU2** to **3** (Energy-saving + auto-tuning)

Refer to section 6.1.5 for details of the setting method.

## [Selection 2: Setting vector control and auto-tuning independently]

Set vector control, automatic torque boost, energy saving and auto-tuning individually.

After setting  $P\bar{L}$  (V/F control mode selection), auto-tuning starts.

Set the auto-tuning parameter  $F400$  to  $\bar{2}$  (Auto-tuning enabled)

[Parameter setting]

| Title  | Function    | Adjustment range                                                                                                                                                                                                               | Default setting |
|--------|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| $F400$ | Auto-tuning | 0: Auto-tuning disabled<br>1: Initialization of $F402$ (after execution : 0)<br>2: Auto-tuning executed (after execution: 0)<br>3: -<br>4: Motor constant auto calculation (after execution: 0)<br>5: 4+2 (after execution: 0) | 0               |

Set  $F400$  to  $\bar{2}$  before the start of operation. Auto-tuning is performed at the start of the motor and set  $F402, F412$ .

- Precautions on auto-tuning

- (1) Conduct auto-tuning after the motor has been connected properly and operation completely stopped.  
If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in abnormal tuning.
- (2) Voltage is applied to the motor during tuning even though it barely rotates. During tuning, " $R\bar{L}n$ " is displayed on the operation panel.
- (3) Tuning is performed when the motor starts for the first time after  $F400$  is set to  $\bar{2}$ .  
Tuning is usually completed within three seconds. If it is aborted, the motor will trip with the display of  $E\bar{L}n$  and no constants will be set for that motor.
- (4) High-speed motors, high-slip motors or other special motors cannot be auto-tuned. For these motors, perform manual tuning using Selection 3 described below.
- (5) Provide cranes and hoists with sufficient circuit protection such as mechanical braking. Insufficient motor torque while tuning may cause machine stalling/falling.
- (6) If auto-tuning is impossible or an " $E\bar{L}n$ " auto-tuning error is displayed, perform manual tuning with selection 4.

## [Selection 3: Setting vector control and motor constant automatically]

After setting  $UL, ULv, F405, F415$  and  $F417$ , motor constants calculated automatically.

$F402, F412$  and  $F416$  are set automatically.

Set the motor constant parameter  $F400$  to  $\bar{4}$  (auto calculation)

Set  $F400=5$  when auto-tuning is executed after setting motor constants automatically.

## [Selection 4: Setting vector control and manual tuning independently]

If an "E<sub>tn</sub>" tuning error is displayed during auto-tuning or when vector control characteristics are to be improved, set independent motor constants.

[Parameter setting]

| Title           | Function                                    | Adjustment range               | Default setting                                    |
|-----------------|---------------------------------------------|--------------------------------|----------------------------------------------------|
| F401            | Slip frequency gain                         | 0-250 (%)                      | 70                                                 |
| F402            | Automatic torque boost value                | 0.1-30.0 (%)                   | Depends on the capacity<br>(Refer to section 11.4) |
| F405            | Motor rated capacity                        | 0.01-22.00 (kW)                |                                                    |
| F415            | Motor rated current                         | 0.01-100.0 (A)                 |                                                    |
| F416            | Motor no-load current                       | 10-90 (%)                      |                                                    |
| F417            | Motor rated speed                           | 100-64000 (min <sup>-1</sup> ) | *1                                                 |
| F459            | Load inertia moment ratio                   | 0.1-100.0 (times)              | 1.0                                                |
| F462            | Speed reference filter coefficient          | 0-100                          | 35                                                 |
| E <sub>tr</sub> | Motor electronic thermal protection level 1 | 10-100 (%) / (A)               | 100                                                |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

Setting procedure Adjust the following parameters:

- F401**: Set the compensation gain for the slipping of the motor. A higher slip frequency reduces motor slipping correspondingly. After setting **F417**, set **F401** for fine adjustment. Be careful as inputting a value larger than necessary causes hunting and other unstable operation.
- F402**: Adjust the primary resistive component of the motor. Torque reduction due to possible voltage drop during low-speed operation can be suppressed by setting a large value in this parameter. Be careful as setting a value larger than necessary may lead to an increased current and then cause a trip at low speeds. (Perform adjustments according to the actual operation.)
- F405**: Set the motor's rated capacity according to the motor's name plate or test report.
- F415**: Set the rated current of the motor. For the rated current, see the motor's nameplate or test report.
- F416**: Set the ratio of the no-load current of the motor to the rated current. Enter the value in % that is obtained by dividing the no-load current specified in the motor's test report by the rated current. A larger value increases the excitation current.
- F417**: Set the rated rotational speed of the motor. For the rated current, see the motor's nameplate or test report.
- Adjustment method for the moment of inertia of the load
- F459**: Adjusts the excess response speed. A larger value gives a smaller overshoot at the acceleration/deceleration completion point. In the default settings, the moment of inertia of the load (including the motor shaft) value is optimally set considering a motor shaft of 1x. When the moment of inertia of the load is not 1x, set a value that matches that actual moment of inertia of the load.
- E<sub>tr</sub>**: If the rated capacity of the motor is one size smaller than that of the inverter, lower the thermal protective level according to the rated current of the motor.

## Caution:

If a combination of the inverter rating and the motor capacity is different for more than 2 classes, vector control may not operate correctly.

## 6.25.2 Setting motor constants for PM motors

**F400**: Auto-tuning

**F462**: Speed reference filter  
coefficient

**F402**: Automatic torque boost value

**F405**: Motor rated capacity

**F912**: q-axis inductance

**F415**: Motor rated current

**F913**: d-axis inductance

**F417**: Motor rated speed

**F459**: Load inertia moment ratio

### Caution:

If the settings for V/F control mode selections  $P\tau = 5$ : vector control for PM motor

Look at the motor's name plate and set the following parameters.

$\omega_L$ : Base frequency 1 (rated frequency) that is calculated from Back EMF

$\omega_L \omega$ : Base frequency voltage 1 (rated voltage) that is calculated from Back EMF

**F405**: Motor rated capacity

**F415**: Motor rated current

**F417**: Motor rated speed

**F912**: Q axis inductance per phase

**F913**: D axis inductance per phase

### [Selection 1: Setting PM motor control and auto-tuning]

After setting  $P\tau = 5$ , auto-tuning occurs.

Set the auto-tuning parameter **F400** to 2 (Auto-tuning enabled)

#### [Parameter setting]

| Title       | Function    | Adjustment range                                                                                                                                                                             | Default setting |
|-------------|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F400</b> | Auto-tuning | 0: Auto-tuning disabled<br>1: Initialization of <b>F402</b> , <b>F912</b> , <b>F913</b><br>(after execution : 0)<br>2: Auto-tuning executed<br>(after execution : 0)<br>3: -<br>4: -<br>5: - | 0               |

Note1) When parameter  $P\tau = 5$  is selected, **F400**=3 to 5 do not work.

Set  $F400$  to 2 to before the start of operation. Tuning is performed at the start of the motor.

- Precautions on auto-tuning
  - (1) Conduct auto-tuning after the motor has been connected properly and operation completely stopped.  
If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in abnormal tuning.
  - (2) Voltage is applied to the motor during tuning even though it barely rotates. During tuning, "Rtn" is displayed on the operation panel.
  - (3) Tuning is performed when the motor starts for the first time after  $F400$  is set to 2.  
Tuning is usually completed within three seconds. If it is aborted, the motor will trip with the display of "Err" and no constants will be set for that motor.
  - (4) If special motors cannot be auto-tuned, perform manual tuning follow Selection 2 described below.
  - (5) Provide cranes and hoists with sufficient circuit protection such as mechanical braking. Insufficient motor torque while tuning may cause machine stalling/falling.
  - (6) If auto-tuning is impossible or an "Err" auto-tuning error is displayed, perform manual tuning with Selection 2.

## [Selection 2: Setting PM motor control and manual tuning]

If an "Err" tuning error is displayed during auto-tuning or when PM motor control characteristics are to be improved, set motor constants manually.

6

[Parameter setting]

| Title  | Function                                    | Adjustment range                | Default setting                                    |
|--------|---------------------------------------------|---------------------------------|----------------------------------------------------|
| $F402$ | Automatic torque boost value                | 0.1-30.0 (%)                    | Depends on the capacity<br>(Refer to section 11.4) |
| $F405$ | Motor rated capacity                        | 0.01-22.00 (kW)                 |                                                    |
| $F415$ | Motor rated current                         | 0.01-100.0 (A)                  |                                                    |
| $F417$ | Motor rated speed                           | 100-64000 ( $\text{min}^{-1}$ ) | *1                                                 |
| $F459$ | Load inertia moment ratio                   | 0.1-100.0 (times)               | 1.0                                                |
| $F462$ | Speed reference filter coefficient          | 0-100                           | 35                                                 |
| $F912$ | Q axis inductance per phase                 | 0.01-650.0 (mH)                 | 10.00                                              |
| $F913$ | D axis inductance per phase                 | 0.01-650.0 (mH)                 | 10.00                                              |
| $Err$  | Motor electronic thermal protection level 1 | 10-100 (%) / (A)                | 100                                                |

\*1: Default setting values vary depending on the setup menu setting.

Setting procedure Adjust the following parameters:

$F402$ : Adjust the primary resistive component of the motor. Decreases in torque due to a possible voltage drop during low-speed operation can be suppressed by setting a large value in this parameter. Be careful as setting a value larger than necessary may lead to an increased current causing a trip at low speeds. (Perform adjustments according to the actual operation.) If the test report exists, see the stator resistance value per phase.

$F402 = \sqrt{3} \times R_s \times F415 / V_{type} \times 100$  [%]

$R_s$  is Stator resistance per phase [ohm]  $V_{type}$  is 200 or 400 [V] (depend on voltage class)

- F405*: Set the motor's rated capacity according to the motor's name plate or test report.  
*F415*: Set the rated current of the motor. For the rated current, see the motor's nameplate or test report.  
*F417*: Set the rated rotational speed of the motor. For the rated current, see the motor's nameplate or test report.

- Adjustment method for the moment of inertia of the load

*F459*: Adjusts the excess response speed. A larger value gives a smaller overshoot at the acceleration/deceleration completion point. In the default settings, the moment of inertia of the load (including the motor shaft) value is optimally set considering a motor shaft of 1x. When the moment of inertia of the load is not 1x, set a value that matches that actual moment of inertia of the load.

*tHr*: If the rated capacity of the motor is one size smaller than that of the inverter, lower the thermal protective level according to the rated current of the motor.

\*Sensorless vector control may not operate properly if the motor capacity differs from the applicable rated capacity of the inverter by more than two grades.

Caution:

If a combination of the inverter rating and the motor capacity is different for more than 2 items, PM motor control may not operate correctly.

## 6.26 Torque limit

### 6.26.1 Torque limit switching

|             |                                      |             |                                     |
|-------------|--------------------------------------|-------------|-------------------------------------|
| <b>F441</b> | : Power running torque limit 1 level | <b>F445</b> | : Regenerative braking torque limit |
| <b>F443</b> | : Regenerative braking torque limit  |             | 2 level                             |
|             | 1 level                              | <b>F454</b> | : Constant output zone torque limit |
| <b>F444</b> | : Power running torque limit 2 level |             | selection                           |

#### • Function

Decrease the output frequency according to the overload condition when the motor torque reaches a certain set level. This function will be invalid when setting a torque limit parameter at 250.


You can also select limiting the constant output or constant torque in the constant output zone.

This function will not work when the parameter  $P\bar{L}=0$ ,  $I$ ,  $\bar{I}$  setting.

#### ■ Setting methods

When setting limits to torque, use internal parameters (Torque limits can also be set with an external control device.)

6



With the parameter  $F454$ , you can select the item for limit treatment in the constant output zone (somewhat weak magnetic field) from constant output ( $F454=0$ : default setting) or constant torque ( $F454=1$ ).

Output voltage limit option ( $F307=1$ ) is recommended for the parameter  $F307$  (supply voltage correction).

Power running torque limit and regenerative braking torque limit can be set with the parameters  $F441$  and  $F443$ .

[Parameter setting]

| Title          | Function                                    | Adjustment range                                     | Default setting |
|----------------|---------------------------------------------|------------------------------------------------------|-----------------|
| <i>F 4 4 1</i> | Power running torque limit 1 level          | 0.0-249.9 (%),<br>250.0: Disabled                    | 250.0           |
| <i>F 4 4 3</i> | Regenerative braking torque limit 1 level   | 0.0-249.9 (%),<br>250.0: Disabled                    | 250.0           |
| <i>F 4 5 4</i> | Constant output zone torque limit selection | 0: Constant output limit<br>1: Constant torque limit | 0               |

Using parameters, two different torque limits can be set for each operating status: power running and regenerative braking. Refer to Section 7.2.1 for the setting for switching from the terminal board.

Power running torque limit 1 : *F 4 4 1*

Regenerative braking torque limit 1 : *F 4 4 3*

Power running torque limit 2 : *F 4 4 4*

Regenerative braking torque limit 2 : *F 4 4 5*

Note: If the value set with *F 5 0 1* (stall prevention level) is smaller than the torque limit, then the value set with *F 5 0 1* acts as the torque limit.

## 6.26.2 Torque limit mode selection at acceleration/deceleration

***F 4 5 1***: Acceleration/deceleration operation after torque limit

### •Function

Using this function in combination with the mechanical brake of the lifting gear (such as a crane or hoist) makes it possible to minimize the delay before the brake starts working, and thus prevents the load from falling due to torque decrease.


Moreover, it improves the motor's response during inching operation and keeps the load from sliding down.

[Parameter setting]

| Title          | Function                                               | Adjustment range                                                            | Default setting |
|----------------|--------------------------------------------------------|-----------------------------------------------------------------------------|-----------------|
| <i>F 4 5 1</i> | Acceleration/deceleration operation after torque limit | 0: In sync with acceleration /<br>deceleration<br>1: In sync with min. time | 0               |

### (1) *F 4 5 1*=0 (In sync with acceleration/deceleration)


The increase in operation frequency is inhibited by the activation of the torque limit function. In this control mode, therefore, the actual speed is always kept in sync with the operation frequency. The operation frequency restarts to increase when torque decreases as a result of the release of the mechanical brake, so the time required for reaching the specified speed is the sum of the delay in operation of the mechanical brake and the acceleration time.



(2)  $F 45 \quad t = t$  (In sync with min. time)

The operation frequency keeps increasing, even if the torque limit function is activated.

In this control mode, the actual speed is kept in sync with the operation frequency, while torque is held at a limit level in spite of torque decrease when releasing the mechanical brake. The use of this function prevents the load from failing and improves the motor's response during inching operation.



## 6.26.3 Power running stall continuous trip detection time

**F452**: Power running stall continuous trip detection time

• **Function**


A function for preventing lifting gear from failing accidentally. If the stall prevention function is activated in succession, the inverter judges that the motor has stalled and trips.

[Parameter setting]

| Title | Function                                           | Adjustment range          | Default setting |
|-------|----------------------------------------------------|---------------------------|-----------------|
| F452  | Power running stall continuous trip detection time | 0.00-10.00 (s)            | 0.00            |
| F441  | Power running torque limit 1 level                 | 0-249%,<br>250:Disabled   | 250             |
| F601  | Stall prevention level 1                           | 10-199,<br>200 (disabled) | 150             |


6

1) In case of overcurrent stall



Gt2 trip is occurred if the output current reached the stall prevention level (F601) or more, and this situation maintain in F452 during power running.

2) In case of torque limitation



"B k 2" trip is occurred if the output torque reached the power running torque limit level (F 4 4 1) or more, and this situation maintain in F 4 5 2 during power running.

## 6.27 Acceleration/deceleration time 2 and 3

### 6.27.1 Selecting acceleration/deceleration patterns

**F502**: Acceleration/deceleration 1 pattern

**F506**: S-pattern lower-limit adjustment amount

**F507**: S-pattern upper-limit adjustment amount

- Function


These parameters allow you to select an acceleration/deceleration pattern that suits the intended use.

| Title       | Function                                | Adjustment range                          | Default setting |
|-------------|-----------------------------------------|-------------------------------------------|-----------------|
| <b>F502</b> | Acceleration/deceleration 1 pattern     | 0: Linear, 1: S-pattern 1, 2: S-pattern 2 | 0               |
| <b>F506</b> | S-pattern lower-limit adjustment amount | 0-50 (%)                                  | 10              |
| <b>F507</b> | S-pattern upper-limit adjustment amount | 0-50 (%)                                  | 10              |

#### 1) Linear acceleration/deceleration



A general acceleration/  
deceleration pattern.

This pattern can usually be  
used.




#### 2) S-pattern 1 acceleration/deceleration

Select this pattern to accelerate/decelerate the motor rapidly to a high-speed region with an output frequency of 60Hz or more or to minimize the shocks applied during acceleration/deceleration. This pattern is suitable for pneumatic transport machines.



## 3) S-pattern 2 acceleration/deceleration

Select this pattern to obtain slow acceleration in a demagnetizing region with a small motor acceleration torque. This pattern is suitable for high-speed spindle operation.



## 6.27.2 Switching of an acceleration/deceleration time 1, 2, 3

**F500**: Acceleration time 2

**F501**: Deceleration time 2

**F503**: Acceleration/deceleration 2 pattern

**F504**: Acceleration/deceleration selection (1,2,3) (panel keypad)

**F505**: Acceleration/deceleration 1 and 2 switching frequency

**F510**: Acceleration time 3

**F511**: Deceleration time 3

**F512**: Acceleration/deceleration 3 pattern

**F513**: Acceleration/deceleration 2 and 3 switching frequency

**F519**: Setting of acceleration/deceleration time unit

- Function


Three different times for acceleration and deceleration can be specified individually. Choose from the following for the method of selection or switching:

- 1) Selection by means of parameters
- 2) Switching by changing frequencies
- 3) Switching by means of terminals

| Title          | Function                                                        | Adjustment range                                                                                   | Default setting |
|----------------|-----------------------------------------------------------------|----------------------------------------------------------------------------------------------------|-----------------|
| <i>F 5 0 0</i> | Acceleration time 2                                             | 0.0-3600 (0.00-360.0) [sec]                                                                        | 10.0            |
| <i>F 5 0 1</i> | Deceleration time 2                                             | 0.0-3600 (0.00-360.0) [sec]                                                                        | 10.0            |
| <i>F 5 0 4</i> | Acceleration/deceleration selection<br>(1, 2, 3) (Panel keypad) | 1: Acceleration/deceleration 1<br>2: Acceleration/deceleration 2<br>3: Acceleration/deceleration 3 | 1               |
| <i>F 5 1 0</i> | Acceleration time 3                                             | 0.0-3600 (0.00-360.0) [sec]                                                                        | 10.0            |
| <i>F 5 1 1</i> | Deceleration time 3                                             | 0.0-3600 (0.00-360.0) [sec]                                                                        | 10.0            |
| <i>F 5 1 9</i> | Setting of acceleration/deceleration<br>time unit               | 0: -<br>1: 0.01s unit (after execution: 0)<br>2: 0.1s unit (after execution: 0)                    | 0               |

- Default setting is 0.1s unit. Acceleration/deceleration time unit can be changed to 0.01s unit by *F 5 1 9* = 1 setting. (The value of *F 5 1 9* return to 0 after setting.)

#### 1) Selection using parameters




Acceleration/deceleration time 1 is initially set as the default. Acceleration/deceleration time 2 and 3 can be selected by changing the setting of the *F 5 0 4*.

Enabled if *EN D* = 1 (panel input enabled)

#### 2) Switching by frequencies (Switching the acceleration/deceleration time automatically at the setting frequency)


| Title          | Function                                                 | Adjustment range                       | Default setting |
|----------------|----------------------------------------------------------|----------------------------------------|-----------------|
| <i>F 5 0 5</i> | Acceleration/deceleration 1 and 2<br>switching frequency | 0.0 (disabled)<br>0.1- <i>U L</i> (Hz) | 0.0             |
| <i>F 5 1 3</i> | Acceleration/deceleration 2 and 3<br>switching frequency | 0.0 (disabled)<br>0.1- <i>U L</i> (Hz) | 0.0             |

Note: Acceleration/deceleration patterns are changed from pattern 1 to pattern 2 and from pattern 2 to pattern 3 in increasing order of frequency, regardless of the order in which frequencies are changed. (For example, if *F 5 0 5* is larger than *F 5 1 3*, *F 5 1 3* pattern 1 is selected in the frequency range below the frequency set with *F 5 0 5*.)



- |                                                                                              |                                                                                              |
|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| (1) Acceleration at the gradient corresponding to acceleration time $R\bar{L}\bar{L}$        | (4) Deceleration at the gradient corresponding to deceleration time $F\bar{S}\bar{I}\bar{I}$ |
| (2) Acceleration at the gradient corresponding to acceleration time $F\bar{S}\bar{Q}\bar{Q}$ | (5) Deceleration at the gradient corresponding to deceleration time $F\bar{S}\bar{Q}\bar{I}$ |
| (3) Acceleration at the gradient corresponding to acceleration time $F\bar{S}\bar{I}\bar{Q}$ | (6) Deceleration at the gradient corresponding to deceleration time $d\bar{E}\bar{L}$        |

3) Switching using external terminals (Switching the acceleration/deceleration time via external terminals)



- |                                                                                              |                                                                                              |
|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| (1) Acceleration at the gradient corresponding to acceleration time $R\bar{L}\bar{L}$        | (4) Deceleration at the gradient corresponding to deceleration time $F\bar{S}\bar{I}\bar{I}$ |
| (2) Acceleration at the gradient corresponding to acceleration time $F\bar{S}\bar{Q}\bar{Q}$ | (5) Deceleration at the gradient corresponding to deceleration time $F\bar{S}\bar{Q}\bar{I}$ |
| (3) Acceleration at the gradient corresponding to acceleration time $F\bar{S}\bar{I}\bar{Q}$ | (6) Deceleration at the gradient corresponding to deceleration time $d\bar{E}\bar{L}$        |

- How to set parameters
  - a) Operating method: Terminal input  
Set the operation control mode selection  $\overline{ENOD}$  to 0.
  - b) Use the S2 and S3 terminals for switching. (Instead, other terminals may be used.)  
S2: Acceleration/deceleration switching signal 1  
S3: Acceleration/deceleration switching signal 2

| Title  | Function                        | Adjustment range | Setting value                                            |
|--------|---------------------------------|------------------|----------------------------------------------------------|
| $F115$ | Input terminal selection 5 (S2) | 0-203            | 24 (the second acceleration/deceleration mode selection) |
| $F116$ | Input terminal selection 6 (S3) | 0-203            | 26 (the third acceleration/deceleration mode selection)  |

- Acceleration/ deceleration pattern  
Acceleration/deceleration patterns can be selected individually, using the acceleration/deceleration 1, 2 and 3 parameters.
  - 1) Linear acceleration/deceleration
  - 2) S-pattern acceleration/deceleration 1
  - 3) S-pattern acceleration/deceleration 2

| Title  | Function                             | Adjustment range | Setting value |
|--------|--------------------------------------|------------------|---------------|
| $F502$ | Acceleration/ deceleration 1 pattern | 0: Linear        | 0             |
| $F503$ | Acceleration/ deceleration 2 pattern | 1: S-pattern 1   | 0             |
| $F512$ | Acceleration/ deceleration 3 pattern | 2: S-pattern 2   | 0             |

- For an explanation of acceleration/deceleration patterns, see 6.27.1.
- Both the settings of the S-pattern lower-limit and upper-limit adjustment parameters ( $F506$  and  $F507$ ) are applied to any acceleration/deceleration S-pattern.

## 6. 28 Shock monitoring function

- $F590$ : Shock monitoring
- $F591$ : Shock monitoring trip/ alarm selection
- $F592$ : Shock monitoring detection direction selection
- $F593$ : Shock monitoring detection level
- $F595$ : Shock monitoring detection time
- $F596$ : Shock monitoring detection hysteresis
- $F597$ : Shock monitoring detection start waiting time
- $F598$ : Shock monitoring detection action selection

⇒ Refer to "Shock monitoring function Instruction Manual: E6581875".

## 6.29 Protection functions

### 6.29.1 Setting motor electronic thermal protection

**EHr**: Motor electronic-thermal protection level 1

**F173**: Motor electronic-thermal protection level 2

**F607**: Motor 150% overload detection time

**F632**: Electronic-thermal memory

Refer to section 5.6.

### 6.29.2 Setting of stall prevention level

**F601**: Stall prevention level 1

**F185**: Stall prevention level 2

| <div style="text-align: center;">  <b>Caution</b> </div> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Prohibited                                           | <ul style="list-style-type: none"> <li>Do not set the stall prevention level (<b>F601</b>) extremely low.<br/>If the stall prevention level parameter (<b>F601</b>) is set at or below the no-load current of the motor, the stall preventive function will be always active and increase the frequency when it judges that regenerative braking is taking place.<br/>Do not set the stall prevention level parameter (<b>F601</b>) below 30% under normal use conditions.</li> </ul> |

6

- Function  
This parameter adjusts the output frequency by activating a current stall prevention function against a current exceeding the **F601**-specified level.

[Parameter setting]

| Title       | Function                 | Adjustment range                   | Default setting |
|-------------|--------------------------|------------------------------------|-----------------|
| <b>F601</b> | Stall prevention level 1 | 10-199 (%) / (A),<br>200: Disabled | 150             |
| <b>F185</b> | Stall prevention level 2 |                                    |                 |

[Display during operation of the stall prevention]

During an **OL** alarm status, (that is, when there is a current flow in excess of the stall prevention level), the output frequency changes. At the same time, to the left of this value, "E" is displayed flashing on and off.

Example of display

**E 50**

- The switching from **F601** to **F185** can be performed by entering a command through terminals.  
Refer to section 6.8.1 for details.

Note: The 100% standard value is the rated output current indicated on the nameplate.

### 6.29.3 Inverter trip retention

#### **F502**: Inverter trip retention selection

- Function


If the inverter trips, this parameter will retain the corresponding trip information. Trip information that has thus been stored into memory can be displayed, even after power has been reset.

#### [Parameter setting]

| Title       | Function                          | Adjustment range                                        | Default setting |
|-------------|-----------------------------------|---------------------------------------------------------|-----------------|
| <b>F502</b> | Inverter trip retention selection | 0: Cleared with power off<br>1: Retained with power off | 0               |

- The causes of up to eight trips that occurred in the past can be displayed in status monitor mode. (Refer to section 8.3)
- Data displayed in status monitor mode when the inverter is tripped is cleared when power is turned off. Check the details monitor for the history of past trips. (Refer to section 8.2.2)
- Trip records are retained even if power is turned off and turned back on during retry operation.

#### ■ Flow of operation when **F502** = 1



### 6.29.4 Emergency stop

#### **F515**: Deceleration time at emergency stop

#### **F603**: Emergency stop selection

#### **F604**: DC braking time during emergency stop

- Function

Set the stop method for an emergency. When operation stops, a trip occurs (E displays) and failure signal FL operates.

When **F603** is set to 2 (Emergency DC braking), set **F251** (DC braking amount) and **F604** (DC braking time during emergency stop).

When **F603** is set to 3 (Deceleration stop), set **F515** (Deceleration time at emergency stop).

## 1) Emergency stop from terminal

Emergency stop occurs at contact a or b. Follow the procedure below to assign a function to an input terminal and select a stop method.

[Parameter setting]

| Title       | Function                              | Adjustment range                                                                                                                                                             | Default setting |
|-------------|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F515</i> | Deceleration time at emergency stop   | 0.0-3600 (360.0) (s)                                                                                                                                                         | 10.0            |
| <i>F603</i> | Emergency stop selection              | 0: Coast stop<br>1: Deceleration stop<br>2: Emergency DC braking<br>3: Deceleration stop ( <i>F515</i> )<br>4: Quick deceleration stop<br>5: Dynamic quick deceleration stop | 0               |
| <i>F604</i> | DC braking time during emergency stop | 0.0-20.0 (s)                                                                                                                                                                 | 1.0             |
| <i>F251</i> | DC braking current                    | 0 - 100 (%)                                                                                                                                                                  | 50              |

Setting example) When assigning the emergency stop function to S2 terminal

| Title       | Function                         | Adjustment range | Setting                                     |
|-------------|----------------------------------|------------------|---------------------------------------------|
| <i>F114</i> | Input terminal selection 4A (S1) | 0 - 203          | 20: EXT (Emergency stop by external signal) |

Setting value 21 is reverse signal.

Note 1) Emergency stopping via the specified terminal is possible, even during panel operation.

## 2) Emergency stop from the operation panel

Emergency stop from the operation panel is possible by pressing the STOP key on the panel twice while the inverter is not in the panel control mode.

- (1) Press the STOP key ..... "E F F" will blink.
- (2) Press the STOP key once again ..... Operation will come to a trip stop in accordance with the setting of the *F603* parameter.  
After this, "E" will be displayed and a failure detection signal generated (FL relay is activated).

Note: While an emergency stop signal is input at a terminal, the trip cannot be reset. Clear the signal and then reset the trip.

## 6.29.5 Output phase failure detection

### ***F605***: Output phase failure detection selection

- Function

This parameter detects inverter output phase failure. If the phase failure status persists for one second or more, trip occurs and the failure signal FL will be activated. Trip information *EPH0* will be displayed.

Set *F605* to 5 to open the motor-inverter connection by switching commercial power operation to inverter operation.

Detection errors may occur for special motors such as high-speed motors.

*F605*=0: No tripping. (Failure signal FL not activated)

*F605*=1: With the power on, the output phase failure will be detected when the first operation starts.

The inverter will trip if the phase failure status persists for one second or more. (Failure signal FL activated)

*F605*=2: The inverter checks for output phase failures every time the operation starts. The inverter will trip if the phase failure status persists for one second or more. (Failure signal FL activated)

*F605*=3: The inverter checks for output phase failures during operation. The inverter will trip if the phase failure status persists for one second or more. (Failure signal FL activated)

*F605*=4: The inverter checks for output phase failures at the start and during operation. The inverter will trip if the phase failure status persists for one second or more. (Failure signal FL activated)

*F605*=5: If the inverter detects an all-phase failure, it will restart on completion of reconnection. The inverter does not check for output phase failures when restarting after a momentary power failure. (Failure signal FL not activated)

[Parameter setting]

| Title       | Function                                 | Adjustment range                                                                                                                                                                                | Default setting |
|-------------|------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F605</i> | Output phase failure detection selection | 0: Disabled<br>1: At start-up (only one time after power on)<br>2: At start-up (each time)<br>3: During operation<br>4: At start-up + during operation<br>5: Detection of cutoff on output side | 0               |

Note1) A check for output phase failures is made during auto-tuning, regardless of the setting of this parameter.

Note2) When parameter *Pt*=5 or 6 is selected, *F605*=3 to 5 do not work.

## 6.29.6 Input phase failure detection

### **F608**: Input phase failure detection selection

- Function

This parameter detects inverter input Phase failure. If the abnormal voltage status of main circuit capacitor persists for few minutes or more, the tripping function and the failure signal FL will be activated. Trip display is *EPH 1*. Detection may not be possible when operating with a light load, or when the motor capacity is smaller than the inverter capacity.

If the power capacity is larger than the inverter capacity (more than 500kVA or more than 10 times), detection errors may occur. If this actually happens, install an AC or DC reactor .

*F608=0*: No tripping. (Failure signal FL not activated)

*F608=1*: Phase failure detection is enabled during operation. The inverter will trip if the abnormal voltage status of main circuit capacitor persists for few minutes or more. (Failure signal FL activated)

[Parameter setting]

| Title       | Function                                | Adjustment range          | Default setting |
|-------------|-----------------------------------------|---------------------------|-----------------|
| <i>F608</i> | Input phase failure detection selection | 0: Disabled<br>1: Enabled | 1               |

Note1: Setting *F608* to 0 (input phase failure detection: disabled) may result in a breakage of the capacitor in the inverter main circuit if operation is continued under a heavy load in spite of the occurrence of an input phase failure.

Note2: Parameter *F608* is invalid for single-phase input model.

Note3: When operating the inverter with DC input, set *F608=0* (none).

## 6.29.7 Control mode for small current

**F609**: Small current detection hysteresis

**F610**: Small current trip/alarm selection

**F611**: Small current detection current

**F612**: Small current detection time

- Function

If the output current falls below the value set at **F611** and doesn't return above **F611**+**F609** for a time that exceeds the value set at **F612**, tripping or output alarm will be activated.

UL is displayed in the event of a trip.

**F610**=0: No tripping. (Failure signal FL not activated)

A small current alarm can be put out from the output terminal.

**F610**=1: The inverter will trip if a current below the current set with **F611** flows for the period of time specified with **F612**. (Failure signal FL activated)


[Parameter setting]

| Title       | Function                           | Adjustment range             | Default setting |
|-------------|------------------------------------|------------------------------|-----------------|
| <b>F609</b> | Small current detection hysteresis | 1-20 (%)                     | 10              |
| <b>F610</b> | Small current trip/alarm selection | 0: Alarm only<br>1: Tripping | 0               |
| <b>F611</b> | Small current detection current    | 0-150 (%) / (A)              | 0               |
| <b>F612</b> | Small current detection time       | 0-255 (s)                    | 0               |

<Example of operation>

Output terminal function: 26 (UC) Low current detection

**F610** = 0 (Alarm only)



\* When setting **F610** to 1 (Trip), trip after low current is detected for the period of time set with **F612**. After tripping, the low current signal remains ON.

## 6.29.8 Detection of output short-circuit

### **F613**: Detection of output short-circuit at start-up

- Function

This parameter detects inverter output short-circuit. It can be usually detected in the length of the standard pulse. When operating low-impedance motor such as high-speed motor, however, select the short-time pulse.

**F613=0**: Detection is executed in the length of the standard pulse every time you start up the inverter.

**F613=1**: Detection is executed in the length of standard pulse only during the first start-up after putting on the power or after resetting.

**F613=2**: Detection is executed with the short-time pulse every time you start up the inverter.

**F613=3**: Detection is executed with the short-time pulse only for the first time after putting power on or after resetting.

#### [Parameter setting]

| Title       | Function                                      | Adjustment range                                                                                                                                                 | Default setting |
|-------------|-----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F613</b> | Detection of output short-circuit at start-up | 0: Each time (standard pulse)<br>1: Only one time after power on (standard pulse)<br>2: Each time (short pulse)<br>3: Only one time after power on (short pulse) | 0               |

6

## 6.29.9 Ground fault detection function

### **F614**: Ground fault detection selection

- Function

This parameter detects inverter ground fault. If a ground fault occurs in the inverter unit or output side, the inverter will trip and the failure signal FL will be activated. **FF2** is displayed in the event of a trip.

**F614=0**: No tripping. (Failure signal FL not activated)

**F614=1**: Ground fault detection is enabled. The inverter will trip if the ground fault is occurred. (Failure signal FL activated)

#### [Parameter setting]

| Title       | Function                         | Adjustment range          | Default setting |
|-------------|----------------------------------|---------------------------|-----------------|
| <b>F614</b> | Ground fault detection selection | 0: Disabled<br>1: Enabled | 1               |

Note: When ground fault detection function sets to "Disabled", installing of ground detector such as ground relay is recommended.

## 6.29.10 Over-torque trip

**F615**: Over-torque trip/alarm selection

**F616**: Over-torque detection level

**F618**: Over-torque detection time

**F619**: Over-torque detection hysteresis

- Function

If the torque value exceeds the value set at **F616** and doesn't return below **F616-F619** for a time that exceeds the value set at **F618**, tripping or output alarm will be activated.

**0L** is displayed in the event of a trip.

**F615=0**: No tripping. (Failure signal FL not activated)

An over-torque alarm can be put out by setting the output terminal function selection parameter.

**F615=1**: The inverter trips when a torque exceeding the **F616**-specified level has been detected for longer than the **F618**-specified time. (Failure signal FL activated)

[Parameter setting]

| Title       | Function                         | Adjustment range             | Default setting |
|-------------|----------------------------------|------------------------------|-----------------|
| <b>F615</b> | Over-torque trip/alarm selection | 0: Alarm only<br>1: Tripping | 0               |
| <b>F616</b> | Over-torque detection level      | 0 (disabled),<br>1-250 (%)   | 150             |
| <b>F618</b> | Over-torque detection time       | 0.0-10.0 (s)    Note         | 0.5             |
| <b>F619</b> | Over-torque detection hysteresis | 0-100 (%)                    | 10              |


Note 1) If **F616** is set to 0(disabled), the alarm is not activated regardless of the **F615** setting.

Note 2) **F618**= 0.0 seconds is the shortest time detected on control.

<Example of operation>

1) Output terminal function: 28 (OT) Over-torque detection

$F615=0$  (Alarm only)



When  $F615 = 1$  (tripping), the inverter will trip if over-torque lasts for the period of time set with  $F618$ . The over-torque signal remains ON.

## 6.29.11 Cooling fan control selection

### **F620**: Cooling fan ON/OFF control

- Function

Operate the cooling fan only when the ambient temperature is high or during operation. This function will extend the service life of the cooling fan than when it is always running while the power is on.

$F620=0$ : Cooling fan automatically controlled. Cooling fan operates only when the ambient temperature is high during operation.

$F620=1$ : Cooling fan not automatically controlled. The fan is always running when the inverter is on.

- If the ambient temperature is high, even when the inverter is stopped, the cooling fan automatically operates.

[Parameter setting]

| Title  | Function                   | Adjustment range                            | Default setting |
|--------|----------------------------|---------------------------------------------|-----------------|
| $F620$ | Cooling fan ON/OFF control | 0: ON/OFF control<br>1: Always ON<br>2-7: - | 0               |

## 6.29.12 Cumulative operation time alarm setting

### **F521**: Cumulative operation time alarm setting

- Function  
Put out an alarm signal after a lapse of the cumulative operation time set with **F521**.

#### [Parameter setting]

| Title       | Function                                | Adjustment range      | Default setting |
|-------------|-----------------------------------------|-----------------------|-----------------|
| <b>F521</b> | Cumulative operation time alarm setting | 0.0-999.0 (100 hours) | 876.0           |

- "0.1" displayed on the monitor refers to 10 hours, and therefore "1.0" denotes 100 hours.

Ex.: 38.5 displayed on the monitor = 3850 (hours)

- Monitor display of cumulative operation time alarm.

It can be confirmed in parts replacement alarm information of status monitor mode.

An example of display: **111111**

- Signal output of cumulative operation time alarm

Assign the cumulative operation time alarm function to any output terminal.

Ex.: When assigning the cumulative operation alarm signal output function to the OUT terminal

| Title       | Function                           | Adjustment range | Setting                                   |
|-------------|------------------------------------|------------------|-------------------------------------------|
| <b>F131</b> | Output terminal selection 2A (OUT) | 0-255            | 56: COT (Cumulative operation time alarm) |

Setting value 57 is reverse signal.

- The cumulative operation time until present time can be checked in status monitor mode.  
(Refer to chapter 8)
- The monitor value of cumulative operation time is reset to 0(zero) by setting **LP=5** (cumulative operation time clear).  
(Refer to section 4.3.2)

## 6.29.13 Undervoltage trip

### **F527**: Undervoltage trip/alarm selection

- Function  
This parameter is used for selecting the control mode when an undervoltage is detected. Trip information is displayed as "**UP**".

**F527=0**: The inverter is stopped. However, it is not tripped (Failure signal FL not activated).

The inverter is stopped when the voltage does not exceed about 60 % of its rating.

**F527=1**: Inverter is stopped. It is also tripped (Failure signal FL activated), only after detection of a voltage not exceeding about 60% of its rating.

**F627=2**: Inverter is stopped. However, it is not tripped (Failure signal FL not activated). The inverter stop (Failure signal FL not activated.), only after detection of a voltage not exceeding 50% of its rating. Be sure to connect the input AC or DC reactor specified in section 10.4.

[Parameter setting]

| Title       | Function                          | Adjustment range                                                                                                                                                                 | Default setting |
|-------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F627</b> | Undervoltage trip/alarm selection | 0: Alarm only (detection level 60% or less)<br>1: Tripping (detection level 60% or less)<br>2: Alarm only (detection level 50% or less, input AC or DC reactor required)<br>3: - | 0               |

## 6.29.14 Analog input break detection

**F633**: Analog input break detection level (VIC)

**F644**: Operation selection of analog input break detection (VIC)

**F649**: Fallback frequency

• Function

The inverter will trip if the VIC value remains below the specified value for about 0.3 seconds. In such a case, trip "**E-18**" and alarm "**AL05**" is displayed.

**F633=0**: Disabled....Not detected.

**F633=1-100**....The inverter will trip if the VIC input remains below the specified value for about 0.3 seconds.

[Parameter setting]

| Title       | Function                                                  | Adjustment range                                                                                                                                             | Default setting |
|-------------|-----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F633</b> | Analog input break detection level (VIC)                  | 0: Disabled<br>1-100%                                                                                                                                        | 0               |
| <b>F644</b> | Operation selection of analog input break detection (VIC) | 0: Tripping<br>1: Alarm only (Coast stop)<br>2: Alarm only ( <b>F649</b> frequency)<br>3: Alarm only (Maintain running)<br>4: Alarm only (Deceleration stop) | 0               |
| <b>F649</b> | Fallback frequency                                        | 1.1-11.1 (Hz)                                                                                                                                                | 0.0             |

Note : The VIC input value may be judged earlier to be abnormal, depending on the degree of deviation of the analog data detected.

## 6.29.15 Parts replacement alarms

### **F 6 3 4**: Annual average ambient temperature (Parts replacement alarms)

- Function

Calculate the remaining service life of the cooling fan, main circuit capacitor and on-block capacitor based on the cumulative power on time, cumulative operation time, cumulative fan operation time, the output current (inverter load factor) and the setting of **F 6 3 4**. An alarm will be monitor displayed and sent out through output terminals when each component is approaching the time of replacement.

#### [Parameter setting]

| Title          | Function                                                      | Adjustment range                                                                      | Default setting |
|----------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------|-----------------|
| <b>F 6 3 4</b> | Annual average ambient temperature (parts replacement alarms) | 1: -10 to +10°C<br>2: 11-20°C<br>3: 21-30°C<br>4: 31-40°C<br>5: 41-50°C<br>6: 51-60°C | 3               |

- Display of part replacement alarm information

The time of replacement can be confirmed with the part replacement alarm information in the Status monitor mode. (Refer to chapter 8)

An example of display: **F 1 1 1 1 1**

- Output of part replacement alarm signal

The parts replacement alarm is assigned to the output terminal.

Setup example) When the parts replacement alarm is assigned to the OUT terminal

| Title          | Function                           | Adjustment range | Setting                            |
|----------------|------------------------------------|------------------|------------------------------------|
| <b>F 1 3 1</b> | Output terminal selection 2A (OUT) | 0-255            | 128: LTA (Parts replacement alarm) |

Setting value 129 is reverse signal.

Note 1: Using **F 6 3 4**, enter the annual average temperature around the inverter. Be careful not to enter the annual highest temperature.

Note 2: Set **F 6 3 4** at the time of installation of the inverter, and do not change its setting after the start of use. Changing the setting may cause parts replacement alarm calculation error.

- The cumulative power on time, cumulative fan operation time and cumulative operation time until present time can be checked by setting status monitor mode. (Refer to chapter 8)
- The monitor value of cumulative fan operation time and cumulative operation time are reset to 0(zero) by parameter **L 4 P** (Refer to section 4.3.2) .

## 6.29.16 Motor PTC thermal protection

**F 147**: Logic input / PTC input selection (S3)

**F 545**: PTC thermal selection

**F 546**: Resistor value for PTC detection

- Function

This function is used to protect motor from overheating using the signal of PTC built-in motor.  
The trip display is "E - 32".


[Parameter setting]

| Title | Function                               | Adjustment range               | Default setting |
|-------|----------------------------------------|--------------------------------|-----------------|
| F 147 | Logic input / PTC input selection (S3) | 0: Logic input<br>1: PTC input | 0               |
| F 545 | PTC thermal selection                  | 1: Tripping<br>2: Alarm only   | 1               |
| F 546 | PTC detection resistor value           | 100-9999 (Ω)                   | 3000            |

Note : Protecting PTC thermal, set **F 147** = 1 (PTC input) and slide switch SW2 to PTC side.

- Tripping level is defined by **F 545** setting. Alarm level is defined by 60% of **F 546** setting.
- Connect the PTC between S3 and CC terminals.  
Detection temperature can be set by **F 546** setting.

[Connection]



- Output of PTC input alarm signal

The PTC input alarm is assigned to the output terminal.

Setup example) When the PTC input alarm is assigned to the OUT terminal

| Title | Function                           | Adjustment range | Setting                               |
|-------|------------------------------------|------------------|---------------------------------------|
| F 131 | Output terminal selection 2A (OUT) | 0-255            | 150: PTCA<br>(PTC input alarm signal) |

Setting value 151 is reverse signal.

## 6.29.17 Number of starting alarm

**F 5 4 8**: Number of starting alarm

- Function  
Counting the number of starting, when it will reach the value of parameter **F 5 4 8** setting, it will be displayed and alarm signal is output.

[Parameter setting]

| Title          | Function                 | Adjustment range        | Default setting |
|----------------|--------------------------|-------------------------|-----------------|
| <b>F 5 4 8</b> | Number of starting alarm | 0.0-999.0 (10000 times) | 999.0           |

- "0.1" displayed on the monitor refers to 1000 times, and therefore "1.0" denotes 10000 times.  
Ex.: 38.5 displayed on the monitor = 385000 (times)
- Display of number of starting alarm information  
Number of starting alarm information in the Status monitor mode allows you to check on the time of replacement. (Refer to chapter 8)  
An example of display: **F 1 1 1 1 1 1**
- Output of number of starting alarm signal  
The number of starting alarm is assigned to the output terminal.

Setup example) When the number of starting alarm is assigned to the OUT terminal

| Title          | Function                           | Adjustment range | Setting                             |
|----------------|------------------------------------|------------------|-------------------------------------|
| <b>F 1 3 1</b> | Output terminal selection 2A (OUT) | 0-255            | 162: NSA (Number of starting alarm) |

Setting value 163 is reverse signal.

- The number of starting, forward number of starting and reverse number of starting until present time can be monitored by setting status monitor mode. (Refer to chapter 8)
- The monitor value of the number of starting, number of forward run and number of reverse run are reset to 0 (zero) by setting **1 4 P = 1 2** (number of starting clear). (Refer to section 4.3.2)

## 6.30 Forced fire-speed control function

**F650**: Forced fire-speed control selection

**F294**: Preset-speed frequency 15

- Function

With forced fire-speed control, operate the motor at the specified frequency in case of an emergency.  
Two kinds of operation are selectable by assignment of input terminal function.

(1) Input terminal function 56 (FORCE) : Input signal is retained once signal is ON.

Motor runs at the speed set by the parameter "F294".

Motor is forced to operate in case of light failure.

(2) Input terminal function 58 (FIRE) : Input signal is retained once signal is ON.

Motor runs at the speed set by the parameter "F294".

Note: In either case, power terminal should be off in order to stop.

[Parameter setting]

| Title | Function                            | Adjustment range          | Default setting |
|-------|-------------------------------------|---------------------------|-----------------|
| F650  | Forced fire-speed control selection | 0: Disabled<br>1: Enabled | 0               |
| F294  | Preset-speed frequency 15           | 0 - 50 (Hz)               | 0.0             |

[Setup example of input terminal]

When the terminal "RES" is assigned.

| Title | Function                          | Adjustment range | Setting value                                                    |
|-------|-----------------------------------|------------------|------------------------------------------------------------------|
| F113  | Input terminal selection 3A (RES) | 0 - 203          | 56 ( Forced run operation )<br>or<br>58 ( Fire speed operation ) |

Each setting value 57, 59 are reverse signal.

- "F113" and output frequency are blinking during forced run operation and fire-speed operation.

## 6.31 Override

- F205** : VIA input point 1 rate  
**F206** : VIA input point 2 rate  
**F214** : VIB input point 1 rate  
**F215** : VIB input point 2 rate  
**F220** : VIC input point 1 rate  
**F221** : VIC input point 2 rate  
**F660** : Override addition input selection  
**F661** : Override multiplication input selection  
**F729** : Operation panel override multiplication gain

• **Function**

These parameters are used to adjust reference frequencies by means of external input.

[Parameter setting]

| Title       | Function                                     | Adjustment range                                                                       | Default setting |
|-------------|----------------------------------------------|----------------------------------------------------------------------------------------|-----------------|
| <b>F205</b> | VIA input point 1 rate                       | 0-250 (%)                                                                              | 0               |
| <b>F206</b> | VIA input point 2 rate                       | 0-250 (%)                                                                              | 100             |
| <b>F214</b> | VIB input point 1 rate                       | -250+250 (%)                                                                           | 0               |
| <b>F215</b> | VIB input point 2 rate                       | -250+250 (%)                                                                           | 100             |
| <b>F220</b> | VIC input point 1 rate                       | 0-250 (%)                                                                              | 0               |
| <b>F221</b> | VIC input point 2 rate                       | 0-250 (%)                                                                              | 100             |
| <b>F660</b> | Override addition input selection            | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4: <b>F729</b> | 0               |
| <b>F661</b> | Override multiplication input selection      | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4: <b>F729</b> | 0               |
| <b>F729</b> | Operation panel override multiplication gain | -100+100 (%)                                                                           | 0               |


The override functions calculate output frequency by the following expression:

$$\text{Frequency command value} \times \left(1 + \frac{\text{Value [\%] selected with } F\bar{5}\bar{5}\bar{5} \text{ } 1}{100}\right) + \text{Value [Hz] selected with } F\bar{5}\bar{5}\bar{5} \text{ } 0$$

## 1) Additive override

In this mode, an externally input override frequency is added to operation frequency command.

[Ex.1: VIA (Reference frequency), VIC (Override input)] [Ex.2: VIB (Reference frequency), VIA (Override input)]



Ex.1:

$F\bar{5}\bar{5}\bar{5} \text{ } 0 = 3$  (VIC input),  $F\bar{5}\bar{5}\bar{5} \text{ } 1 = 0$  (disabled)

**Output frequency = Reference frequency + Override (VIC input [Hz])**

Ex.2:


$F\bar{5}\bar{5}\bar{5} \text{ } 0 = 1$  (VIA input),  $F\bar{5}\bar{5}\bar{5} \text{ } 1 = 0$  (disabled)

**Output frequency = Reference frequency + Override (VIA input [Hz])**

## 2) Multiplicative override

In this mode, each output frequency is multiplied by an externally override frequency.

[Ex.1: VIA (Reference frequency), VIC (Override input)] [Ex.2: VIB (Reference frequency), VIA (Override input)]



Ex.1:

$F660=0$  (Disabled),  $F661=3$  (VIC input),  $F70d=1$  (VIA input),  $FH=800$ ,  $UL=800$

VIA input, ( $F201=0$ ,  $F202=00$ ,  $F203=100$ ,  $F204=800$ )

VIC input ( $F216=0$ ,  $F220=0$ ,  $F218=100$ ,  $F221=100$ )

⇒ Setting of VIA input: Refer to Section 7.3.1, Setting of VIC input: Refer to Section 7.3.2.

$$\text{Output frequency} = \text{Reference frequency} \times \{1 + \text{Override (VIC input } [\%]/100)\}$$

Ex.2:

$F660=0$  (Disabled),  $F661=1$  (VIA input),  $F70d=2$  (VIB input),  $FH=800$ ,  $UL=800$

VIB input ( $F210=0$ ,  $F211=00$ ,  $F212=100$ ,  $F213=800$ )

VIA input ( $F201=0$ ,  $F205=0$ ,  $F203=100$ ,  $F206=100$ )

⇒ Setting of VIB input: Refer to Section 7.3.3, Setting of VIA input: Refer to Section 7.3.1.

$$\text{Output frequency} = \text{Reference frequency} \times \{1 + \text{Override (VIA input } [\%]/100)\}$$

Ex.3:

| Title  | Function                                     | Adjustment range   | Default setting |
|--------|----------------------------------------------|--------------------|-----------------|
| $F729$ | Operation panel override multiplication gain | $-100 \sim +100\%$ | 0               |

$$\text{Output frequency} = \text{Reference frequency} \times \{1 + \text{Override (} F729 \text{ setting value } [\%]/100)\}$$

## 6.32 Analog input terminal function selection

**F214** : VIB input point 1 rate

**F215** : VIB input point 2 rate

**F663** : Analog input terminal function selection (VIB)

• Function

Parameter is normally set from operation panel. However some parameters can be continuously set from external analog input by using this function. VIB terminal is used.

[Parameter setting]

| Title       | Function                                       | Adjustment range                                                                                                                                                                                                                                   | Default setting |
|-------------|------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F214</b> | VIB input point 1 rate                         | -250~+250 (%)                                                                                                                                                                                                                                      | 0               |
| <b>F215</b> | VIB input point 2 rate                         | -250~+250 (%)                                                                                                                                                                                                                                      | 100             |
| <b>F663</b> | Analog input terminal function selection (VIB) | 0: Frequency command<br>1: Acceleration/deceleration time<br>2: Upper limit frequency<br>3, 4: -<br>5: Torque boost value<br>6: Stall prevention level<br>7: Motor electronic-thermal protection level<br>8 to 10: -<br>11: Base frequency voltage | 0               |

- Analog input terminal function assigns VIB terminal. The range of analog input voltage is 0% to +100%. From -100% to 0% cannot be used.
- The parameter that is selected by **F663** can be adjusted range as following table.

| Setting of <b>F663</b>                       | Object parameter                        | VIB : 0% input                        | VIB : 100% input                      |
|----------------------------------------------|-----------------------------------------|---------------------------------------|---------------------------------------|
| 0: Frequency command                         | -                                       | -                                     | -                                     |
| 1: Acceleration/ deceleration time           | <i>ACC, DEC, F500, F501, F510, F511</i> | Parameter setting value x <b>F214</b> | Parameter setting value x <b>F215</b> |
| 2: Upper limit frequency                     | <i>UL</i>                               | Parameter setting value x <b>F214</b> | Parameter setting value x <b>F215</b> |
| 5: Torque boost value                        | <i>ub, F172</i>                         | Parameter setting value x <b>F214</b> | Parameter setting value x <b>F215</b> |
| 6: Stall prevention level                    | <i>F185, F601</i>                       | Parameter setting value x <b>F214</b> | Parameter setting value x <b>F215</b> |
| 7: Motor electronic-thermal protection level | <i>thr, F173</i>                        | Parameter setting value x <b>F214</b> | Parameter setting value x <b>F215</b> |
| 11: Base frequency voltage                   | <i>ULV, F171</i>                        | Parameter setting value x <b>F214</b> | Parameter setting value x <b>F215</b> |

Note: Adjustments are made by the inverter itself, so no changes are made to parameter settings

## 6.33 Adjustment parameters

### 6.33.1 Inputting integral input power pulse

**F557**: Integral input power pulse output unit

**F558**: Integral input power pulse output width

- Function  
Pulse signal can be output each time integral input power reaches integral power unit that is set by **F557**.  
Pulse output width is set by **F558**.

[Parameter setting]

| Title       | Function                                | Adjustment range                              | Default setting |
|-------------|-----------------------------------------|-----------------------------------------------|-----------------|
| <b>F557</b> | Integral input power pulse output unit  | 0: 0.1kWh<br>1: 1kWh<br>2: 10kWh<br>3: 100kWh | 1               |
| <b>F558</b> | Integral input power pulse output width | 0.1-1.0 (s)                                   | 0.1             |

Setting example) When integral input power pulse is output from output terminal

| Title       | Function                     | Adjustment range | Setting                                             |
|-------------|------------------------------|------------------|-----------------------------------------------------|
| <b>F131</b> | Output terminal selection 2A | 0 - 255          | 180: IPU (Integral input power pulse output signal) |

There is no reverse signal.

### 6.33.2 Pulse train output for meters

**F559**: Logic output/pulse train output selection (OUT)

**F576**: Pulse train output function selection (OUT)

**F577**: Maximum numbers of pulse train output

**F578**: Pulse train output filter

- Function  
Pulse trains can be sent out through the OUT output terminals.  
Set a pulse output mode and the number of pulses.

Ex.: When operations frequencies (0 to 60Hz) are put out by means of 0 to 600 pulses

**FH**=60.0, **F559**=1, **F576**=0, **F577**=0.60

[Parameter setting]

| Title          | Function                                        | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Reference of maximum value of <i>F 5 7 7</i>                                                                                                                                            | Default setting |
|----------------|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F 5 5 9</i> | Logic output/pulse train output selection (OUT) | 0: Logic output<br>1: Pulse train output                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | —                                                                                                                                                                                       | 0               |
| <i>F 5 7 5</i> | Pulse train output function selection (OUT)     | 0: Output frequency<br>1: Output current<br>2: Frequency command value<br>3: Input voltage (DC detection)<br>4: Output voltage (command value)<br>5: Input power<br>6: Output power<br>7: Torque<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency<br>13: V/A input value<br>14: V/B input value<br>15: Fixed output 1 (output current 100% equivalent)<br>16: Fixed output 2 (output current 50% equivalent)<br>17: Fixed output 3 (Other than the output current)<br>18: Communication data<br>19: -<br>20: VIC input value<br>21, 22: -<br>23: PID feedback value | <i>F H</i><br>185%<br><i>F H</i><br>150%<br>150%<br>185%<br>250%<br>-<br>100%<br>100%<br>100%<br><i>F H</i><br>10 V<br>10 V<br>185%<br>185%<br>100%<br>100.0%<br>-<br>20mA<br>-<br>100% | 0               |
| <i>F 5 7 7</i> | Maximum numbers of pulse train output           | 0.50-2.00 (kpps)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | —                                                                                                                                                                                       | 0.80            |
| <i>F 5 7 8</i> | Pulse train output filter                       | 2-1000 (ms)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | —                                                                                                                                                                                       | 64              |

- Digital panel meter for reference  
Type: K3MA-F (OMRON)  
Connection terminal: OUT-E4, NO-E5

Note 1: When item of *F 5 7 5* reaches "Reference of max. value", the number of pulse train set by *F 5 7 7* are sent to output terminals (OUT)

Note 2: The ON pulse width is maintained constant.

The ON pulse width is fixed at a width that causes the duty to reach 50% at the maximum pulse number set with *F 5 7 7*.

Therefore, the duty is variable.

For example, the ON pulse width is approximately 0.6 ms when *F 5 7 7* = 0.80 (pps)  
approximately 0.5 ms when *F 5 7 7* = 1.00 (pps)  
approximately 0.3 ms when *F 5 7 7* = 1.60 (pps)

Note 3: The minimum pulse output rate is 10pps. Keep in mind that no pulses can be put out at any rate smaller than this.

Note 4: *F 5 7 5* = *f<sub>c</sub>* is the motor drive frequency.

### 6.33.3 Calibration of analog output

**F581**: Analog output signal selection

**F584**: Analog output filter

**F591**: Inclination characteristic of analog output

**F592**: Analog output bias

- Function

Output signal from the FM terminal can be switched between 0 to 1mA output, 0 to 20mA output, and 0 to 10Vdc output with the **F581** setting. The standard setting is 0 to 1mA output.

\* Optional frequency meter: When using QS60T, set **F581** to 2 (meter option (0 to 1mA) output).

[Parameter setting]


| Title       | Function                                    | Adjustment range                                                                            | Default setting |
|-------------|---------------------------------------------|---------------------------------------------------------------------------------------------|-----------------|
| <b>F581</b> | Analog output signal selection              | 0: Meter option (0 to 1mA)<br>1: Current (0 to 20mA) output<br>2: Voltage (0 to 10V) output | 0               |
| <b>F584</b> | Analog output filter                        | 2-1000 (ms)                                                                                 | 2               |
| <b>F591</b> | Inclination characteristic of analog output | 0: Negative inclination (downward slope)<br>1: Positive inclination (upward slope)          | 1               |
| <b>F592</b> | Analog output bias                          | -1.0 - +100.0 (%)                                                                           | 0.0             |

Note 1: In case of 0 to 20mA output (4 to 20mA output), or 0 to 10Vdc output, set **F581** to 1 or 2.


In case of 4 to 20mA output, **F592** needs adjustment.

### ■ Example of setting


$F68\ I=1, F69\ I=1, F69Z=0(\%)$




$F68\ I=1, F69\ I=1, F69Z=20(\%)$



$F68\ I=1, F69\ I=0, F69Z=100(\%)$



$F68\ I=1, F69\ I=0, F69Z=100(\%)$



- The analog output inclination can be adjusted using the parameter  $F69$ .  
Refer to section 5.1 about how to adjustment.

## 6.34 Operation panel parameter

### 6.34.1 Prohibition of key operations and parameter settings

**F700**: Parameter protection selection

**F730**: Panel frequency setting prohibition (F L)

**F731**: Disconnection detection of extension panel

**F732**: Local/remote key prohibition of extension panel

**F733**: Panel operation prohibition (RUN key)

**F734**: Panel emergency stop operation prohibition

**F735**: Panel reset operation prohibition

**F736**: **ENOD/ENOD** change prohibition during operation

**F737**: All key operation prohibition

**F738**: Password setting (F700)

**F739**: Password verification

- Function

These parameters allow you to prohibit or allow operation of the RUN and STOP keys on the operation panel and the change of parameters. Using these parameters, you can also prohibit various key operations. Lock parameters with a password to prevent configuration.

[Parameter setting]

| Title       | Function                                        | Adjustment range                                                                                                                                                                                                             | Default setting |
|-------------|-------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F700</b> | Parameter protection selection                  | 0: Permitted<br>1: Writing prohibited (Panel and extension panel)<br>2: Writing prohibited (1 + RS485 communication)<br>3: Reading prohibited (Panel and extension panel)<br>4: Reading prohibited (3 + RS485 communication) | 0               |
| <b>F730</b> | Panel frequency setting prohibition (F L)       | 0: Permitted, 1: Prohibited                                                                                                                                                                                                  | 0               |
| <b>F731</b> | Disconnection detection of extension panel      | 0: Permitted, 1: Prohibited                                                                                                                                                                                                  | 0               |
| <b>F732</b> | Local/remote key prohibition of extension panel | 0: Permitted, 1: Prohibited                                                                                                                                                                                                  | 1               |
| <b>F733</b> | Panel operation prohibition (RUN key)           | 0: Permitted, 1: Prohibited                                                                                                                                                                                                  | 0               |

| Title | Function                                           | Adjustment range                                  | Default setting |
|-------|----------------------------------------------------|---------------------------------------------------|-----------------|
| F 734 | Panel emergency stop operation prohibition         | 0: Permitted, 1: Prohibited                       | 0               |
| F 735 | Panel reset operation prohibition                  | 0: Permitted, 1: Prohibited                       | 0               |
| F 736 | Load / Forward change prohibition during operation | 0: Permitted, 1: Prohibited                       | 1               |
| F 737 | All key operation prohibition                      | 0: Permitted, 1: Prohibited                       | 0               |
| F 738 | Password setting (F 700)                           | 0: Password unset<br>1-9998<br>9999: Password set | 0               |
| F 739 | Password verification                              | 0: Password unset<br>1-9998<br>9999: Password set | 0               |

- Parameters can be edited regardless of the setting of F 700 by assigning the parameter editing permission (function number 110, 111) to an input terminal.

Note1: F 700=2 and 4 will be available after reset operation.

Note 2: For the setting of F 737 to take effect, the inverter needs to be turned off and turned back on after the setting.

Note 3: The following changing value by setting dial like F 7 cannot be prohibited by F 700.

- F P 1d (F 389=3)

- Preset speed frequency (F 724=1)

Set F 730=1 to prohibit the change of these values.

6

#### 1) Setup and resetting method when protection using a password is necessary

#### ■ Password setup method

Preparation: Parameters other than F 700, F 738, and F 739 cannot be changed when F 700 is set to 1 to 4.

- When F 738 or F 739 is read out and the value is 0, a password hasn't been set.  
You can set a password.
- When F 738 or F 739 is read out and the value is 9999, a password has already been set.
- You can set a password If it hasn't been set. Select and register a number from 1 to 9998 for F 738.  
The number is the password. Do not forget your password as it is required to release the lock.
- The settings for parameter F 700 cannot be changed.

Note4: The lock cannot be released If you forget the password. Do not forget this password as we cannot retrieve it.

Note5: Password cannot be set when parameter F 700=0.

Set the password after parameter F 700=1 to 4.

Note6: Password can be read out to parameter writer (optional device) only for 5 minutes after setting F 738. Please note that password will not be able to read out due to password protection after 5 minutes have elapsed or when the power is off.

#### ■ Password examination method

- When F 738 or F 739 are read out and the value is 9999, a password has already been set.  
Password has to be removed in order to change parameters.
- Enter a the number (1 to 9998) registered to F 739 when the password was set for F 738.

- (3) If the password matches, *PASS* blinks on the display and the password is removed.
- (4) If the password is incorrect, *ERR* blinks on the display and *FFFF* is displayed again.
- (5) When the password is removed, the setting for parameter *FFFF* can be changed.
- (6) By setting parameter *FFFF=0*, the all parameter settings can be changed.

Note7: Entry of *FFFF* setting is possible up to 3 times. Please note it is impossible to set, if you enter the wrong number for 3 times. Number of times is reset after power is off.

## 2) Resetting method of prohibition settings: *FFFF* and *FFFF*

### ■ Resetting method

- (1) Canceling the *FFFF* prohibition setting

The setting of only parameter *FFFF* can be changed at any time, even if it is set to *1*.

- (2) Canceling the *FFFF* prohibition setting

When this parameter is set to *1* (key operation prohibited), press and hold down the ENT key for 5 seconds or more. The message *Undo* appears and this setting is canceled temporarily to enable key operation. To cancel this setting permanently, change the setting of *FFFF* directly

## 3) Setup method when parameter protection is necessary

### ■ Prohibit changing parameters settings and reading parameters from logic input

Set "Parameter editing prohibition" or "Parameter reading/editing prohibition" for an input terminal.

Activating the "Parameter editing prohibited" function prevents changes to parameters.

Activating the "Parameter reading/editing prohibition" function prevents reads and writes to parameters.

The following table shows an example of setting input terminal S1 and S2.

| Title        | Function                         | Adjustment range | Setting                                      |
|--------------|----------------------------------|------------------|----------------------------------------------|
| <i>FFFF4</i> | Input terminal selection 4A (S1) | 0-203            | 200: PWP<br>(Parameter editing prohibition)  |
| <i>FFFF5</i> | Input terminal selection 5 (S2)  | 0-203            | 202: PRWP<br>(Parameter reading prohibition) |

Setting value 201, 203 are reverse signal.

## 6.34.2 Change the unit (A/V) from a percentage of current and voltage

**F701**: Current/voltage unit selection

⇒ Refer to section 5.10.1.

## 6.34.3 Display the motor or the line speed

**F702**: Frequency free unit display magnification

**F703**: Frequency free unit coverage selection

**F705**: Inclination characteristic of free unit display

**F706**: Free unit display bias

⇒ Refer to section 5.10.2.

## 6.34.4 Change the steps in which the value increment

**F707**: Free step 1 (1-step rotation of setting dial)

**F708**: Free step 2 (panel display)

- Function  
Changeable step width can be changed at panel frequency setting.  
This function is useful when only running with frequencies of intervals of 1 Hz, 5 Hz, and 10 Hz units.

Note 1: The settings of these parameters don't work when the free unit selection (**F702**) is enabled.

Note 2: In case setting other than 0 to **F707** and increasing frequency by turning the setting dial to the right, frequency will not be increased beyond this point with the **H** alarm when the frequency exceeds **UL** (Upper limit frequency) with just one more step rotation.  
Similarly, when decreasing the frequency by turning the setting dial to the left and if the frequency falls below **LL** (lower limit frequency) with just one more step rotation, the **L** alarm is displayed in advance and the frequency cannot be lowered beyond this point.

- When **F707** is not 0.00, and **F708** = 0 (disabled)

Under normal conditions, the frequency command value from the operation panel increases by 0.1 Hz when you turn the setting dial to the right. If **F707** is not 0.00, the frequency command value will increase by the value with **F707** each time you turn the setting dial to the right by 1 step. Similarly, the frequency command value from the operation panel will decrease by the value set with **F707** when you turn the setting dial to the left by 1 step.

- When  $F707$  is not 0.00, and  $F708$  is not 0

The value displayed on the panel also can also be changed in steps.

$$\boxed{\text{Output frequency displayed in standard monitor mode}} = \boxed{\text{Internal output frequency}} \times \frac{F708}{F707}$$

[Parameter setting]

| Title  | Function                                      | Adjustment range                | Default setting |
|--------|-----------------------------------------------|---------------------------------|-----------------|
| $F707$ | Free step 1 (1-step rotation of setting dial) | 0.00: Automatic<br>0.01-FH (Hz) | 0.00            |
| $F708$ | Free step 2 (panel display)                   | 0: Automatic<br>1-255           | 0               |

- Operation example 1

$F707 = 0.00$  (disabled)

By rotating the setting dial 1 step, the panel frequency command value changes only 0.1 Hz.

When  $F707 = 10.00$  (Hz) is set

Rotating the setting dial 1 step changes the panel frequency command value in 10.00 Hz increments, from 0.00 up to 60.00 (Hz).

- Operation example 2

When  $F707 = 1.00$  (Hz), and  $F708 = 1$ :

By rotating the setting dial 1 step, the frequency setting  $F7$  changes in steps of 1Hz: 0 → 1 → 2 → ... → 60 (Hz) and also the value displayed on the operation panel changes in steps of 1. Use these settings to hide decimal fractions and also the value displayed on the operation panel changes in steps of 1. Use these settings to hide decimal fractions.

### 6.34.5 Select the initial display of the panel

$F710$ : Initial panel display selection

$F720$ : Initial extension panel display selection

- Function

This parameter specifies display format of the standard monitor mode when power is ON. Different contents can be displayed on the operation panel of main unit and the extension panel (option).

- Changing the display format while power is ON

When the power is ON, the standard monitor mode displays the output frequency (default setting) such as "0.0" or "0FF". This format can be changed to any other monitor display format by setting  $F710$ .

However, the initial letter including  $E$  or  $F$  will not be displayed. When the power is ON, set the display of the extension panel at  $F720$ .

- Different contents can be displayed on the operation panel of main unit and the extension panel (option).

[Parameter setting]

| Title          | Function                                  | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Default setting |
|----------------|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F 7 1 0</i> | Initial panel display selection           | 0: Output frequency (Hz/free unit)<br>1: Output current (%/A)<br>2: Frequency command value (Hz/free unit)<br>3: Input voltage (DC detection) (%/V)<br>4: Output voltage (command value) (%/V)<br>5: Input power (kW)<br>6: Output power (kW)<br>7: Torque (%)<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency (Hz/free unit)<br>13: VIA input value (%)<br>14: VIB input value (%)<br>15 to 17: -<br>18: Arbitrary code from communication<br>19: -<br>20: VIC input value (%)<br>21: Pulse train input value (pps)<br>22: -                                                                                                        | 0               |
| <i>F 7 2 0</i> | Initial extension panel display selection | 23: PID feedback value (Hz/free unit)<br>24: Integral Input power (kWh)<br>25: Integral Output power (kWh)<br>26: Motor load factor (%)<br>27: Inverter load factor (%)<br>28: Inverter rated current (A)<br>29: FM output value (%)<br>30: Pulse train output value (pps)<br>31: Cumulative power on time (100 hours)<br>32: Cumulative fan operation time (100 hours)<br>33: Cumulative operation time (100 hours)<br>34: Number of starting (10000 times)<br>35: Forward number of starting (10000 times)<br>36: Reverse number of starting (10000 times)<br>37: Number of trip (times)<br>38, 39: -<br>40: Inverter rated current (Carrier frequency corrected)<br>41 to 51: -<br>52: Frequency command value / output frequency (Hz/free unit) | 0               |

- For details on *F 7 1 0* / *F 7 2 0* = *18*, see "Communication Function Instruction Manual : E6581913".
- Note: If *F 7 2 0* = *18* setting, fixed value is displayed.

## 6.34.6 Change display of the status monitor

**F711** to **F718**: Status monitor 1 to 8

Change monitor display items in the status monitor mode.

⇒ Refer to chapter 8 for details.

## 6.34.7 Change the status monitor condition

**F709**: Standard monitor hold function

**F746**: Status monitor filter

- Function  
The standard monitor display can be hold.  
Some status monitors can be filtered to display.

- If **F709** is set to **0**, the monitored values selected with **F710** (standard monitor display selection parameter) are displayed. For peak hold values and minimum hold values, the minimum values in each operation cycle are displayed. When the motor is at a standstill, the values monitored last are held as they were until the motor is started the next time.

The maximum and minimum values monitored after power is turned on is always displayed no matter whether the motor is in operation or at a standstill.

The maximum and minimum values are cleared to press the EASY key by setting **F750** to **3**.

- "Output current", "Input voltage", "Output voltage" and "Torque" can be filtered by **F746**.

⇒ Refer to chapter 8 about status monitor.

[Parameter setting]

| Title       | Function                       | Adjustment range                                                                                                                                         | Default setting |
|-------------|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>F709</b> | Standard monitor hold function | 0: Real time<br>1: Peak hold<br>2: Minimum hold                                                                                                          | 0               |
| <b>F746</b> | Status monitor filter          | 8-1000 (ms)                                                                                                                                              | 200             |
| <b>F750</b> | EASY key function selection    | 0: Easy / standard setting mode switching function<br>1: Shortcut key<br>2: Local / remote key<br>3: Monitor peak / minimum hold trigger<br>4: -<br>5: - | 0               |

## 6.34.8 Cancel the operation command

**F719**: Selection of operation command clear

- Function

This parameter allows you to select operation command retained or operation command canceled, when coast stop occurs due to standby terminal function (ST) or coast stop command terminal function, and when under voltage in main circuit alarm occurs, during panel operation or RS485 communication operation.

| Parameter setting | At coast stop              | Under voltage in main circuit alarm (UVF) occurrence | Load is changed            |
|-------------------|----------------------------|------------------------------------------------------|----------------------------|
| F719=0            | Operation command canceled | Operation command retained                           |                            |
| F719=1            | Operation command retained |                                                      |                            |
| F719=2            | Operation command canceled |                                                      | Operation command retained |
| F719=3            | Operation command canceled |                                                      |                            |

Operation command retained :

Inverter restarts due to canceling coast stop at coast stop.

Inverter restarts due to supply power source again when the under voltage in main circuit alarm (U.V.F) occurs.

Operation command canceled :

Inverter doesn't restart after coast stop or occurring the under voltage in main circuit alarm (U.V.F).

Press RUN key to operate again in panel operation.

Switch to ON the operation command in RS485 communication operation.

| Title | Function                             | Adjustment range                                                                                                                                               | Default setting |
|-------|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| F719  | Selection of operation command clear | 0: Clear at coast stop and retained at U.V.F.<br>1: Retained at coast stop and U.V.F.<br>2: Clear at coast stop and U.V.F.<br>3: 2+ clear when Load is changed | 1               |

[Setup example of input terminal]

When it is assigned to the RES terminal.

| Title | Function                          | Adjustment range | Setting                      |
|-------|-----------------------------------|------------------|------------------------------|
| F113  | Input terminal selection 3A (RES) | 0-203            | 6: ST (Standby)              |
| F113  | Input terminal selection 3A (RES) | 0-203            | 96: FRR (Coast stop command) |

Setting value 7, 97 are reverse signal.

6.34.9 Select the operation panel stop pattern

**F721**: Selection of operation panel stop pattern

- Function

This parameter are used to select a panel stop pattern in which the motor started by pressing the

**RUN**

**STOP**

key on the operation panel.

1) Deceleration stop

The motor slows down to a stop in the deceleration time set with *dEC* (or *F501* or *F511*).

2) Coast stop

The inverter cuts off power supply to the motor. The motor comes to a stop after coasting for a while. Depending on the load, the motor may keep running for a longer time.

[Parameter setting]

| Title       | Function           | Adjustment range                      | Default setting |
|-------------|--------------------|---------------------------------------|-----------------|
| <i>F721</i> | Panel stop pattern | 0: Deceleration stop<br>1: Coast stop | 0               |

## 6.34.10 Select the panel display at power on

**F790**: Panel display selection at power on

**F791**: 1st and 2nd characters of **F790**

**F792**: 3rd and 4th characters of **F790**

**F793**: 5th and 6th characters of **F790**

**F794**: 7th and 8th characters of **F790**

- Function  
These parameters allow you to change the characters on panel display at power on.  
Default setting is "HELL0".

[Parameter setting]

| Title       | Function                              | Adjustment range                                            | Default setting |
|-------------|---------------------------------------|-------------------------------------------------------------|-----------------|
| <b>F790</b> | Panel display selection at power on   | 0: <b>HELL0</b><br>1: <b>F791</b> to <b>F794</b><br>2, 3: - | 0               |
| <b>F791</b> | 1st and 2nd characters of <b>F790</b> | 0-FFFF                                                      | 2d2d            |
| <b>F792</b> | 3rd and 4th characters of <b>F790</b> | 0-FFFF                                                      | 2d2d            |
| <b>F793</b> | 5th and 6th characters of <b>F790</b> | 0-FFFF                                                      | 2d2d            |
| <b>F794</b> | 7th and 8th characters of <b>F790</b> | 0-FFFF                                                      | 2d2d            |

Select **F790**=1 and set displayed characters with **F791** to **F794** if it is displayed characters other than "HELL0".

Refer to "ASCII LED" of "Communication Function Instruction Manual : E6581913" about setting characters and set by hex number.

## 6.35 Tracing functions

**F740** : Trace selection

**F742** : Trace data 1

**F741** : Trace cycle

**F743** : Trace data 2

**F744** : Trace data 3

**F745** : Trace data 4

⇒ For details, refer to "Trace Function Instruction Manual : E6581922".

## 6.36 Integrating wattmeter

**F748** : Integrating wattmeter retention selection

**F749** : Integrating wattmeter display unit selection

### •Function

At the main power off, display unit of integral output power values and whether or not retain integral output power values are selectable.

The integrating wattmeter display can be cleared by the signal to the input terminal.

Input terminal function 74, 75 (Integrating wattmeter display clear)

| Title       | Function                                     | Adjustment range                                                   | Default setting                                    |
|-------------|----------------------------------------------|--------------------------------------------------------------------|----------------------------------------------------|
| <b>F748</b> | Integrating wattmeter retention selection    | 0: Disabled<br>1: Enabled                                          | 0                                                  |
| <b>F749</b> | Integrating wattmeter display unit selection | 0:1=1kWh<br>1:1=10kWh<br>2:1=100kWh<br>3:1=1000kWh<br>4:1=10000kWh | Depends on the capacity<br>(Refer to section 11.4) |

## 6.37 Parameter registration to easy setting mode

**F750** : EASY key function selection

**F751** to **F782** : Easy setting mode parameter 1 to 32

Up to 32 arbitrary parameters can be registered to easy setting mode.

⇒ Refer to section 4.5 for details.

## 6.38 Communication function

### 6.38.1 Setting of communication function

|             |                                                                 |             |                                         |
|-------------|-----------------------------------------------------------------|-------------|-----------------------------------------|
| <b>F800</b> | Baud rate                                                       | <b>F814</b> | Communication command point 2 frequency |
| <b>F801</b> | Parity                                                          | <b>F829</b> | Selection of communication protocol     |
| <b>F802</b> | Inverter number                                                 | <b>F856</b> | Number of motor poles for communication |
| <b>F803</b> | Communication time-out time                                     | <b>F870</b> | Block write data 1                      |
| <b>F804</b> | Communication time-out action                                   | <b>F871</b> | Block write data 2                      |
| <b>F805</b> | Communication waiting time                                      | <b>F875</b> | Block read data 1                       |
| <b>F806</b> | Setting of master and slave for communication between inverters | <b>F876</b> | Block read data 2                       |
| <b>F808</b> | Communication time-out detection condition                      | <b>F877</b> | Block read data 3                       |
| <b>F810</b> | Communication command point selection                           | <b>F878</b> | Block read data 4                       |
| <b>F811</b> | Communication command point 1 setting                           | <b>F879</b> | Block read data 5                       |
| <b>F812</b> | Communication command point 1 frequency                         | <b>F899</b> | Communication function reset            |
| <b>F813</b> | Communication command point 2 setting                           |             |                                         |



#### Warning



Mandatory  
action

- Set the parameter Communication time-out time (**F803**), Communication time-out action (**F804**) and Disconnection detection of extension panel (**F731**). If these are not properly set, the inverter cannot be stopped immediately in breaking communication and this could result in injury and accidents.
- An emergency stop device and the interlock that fit with system specifications must be installed. If these are not properly installed, the inverter cannot be stopped immediately and this could result in injury and accidents.

Refer to "Communication Function Instruction Manual : E6581913" for details.

- Function  
2-wire RS485 communication is built-in as standard.  
Connect with the host to create a network for transmitting data between multiple inverters. A computer link function and Inverter-to-inverter communication function are available.  
<Computer-linking functions>  
The following functions are enabled by data communication between the computer and inverter
  - (1) Monitoring inverter status (such as the output frequency, current, and voltage)
  - (2) Sending RUN, STOP and other control commands to the inverter
  - (3) Reading, editing and writing inverter parameter settings
 < Inverter-to-inverter communication function >  
This function allows you to set up a network that makes it possible to carry out proportional operation of multiple inverters (without using a computer).
- Timer function ...Function used to detect cable interruptions during communication.  
When data is not sent even once to the inverter during a user-defined period of time, an inverter trip (E r r 5 is displayed on the panel) or an output terminal alarm("E" is displayed) can be output.
- Broadcast communication function ...Function used to send a command (data write) to multiple inverters with a single communication.
- Peer-to-peer communication function ...Refers to the function that enables the master inverter to send the data selected with a parameter to all slave inverters on the same network. This function allows you to set up a network that makes it possible to carry out synchronized operation or proportional operation (setting of point frequencies) in an abbreviated manner.
- Communication protocol ...Toshiba inverter protocol and Modbus RTU protocol are supported

- 2-wire RS485 communication options are as follows.

- (1) USB communication conversion unit (Type: USB001Z)  
Cable for communication between the inverter and the unit (Type: CAB0011 (1m), CAB0013 (3m), CAB0015 (5m))  
Cable for communication between the unit and computer: Use a commercially available USB 1.1 or 2.0 cables. (Type: A-B, Cable length: 0.25 to 1.5m)
- (2) Parameter writer (Type: RKP002Z)  
Communication cable (Type: CAB0011 (1m), CAB0013 (3m), CAB0015 (5m))
- (3) Parameter writer (Type: PWU003Z)  
RJ45 cable (1m) is attached.
- (4) Extension panel (Type: RKP007Z)  
Communication cable (Type: CAB0071 (1m), CAB0073 (3m), CAB0075 (5m))

Note1) In case of using above options, set the parameter F B 0 5=0.00

■ Settings for run/stop via communication

| Title | Function               | Adjustment range | Standard defaults | Setting example          |
|-------|------------------------|------------------|-------------------|--------------------------|
| C n d | Command mode selection | 0 - 4            | 1 (Panel keypad)  | 2 (RS485 communications) |

## ■ Settings for speed command via communication

| Title       | Function                         | Adjustment range | Standard defaults  | Setting example          |
|-------------|----------------------------------|------------------|--------------------|--------------------------|
| <i>F80d</i> | Frequency setting mode selection | 0 - 14           | 0 (Setting dial 1) | 4 (RS485 communications) |

## ■ Communication function parameters (2-wire RS485 communication)

Communication speed, parity, inverter number, and communication error trip time settings can be changed via panel operations or communication.

## [Parameter setting]

| Title       | Function                                                        | Adjustment range                                                                                                                                                                                                                                                                                                       | Default setting |
|-------------|-----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F800</i> | Baud rate                                                       | 3: 9600bps<br>4: 19200bps<br>5: 38400bps                                                                                                                                                                                                                                                                               | 4               |
| <i>F801</i> | Parity                                                          | 0: No parity<br>1: Even parity<br>2: Odd parity                                                                                                                                                                                                                                                                        | 1               |
| <i>F802</i> | Inverter number                                                 | 0-247                                                                                                                                                                                                                                                                                                                  | 0               |
| <i>F803</i> | Communication time-out time<br>*1                               | 0: Disabled<br>0.1-100.0 (s)                                                                                                                                                                                                                                                                                           | 0.0             |
| <i>F804</i> | Communication time-out action<br>*1                             | 0: Alarm only<br>1: Trip (Coast stop)<br>2: Trip (Deceleration stop)                                                                                                                                                                                                                                                   | 0               |
| <i>F805</i> | Communication waiting time                                      | 0.00-2.00                                                                                                                                                                                                                                                                                                              | 0.00            |
| <i>F806</i> | Setting of master and slave for communication between inverters | 0: Slave (0 Hz command issued in case the master inverter fails)<br>1: Slave (Operation continued in case the master inverter fails)<br>2: Slave (Emergency stop tripping in case the master inverter fails)<br>3: Master (transmission of frequency commands)<br>4: Master (transmission of output frequency signals) | 0               |
| <i>F808</i> | Communication time-out detection condition                      | 0: Valid at any time<br>1: Communication selection of <i>F80d</i> or <i>F80d</i><br>2: 1 + during operation                                                                                                                                                                                                            | 1               |
| <i>F810</i> | Communication command point selection                           | 0: Disabled<br>1: Enabled                                                                                                                                                                                                                                                                                              | 0               |
| <i>F811</i> | Communication command point 1 setting                           | 0-100                                                                                                                                                                                                                                                                                                                  | 0               |
| <i>F812</i> | Communication command point 1 frequency                         | 0.0- <i>FH</i>                                                                                                                                                                                                                                                                                                         | 0               |
| <i>F813</i> | Communication command point 2 setting                           | 0-100                                                                                                                                                                                                                                                                                                                  | 100             |
| <i>F814</i> | Communication command point 2 frequency                         | 0.0- <i>FH</i>                                                                                                                                                                                                                                                                                                         | *2              |
| <i>F829</i> | Selection of communication protocol                             | 0: Toshiba inverter protocol<br>1: Modbus RTU protocol                                                                                                                                                                                                                                                                 | 0               |

| Title       | Function                                | Adjustment range                                                                                                                                  | Default setting |
|-------------|-----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <i>F856</i> | Number of motor poles for communication | 1: 2 poles<br>2: 4 poles<br>3: 6 poles<br>4: 8 poles<br>5: 10 poles<br>6: 12 poles<br>7: 14 poles<br>8: 16 poles                                  | 2               |
| <i>F870</i> | Block write data 1                      | 0: No selection<br>1: Communication command 1<br>2: Communication command 2<br>3: Frequency command value<br>4: Output data on the terminal block | 0               |
| <i>F871</i> | Block write data 2                      | 5: FM analog output<br>6: Motor speed command                                                                                                     | 0               |
| <i>F875</i> | Block read data 1                       | 0: No selection<br>1: Status information 1<br>2: Output frequency<br>3: Output current                                                            | 0               |
| <i>F876</i> | Block read data 2                       | 4: Output voltage<br>5: Alarm information                                                                                                         | 0               |
| <i>F877</i> | Block read data 3                       | 6: PID feedback value<br>7: Input terminal monitor<br>8: Output terminal monitor                                                                  | 0               |
| <i>F878</i> | Block read data 4                       | 9: Terminal VIA monitor<br>10: Terminal VIB monitor<br>11: Terminal VIC monitor                                                                   | 0               |
| <i>F879</i> | Block read data 5                       | 12: Input voltage (DC detection)<br>13: Motor speed<br>14: Torque                                                                                 | 0               |
| <i>F899</i> | Communication function reset            | 0: -<br>1: Reset (after execution: 0)                                                                                                             | 0               |

\*1: Disabled..... Indicates that the inverter will not be tripped even if a communication error occurs.

Trip..... The inverter trips when a communication time-over occurs.

In this case a trip information *E r 5* flashes on and off on the operation panel.

Alarm ..... When a communication time-over occurs, an alarm can be output from the output terminal.

Output terminal function: 78 (RS485 communication error) or 79 (RS485 communication error reverse)

\*2: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

Note2) Changes to the parameters *F800*, *F801* and *F806* do not take effect until the power is turned off and then on again.

## 6.38.2 Using RS485

### ■ Communication function settings

Commands and frequency settings are given priority by communication. (Prioritized by commands from the panel or terminal block.) Thus, command and frequency settings from communication are activated, regardless of the command mode selection ( $\mathcal{L} \mathcal{R} \mathcal{Q} \mathcal{d}$ ) or frequency settings mode selection settings ( $F \mathcal{R} \mathcal{Q} \mathcal{d}$ ). However, setting 48: SCLC (switching from communication to local) with input terminal function selection and when inputting from an external device, it is possible to operate at command mode selection ( $\mathcal{L} \mathcal{R} \mathcal{Q} \mathcal{d}$ ) and frequency setting mode selection ( $F \mathcal{R} \mathcal{Q} \mathcal{d}$ ) settings.

Moreover, selecting local mode with the EASY key as Local / remote key function changes to panel frequency/panel operation mode.


### ■ Transmission specifications

| Item                             | Specifications                                                                                                                                                                                                                                        |                                    |
|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|
| Communication protocol           | TOSHIBA inverter protocol                                                                                                                                                                                                                             | MODBUS-RTU protocol                |
| Interface                        | RS485 compliant                                                                                                                                                                                                                                       |                                    |
| Transmission scheme              | Half duplex [Serial bus type (Line terminations resistor necessary at both ends of system)]                                                                                                                                                           |                                    |
| Wiring                           | 2-wire                                                                                                                                                                                                                                                |                                    |
| Transmission distance            | 500 m max. (total length)                                                                                                                                                                                                                             |                                    |
| Connection terminals             | 32max. (including upper host computer) Inverters connected in the system: 32max.                                                                                                                                                                      |                                    |
| Synchronization scheme           | Start-stop synchronization                                                                                                                                                                                                                            |                                    |
| Communication baud rate          | 9600 bps to 38.4kbps                                                                                                                                                                                                                                  |                                    |
| Character transmission           | <ASCII mode> JIS X0201 8-bit(ASCII)<br><Binary mode> Binary codes fixed to 8 bits                                                                                                                                                                     | Binary codes fixed to 8 bits       |
| Error detecting scheme 1         | Parity: Even/Odd/Non parity (selectable using a parameter)                                                                                                                                                                                            |                                    |
| Error detecting scheme 2         | Checksum                                                                                                                                                                                                                                              | CRC                                |
| Stop bit length                  | Received by inverter : 1bit / Sent by inverter : 2 bits                                                                                                                                                                                               |                                    |
| Order of bit transmission format | Low-order bits transmitted first                                                                                                                                                                                                                      |                                    |
| Character transmission format    | 11-bit characters (Stop bit = 1 , with parity)                                                                                                                                                                                                        |                                    |
| Inverter Number                  | <ASCII mode> 0-99<br><Binary mode> 0-63 (3Fh)                                                                                                                                                                                                         | 1-247                              |
| Broadcast communication          | Inverter Number should be set to<br><ASCII mode> ** (*? or ?? (?=0-9) is available)<br><Binary mode> 255 (0FFh)                                                                                                                                       | Inverter Number should be set to 0 |
| Frame length                     | Variable                                                                                                                                                                                                                                              |                                    |
| Error correction                 | None                                                                                                                                                                                                                                                  |                                    |
| Response monitoring              | None                                                                                                                                                                                                                                                  |                                    |
| Other                            | Inverter operation at communication time-over: Select from trip/alarm/none<br>• When alarm is selected, an alarm is output from the output terminal.<br>When trip is selected, $\mathcal{E} \mathcal{r} \mathcal{r} \mathcal{S}$ blinks on the panel. |                                    |

## ■ Connection example when using the computer link function

<Independent communication>

Perform computer-inverter connection as follows to send operation frequency commands from the host computer to inverter No. 3:



INV= inverter


"Given away": Only the inverter with the selected inverter number conducts data processing. All other inverters, even if they have received the data, give it away and stand by to receive the next data.

- : Use the terminal block to branch the cable.

- (1) Data is sent from the host computer.
- (2) Data from the computer is received at each inverter and the inverter numbers are checked.
- (3) The command is decoded and processed only by the inverter with the selected inverter number.
- (4) The selected inverter responds by sending the processing results, together with its own inverter number, to the host computer.
- (5) As a result, only the selected inverter starts operating in accordance with the operation frequency command by communicating independently.

## &lt;Broadcast communication&gt;

When sending an operation frequency command via a broadcast from the host computer



INV= inverter

- : Split the cable among terminal blocks.

- (1) Send data from the host computer.
- (2) The inverters receive data from the host computer and the inverter number is checked.
- (3) When \* is next to the position of an inverter number, it is judged a broadcast. The command is decoded and processed.
- (4) To prevent data conflicts, only inverters where \* is overwritten to 0 can reply with data to the host computer.
- (5) As a result, all inverters are operating with the broadcast operation frequency command.

Note: Specify inverter numbers by group for group broadcasts.


(Function only for ASCII mode. For parity mode, see the Communications Function Instruction Manual.)

(Ex) When \*1 is set, inverters 01, 11, 21, 31 to 91 can be broadcast to.

In this case, the inverter specified in 01 can reply.

■ Peer-to-peer communication

When all slave inverters are connected they operate at the same frequency as the master inverter (no setting of point frequencies in this case)



INV= inverter

- : Use the terminal block to branch the cable.

- (1) The master inverter transmits frequency command data to its slave inverters.
- (2) The slave inverter calculate a frequency reference from the data received and save the frequency calculated.
- (3) As a result, all slave inverters operate at the same frequency as the master inverter.

Note: The master inverter always sends frequency command data to its slave inverters.

The slave inverters are always on standby so that they can receive an frequency command from the master inverter at anytime.

6

6.38.3 Free notes

**F880**: Free notes

- Function  
To enable easier management and maintenance of the inverter, it is possible to enter the identification number.

[Parameter setting]

| Title | Function   | Adjustment range  | Default setting |
|-------|------------|-------------------|-----------------|
| F880  | Free notes | 0 – 65530 (65535) | 0               |

### 6.38.4 Open network option

**[L700]** to **[L789]**, **[L800]** to **[L830]** : CANopen communication parameters

**[L001]** to **[L111]**, **[L885]** to **[L896]** : Communication option common parameters

**[L120]** to **[L148]** : CC-Link option parameters

**[L150]** to **[L164]** : PROFIBUS DP option parameters

**[L200]** to **[L203]** : DeviceNet option parameters

**[L400]** to **[L421]**, **[L850]** to **[L880]** : EtherCAT option parameters

**[L500]** to **[L536]** : EtherNet common parameters

**[L554]** to **[L556]** : EtherNet/IP option parameters

**[L600]** to **[L604]** : Modbus TCP option parameters

- CANopen option (Type: CAN001Z, CAN002Z, CAN003Z)
- CC-Link option (Type: CCL003Z)
- PROFIBUS DP option (Type: PDP003Z)
- DeviceNet option (Type: DEV003Z)
- EtherNet / IP-Modbus TCP option (Type: IPE002Z)
- EtherCAT option (Type: IPE003Z)

⇒ Refer to each Instruction Manual of option for details.

## 6.39 Permanent magnet motors

**[F910]** : Step-out detection current level

**[F911]** : Step-out detection time

**[F912]** : q-axis inductance

**[F913]** : d-axis inductance

**[F915]** : Factory specific coefficient 9L

- Function

If the permanent magnet motor (PM motor) steps out and if the exciting current increases (it increases in such a case) and remains above the value set with **F910** for the period of time set with **F911**, the inverter will judge the motor to be stepping out and trip it. At that time, the trip message "SOUT" is displayed.

| Title       | Function                         | Adjustment range                    | Default setting |
|-------------|----------------------------------|-------------------------------------|-----------------|
| <b>F910</b> | Step-out detection current level | 1 - 150 (%)                         | 100             |
| <b>F911</b> | Step-out detection time          | 0.00: No detection<br>0.01-2.55 (s) | 0.00            |
| <b>F912</b> | q-axis inductance                | 0.01-650.0 (mH)                     | 10.00           |
| <b>F913</b> | d-axis inductance                | 0.01-650.0 (mH)                     | 10.00           |
| <b>F915</b> | Factory specific coefficient 9L  | -                                   | -               |

⇒ Refer to section 6.25.2 about setting motor constants.

Note 1: When using an PM motor, consult your Toshiba distributor, since the inverter is not compatible with all types of PM motors.

Note 2: The inverter may fail to detect step-out in some cases, because it uses an electrical method to detect step-out. To avoid detection failures, you are recommended to install a mechanical step-out detector.

## 6.40 Traverse function

- F980**: Traverse selection
- F981**: Traverse acceleration time
- F982**: Traverse deceleration time
- F983**: Traverse step
- F984**: Traverse jump step

⇒ Refer to "Traverse control Instruction Manual : E6581877" for details.


## 7. Operations with external signal

### 7.1 Operating external signals

You can control the inverter externally.

The parameter settings differ depending upon your method of operation. Determine your method of operation (the operational signal input method, speed (frequency) command input method) before using the procedure below to set the parameters.

[Procedure for setting parameters]



\* For settings based on communication, refer to the Communication Manual (E6581913) or section 6.38.

## 7.2 Applied operations by an I/O signal (operation from the terminal block)

Input terminal sink and source logic are set by using slide switch SW1.

### 7.2.1 Input terminal function (sink logic)


This function is used to send a signal to the input terminal from an external programmable controller to operate or configure the inverter.

The ability to select from a variety of functions allows for flexible system design.

Default settings of slide switch SW1 and SW2 are as follows;

SW1: PLC side, SW2: VIB side and S3 side.

Refer to page B-11 to 13 for details.




### ■ Settings for the logic input terminal function

| Terminal symbol | Title   | Function                                       | Adjustment range                       | Default setting |
|-----------------|---------|------------------------------------------------|----------------------------------------|-----------------|
| F               | F 1 1 1 | Input terminal selection 1A (F)                | 0-203 Note 1)                          | 2 (F)           |
|                 | F 1 5 1 | Input terminal selection 1B (F)                |                                        | 0 (No function) |
|                 | F 1 5 5 | Input terminal selection 1C (F)                |                                        | 0 (No function) |
| R               | F 1 1 2 | Input terminal selection 2A (R)                | 0-203 Note 1)                          | 4 (R)           |
|                 | F 1 5 2 | Input terminal selection 2B (R)                |                                        | 0 (No function) |
|                 | F 1 5 6 | Input terminal selection 2C (R)                |                                        | 0 (No function) |
| RES             | F 1 1 3 | Input terminal selection 3A (RES)              | 0-203 Note 1)                          | 8 (RES)         |
|                 | F 1 5 3 | Input terminal selection 3B (RES)              |                                        | 0 (No function) |
|                 | F 1 1 4 | Input terminal selection 4A (S1)               |                                        | 10 (SS1)        |
| S1              | F 1 5 4 | Input terminal selection 4B (S1)               | 0-203 Note 1)                          | 0 (No function) |
|                 | F 1 1 5 | Input terminal selection 5 (S2)                |                                        | 12 (SS2)        |
| S2              | F 1 4 6 | Logic input / pulse train input selection (S2) | 0: Logic input<br>1: Pulse train input | 0               |
|                 | F 1 1 6 | Input terminal selection 6 (S3)                |                                        | 14 (SS3)        |
| S3              | F 1 4 7 | Logic input / PTC input selection (S3)         | 0: Logic input<br>1: PTC input         | 0               |
| VIB             | F 1 1 7 | Input terminal selection 7 (VIB)               | 0-203 Note 5)                          | 16 (SS4)        |
| VIA             | F 1 1 8 | Input terminal selection 8 (VIA)               | 8-55 Note 6)                           | 24 (AD2)        |
| VIA<br>VIB      | F 1 0 9 | Analog/logic input selection (VIA/VIB)         | 0-4                                    | 0               |
| F to VIB        | F 1 4 4 | Input terminal response time                   | 1-1000 (ms) Note 7)                    | 1               |

- Note 1) Multiple functions assigned to a single terminal operate simultaneously.
- Note 2) In case of setting always active function, assign the menu number to  $F104$ ,  $F108$  and  $F110$  (always active function selection).
- Note 3) In case of using terminal S2 as a logic input, set the parameter  $F146=0$  (logic input).
- Note 4) In case of using terminal S3 as a logic input, set the slide switch SW2 (lower) to S3 side and the parameter  $F146=0$  (logic input).
- Note 5) In case of using terminal VIB as a logic input, set the side switch SW2 (upper) to S4 side and set the parameter  $F109=1, 3$ , or  $4$  (logic input). Since/ source logic depends on the slide switch SW1.
- Note 6) In case of using terminal VIA as a logic input, set the parameter  $F109=3$  or  $4$  (logic input).
- Note 7) When stable operation cannot be attained because of frequency setting circuit noise, increase the value of  $F144$ .

## ■ Connecting


- 1) For logic input



### With sink settings

- Operates by short circuiting between the input terminal and CC (common). Use for forward run, reverse run, preset-speed and so on.



- 2) For connection (sink logic) via transistor output



- Control by connecting the input terminal and CC (common) to the output (non-logic switch) of the programmable controller. Use for forward run, reverse run, preset-speed and so on. Use a 5 mA transistor that operates at 24 V dc.

## ■ Usage example ... 3-wire operation (one-push operation)

Use the 3-wire operation function to operate the inverter, maintaining operation without using the sequence circuit by inputting an external signal (reset logic signal).



Note 1) Set  $F \setminus 10 = 5$  (ST: standby) and  $CCd = 0$  (terminal block) for 3 wire operation. Assign HD (operation hold) to any input terminal at input terminal selection. When assigning the S2 terminal as shown above, set  $F \setminus 15 = 50$  (HD: Operation hold).

Note 2) If the terminals are ON before turning on the power, terminal input is ignored when the power is turned ON. (Prevents sudden movements.) After turning the power ON, turn terminal input ON again.

Note 3) When HD is OFF, F and R are ignored even when ON. R does not operate even if it's ON when HD is ON. Likewise in this state, F does not operate even if it's ON. Turn F and R OFF and then turn them ON.

Note 4) During 3 wire operation, sending the jog run mode command stops operation.

Note 5) Be aware that DC braking continues even if a startup signal is input during DC braking.

Note 6) Only F and R maintain HD (operation hold). When using F or R in combination with other functions, be aware that the other functions do not hold. For example, when F and SS1 are assigned, F holds, but SS1 does not.

[Parameter settings]

| Terminal symbol | Title            | Function                        | Adjustment range | Setting example         |
|-----------------|------------------|---------------------------------|------------------|-------------------------|
| S2              | $F \setminus 15$ | Input terminal selection 5 (S2) | 0-203            | 50: HD (Operation hold) |

# ■ List of logic input terminal function settings

| Parameter programmed value |                | Function                                  | Parameter programmed value |                | Function                                           |
|----------------------------|----------------|-------------------------------------------|----------------------------|----------------|----------------------------------------------------|
| Positive logic             | Negative logic |                                           | Positive logic             | Negative logic |                                                    |
| 0                          | 1              | No function                               | 74                         | 75             | Integrating wattmeter (kWh) display clear          |
| 2                          | 3              | Forward run command                       | 76                         | 77             | Trace back trigger signal                          |
| 4                          | 5              | Reverse run command                       | 78                         | 79             | Light-load high-speed operation prohibitive signal |
| 6                          | 7              | Standby                                   | 80                         | 81             | Holding of RY-RC terminal output                   |
| 8                          | 9              | Reset command                             | 82                         | 83             | Holding of OUT-NO terminal output                  |
| 10                         | 11             | Preset-speed command 1                    | 88                         | 89             | Frequency UP *2                                    |
| 12                         | 13             | Preset-speed command 2                    | 90                         | 91             | Frequency DOWN *2                                  |
| 14                         | 15             | Preset-speed command 3                    | 92                         | 93             | Clear frequency UP/DOWN *2                         |
| 16                         | 17             | Preset-speed command 4                    | 96                         | 97             | Coast stop command                                 |
| 18                         | 19             | Jog run mode                              | 98                         | 99             | Forward/reverse selection                          |
| 20                         | 21             | Emergency stop by external signal         | 100                        | 101            | Run/Stop command                                   |
| 22                         | 23             | DC braking command                        | 104                        | 105            | Frequency reference command forced switching       |
| 24                         | 25             | 2nd acceleration/deceleration             | 106                        | 107            | Frequency setting mode terminal block              |
| 26                         | 27             | 3rd acceleration/deceleration             | 108                        | 109            | Command mode terminal block                        |
| 28                         | 29             | 2nd V/F control mode switching            | 110                        | 111            | Parameter editing permission                       |
| 32                         | 33             | 2nd stall prevention level                | 120                        | 121            | Fast stop command 1                                |
| 36                         | 37             | PID control prohibition                   | 122                        | 123            | Fast stop command 2                                |
| 46                         | 47             | External thermal error input              | 134                        | 135            | Traverse permission signal                         |
| 48                         | 49             | Forced local from communication           | 136                        | 137            | Low voltage operation                              |
| 50                         | 51             | Operation hold (hold of 3-wire operation) | 140                        | 141            | Forward deceleration                               |
| 52                         | 53             | PID integral/differential clear           | 142                        | 143            | Forward stop                                       |
| 54                         | 55             | PID characteristics switching             | 144                        | 145            | Reverse deceleration                               |
| 56                         | 57             | Forced run operation                      | 146                        | 147            | Reverse stop                                       |
| 58                         | 59             | Fire speed operation                      | 148 to 151                 |                | Factory specific coefficient *1                    |
| 60                         | 61             | Acceleration/deceleration suspend signal  | 152                        | 153            | No.2 motor switching                               |
| 62                         | 63             | Power failure synchronized signal         | 200                        | 201            | Parameter editing prohibition                      |
| 64                         | 65             | Factory specific coefficient *1           | 202                        | 203            | Parameter reading prohibition                      |
| 70                         | 71             | Factory specific coefficient *1           |                            |                |                                                    |

\*1: Factory specific coefficients are manufacturer setting menus. Do not change the value of these parameters.

\*2: Active when  $FND$  (frequency setting mode selection) = 5 (UP/DOWN from external logic input) is set.

The frequency setup range is from  $0.0$  to  $FH$  (maximum frequency). The acceleration/deceleration time relative to the set frequency is  $RL/dEL$  while the acceleration/deceleration speed is not switched.

- Refer to section 11.6 for details about the input terminal function.

## 7.2.2 Output terminal function (sink logic)


This function is used to output a variety of signals to external devices from the inverter. With the logic output terminal function, you can select from multiple output terminal functions. Set two types of functions for the RY-RC, OUT terminal and then you can output when either one or both of them is ON.

Default settings of slide switch SW1 and SW2 are as follows;

SW1: PLC side, SW2: VIB side and S3 side.

Refer to page B-11 to 13 for details.

[Control terminal block]




### 7

#### ■ Usage

Function of FLA, B, C terminals:  
Set at parameter *F 132* Note 1)

Function of RY terminal:  
Set at parameter *F 130* and *F 131* Note 1)

Function of OUT terminal:  
Set at parameter *F 134* and *F 138*



Note1) A chattering (momentary ON/OFF of contact) is generated by external factors of the vibration and the impact, etc. In particular, please set the filter of 10ms or more, or timer for measures when connecting it directly with input unit terminal of programmable controller. Please use the OUT terminal as much as possible when the programmable controller is connected.

### ■ Assign one type of function to an output terminal

| Terminal symbol | Title        | Function                     | Adjustment range | Default setting                        |
|-----------------|--------------|------------------------------|------------------|----------------------------------------|
| RY-RC           | <i>F 130</i> | Output terminal selection 1A | 0 - 255          | 4 (Low-speed detection signal)         |
| OUT             | <i>F 131</i> | Output terminal selection 2A |                  | 6 (Output frequency attainment signal) |
| FL<br>(A, B, C) | <i>F 132</i> | Output terminal selection 3  |                  | 10 (Fault signal)                      |

Note 2) When assigning 1 type of function to the RY-RC terminal, set only *F 130*.

Leave parameter *F 137* as the default setting (*F 137* = 255).

Note 3) When assigning 1 type of function to the OUT terminal, set only *F 131*.

Leave parameter *F 138* as the default setting (*F 138* = 255).

### ■ Assign two types of functions to the output terminal (RY-RC, OUT)

| Terminal symbol | Title        | Function                        | Adjustment range                                                  | Default setting                        |
|-----------------|--------------|---------------------------------|-------------------------------------------------------------------|----------------------------------------|
| RY-RC           | <i>F 130</i> | Output terminal selection 1A    | 0 - 255                                                           | 4 (Low-speed detection signal)         |
|                 | <i>F 137</i> | Output terminal selection 1B    |                                                                   | 255 (Always ON)                        |
| OUT             | <i>F 131</i> | Output terminal selection 2A    |                                                                   | 6 (Output frequency attainment signal) |
|                 | <i>F 138</i> | Output terminal selection 2B    |                                                                   | 255 (Always ON)                        |
| RY-RC,<br>OUT   | <i>F 139</i> | Output terminal logic selection | 0: <i>F 130</i> and <i>F 137</i><br><i>F 131</i> and <i>F 138</i> | 0                                      |
|                 |              |                                 | 1: <i>F 130</i> or <i>F 137</i><br><i>F 131</i> and <i>F 138</i>  |                                        |
|                 |              |                                 | 2: <i>F 130</i> and <i>F 137</i><br><i>F 131</i> or <i>F 138</i>  |                                        |
|                 |              |                                 | 3: <i>F 130</i> or <i>F 137</i><br><i>F 131</i> or <i>F 138</i>   |                                        |


Note 4) *F 131* and *F 138* are active only when *F 669* = 0: Logic output (default).

Function is inactive when *F 669* = 1: Pulse train output is set.

## (1) Output signals when two types of functions are simultaneously turned ON. <AND>

In case of RY-RC terminal, signals are output when parameter  $F\ 139 = 0$  or  $2$ , and the functions set at parameters  $F\ 130$  and  $F\ 137$  are simultaneously turned on.

### • Timing chart




\* OUT terminal outputs signals when parameter  $F\ 139 = 0$  or  $2$ , and the functions set at parameters  $F\ 131$  and  $F\ 138$  are simultaneously turned on.

7

## (2) Output signals when either one of two types of functions is turned ON. <OR>

In case of RY-RC terminal, signals are output when parameter  $F\ 139 = 1$  or  $3$ , and either of the functions set at parameters  $F\ 130$  and  $F\ 137$  is turned on.

### • Timing chart



\*OUT terminal outputs signals when parameter  $F\ 139 = 2$  or  $3$ , and either of the functions set at parameters  $F\ 131$  and  $F\ 138$  is turned on.

### (3) Holding the output of signals in ON status

- If the conditions for activating the functions assigned to RY-RC terminal and OUT terminal agree with and as a result the output of signals is put in ON status, the output of signals is held ON, even if the conditions change. (Output terminal holding function)

Assign function 80 to 83 to an input terminal.

Once RY-RC terminal or OUT terminal is turned on when the assigned input terminal is ON, RY-RC terminal or OUT terminal is held ON.

| Function No. | Code  | Function                          | Action                                                                                                              |
|--------------|-------|-----------------------------------|---------------------------------------------------------------------------------------------------------------------|
| 80           | HDRY  | Holding of RY-RC terminal output  | ON : Once turned on, RY-RC are held on.<br>OFF: The status of RY-RC changes in real time according to conditions.   |
| 82           | HDOUT | Holding of OUT-NO terminal output | ON : Once turned on, OUT-NO are held on.<br>OFF: The status of OUT-NO changes in real time according to conditions. |

Each one of the following numbers (81, 83) is an inverse signal.

#### ■ Usage example ...operational signal, brake signal


Low-speed detection signal outputs the signal when the output frequency exceeds the setting of  $F 100$ .

This signal can be used as an operation signal by setting  $F 100$  to 0.0Hz. (Default setting)

This signal can also be used as an electromagnetic brake excitation/release signal.

Setting example) When outputting the brake signal from RY-RC terminal

| Title   | Function                             | Adjustment range | Example of setting                  |
|---------|--------------------------------------|------------------|-------------------------------------|
| $F 100$ | Low-speed signal output frequency    | 0.0 - $F H$ (Hz) | 2.5                                 |
| $F 130$ | Output terminal selection 1A (RY-RC) | 0-255            | 4: LOW (Low-speed detection signal) |



## ■ List of output terminal function settings

<Explanation of terminology>

- Alarm ..... Alarm output when a setting has been exceeded.
- Pre-alarm ..... Alarm output when the inverter may cause a trip during continued operation.

List of detection levels for output terminal selection

| Parameter programmed value |                | Function                                                                 | Parameter programmed value |                | Function                                      |
|----------------------------|----------------|--------------------------------------------------------------------------|----------------------------|----------------|-----------------------------------------------|
| Positive logic             | Negative logic |                                                                          | Positive logic             | Negative logic |                                               |
| 0                          | 1              | Frequency lower limit                                                    | 108                        | 109            | Heavy load output                             |
| 2                          | 3              | Frequency upper limit                                                    | 120                        | 121            | Lower limit frequency stop                    |
| 4                          | 5              | Low-speed detection signal                                               | 122                        | 123            | Power failure synchronized operation          |
| 6                          | 7              | Output frequency attainment signal (acceleration/deceleration completed) | 124                        | 125            | Traverse in progress                          |
| 8                          | 9              | Set frequency attainment signal                                          | 126                        | 127            | Traverse deceleration in progress             |
| 10                         | 11             | Fault signal (trip output)                                               | 128                        | 129            | Parts replacement alarm                       |
| 14                         | 15             | Over-current detection pre-alarm                                         | 130                        | 131            | Over-torque detection pre-alarm               |
| 16                         | 17             | Overload detection pre-alarm                                             | 132                        | 133            | Frequency setting mode selection 1/2          |
| 20                         | 21             | Overheat detection pre-alarm                                             | 136                        | 137            | Panel / remote selection                      |
| 22                         | 23             | Overvoltage detection pre-alarm                                          | 138                        | 139            | Forced continuous operation in progress       |
| 24                         | 25             | Power circuit undervoltage detection                                     | 140                        | 141            | Specified frequency operation in progress     |
| 26                         | 27             | Small current detection                                                  | 144                        | 145            | Signal in accordance of frequency command     |
| 28                         | 29             | Over-torque detection                                                    | 146                        | 147            | Fault signal (output also at a retry waiting) |
| 30                         | 31             | Braking resistor overload pre-alarm                                      | 150                        | 151            | PTC input alarm signal                        |
| 40                         | 41             | Run/Stop                                                                 | 152                        | 153            | Factory specific coefficient *1               |
| 42                         | 43             | Serious failure                                                          | 154                        | 155            | Analog input break detection alarm            |
| 44                         | 45             | Light failure                                                            | 156                        | 157            | F terminal status                             |
| 50                         | 51             | Cooling fan ON/OFF                                                       | 158                        | 159            | R terminal status                             |
| 52                         | 53             | In jogging operation                                                     | 160                        | 161            | Cooling fan replacement alarm                 |
| 54                         | 55             | Operation panel / terminal block operation                               | 162                        | 163            | Number of starting alarm                      |
| 56                         | 57             | Cumulative operation time alarm                                          | 166                        | 167            | Acceleration operation in progress            |
| 58                         | 59             | Communication option communication error                                 | 168                        | 169            | Deceleration operation in progress            |
| 60                         | 61             | Forward/reverse run                                                      | 170                        | 171            | Constant speed operation in progress          |
| 62                         | 63             | Ready for operation 1                                                    | 172                        | 173            | DC braking in progress                        |
| 64                         | 65             | Ready for operation 2                                                    | 174 to 179                 |                | Factory specific coefficient *1               |
| 68                         | 69             | Brake release                                                            | 180                        | 181            | Integral input power pulse output signal      |
| 70                         | 71             | Pre-alarm                                                                | 182                        | 183            | Shock monitoring pre-alarm signal             |
| 78                         | 79             | RS485 communication error                                                | 222 to 253                 |                | Factory specific coefficient *1               |
| 92                         | 93             | Designated data output 1                                                 | 254                        |                | Always OFF                                    |
| 94                         | 95             | Designated data output 2                                                 | 255                        |                | Always ON                                     |
| 106                        | 107            | Light load output                                                        |                            |                |                                               |

\*1: Factory specific coefficients are manufacturer setting menus. Do not change the value of these parameters.

Note 1) ON with positive logic : Open collector output transistor or relay turned ON.  
OFF with positive logic : Open collector output transistor or relay turned OFF.  
ON with negative logic : Open collector output transistor or relay turned OFF.  
OFF with negative logic: Open collector output transistor or relay turned ON.

- Refer to section 11.7 for details about the output terminal functions or levels.

## 7.3 Speed instruction (analog signal) settings from external devices

Function of analog input terminals can be selected from four functions (external potentiometer, 0 to 10Vdc, 4 (0) to 20mA, -10 to +10Vdc).

The selective function of analog input terminals gives system design flexibility.


The maximum resolution is 1/1000.

Default settings of slide switch SW1 and SW2 are as follows;

SW1: PLC side, SW2: VIB side and S3 side.

Refer to page B-11 to 13 for details.

[Control terminal block]



### ■ Analog input terminal function settings

| Terminal symbol | Title | Function                    | Adjustment range    | Default setting |
|-----------------|-------|-----------------------------|---------------------|-----------------|
| VIA             | F201  | VIA input point 1 setting   | 0 - 100%            | 0               |
|                 | F202  | VIA input point 1 frequency | 0.0 - 500.0Hz       | 0.0             |
|                 | F203  | VIA input point 2 setting   | 0 - 100%            | 100             |
|                 | F204  | VIA input point 2 frequency | 0.0 - 500.0Hz       | *1              |
| VIB             | F210  | VIB input point 1 setting   | -100 - +100%        | 0               |
|                 | F211  | VIB input point 1 frequency | 0.0 - 500.0Hz       | 0.0             |
|                 | F212  | VIB input point 2 setting   | -100 - +100%        | 100             |
|                 | F213  | VIB input point 2 frequency | 0.0 - 500.0Hz       | *1              |
| VIC             | F216  | VIC input point 1 setting   | 0 - 100%            | 20              |
|                 | F217  | VIC input point 1 frequency | 0.0 - 500.0Hz       | 0.0             |
|                 | F218  | VIC input point 2 setting   | 0 - 100%            | 100             |
|                 | F219  | VIC input point 2 frequency | 0.0 - 500.0Hz       | *1              |
| VIA to VIC      | F209  | Analog input filter         | 2 - 1000 ms Note 1) | 64              |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

Note1) When stable operation cannot be attained because of frequency setting circuit noise, increase the value of F209.

Note 2) Refer to section 5.8 when switching between two types of analog signals.

### 7.3.1 Settings depending on voltage (0 to 10 V) input <external potentiometer>


You can set the frequency settings by connecting the external potentiometer (1k to 10kΩ) between PP, VIA, and CC terminals.

You can also set by inputting an analog voltage signal of 0 to 10Vdc between the VIA and CC terminals.

The following shows examples when the run command is input from the terminal.

| Title          | Function                               | Adjustment range | Default setting       | Setting example          |
|----------------|----------------------------------------|------------------|-----------------------|--------------------------|
| <i>C n d</i>   | Command mode selection                 | 0 - 4            | 1<br>(panel keypad)   | 0<br>(terminal block)    |
| <i>F n d</i>   | Frequency setting mode selection 1     | 0 - 14           | 0<br>(setting dial 1) | 1<br>(terminal VIA)      |
| <i>F 1 0 9</i> | Analog/logic input selection (VIA/VIB) | 0 - 4            | 0                     | 0 or 1<br>(Analog input) |
| <i>F 2 0 1</i> | VIA input point 1 setting              | 0 - 100%         | 0                     | 0                        |
| <i>F 2 0 2</i> | VIA input point 1 frequency            | 0.0 - 500.0Hz    | 0.0                   | 0.0                      |
| <i>F 2 0 3</i> | VIA input point 2 setting              | 0 - 100%         | 100                   | 100                      |
| <i>F 2 0 4</i> | VIA input point 2 frequency            | 0.0 - 500.0Hz    | *1                    | 50.0/60.0                |
| <i>F 2 0 9</i> | Analog input filter                    | 2 - 1000 ms      | 64                    | 64                       |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.




### 7.3.2 Settings depending on current (4 to 20 mA) input

You can set the frequency settings by inputting an analog current signal of 4 (0) to 20mA dc between the VIC and CC terminals.

The following shows examples when the run command is input from the terminal.

| Title              | Function                           | Adjustment range | Default setting       | Setting example       |
|--------------------|------------------------------------|------------------|-----------------------|-----------------------|
| $\overline{CND}$   | Command mode selection             | 0 – 4            | 1<br>(panel keypad)   | 0<br>(terminal block) |
| $\overline{FND}$   | Frequency setting mode selection 1 | 0 – 14           | 0<br>(setting dial 1) | 8<br>(terminal VIC)   |
| $\overline{F2:16}$ | VIC input point 1 setting          | 0 – 100%         | 20                    | 20 (or 0)             |
| $\overline{F2:17}$ | VIC input point 1 frequency        | 0.0 - 500.0Hz    | 0.0                   | 0.0                   |
| $\overline{F2:18}$ | VIC input point 2 setting          | 0 – 100%         | 100                   | 100                   |
| $\overline{F2:19}$ | VIC input point 2 frequency        | 0.0 - 500.0Hz    | *1                    | 50.0/60.0             |
| $\overline{F2:9}$  | Analog input filter                | 2 - 1000 ms      | 64                    | 64                    |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.




### 7.3.3 Settings depending on voltage (-10 to +10 V) input

You can set the frequency settings by inputting an analog voltage signal of -10 to +10Vdc between the VIB and CC terminals.

The following shows examples when the run command is input from the terminal.


| Title          | Function                               | Adjustment range         | Default setting       | Setting example       |
|----------------|----------------------------------------|--------------------------|-----------------------|-----------------------|
| <i>C n d</i>   | Command mode selection                 | 0 - 4                    | 1<br>(panel keypad)   | 0<br>(terminal block) |
| <i>F n d</i>   | Frequency setting mode selection       | 0 - 14                   | 0<br>(setting dial 1) | 2<br>(terminal VIB)   |
| <i>F 1 0 1</i> | Analog input terminal selection (VIB)  | 0: 0-+10V<br>1: -10-+10V | 0                     | 1<br>(-10 - +10V)     |
| <i>F 1 0 9</i> | Analog/logic input selection (VIA/VIB) | 0 - 4                    | 0                     | 0<br>(Analog input)   |
| <i>F 2 1 0</i> | VIB input point 1 setting              | -100 - +100%             | 0                     | 0                     |
| <i>F 2 1 1</i> | VIB input point 1 frequency            | 0.0 - 500.0Hz            | 0.0                   | 0.0                   |
| <i>F 2 1 2</i> | VIB input point 2 setting              | -100 - +100%             | 100                   | 100                   |
| <i>F 2 1 3</i> | VIB input point 2 frequency            | 0.0 - 500.0Hz            | *1                    | 50.0/60.0             |
| <i>F 2 0 9</i> | Analog input filter                    | 2 - 1000 ms              | 64                    | 64                    |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.



## 8. Monitoring the operation status

### 8.1 Flow of status monitor mode



## 8.2 Status monitor mode

### 8.2.1 Status monitor under normal conditions

In this mode, you can monitor the operation status of the inverter.

To display the operation status during normal operation:

Press the MODE key twice.

Setting procedure (eg. operation at 60Hz)

|                  | Item displayed            | Panel operated                                                                    | LED display | Communication No. | Description                                                                                                                            |
|------------------|---------------------------|-----------------------------------------------------------------------------------|-------------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------|
|                  | Output frequency *        |                                                                                   | 60.0        |                   | The output frequency is displayed (Operation at 60Hz). (When standard monitor display selection $F710$ is set at 0 [output frequency]) |
|                  | Parameter setting mode    | MODE                                                                              | RUH         |                   | The first basic parameter "RUH" (history function) is displayed.                                                                       |
|                  | Direction of rotation     | MODE                                                                              | F - F       | FE01              | The direction of rotation is displayed.<br>(F - F: forward run, F - r: reverse run)                                                    |
| Note 1           | Frequency command value * |  | F60.0       | FE02              | The frequency command value (Hz/free unit) is displayed.<br>(In case of $F711=2$ )                                                     |
| Note 2           | Output current *          |  | 880         | FC02              | The inverter output current (load current) (%A) is displayed.<br>(In case of $F712=1$ )                                                |
| Note 2<br>Note 3 | Input voltage *           |  | Y100        | FC05              | The inverter input voltage (DC detection) (%V) is displayed.<br>(In case of $F713=3$ )                                                 |
| Note 2           | Output voltage *          |  | P100        | FC08              | The inverter output voltage (%V) is displayed.<br>(In case of $F714=4$ )                                                               |
|                  | Input power *             |  | h12.3       | FC06              | The inverter input power (kW) is displayed.<br>(In case of $F715=5$ )                                                                  |
|                  | Output power *            |  | H11.8       | FC07              | The inverter output power (kW) is displayed.<br>(In case of $F716=6$ )                                                                 |
|                  | Inverter load factor *    |  | L70         | FE27              | The inverter load factor (%) is displayed.<br>(In case of $F717=27$ )                                                                  |
|                  | Output frequency *        |  | 60.0        | FE00              | The output frequency (Hz/free unit) is displayed.<br>(In case of $F718=0$ )                                                            |

\* Monitor items can be selected by setting parameters  $F710$  to  $F718$ , ( $F720$ ). Refer to Note 12.

Refer to page H-8 and 9 for notes.

(Continued overleaf)

(Continued)

|        | Item displayed              | Panel operated | LED display | Communication No. | Description                                                                                                                                             |
|--------|-----------------------------|----------------|-------------|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| Note 4 | Input terminal              |                |             | FE06              | <p>The ON/OFF status of each of the control signal input terminals (F, R, RES, S1, S2, S3, VIB, VIA) are displayed in bits.</p> <p>ON:  <br/> OFF: </p> |
| Note 5 | Output terminal             |                |             | FE07              | <p>The ON/OFF status of each of the control signal output terminals (RY-RC, OUT, FL) are displayed in bits.</p> <p>ON:  <br/> OFF: </p>                 |
|        | CPU1 version                |                |             | FE08              | The version of the CPU1 is displayed.                                                                                                                   |
|        | CPU2 version                |                |             | FE73              | The version of the CPU2 is displayed.                                                                                                                   |
|        | Inverter rated current      |                |             | FE70              | The inverter rated current (A) is displayed.                                                                                                            |
| Note 6 | Overload and region setting |                |             | 0998<br>0099      | The inverter overload characteristic and region setting is displayed.                                                                                   |
| Note 7 | Past trip 1                 |                |             | FE10              | Past trip 1 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 2                 |                |             | FE11              | Past trip 2 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 3                 |                |             | FE12              | Past trip 3 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 4                 |                |             | FE13              | Past trip 4 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 5                 |                |             | FD10              | Past trip 5 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 6                 |                |             | FD11              | Past trip 6 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 7                 |                |             | FD12              | Past trip 7 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 8                 |                |             | FD13              | Past trip 8 (displayed alternately)                                                                                                                     |

Refer to page H-8 and 9 for notes.

(Continued overleaf)

(Continued)

| Item displayed                      | Panel operated | LED display | Communication No. | Description                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------|----------------|-------------|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Communication Status                |                | SL . .      | FD57              | The status of signal transmission and reception of communication are displayed in bits.<br><br>RX: signal receiving TX: signal transmitting<br>receiving or transmitting : .<br>not receiving or not transmitting: .                                                                                                          |
| Parts replacement alarm information |                | n . . . . . | FE79              | The ON/OFF status of each of the cooling fan, circuit board capacitor, main circuit capacitor of parts replacement alarm, cumulative operation time or number of starting are displayed in bits.<br><br>Number of starting Cooling fan<br>Cumulative operation time Control circuit board capacitor<br>Main circuit capacitor |
| Cumulative operation time           |                | t 10.1      | FE14              | The cumulative operation time is displayed. (0.10=10 hours, 1.00=100 hours)                                                                                                                                                                                                                                                   |
| Number of starting                  |                | n 34.5      | FD32              | Number of starting (10000 times)                                                                                                                                                                                                                                                                                              |
| Default display mode                |                | 60.0        |                   | The output frequency is displayed (Operation at 60Hz).                                                                                                                                                                                                                                                                        |

8.2.2 Display of detailed information on a past trip

Details on a past trip (of trips 1 to 8) can be displayed, as shown in the table below, by pressing the center of the setting dial when the trip record is selected in the status monitor mode.

Unlike the "Display of trip information at the occurrence of a trip" in 8.3.2, details on a past trip can be displayed, even after the inverter is turned off or reset.

| Item displayed   | Panel operated | LED display | Description                                                                                                                                                                           |
|------------------|----------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Past trip 1      |                | 0C 1 ⇄ 1    | Past trip 1 (displayed alternately)                                                                                                                                                   |
| Continuous trips |                | n 2         | For 0C R, 0C L and E r r S the number of times (maximum of 31) the same trip occurred in succession is displayed (unit: times). Detailed information is recorded at the latest value. |

|                  | Item displayed            | Panel operated | LED display        | Description                                                                                                                             |
|------------------|---------------------------|----------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
|                  | Output frequency          |                | 050.0              | The output frequency when the trip occurred is displayed.                                                                               |
|                  | Direction of rotation     |                | F <sub>r</sub> - F | The direction of rotation when the trip occurred is displayed.<br>(F <sub>r</sub> - F: Forward run, F <sub>r</sub> - r: Reverse run)    |
| Note 1           | Frequency command value * |                | F80.0              | The frequency command value when the trip occurred is displayed.                                                                        |
| Note 2           | Output current            |                | C150               | The inverter output current when the trip occurred is displayed. (%/A)                                                                  |
| Note 2<br>Note 3 | Input voltage             |                | Y120               | The inverter input voltage (DC detection) when the trip occurred is displayed. (%/V).                                                   |
| Note 2           | Output voltage            |                | P100               | The inverter output voltage when the trip occurred is displayed. (%/V)                                                                  |
| Note 4           | Input terminal            |                | .....              | The ON/OFF status of each of the control signal input terminals (F, R, RES, S1, S2, S3, VIB, VIA) are displayed in bits.<br>ON:<br>OFF: |
|                  |                           |                |                    |                                                                                                                                         |
| Note 5           | Output terminal           |                | 0...11             | The ON/OFF status of each of the control signal output terminals (RY-RC, OUT, FL) are displayed in bits.<br>ON:<br>OFF:                 |
|                  |                           |                |                    |                                                                                                                                         |
| Note 9           | Cumulative operation time |                | t8.56              | The cumulative operation time when the trip occurred is displayed.<br>(0.10=10 hours, 1.00=100 hours)                                   |
|                  | Past trip 1               |                | 0C1 ⇄ 1            | Press this key to return to past trip 1.                                                                                                |

\*The monitor value of a trip is not always recorded as the maximum value because of the time required for detection.

Refer to page H-8 and 9 for notes.

## 8.3 Display of trip information

### 8.3.1 Trip code display

If the inverter trips, an error code is displayed to suggest the cause. Since trip records are retained, information on each trip can be displayed anytime in the status monitor mode.

Refer to section 13.1 for details about trip code display.

- The monitor value of a trip is not always recorded as the maximum value because of the time required for detection.

### 8.3.2 Display of trip information at the occurrence of a trip

At the occurrence of a trip, the same information as that displayed in the mode described in "8.2.1 Status monitor under normal conditions", can be displayed, as shown in the table below, if the inverter is not turned off or reset. To display trip information after turning off or resetting the inverter, follow the steps described in "8.2.2 Display of detailed information on a past trip".

#### ■ Example of call-up of trip information

|                  | Item displayed            | Panel operated | LED display    | Communication No. | Description                                                                                                                        |
|------------------|---------------------------|----------------|----------------|-------------------|------------------------------------------------------------------------------------------------------------------------------------|
|                  | Cause of trip             |                | <i>OP2</i>     |                   | Status monitor mode (The code blinks if a trip occurs.)<br>The motor coasts and comes to a stop (coast stop).                      |
|                  | Parameter setting mode    |                | <i>RUH</i>     |                   | The first basic parameter " <i>RUH</i> " (history function) is displayed.                                                          |
|                  | Direction of rotation     |                | <i>F r - F</i> | FE01              | The direction of rotation at the occurrence of a trip is displayed. ( <i>F r - F</i> : forward run, <i>F r - r</i> : reverse run). |
| Note 1           | Frequency command value * |                | <i>F 50.0</i>  | FE02              | The frequency command value (Hz/free unit) at the occurrence of a trip is displayed.<br>(In case of <i>F 7 1 1=2</i> )             |
| Note 2           | Output current *          |                | <i>I 130</i>   | FC02              | The output power of the inverter at the occurrence of a trip (%A) is displayed.<br>(In case of <i>F 7 1 2=1</i> )                  |
| Note 2<br>Note 3 | Input voltage *           |                | <i>V 141</i>   | FC05              | The inverter input voltage (DC detection) (%V) at the occurrence of a trip is displayed.<br>(In case of <i>F 7 1 3=3</i> )         |
| Note 2           | Output voltage *          |                | <i>P 100</i>   | FC08              | The output voltage of the inverter at the occurrence of a trip (%V) is displayed.<br>(In case of <i>F 7 1 4=4</i> )                |
|                  | Input power *             |                | <i>P 12.3</i>  | FC06              | The inverter input power (kW) is displayed.<br>(In case of <i>F 7 1 5=5</i> )                                                      |
|                  | Output power *            |                | <i>H 11.8</i>  | FC07              | The inverter output power (kW) is displayed.<br>(In case of <i>F 7 1 6=6</i> )                                                     |
|                  | Inverter load factor *    |                | <i>L 70</i>    | FE27              | The inverter load factor (%) at the occurrence of a trip is displayed.<br>(In case of <i>F 7 1 7=27</i> )                          |
|                  | Output frequency *        |                | <i>o 50.0</i>  | FE00              | The inverter output frequency (Hz/free unit) at the occurrence of a trip is displayed.<br>(In case of <i>F 7 1 8=0</i> )           |

\* Monitor items can be selected by settings parameters *F 7 10* to *F 7 18* (*F 7 20*). Note 12

Refer to page H-8 and 9 for notes.

(Continued overleaf)

(Continued)

|        | Item displayed              | Panel operated | LED display | Communication No. | Description                                                                                                                                             |
|--------|-----------------------------|----------------|-------------|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| Note 4 | Input terminal              |                | .....       | FE06              | <p>The ON/OFF status of each of the control signal input terminals (F, R, RES, S1, S2, S3, VIB, VIA) are displayed in bits.</p> <p>ON: 1<br/>OFF: 0</p> |
| Note 5 | Output terminal             |                | 0 . . .     | FE07              | <p>The ON/OFF status of each of the control signal output terminals (RY-RC, OUT, FL) are displayed in bits.</p> <p>ON: 1<br/>OFF: 0</p>                 |
|        | CPU1 version                |                | u 10 1      | FE08              | The version of the CPU1 is displayed.                                                                                                                   |
|        | CPU2 version                |                | u c 0 1     | FE73              | The version of the CPU2 is displayed.                                                                                                                   |
|        | Inverter rated current      |                | A 33.0      | FE70              | The inverter rated current (A) is displayed.                                                                                                            |
| Note 6 | Overload and region setting |                | E - EU      | 0998<br>0099      | The inverter overload characteristic and region setting is displayed.                                                                                   |
| Note 7 | Past trip 1                 |                | GP 2 ⇄ 1    | FE10              | Past trip 1 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 2                 |                | GH ⇄ 2      | FE11              | Past trip 2 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 3                 |                | GP 3 ⇄ 3    | FE12              | Past trip 3 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 4                 |                | GL 1 ⇄ 4    | FE13              | Past trip 4 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 5                 |                | GL r ⇄ 5    | FD10              | Past trip 5 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 6                 |                | GL 1 ⇄ 6    | FD11              | Past trip 6 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 7                 |                | GL 2 ⇄ 7    | FD12              | Past trip 7 (displayed alternately)                                                                                                                     |
| Note 7 | Past trip 8                 |                | n Err ⇄ 8   | FD13              | Past trip 8 (displayed alternately)                                                                                                                     |

Refer to page H-8 and 9 for notes.

(Continued overleaf)

(Continued)

| Item displayed                                | Panel operated | LED display | Communication No. | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------------------------|----------------|-------------|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Communication Status                          |                | 5 L . . .   | FD57              | The status of signal transmission and reception of communication are displayed in bits.<br><br><div style="text-align: center;"> </div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> <span>RX: signal receiving</span> <span>TX: signal transmitting</span> </div> <div style="margin-top: 5px;"> receiving or transmitting : 1<br/> not receiving or not transmitting: 0 </div>                                                                                                                      |
| Note 8<br>Parts replacement alarm information |                | n . . . . . | FE79              | The ON/OFF status of each of the cooling fan, circuit board capacitor, main circuit capacitor of parts replacement alarm, cumulative operation time or number of starting are displayed in bits.<br><br><div style="display: flex; justify-content: space-between;"> <div> ON: 1<br/> OFF: 0 </div> <div style="text-align: center;"> </div> <div> Cooling fan<br/> Control circuit board capacitor </div> </div> <div style="margin-top: 5px;"> Number of starting<br/> Cumulative operation time<br/> Main circuit capacitor </div> |
| Note 9<br>Cumulative operation time           |                | t 10.1      | FE14              | The cumulative operation time is displayed.<br>(0.10=10 hours, 1.00=100 hours)                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Number of starting                            |                | n 34.5      | FD32              | Number of starting (10000 times)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Default display mode                          |                | MODE 002    |                   | The cause of the trip is displayed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

Note 1: The characters to the left disappear at 100 Hz or more. (Ex: 120 Hz is 120.0)

Note 2: You can switch between % and A (ampere)/V (volt), using the parameter F 70 1 (current/voltage unit selection).

Note 3: The input (DC) voltage displayed is  $1/\sqrt{2}$  times as large as the rectified d.c. input voltage.

Note 4: &lt; VIA bar &gt; F 100 = 3, 4 (Contact input): activated ON/OFF depend on VIA terminal input.

F 100 = 0 (Analog input): always OFF.

&lt; VIB bar &gt; F 100 = 1 to 4 (Contact input): activated ON/OFF depend on VIB terminal input.

F 100 = 0 (Analog input): always OFF.

&lt; S2 bar &gt; F 146 = 0 (Contact input): activated ON/OFF depend on S2 terminal input.

F 146 = 1 (Pulse train input): always OFF.

&lt; S3 bar &gt; F 147 = 0 (Contact input): activated ON/OFF depend on S3 terminal input.

F 147 = 1 (PTC input): always OFF.

Note 5: &lt; OUT bar &gt; F 669 = 0 (Logic output): activated ON/OFF depend on OUT terminal output.

F 669 = 1 (Pulse train output): always OFF.

Note 6: Overload characteristic of inverter and region setting are displayed on the monitor as follows;

$\bar{C}$ -xx :  $\overline{RUL} = 1$  (Constant torque characteristic) is selected.

$\bar{U}$ -xx :  $\overline{RUL} = 2$  (Variable torque characteristic) is selected.

x- $\bar{E}\bar{U}$  : Setup menu is selected to  $\bar{E}\bar{U}$ .

x- $\bar{RS}$  : Setup menu is selected to  $\bar{RS}$   $\bar{IR}$ .

x- $\bar{US}$  : Setup menu is selected to  $\bar{US}$   $\bar{R}$ .

x- $\bar{UP}$  : Setup menu is selected to  $\bar{UP}$ .

Note 7: Past trip records are displayed in the following sequence: 1 (latest trip record)  $\leftrightarrow 2 \leftrightarrow 3 \leftrightarrow 4 \leftrightarrow 5 \leftrightarrow 6 \leftrightarrow 7 \leftrightarrow 8$  (oldest trip record). If no trip occurred in the past, the message " $\bar{n}\bar{E}\bar{r}\bar{r}$ " will be displayed. Details on past trip record 1 to 8 can be displayed by pressing the center of the setting dial when past trip 1 to 8 is displayed. Refer to section 8.2.2 for details.

Note 8: Parts replacement alarm is displayed based on the value calculated from the annual average ambient temperature specified using  $\bar{F}\bar{E}\bar{3}\bar{4}$ , the ON time of the inverter, the operating time of the motor and the output current (load factor). Use this alarm as a guide only, since it is based on a rough estimation.

Note 9: The cumulative operation time increments only when the machine is in operation.

Note 10: If there is no trip record,  $\bar{n}\bar{E}\bar{r}\bar{r}$  is displayed.

Note 11: Of the items displayed on the monitor, the reference values of items expressed in percent are listed below.

- Output current: The current monitored is displayed in percentage. The value indicated on the nameplate is 100%. The unit can be switched to A (amperes).
- Input voltage: The voltage displayed is the voltage determined by converting the voltage measured in the DC section into an AC voltage. The reference value (100% value) is 200V (240V class), 400V (500V class). The unit can be switched to V (volts).
- Output voltage: The voltage displayed is the output command voltage. The reference value (100% value) is 200V (240V class), 400V (500V class). This unit can be switched to V (volts).
- Load factor of inverter: Depending on the PWM carrier frequency ( $\bar{F}\bar{3}\bar{0}\bar{0}$ ) setting and so on, the actual rated current may become smaller than the rated output current indicated on the nameplate. With the actual rated current at that time (after a reduction) as 100%, the proportion of the load current to the rated current is indicated in percent. The load factor is also used to calculate the conditions for overload trip ( $\bar{OL}\bar{I}$ ).

Note 12: Status monitor of \* mark is displayed by  $\bar{F}\bar{7}\bar{1}\bar{0}$  to  $\bar{F}\bar{7}\bar{1}\bar{8}$  and  $\bar{F}\bar{7}\bar{2}\bar{0}$  setting. The left side character is as following table by each parameter setting number.

| Parameter                         | Setting No. | LED display | Function                                                                     | Unit                 | Communication No. |
|-----------------------------------|-------------|-------------|------------------------------------------------------------------------------|----------------------|-------------------|
| F 7 1 0<br>to F 7 1 8,<br>F 7 2 0 | 0           | o 8 0.0     | Output frequency                                                             | Hz / free unit       | FE00              |
|                                   | 1           | l 15.5      | Output current *1                                                            | % / A                | FC02              |
|                                   | 2           | F 5 0.0     | Frequency command value                                                      | Hz / free unit       | FE02              |
|                                   | 3           | y 1 0.0     | Input voltage (DC detection) *1                                              | % / V                | FC05              |
|                                   | 4           | P 9 0       | Output voltage (command value) *1                                            | % / V                | FC08              |
|                                   | 5           | h 3.0       | Input power *1                                                               | kW                   | FC06              |
|                                   | 6           | H 2.8       | Output power *1                                                              | kW                   | FC07              |
|                                   | 7           | q 8 0       | Torque *1, *2                                                                | %                    | FC04              |
|                                   | 9           | G 6 0       | Motor cumulative load factor                                                 | %                    | FE23              |
|                                   | 10          | L 8 0       | Inverter cumulative load factor                                              | %                    | FE24              |
|                                   | 11          | r 8 0       | PBR (Braking resistor) cumulative load factor                                | %                    | FE25              |
|                                   | 12          | b 5 1.0     | Stator frequency                                                             | Hz / free unit       | FE15              |
|                                   | 13          | R 6 5       | VIA input value                                                              | %                    | FE35              |
|                                   | 14          | b 4 5       | VIB input value *2                                                           | %                    | FE36              |
|                                   | 18          | *3          | Arbitrary code from communication                                            | *3                   | *3                |
|                                   | 20          | f 3 5       | VIC input value                                                              | %                    | FE37              |
|                                   | 21          | P 8 0 0     | Pulse train input value                                                      | pps                  | FE56              |
|                                   | 23          | d 4 0.0     | PID feedback value                                                           | Hz / free unit       | FE22              |
|                                   | 24          | h 3 5 6     | Integral input power                                                         | Depend on<br>F 7 4 9 | FE76              |
|                                   | 25          | H 3 4 8     | Integral output power                                                        | Depend on<br>F 7 4 9 | FE77              |
|                                   | 26          | G 7 5       | Motor load factor                                                            | %                    | FE26              |
|                                   | 27          | L 7 0       | Inverter load factor                                                         | %                    | FE27              |
|                                   | 28          | R 3 3.0     | Inverter rated current                                                       | A                    | FE70              |
|                                   | 29          | F 7 0       | FM output value                                                              | %                    | FE40              |
|                                   | 30          | P 8 0 0     | Pulse train output value                                                     | pps                  | FD40              |
|                                   | 31          | P 3 4.5     | Cumulative power on time                                                     | 100 hours            | FE80              |
|                                   | 32          | F 2 8.6     | Cumulative fan operation time                                                | 100 hours            | FD41              |
|                                   | 33          | t 2 7.7     | Cumulative operation time                                                    | 100 hours            | FD14              |
|                                   | 34          | n 8 9.0     | Number of starting times                                                     | 10000 times          | FD32              |
|                                   | 35          | F 4 5.5     | Forward number of starting times                                             | 10000 times          | FD33              |
|                                   | 36          | r 4 3.5     | Reverse number of starting times                                             | 10000 times          | FD34              |
|                                   | 37          | R 2         | Number of trip                                                               | times                | FD35              |
|                                   | 40          | R 3 3.0     | Inverter rated current (Carrier frequency corrected)                         | A                    | FD70              |
|                                   | 52          | c 5 0.0     | During stop : Frequency command value<br>During operation : Output frequency | Hz / free unit       | FE99              |

\*1: These monitor values can be filtered by *F 745* setting.

\*2: If a negative value of signed signal is specified, the negative sign "-" is displayed. When the negative sign "-" is displayed, do not display "q", "b".

\*3: Data set with FA65-FA79 is displayed.

⇒ For details, refer to Communication Function Instruction Manual(E6581913).

## 9. Measures to satisfy the standards

### 9.1 How to cope with the CE Marking Directive

In Europe, the EMC Directive and the Low Voltage Directive, which took effect in 1996 and 1997, respectively, made it obligatory to put the CE mark on every applicable product to prove that it complies with the directives. Inverters do not work alone but are designed to be installed in a control panel and always used in combination with other machines or systems for the purpose of controlling them. So they themselves were not considered to be subject to the EMC Directive. However the component also became subject to law with the enforcement of the new EMC Directive in 2007. For this reason, we put CE mark on all inverters in accordance with the EMC Directive and the Low Voltage Directive.

The CE mark must be put on all machines and systems with built-in inverters because such machines and systems are subject to the above directives. If they are "final" products, they might also be subject to the Machinery Directive. It is the responsibility of the manufacturers of such final products to put the CE mark on each final product. In order to make machines and systems with built-in inverters comply with the EMC Directive and the Low Voltage Directive, this section explains how to install inverters and what measures should be taken to satisfy the EMC Directive.

We have tested representative models with them installed under the environment described later in this manual to check for conformity with the EMC Directive. However, we cannot check the inverters under your operating environment. EMC varies depending on the composition of the control panel with a built-in inverter(s), the relationship with other built-in electrical components, the wiring condition, the layout condition, and so on. Therefore, please verify yourself whether your machine or system conforms to the EMC Directive.

#### 9.1.1 About the EMC Directive

The CE mark must be put on every final product that includes an inverter(s) and a motor(s). In this series of inverters are equipped with an EMC filter and complies with the EMC Directive if wiring is carried out correctly.

■ EMC Directive  
2004/108/EC

The EMC standards are broadly divided into two categories; Emission and Immunity, each of which is further categorized according to the operating environment of each individual machine. Since inverters are intended for use with industrial systems under industrial environments, they fall within the EMC categories listed in Table 1 below. We consider that the tests required for machines and systems as final products are almost the same as those required for inverters.

Table 1 EMC standards

| Category | Subcategory                                          | Product standards | Test standard    |
|----------|------------------------------------------------------|-------------------|------------------|
| Emission | Radiated noise                                       | IEC 61800-3       | CISPR11(EN55011) |
|          | Conducted noise                                      |                   | CISPR11(EN55011) |
| Immunity | Static discharge                                     |                   | IEC61000-4-2     |
|          | Radioactive radio-frequency magnetic contactor field |                   | IEC61000-4-3     |
|          | First transient burst                                |                   | IEC61000-4-4     |
|          | Surge                                                |                   | IEC61000-4-5     |
|          | Radio-frequency induction/transmission interference  |                   | IEC61000-4-6     |
|          | Voltage dip/Interruption of power                    |                   | IEC61000-4-11    |

**9.1.2 Measures to satisfy the EMC Directive**

This subsection explains what measures must be taken to satisfy the EMC Directive.

(1) Insert an EMC filter on the input side of the inverter to reduce conducted noise and radiated noise from input cables.

Single-phase 240V class and three-phase 500V class inverters are equipped with an EMC filter.

Table 2 Combinations of inverter and EMC filter

Three-phase 240 V class

| Inverter type  | Combination of inverter and filter                                                |                                                                                   |
|----------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
|                | Conducted noise<br>IEC61800-3, category C1<br>(Motor wiring length of 1m or less) | Conducted noise<br>IEC61800-3, category C2<br>(Motor wiring length of 5m or less) |
| VFS15-2004PM-W | EMFS11-2007AZ                                                                     |                                                                                   |
| VFS15-2007PM-W | EMFS11-2007AZ                                                                     |                                                                                   |
| VFS15-2015PM-W | EMFS11-4015BZ                                                                     |                                                                                   |
| VFS15-2022PM-W | EMFS11-4015BZ                                                                     |                                                                                   |
| VFS15-2037PM-W | EMFS11-4025CZ                                                                     |                                                                                   |
| VFS15-2055PM-W | EMFS11-4047DZ                                                                     |                                                                                   |
| VFS15-2075PM-W | EMFS11-4047DZ                                                                     |                                                                                   |
| VFS15-2110PM-W | EMFS11-2083EZ                                                                     |                                                                                   |
| VFS15-2150PM-W | EMFS11-2083EZ                                                                     |                                                                                   |

## Single-phase 240 V class


| Combination of inverter and filter |                                                                                      |                                                                                       |                                                                                       |
|------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Inverter type                      | Conducted noise<br>IEC61800-3, category C2<br>(Motor wiring length of<br>5m or less) | Conducted noise<br>IEC61800-3, category C1<br>(Motor wiring length of<br>20m or less) | Conducted noise<br>IEC61800-3, category C2<br>(Motor wiring length of<br>50m or less) |
| VFS15S-2002PL-W                    | Built-in filter                                                                      | EMFS11S-2009AZ                                                                        |                                                                                       |
| VFS15S-2004PL-W                    |                                                                                      | EMFS11S-2009AZ                                                                        |                                                                                       |
| VFS15S-2007PL-W                    |                                                                                      | EMFS11S-2009AZ                                                                        |                                                                                       |
| VFS15S-2015PL-W                    |                                                                                      | EMFS11S-2016BZ                                                                        |                                                                                       |
| VFS15S-2022PL-W                    |                                                                                      | EMFS11S-2022CZ                                                                        |                                                                                       |

## Three-phase 500 V class

| Combination of inverter and filter |                                                                                        |                                                                                          |                                                                                          |                                                                                          |
|------------------------------------|----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Inverter type                      | Conducted noise<br>IEC61800-3,<br>category C2<br>Motor wiring length of<br>5m or less) | Conducted noise<br>IEC61800-3,<br>category C3<br>(Motor wiring length<br>of 25m or less) | Conducted noise<br>IEC61800-3,<br>category C1<br>(Motor wiring length<br>of 20m or less) | Conducted noise<br>IEC61800-3,<br>category C2<br>(Motor wiring length<br>of 50m or less) |
| VFS15-4004PL-W                     | Built-in filter                                                                        | Built-in filter                                                                          | EMFS11-4015BZ                                                                            |                                                                                          |
| VFS15-4007PL-W                     |                                                                                        |                                                                                          | EMFS11-4015BZ                                                                            |                                                                                          |
| VFS15-4015PL-W                     |                                                                                        |                                                                                          | EMFS11-4015BZ                                                                            |                                                                                          |
| VFS15-4022PL-W                     |                                                                                        |                                                                                          | EMFS11-4025CZ                                                                            |                                                                                          |
| VFS15-4037PL-W                     |                                                                                        |                                                                                          | EMFS11-4025CZ                                                                            |                                                                                          |
| VFS15-4055PL-W                     |                                                                                        |                                                                                          | EMFS11-4047DZ                                                                            |                                                                                          |
| VFS15-4075PL-W                     |                                                                                        |                                                                                          | EMFS11-4047DZ                                                                            |                                                                                          |
| VFS15-4110PL-W                     | -                                                                                      | Built-in filter                                                                          | EMFS11-4049EZ                                                                            |                                                                                          |
| VFS15-4150PL-W                     |                                                                                        |                                                                                          | EMFS11-4049EZ                                                                            |                                                                                          |

- (2) Use shielded power cables, such as inverter output cables, and shielded control cables. Route the cables and wires so as to minimize their lengths. Keep a distance between the power cable and the control cable and between the input and output wires of the power cable. Do not route them in parallel or bind them together. Instead, if necessary, cross at right angle.
- (3) It is more effective in limiting the radiated noise to install the inverter in a sealed steel cabinet. Using wires as thick and short as possible, earth the metal plate and the control panel securely with a distance kept between the earth cable and the power cable.
- (4) Route the input and output wires apart as far as possible from each other.
- (5) To suppress radiated noise from cables, ground all shielded cables through a noise cut plate.  
It is effective to earth shielded cables in the vicinity of the inverter and cabinet (within a radius of 10cm from each of them). Inserting a ferrite core in a shielded cable is even more effective in limiting the radiated noise.
- (6) To further limit the radiated noise, insert a zero-phase reactor in the inverter output line and insert ferrite cores in the earth cables of the metal plate and cabinet.

[Example of wiring]



## 9.1.3 About the Low Voltage Directive

The Low Voltage Directive provides for the safety of machines and systems. All Toshiba inverters are CE-marked in accordance with the standard EN 50178 specified by the Low Voltage Directive, and can therefore be installed in machines or systems and imported without problem to European countries.

Applicable standard: IEC61800-5-1

Pollution level: 2

Overvoltage category: 3

## 9.1.4 Measures to satisfy the Low Voltage Directive

When incorporating the inverter into a machine or system, it is necessary to take the following measures so that the inverter satisfies the Low Voltage Directive.

- (1) Install the inverter in a cabinet and ground the inverter enclosure. When doing maintenance, be extremely careful not to put your fingers into the inverter through a wiring hole and touch a charged part, which may occur depending on the model and capacity of the inverter used.
- (2) Connect earth wiring to the earth terminal on the EMC plate. Or install the EMC plate (attached as standard) and another cable connect to earth terminal on the EMC plate. Refer to the table in 10.1 for details about earth cable sizes. A minimum wire size of 10mm<sup>2</sup> may be required to meet standards limiting leakage current.
- (3) Install a non-fuse circuit breaker or a fuse on the input side of the inverter. (Refer to section 10.1 and 9.2.3)

## 9.2 Compliance with UL Standard and CSA Standard

9

This inverter that conform to the UL Standard and CSA Standard based on the rated current of the nameplate have the UL/CSA mark on the nameplate.

### 9.2.1 Compliance with Installation

A UL certificate was granted on the assumption that the inverter would be installed in a cabinet. Therefore, install the inverter in a cabinet and if necessary, take measures to maintain the ambient temperature (temperature in the cabinet) within the specified temperature range. (Refer to section 1.4.4)

Note ) 0.75 kW or less in 240V class of VF-S15, maintain the ambient temperature of 40°C or less for the compliance with UL standard.

### 9.2.2 Compliance with Connection

Use the UL conformed cables (Rating 75 °C or more, Use the copper conductors only,) to the main circuit terminals (R/L1, S/L2, S/L2/N, T/L3, U/T1, V/T2, W/T3).

For instruction in the United States, Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.

For instruction in the Canada, Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Canadian Electrical Code and any additional local codes.

## 9.2.3 Compliance with Peripheral devices

Use the UL listed fuses at connecting to power supply.

Short circuit test is performed under the condition of the power supply short-circuit currents in below.

These interrupting capacities and fuse rating currents depend on the applicable motor capacities.

### ■ AIC, Fuse and Wire sizes

| Inverter model  | Voltage (V) | Input withstand rating (kA) | Output interrupt rating (kA) | Branch circuit protection | Rating (A) | Cable sizes of power circuit | Earth Cable |
|-----------------|-------------|-----------------------------|------------------------------|---------------------------|------------|------------------------------|-------------|
| Markig          | Y           | (1)                         | X (2)                        | Z1                        | Z2         | -                            | -           |
| VFS15-2004PM-W  | 240         | 5                           | 5                            | Class CC                  | 7          | AWG 14                       | AWG 14      |
| VFS15-2007PM-W  | 240         | 5                           | 5                            | Class J                   | 15         | AWG 14                       | AWG 14      |
| VFS15-2015PM-W  | 240         | 5                           | 5                            | Class J                   | 25         | AWG 14                       | AWG 14      |
| VFS15-2022PM-W  | 240         | 5                           | 5                            | Class J                   | 25         | AWG 12                       | AWG 14      |
| VFS15-2037PM-W  | 240         | 5                           | 5                            | Class J                   | 45         | AWG 10                       | AWG 10      |
| VFS15-2055PM-W  | 240         | 22                          | 5                            | Class J                   | 60         | AWG 8                        | AWG 10      |
| VFS15-2075PM-W  | 240         | 22                          | 5                            | Class J                   | 70         | AWG 6                        | AWG 10      |
| VFS15-2110PM-W  | 240         | 22                          | 5                            | Class J                   | 100        | AWG 6*2                      | AWG 8       |
| VFS15-2150PM-W  | 240         | 22                          | 5                            | Class J                   | 110        | AWG 6*2                      | AWG 8       |
| VFS15S-2002PL-W | 240         | 1                           | 5                            | Class CC                  | 7          | AWG 14                       | AWG 14      |
| VFS15S-2004PL-W | 240         | 1                           | 5                            | Class J                   | 15         | AWG 14                       | AWG 14      |
| VFS15S-2007PL-W | 240         | 1                           | 5                            | Class J                   | 25         | AWG 14                       | AWG 14      |
| VFS15S-2015PL-W | 240         | 1                           | 5                            | Class J                   | 40         | AWG 10                       | AWG 12      |
| VFS15S-2022PL-W | 240         | 1                           | 5                            | Class J                   | 45         | AWG 10                       | AWG 10      |
| VFS15-4004PL-W  | 500         | 5                           | 5                            | Class CC                  | 6          | AWG 14                       | AWG 14      |
| VFS15-4007PL-W  | 500         | 5                           | 5                            | Class CC                  | 6          | AWG 14                       | AWG 14      |
| VFS15-4015PL-W  | 500         | 5                           | 5                            | Class CC                  | 12         | AWG 14                       | AWG 14      |
| VFS15-4022PL-W  | 500         | 5                           | 5                            | Class J                   | 15         | AWG 14                       | AWG 14      |
| VFS15-4037PL-W  | 500         | 5                           | 5                            | Class J                   | 25         | AWG 12                       | AWG 14      |
| VFS15-4055PL-W  | 500         | 22                          | 5                            | Class J                   | 40         | AWG 10                       | AWG 10      |
| VFS15-4075PL-W  | 500         | 22                          | 5                            | Class J                   | 40         | AWG 8                        | AWG 10      |
| VFS15-4110PL-W  | 500         | 22                          | 5                            | Class J                   | 60         | AWG 8                        | AWG 10      |
| VFS15-4150PL-W  | 500         | 22                          | 5                            | Class J                   | 70         | AWG 6                        | AWG 10      |

Suitable for use on a circuit capable of delivering not more than   X   rms symmetrical kilo Amperes,   Y   Volts maximum, when protected by   Z1   with a maximum rating of   Z2  .

- (1) Input withstand rating is that for which the product has been designed thermally. Installation on a supply greater than this level will require additional inductance to satisfy this level.
- (2) Output interrupt rating relies on Integral solid state short circuit protection. This does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes. This is dependant on the type of installation.

In case of using VF-S15 with a higher AIC capability up to 100kA(\*1), install the minimum input inductance or more listed in the following table. The Short Circuit Current Ratings (SCCR) become 100kA(\*1) by installing VF-S15 with the circuit breakers(GV3P) or the fuses listed in the following table.

## ■ AIC 100kA, Branch circuit protection and Wire sizes

| Inverter model  | Minimum input Inductance (mH) | Branch circuit protection    |                 |                                   |                     | Cable sizes of power circuit | Earth Cable |
|-----------------|-------------------------------|------------------------------|-----------------|-----------------------------------|---------------------|------------------------------|-------------|
|                 |                               | With Fuses (Bussman /Ferraz) | Fuse Rating (A) | With circuit breakers (Schneider) | Breaker Setting (A) |                              |             |
| VFS15-2004PM-W  | 0.05                          | Class J                      | 10              | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15-2007PM-W  | 0.05                          | Class J                      | 15              | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15-2015PM-W  | 0.05                          | Class J                      | 25              | GV3P13                            | 10                  | AWG 14                       | AWG 14      |
| VFS15-2022PM-W  | 0.05                          | Class J                      | 25              | GV3P18                            | 18                  | AWG 12                       | AWG 14      |
| VFS15-2037PM-W  | 0.05                          | Class J                      | 45              | GV3P25                            | 25                  | AWG 10                       | AWG 10      |
| VFS15-2055PM-W  | 0.02                          | Class J                      | 60              | GV3P40                            | 40                  | AWG 8                        | AWG 10      |
| VFS15-2075PM-W  | 0.02                          | Class J                      | 70              | GV3P50                            | 50                  | AWG 6                        | AWG 10      |
| VFS15-2110PM-W  | 0.02                          | Class J                      | 100             | GV3P65                            | 65                  | AWG 6*2                      | AWG 8       |
| VFS15-2150PM-W  | 0.02                          | Class J                      | 110             |                                   |                     | AWG 6*2                      | AWG 8       |
| VFS15S-2002PL-W | 0.28                          | Class J                      | 10              | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15S-2004PL-W | 0.28                          | Class J                      | 15              | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15S-2007PL-W | 0.28                          | Class J                      | 25              | GV3P13                            | 13                  | AWG 14                       | AWG 14      |
| VFS15S-2015PL-W | 0.28                          | Class J                      | 40              | GV3P25                            | 25                  | AWG 10                       | AWG 12      |
| VFS15S-2022PL-W | 0.28                          | Class J                      | 45              | GV3P32                            | 32                  | AWG 10                       | AWG 10      |
| VFS15-4004PL-W  | 0.10                          | Class J                      | 6               | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15-4007PL-W  | 0.10                          | Class J                      | 6               | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15-4015PL-W  | 0.10                          | Class J                      | 15              | GV3P13                            | 9                   | AWG 14                       | AWG 14      |
| VFS15-4022PL-W  | 0.10                          | Class J                      | 15              | GV3P13                            | 10                  | AWG 14                       | AWG 14      |
| VFS15-4037PL-W  | 0.10                          | Class J                      | 25              | GV3P13                            | 13                  | AWG 12                       | AWG 14      |
| VFS15-4055PL-W  | 0.03                          | Class J                      | 40              | GV3P18                            | 18                  | AWG 10                       | AWG 10      |
| VFS15-4075PL-W  | 0.03                          | Class J                      | 40              | GV3P25                            | 25                  | AWG 8                        | AWG 10      |
| VFS15-4110PL-W  | 0.03                          | Class J                      | 60              | GV3P32                            | 32                  | AWG 8                        | AWG 10      |
| VFS15-4150PL-W  | 0.03                          | Class J                      | 70              | GV3P40 (*1)                       | 40                  | AWG 6                        | AWG 10      |

(\*1) In case VFS15-4150PL-W with the circuit breaker, the Short Circuit Current Ratings (SCCR) is 65kA, not 100kA.

### 9.2.4 Motor thermal protection

Select the electronic thermal protection characteristics that fit with the ratings and characteristics of the motor.

(Refer to section 5.6)

In case of multi motor operation with one inverter, thermal relay should be connected to each motor.

## 10. Peripheral devices

|  <b>Warning</b>      |                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>When using switchgear for the inverter, it must be installed in a cabinet. Failure to do so can lead to risk of electric shock.</li> </ul> |
| <br>Be Grounded      | <ul style="list-style-type: none"> <li>Ground must be connected securely. If the ground is not securely connected, it could lead to electric shock or fire.</li> </ul>            |

### 10.1 Selection of wiring materials and devices

#### ■ Selection of wire size

| Voltage class      | Applicable motor (kW) | Wire size (mm²) Note 4)       |              |               |              |               |              |                       |     |
|--------------------|-----------------------|-------------------------------|--------------|---------------|--------------|---------------|--------------|-----------------------|-----|
|                    |                       | Power circuit Note 1) Note 5) |              |               |              |               |              | DC Reactor (Optional) |     |
|                    |                       | Input                         |              |               |              | Output        |              |                       |     |
|                    |                       | without DCL                   |              | with DCL      |              | IEC Compliant | For Japan *1 |                       |     |
| IEC Compliant      | For Japan *1          | IEC Compliant                 | For Japan *1 | IEC Compliant | For Japan *1 |               |              |                       |     |
| 3 phase 240V class | 0.4                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 0.75                  | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 1.5                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 2.2                   | 2.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 4.0                   | 4.0                           | 2.0          | 2.5           | 2.0          | 2.5           | 2.0          | 4.0                   | 2.0 |
|                    | 5.5                   | 10                            | 5.5          | 4.0           | 2.0          | 6.0           | 3.5          | 6.0                   | 3.5 |
|                    | 7.5                   | 16                            | 8.0          | 6.0           | 3.5          | 10            | 3.5          | 10                    | 5.5 |
|                    | 11                    | 25                            | 14           | 10            | 5.5          | 16            | 8.0          | 16                    | 8.0 |
|                    | 15                    | 35                            | 22           | 16            | 14           | 25            | 14           | 25                    | 14  |
|                    | 18.5                  | 50                            | 22           | 25            | 14           | 35            | 14           | 35                    | 22  |
| 1 phase 240V class | 0.2                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 0.4                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 0.75                  | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 1.5                   | 2.5                           | 2.0          | 2.5           | 2.0          | 1.5           | 2.0          | 2.5                   | 2.0 |
|                    | 2.2                   | 4.0                           | 2.0          | 4.0           | 2.0          | 1.5           | 2.0          | 4.0                   | 2.0 |
|                    | 3.0                   | 4.0                           | 2.0          | 4.0           | 2.0          | 1.5           | 2.0          | 4.0                   | 2.0 |
| 3 phase 500V class | 0.4                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 0.75                  | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 1.5                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 2.2                   | 1.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 4.0                   | 2.5                           | 2.0          | 1.5           | 2.0          | 1.5           | 2.0          | 1.5                   | 2.0 |
|                    | 5.5                   | 4.0                           | 2.0          | 1.5           | 2.0          | 2.5           | 2.0          | 2.5                   | 2.0 |
|                    | 7.5                   | 6.0                           | 3.5          | 2.5           | 2.0          | 2.5           | 2.0          | 4.0                   | 2.0 |
|                    | 11                    | 10                            | 5.5          | 4.0           | 2.0          | 6.0           | 3.5          | 6.0                   | 3.5 |
|                    | 15                    | 16                            | 8.0          | 6.0           | 3.5          | 10            | 3.5          | 10                    | 5.5 |
|                    | 18.5                  | 16                            | 8.0          | 10            | 5.5          | 10            | 5.5          | 16                    | 8.0 |

| Voltage class      | Applicable motor (kW) | Wire size (mm <sup>2</sup> ) Note 4) |              |                 |              |
|--------------------|-----------------------|--------------------------------------|--------------|-----------------|--------------|
|                    |                       | Braking resistor (optional)          |              | Grounding cable |              |
|                    |                       | IEC Compliant                        | For Japan *1 | IEC Compliant   | For Japan *1 |
| 3 phase 240V class | 0.4                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 0.75                  | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 1.5                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 2.2                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 4.0                   | 2.5                                  | 2.0          | 4.0             | 3.5          |
|                    | 5.5                   | 4.0                                  | 2.0          | 10              | 5.5          |
|                    | 7.5                   | 6.0                                  | 3.5          | 16              | 5.5          |
|                    | 11                    | 16                                   | 5.5          | 16              | 8.0          |
|                    | 15                    | 25                                   | 14           | 16              | 8.0          |
|                    | 18.5                  | 25                                   | 14           | 25              | 8.0          |
| 1 phase 240V class | 0.2                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 0.4                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 0.75                  | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 1.5                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 2.2                   | 1.5                                  | 2.0          | 4.0             | 3.5          |
|                    | 3.0                   | 1.5                                  | 2.0          | 4.0             | 3.5          |
| 3 phase 500V Class | 0.4                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 0.75                  | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 1.5                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 2.2                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 4.0                   | 1.5                                  | 2.0          | 2.5             | 2.0          |
|                    | 5.5                   | 1.5                                  | 2.0          | 4.0             | 3.5          |
|                    | 7.5                   | 2.5                                  | 2.0          | 6.0             | 3.5          |
|                    | 11                    | 4.0                                  | 2.0          | 10              | 5.5          |
|                    | 15                    | 6.0                                  | 3.5          | 16              | 5.5          |
|                    | 18.5                  | 10                                   | 5.5          | 16              | 5.5          |

\*1: For Japan: JEAC8001-2005 compliant

Note 1: Sizes of the wires connected to the input terminals R/L1, S/L2 and T/L3 (Single-phase models are R/L1 and S/L2/N) and the output terminals U/T1, V/T2 and W/T3 when the length of each wire does not exceed 30m. If there is a need to bring the inverter into UL compliance, use wires specified in chapter 9.

Note 2: For the control circuit, use shielded wires 0.75 mm<sup>2</sup> or more in diameter.

Note 3: For grounding, use wires with a size equal to or larger than the above.

Note 4: The wire sizes specified in the above table apply to HIV wires (copper wires shielded with an insulator with a maximum allowable temperature of 75°C) used at an ambient temperature of 50°C or less.

Note 5: In case of  $RUL = \overline{2}$  setting, contact your Toshiba distributor for wire size.

## ■ Selection of wiring devices

| Voltage class                 | Applicable motor (kW) | Input current (A) |          | Molded case circuit breaker (MCCB)<br>Earth leakage circuit breaker (ELCB) |          | Magnetic contactor (MC)<br>Note 2) Note 3) |          |
|-------------------------------|-----------------------|-------------------|----------|----------------------------------------------------------------------------|----------|--------------------------------------------|----------|
|                               |                       | Without DCL       | With DCL | Rated current (A)                                                          |          | Rated current (A)                          |          |
|                               |                       |                   |          | Without DCL                                                                | With DCL | Without DCL                                | With DCL |
| 3 phase 240V class            | 0.4                   | 3.6               | 1.8      | 5                                                                          | 5        | 20                                         | 20       |
|                               | 0.75                  | 6.3               | 3.4      | 10                                                                         | 5        | 20                                         | 20       |
|                               | 1.5                   | 11.1              | 6.5      | 15                                                                         | 10       | 20                                         | 20       |
|                               | 2.2                   | 14.9              | 9.2      | 20                                                                         | 15       | 20                                         | 20       |
|                               | 4.0                   | 23.8              | 15.9     | 30                                                                         | 20       | 32                                         | 20       |
|                               | 5.5                   | 35.6              | 21.5     | 50                                                                         | 30       | 50                                         | 32       |
|                               | 7.5                   | 46.1              | 28.9     | 60                                                                         | 40       | 60                                         | 32       |
|                               | 11                    | 63.1              | 41.5     | 100                                                                        | 60       | 80                                         | 50       |
|                               | 15                    | 82.1              | 55.7     | 125                                                                        | 75       | 100                                        | 60       |
|                               | 18.5                  | 89.1              | 70.0     | 125                                                                        | 100      | 100                                        | 80       |
| 1 phase 240V class            | 0.2                   | 3.4               | 2.0      | 5                                                                          | 5        | 20                                         | 20       |
|                               | 0.4                   | 5.9               | 4.0      | 10                                                                         | 5        | 20                                         | 20       |
|                               | 0.75                  | 10.0              | 7.6      | 15                                                                         | 10       | 20                                         | 20       |
|                               | 1.5                   | 17.8              | 14.6     | 30                                                                         | 20       | 32                                         | 20       |
|                               | 2.2                   | 24.0              | 20.1     | 30                                                                         | 30       | 32                                         | 32       |
|                               | 3.0                   | 24.0              | 23.6     | 30                                                                         | 30       | 32                                         | 32       |
| 3 phase 500V class<br>Note 6) | 0.4                   | 2.1               | 0.9      | 5                                                                          | 5        | 20                                         | 20       |
|                               | 0.75                  | 3.6               | 1.8      | 5                                                                          | 5        | 20                                         | 20       |
|                               | 1.5                   | 6.4               | 3.4      | 10                                                                         | 5        | 20                                         | 20       |
|                               | 2.2                   | 8.8               | 4.8      | 15                                                                         | 10       | 20                                         | 20       |
|                               | 4.0                   | 13.7              | 8.3      | 20                                                                         | 15       | 20                                         | 20       |
|                               | 5.5                   | 20.7              | 11.2     | 30                                                                         | 15       | 32                                         | 20       |
|                               | 7.5                   | 26.6              | 15.1     | 40                                                                         | 20       | 32                                         | 20       |
|                               | 11                    | 36.6              | 21.7     | 50                                                                         | 30       | 50                                         | 32       |
|                               | 15                    | 47.7              | 29.0     | 60                                                                         | 40       | 60                                         | 32       |
|                               | 18.5                  | 52.7              | 36.3     | 75                                                                         | 50       | 60                                         | 50       |

The recommended molded case circuit breaker (MCCB) must be connected to primary side of each inverter to protect the wiring system.

Note 1: Selections for use the Toshiba 4-pole standard motor with power supply voltage of 200V/ 400 - 50Hz.

Note 2: Be sure to attach a surge absorber to the exciting coil of the relay and the magnetic contactor.

Note 3: When using the auxiliary contacts 2a of the magnetic contactor MC for the control circuit, connect the contacts 2a in parallel to increase reliability.

Note 4: When a motor is driven by commercial power supply using commercial power supply / inverter switching circuit, use a magnetic contactor appropriated AC-3 class the motor rated current.

Note 5: Select an MCCB with a current breaking rating appropriate to the capacity of the power supply, because short-circuit currents vary greatly depending on the capacity of the power supply and the condition of the wiring system. The MCCB, MC and ELCB in this table were selected, on the assumption that a power supply with a normal capacity would be used.

Note 6: For the operation and control circuits, regulate the voltage at 200V to 240V with a step-down transformer for 500V class.

Note 7: In case of  $RUL = 2$  setting, be sure to select the wiring device for 1 rating up motor.

Note 8: Regarding influence of leakage current, refer to section 1.4.3.

## 10.2 Installation of a magnetic contactor

If using the inverter without installing a magnetic contactor (MC) in the primary circuit, use an MCCB (with a power cut off device) to open the primary circuit when the inverter protective circuit is activated.


When using an optional braking resistor, install a magnetic contactor (MC) or molded-case circuit breaker with a power cutoff device on the primary power supply of the inverter, so that the power circuit opens when the failure detection relay (FL) in the inverter or the externally installed overload relay is actuated.

### ■ Magnetic contactor in the primary circuit

To detach the inverter from the power supply in any of the following cases, insert a magnetic contactor (primary-side magnetic contactor) between the inverter and the power supply.

- (1) If the motor overload relay is tripped
- (2) If the protective detector (FL) built into the inverter is activated
- (3) In the event of a power failure (for prevention of auto-restart)
- (4) If the resistor protective relay is tripped when a braking resistor (option) is used

When using the inverter with no magnetic contactor (MC) on the primary side, install a molded-case circuit breaker with a voltage tripping coil instead of an MC and adjust the circuit breaker so that it will be tripped if the protective relay referred to above is activated. To detect a power failure, use an undervoltage relay or the like.



Example of connection of a magnetic contactor in the primary circuit

### Notes on wiring

- When frequently switching between start and stop, do not use the magnetic contactor on the primary side as an on-off switch for the inverter.  
Instead, stop and start the inverter by using terminals F and CC (forward run) or R and CC (reverse run).
- Be sure to attach a surge absorber to the exciting coil of the magnetic contactor (MC).

## ■ Magnetic contactor in the secondary circuit

A magnetic contactor may be installed on the secondary side to switch controlled motors or supply commercial power to the load when the inverter is out of operation.

### Notes on wiring

- Be sure to interlock the magnetic contactor on the secondary side with the power supply to prevent commercial power from being applied to the inverter output terminals.
- When installing a magnetic contactor (MC) between the inverter and the motor, avoid turning the magnetic contactor on or off during operation. Turning the magnetic contactor on or off during operation causes a current to rush into the inverter which could lead to malfunction.


## 10.3 Installation of an overload relay

---

- 1) This inverter has an electronic-thermal overload protective function.  
In the following cases, however, an overload relay suitable for the adjustment of the motor electronic thermal protection level ( $I_{th}$ ) and appropriate to the motor used should be installed between the inverter and the motor.
  - When using a motor with a current rating different to that of the corresponding Toshiba general-purpose motor
  - When operating a single motor with an output smaller than that of the applicable standard motor or more than one motor simultaneously.
- 2) When using this inverter to operate a constant-torque motor, such as the Toshiba VF motor, adjust the protection characteristic of the electronic thermal protection unit ( $I_{th}$ ) to the VF motor use.
- 3) It is recommended to use a motor with a thermal relay embedded in the motor coil to give sufficient protection to the motor, especially when it runs in a low-speed range.

## 10.4 Optional external devices


The following external devices are optionally available for this inverter series.



|                                                    |            |
|----------------------------------------------------|------------|
| (10) Parameter writer                              | : RKP002Z  |
|                                                    | PWU003Z    |
| (11) Extension panel                               | : RKP007Z  |
| (12) Remote control panel                          | : CBVR-7B1 |
| (13) Frequency meter                               | : QS60T    |
| (14) FRH kit                                       | : FRH KIT  |
| (15) USB communication converter                   | : USB001Z  |
| (16) CC-Link communication option                  | : CCL003Z  |
| (17) PROFIBUS DP communication option              | : PDP003Z  |
| (18) DeviceNet communication option                | : DEV003Z  |
| (19) EtherNet / IP-Modbus TCP communication option | : IPE002Z  |
|                                                    | : IPE003Z  |
| (20) EtherCAT communication option                 | : CAN001Z  |
| (21) CANopen communication option                  | : CAN002Z  |
|                                                    | : CAN003Z  |
| (22) Communication option adaptor                  | : SBP009Z  |


## ■ How to mount the option

- 1) Mount the option to the option adapter.




Note: Insert the option straightly and slowly along the guide inside option adapter. Neglect of this will result in the damage to the connector pin.


- 2) Unlock the front cover and open it.




- 3) Remove the option connector cover on the front cover from the back side.




- 4) Close the front cover and lock it.




- 5) Hang the hook of the option adapter on the bottom of the front cover and mount it to the inverter.



Side view




## ■ The option is mounted



After mounting the option adapter, the depth increases 25.5mm.

## ■ How to wire the grounding cable

Wire the attached grounding cable to grounding terminal of inverter.



# 11. Table of parameters and data

## 11.1 Frequency setting parameter

| Title    | Function                               | Unit | Minimum setting unit<br>Panel/Comm<br>unication | Adjustment range             | Default setting | User setting | Reference |
|----------|----------------------------------------|------|-------------------------------------------------|------------------------------|-----------------|--------------|-----------|
| $F\zeta$ | Operation frequency of operation panel | Hz   | 0.1/0.01                                        | $\zeta\zeta - \text{U}\zeta$ | 0.0             |              | 3.2.2     |

## 11.2 Basic parameters

### • Five navigation functions

| Title       | Communication No. | Function                             | Unit | Minimum setting unit<br>Panel/Comm<br>unication | Adjustment range                                                                                                                              | Default setting | User setting | Reference    |
|-------------|-------------------|--------------------------------------|------|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|--------------|
| $RUH$       | -                 | History function                     | -    | -                                               | Displays parameters in groups of five in the reverse order to that in which their settings were changed.<br>* (Possible to edit)              | -               |              | 6.1.1        |
| $RU\theta$  | 0090              | Application easy setting *10         | -    | -                                               | 0: -<br>1: Initial easy setting<br>2: Conveyor<br>3: Material handling<br>4: Hoisting<br>5: Fan<br>6: Pump<br>7: Compressor                   | 0               |              | 6.1.2        |
| $RU\phi$    | 0093              | Guidance function                    | -    | -                                               | 0: -<br>1: -<br>2: Preset speed guidance<br>3: -<br>4: Motor 1 & 2 switching operation guidance<br>5: Motor constant setting guidance<br>6: - | 0               |              | 6.1.3        |
| $RU\lambda$ | 0094              | Overload characteristic selection    | -    | -                                               | 0: -<br>1: Constant torque characteristic (150%-60s)<br>2: Variable torque characteristic (120%-60s)                                          | 0               |              | 5.6<br>6.18  |
| $RU\iota$   | 0000              | Automatic acceleration/ deceleration | -    | -                                               | 0: Disabled (manual setting)<br>1: Automatic<br>2: Automatic (only at acceleration)                                                           | 0               |              | 5.2<br>6.1.4 |
| $RU\varrho$ | 0001              | Torque boost setting macro function  | -    | -                                               | 0: -<br>1: Automatic torque boost + auto-tuning<br>2: Vector control + auto-tuning<br>3: Energy saving + auto-tuning                          | 0               |              | 6.1.5        |

\*10: Refer to section 11.8 about parameters that are set by this parameter.

• Basic parameters

| Title          | Communication No. | Function                                     | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Default setting | User setting | Reference                            |
|----------------|-------------------|----------------------------------------------|------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|--------------------------------------|
| <i>C N d</i>   | 0003              | Command mode selection                       | -    | -                                           | 0: Terminal block<br>1: Panel keypad (including extension panel)<br>2: RS485 communication<br>3: CANopen communication<br>4: Communication option                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 1               |              | 3.2<br>6.2.1<br>7.3                  |
| <i>F N d</i>   | 0004              | Frequency setting mode selection 1           | -    | -                                           | 0: Setting dial 1 (including extension panel) (save even if power is off)<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Setting dial 2 (including extension panel) (press in center to save)<br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input<br>12, 13: -<br>14: <i>S r d</i>                                                                                                                                                                                                                                                                                                                                                                                                  | 0               |              | 3.2<br>6.2.1<br>6.10.1<br>5.8<br>7.3 |
| <i>F N S L</i> | 0005              | Meter selection                              | -    | -                                           | 0: Output frequency<br>1: Output current<br>2: Frequency command value<br>3: Input voltage (DC detection)<br>4: Output voltage (command value)<br>5: Input power<br>6: Output power<br>7: Torque<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency<br>13: VIA input value<br>14: VIB input value<br>15: Fixed output 1<br>(output current 100% equivalent)<br>16: Fixed output 2<br>(output current 50% equivalent)<br>17: Fixed output 3<br>(Other than the output current)<br>18: RS485 communication data<br>19: For adjustments ( <i>F N</i> set value is displayed.)<br>20: VIC input value<br>21, 22: -<br>23: PID feedback value<br>24: Integral input power<br>25: Integral output power | 0               |              | 5.1                                  |
| <i>F N</i>     | 0006              | Meter adjustment gain                        | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | -               |              |                                      |
| <i>F r</i>     | 0008              | Forward/reverse run selection (Panel keypad) | -    | -                                           | 0: Forward run<br>1: Reverse run<br>2: Forward run (F/R switching on extension panel)<br>3: Reverse run (F/R switching on extension panel)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 0               |              | 6.2.2                                |

| Title   | Communication No. | Function                                               | Unit  | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                               |                |                     |         | Default setting | User setting | Reference     |
|---------|-------------------|--------------------------------------------------------|-------|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|---------------------|---------|-----------------|--------------|---------------|
| $AC$    | 0009              | Acceleration time 1                                    | s     | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                                                                                                                                                                            |                |                     |         | 10.0            |              | 5.2           |
| $de$    | 0010              | Deceleration time 1                                    | s     | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                                                                                                                                                                            |                |                     |         | 10.0            |              |               |
| $FH$    | 0011              | Maximum frequency                                      | Hz    | 0.1/0.01                                    | 30.0-500.0                                                                                                                                                                                                                     |                |                     |         | 80.0            |              | 5.3           |
| $UL$    | 0012              | Upper limit frequency                                  | Hz    | 0.1/0.01                                    | 0.5- $FH$                                                                                                                                                                                                                      |                |                     |         | *1              |              | 5.4           |
| $LL$    | 0013              | Lower limit frequency                                  | Hz    | 0.1/0.01                                    | 0.0- $UL$                                                                                                                                                                                                                      |                |                     |         | 0.0             |              |               |
| $UL$    | 0014              | Base frequency 1                                       | Hz    | 0.1/0.01                                    | 20.0-500.0                                                                                                                                                                                                                     |                |                     |         | *1              |              | 5.5           |
| $UL$    | 0409              | Base frequency voltage 1                               | V     | 1/0.1                                       | 50-330 (240V class)<br>50-660 (500V class)                                                                                                                                                                                     |                |                     |         | *1              |              | 5.5<br>6.19.6 |
| $Pt$    | 0015              | V/F control mode selection                             | -     | -                                           | 0: V/F constant<br>1: Variable torque<br>2: Automatic torque boost control<br>3: Vector control<br>4: Energy-saving<br>5: Dynamic energy-saving<br>(For fan and pump)<br>6: PM motor control<br>7: V/F 5-point setting<br>8: - |                |                     |         | *1              |              | 6.3           |
| $ub$    | 0016              | Torque boost value 1                                   | %     | 0.1/0.1                                     | 0.0-30.0                                                                                                                                                                                                                       |                |                     |         | *2              |              | 6.4           |
| $thr$   | 0600              | Motor electronic-thermal protection level 1            | % (A) | 1/1                                         | 10-100 *12                                                                                                                                                                                                                     |                |                     |         | 100             |              | 5.6<br>6.29.1 |
| $ELN$   | 0017              | Electronic-thermal protection characteristic selection | -     | -                                           | Setting                                                                                                                                                                                                                        |                | Overload protection |         | OL stall        | 0            | 5.6           |
|         |                   |                                                        |       |                                             | 0                                                                                                                                                                                                                              | Standard motor | valid               | invalid |                 |              |               |
|         |                   |                                                        |       |                                             | 1                                                                                                                                                                                                                              |                | valid               | valid   |                 |              |               |
|         |                   |                                                        |       |                                             | 2                                                                                                                                                                                                                              |                | invalid             | invalid |                 |              |               |
|         |                   |                                                        |       |                                             | 3                                                                                                                                                                                                                              |                | invalid             | valid   |                 |              |               |
|         |                   |                                                        |       |                                             | 4                                                                                                                                                                                                                              | V/F motor      | valid               | invalid |                 |              |               |
|         |                   |                                                        |       |                                             | 5                                                                                                                                                                                                                              |                | valid               | valid   |                 |              |               |
|         |                   |                                                        |       |                                             | 6                                                                                                                                                                                                                              |                | invalid             | invalid |                 |              |               |
| 7       | invalid           | valid                                                  |       |                                             |                                                                                                                                                                                                                                |                |                     |         |                 |              |               |
| $sr0$   | 0030              | Preset-speed frequency 0                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              | 5.7           |
| $sr1$   | 0018              | Preset-speed frequency 1                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $sr2$   | 0019              | Preset-speed frequency 2                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $sr3$   | 0020              | Preset-speed frequency 3                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $sr4$   | 0021              | Preset-speed frequency 4                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $sr5$   | 0022              | Preset-speed frequency 5                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $sr6$   | 0023              | Preset-speed frequency 6                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $sr7$   | 0024              | Preset-speed frequency 7                               | Hz    | 0.1/0.01                                    | $LL-UL$                                                                                                                                                                                                                        |                |                     |         | 0.0             |              |               |
| $FPI d$ | 0025              | Process input value of PID control                     | Hz    | 0.1/0.01                                    | $F368-F367$                                                                                                                                                                                                                    |                |                     |         | 0.0             |              | 6.24          |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*2: Default setting values vary depending on the capacity. Refer to section 11.4.

\*8: These parameters can be changed to 0.01s unit by setting  $F519=1$ .

\*12: When  $F701=1$ , adjustment range is 100%=rated current, or 100%=200V(240V class)/ 400V(500V class).

| Title   | Communication No. | Function                           | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                   | Default setting | User setting | Reference |
|---------|-------------------|------------------------------------|------|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| Ⓔ Ⓜ Ⓟ   | 0007              | Default setting                    | -    | -                                           | 0: -<br>1: 60Hz default setting<br>2: 60Hz default setting<br>3: Default setting 1 (Initialization)<br>4: Trip record clear<br>5: Cumulative operation time clear<br>6: Initialization of type information<br>7: Save user setting parameters<br>8: Load user setting parameters<br>9: Cumulative fan operation time record clears<br>10, 11: -<br>12: Number of starting clear<br>13: Default setting 2 (Complete initialization) | 0               |              | 4.3.2     |
| Ⓜ Ⓔ Ⓔ   | 0099              | Checking the region setting<br>* 5 | -    | -                                           | 0: Start setup menu<br>1: Japan (read only)<br>2: North America (read only)<br>3: Asia (read only)<br>4: Europe (read only)                                                                                                                                                                                                                                                                                                        | *1              |              | 4.4       |
| Ⓟ Ⓜ Ⓔ Ⓔ | 0050              | EASY key mode selection            | -    | -                                           | 0: Standard setting mode at power on<br>1: Easy setting mode at power on<br>2: Easy setting mode only                                                                                                                                                                                                                                                                                                                              | 0               |              | 4.5       |
| Ⓕ 1 - - | -                 | Extended parameter starting at 100 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            | 4.2.2     |
| Ⓕ 2 - - | -                 | Extended parameter starting at 200 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 3 - - | -                 | Extended parameter starting at 300 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 4 - - | -                 | Extended parameter starting at 400 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 5 - - | -                 | Extended parameter starting at 500 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 6 - - | -                 | Extended parameter starting at 600 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 7 - - | -                 | Extended parameter starting at 700 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 8 - - | -                 | Extended parameter starting at 800 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓕ 9 - - | -                 | Extended parameter starting at 900 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓖ - - - | -                 | Extended parameter starting at A   | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓔ - - - | -                 | Extended parameter starting at C   | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            |           |
| Ⓔ Ⓡ Ⓡ Ⓡ | -                 | Automatic edit function            | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                  | -               | -            | 4.3.1     |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*5: Set "0" to activate the setup menu. Refer to section 11.5 about setting contents selected in setup menu.

## 11.3 Extended parameters

### • Input/output parameters 1

| Title | Communication No. | Function                                 | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                      | Default setting | User setting | Reference                                |
|-------|-------------------|------------------------------------------|------|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|------------------------------------------|
| F 100 | 0100              | Low-speed signal output frequency        | Hz   | 0.1/0.01                                    | 0.0- <i>F<sub>H</sub></i>                                                                                                                                                                                             | 0.0             |              | 6.5.1                                    |
| F 101 | 0101              | Speed reach setting frequency            | Hz   | 0.1/0.01                                    | 0.0- <i>F<sub>H</sub></i>                                                                                                                                                                                             | 0.0             |              | 6.5.3                                    |
| F 102 | 0102              | Speed reach detection band               | Hz   | 0.1/0.01                                    | 0.0- <i>F<sub>H</sub></i>                                                                                                                                                                                             | 2.5             |              | 6.5.2<br>6.5.3                           |
| F 104 | 0104              | Always active function selection 1       | -    | -                                           | 0-7, 10-153: *6<br>8,9: -                                                                                                                                                                                             | 0 (No function) |              | 6.7.1                                    |
| F 105 | 0105              | Priority selection (Both F and R are ON) | -    | -                                           | 0: Reverse<br>1: Deceleration Stop                                                                                                                                                                                    | 1               |              | 6.6.1                                    |
| F 107 | 0107              | Analog input terminal selection (VIB)    | -    | -                                           | 0: 0-+10V<br>1: -10-+10V                                                                                                                                                                                              | 0               |              | 6.6.2<br>6.10.2<br>7.3                   |
| F 108 | 0108              | Always active function selection 2       | -    | -                                           | 0-7, 10-153: *6<br>8,9: -                                                                                                                                                                                             | 0 (No function) |              | 6.7.1                                    |
| F 109 | 0109              | Analog/logic input selection (VIA/VIB)   | -    | -                                           | 0: VIA - analog input<br>VIB - analog input<br>1: VIA - analog input<br>VIB - contact input<br>2: -<br>3: VIA - contact input (Sink)<br>VIB - contact input<br>4: VIA - contact input (Source)<br>VIB - contact input | 0               |              | 6.6.3<br>6.7.2<br>6.10.2<br>7.2.1<br>7.3 |
| F 110 | 0110              | Always active function selection 3       | -    | -                                           | 0-7, 10-153: *6<br>8,9: -                                                                                                                                                                                             | 6 (ST)          |              | 6.7.1                                    |
| F 111 | 0111              | Input terminal selection 1A (F)          | -    | -                                           | 0-203 *6                                                                                                                                                                                                              | 2 (F)           |              | 6.7.2<br>7.2.1                           |
| F 112 | 0112              | Input terminal selection 2A (R)          | -    | -                                           |                                                                                                                                                                                                                       | 4 (R)           |              |                                          |
| F 113 | 0113              | Input terminal selection 3A (RES)        | -    | -                                           |                                                                                                                                                                                                                       | 8 (RES)         |              |                                          |
| F 114 | 0114              | Input terminal selection 4A (S1)         | -    | -                                           |                                                                                                                                                                                                                       | 10 (SS1)        |              |                                          |
| F 115 | 0115              | Input terminal selection 5 (S2)          | -    | -                                           |                                                                                                                                                                                                                       | 12 (SS2)        |              |                                          |
| F 116 | 0116              | Input terminal selection 6 (S3)          | -    | -                                           |                                                                                                                                                                                                                       | 14 (SS3)        |              |                                          |
| F 117 | 0117              | Input terminal selection 7 (VIB)         | -    | -                                           |                                                                                                                                                                                                                       | 16 (SS4)        |              |                                          |
| F 118 | 0118              | Input terminal selection 8 (VIA)         | -    | -                                           | 8-55 *6                                                                                                                                                                                                               | 24 (AD2)        |              |                                          |

\*6: Refer to section 11.6 for details about input terminal function.

| Title        | Communication No. | Function                                       | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                             | Default setting | User setting | Reference                          |
|--------------|-------------------|------------------------------------------------|------|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|------------------------------------|
| <i>F 130</i> | 0130              | Output terminal selection 1A (RY-RC)           | -    | -                                           | 0-255 *7                                                                                                                                                                                                                                                                     | 4 (LOW)         |              | 6.7.3<br>7.2.2                     |
| <i>F 131</i> | 0131              | Output terminal selection 2A (OUT)             | -    | -                                           |                                                                                                                                                                                                                                                                              | 6 (RCH)         |              |                                    |
| <i>F 132</i> | 0132              | Output terminal selection 3 (FL)               | -    | -                                           |                                                                                                                                                                                                                                                                              | 10 (FL)         |              |                                    |
| <i>F 137</i> | 0137              | Output terminal selection 1B (RY-RC)           | -    | -                                           |                                                                                                                                                                                                                                                                              | 255 (always ON) |              |                                    |
| <i>F 138</i> | 0138              | Output terminal selection 2B (OUT)             | -    | -                                           |                                                                                                                                                                                                                                                                              | 255 (always ON) |              |                                    |
| <i>F 139</i> | 0139              | Output terminal logic selection (RY-RC, OUT)   | -    | -                                           | 0: <i>F 130</i> and <i>F 137</i><br><i>F 131</i> and <i>F 138</i><br>1: <i>F 130</i> or <i>F 137</i><br><i>F 131</i> and <i>F 138</i><br>2: <i>F 130</i> and <i>F 137</i><br><i>F 131</i> or <i>F 138</i><br>3: <i>F 130</i> or <i>F 137</i><br><i>F 131</i> or <i>F 138</i> | 0               |              |                                    |
| <i>F 144</i> | 0144              | Input terminal response time                   | ms   | 1/1                                         | 1-1000                                                                                                                                                                                                                                                                       | 1               |              | 6.7.2<br>7.2.1                     |
| <i>F 146</i> | 0146              | Logic input / pulse train input selection (S2) | -    | -                                           | 0: Logic input<br>1: Pulse train input                                                                                                                                                                                                                                       | 0               |              | 6.7.2<br>6.10.5<br>7.2.1           |
| <i>F 147</i> | 0147              | Logic input / PTC input selection (S3)         | -    | -                                           | 0: Logic input<br>1: PTC input                                                                                                                                                                                                                                               | 0               |              | 2.3.2<br>6.7.2<br>6.29.16<br>7.2.1 |
| <i>F 151</i> | 0151              | Input terminal selection 1B (F)                | -    | -                                           | 0-203 *6                                                                                                                                                                                                                                                                     | 0               |              | 6.7.2<br>7.2.1                     |
| <i>F 152</i> | 0152              | Input terminal selection 2B (R)                | -    | -                                           |                                                                                                                                                                                                                                                                              | 0               |              |                                    |
| <i>F 153</i> | 0153              | Input terminal selection 3B (RES)              | -    | -                                           |                                                                                                                                                                                                                                                                              | 0               |              |                                    |
| <i>F 154</i> | 0154              | Input terminal selection 4B (S1)               | -    | -                                           |                                                                                                                                                                                                                                                                              | 0               |              |                                    |
| <i>F 155</i> | 0155              | Input terminal selection 1C (F)                | -    | -                                           |                                                                                                                                                                                                                                                                              | 0               |              |                                    |
| <i>F 156</i> | 0156              | Input terminal selection 2C (R)                | -    | -                                           |                                                                                                                                                                                                                                                                              | 0               |              |                                    |
| <i>F 167</i> | 0167              | Frequency command agreement detection range    | Hz   | 0.1/0.01                                    | 0.0- <i>FH</i>                                                                                                                                                                                                                                                               | 2.5             |              | 6.24                               |

\*6: Refer to section 11.6 for details about input terminal function.

\*7: Refer to section 11.7 for details about output terminal function.

• Basic parameter 2

| Title        | Communication No. | Function                                    | Unit     | Minimum setting unit<br>Panel/Communication | Adjustment range                           | Default setting | User setting | Reference              |
|--------------|-------------------|---------------------------------------------|----------|---------------------------------------------|--------------------------------------------|-----------------|--------------|------------------------|
| <i>F 170</i> | 0170              | Base frequency 2                            | Hz       | 0.1/0.01                                    | 20.0-500.0                                 | *1              |              | 6.8.1                  |
| <i>F 171</i> | 0171              | Base frequency voltage 2                    | V        | 1/0.1                                       | 50-330 (240V class)<br>50-660 (500V class) | *1              |              |                        |
| <i>F 172</i> | 0172              | Torque boost value 2                        | %        | 0.1/0.1                                     | 0.0-30.0                                   | *2              |              |                        |
| <i>F 173</i> | 0173              | Motor electronic-thermal protection level 2 | %<br>(A) | 1/1                                         | 10-100 *12                                 | 100             |              | 5.6<br>6.8.1<br>6.29.1 |
| <i>F 185</i> | 0185              | Stall prevention level 2                    | %<br>(A) | 1/1                                         | 10-199, *12<br>200 (disabled)              | 150             |              | 6.8.1<br>6.29.2        |
| <i>F 190</i> | 0190              | V/f 5-point setting VF1 frequency           | Hz       | 0.1/0.01                                    | 0.0- <i>F H</i>                            | 0.0             |              | 6.3<br>6.9             |
| <i>F 191</i> | 0191              | V/f 5-point setting VF1 voltage             | %<br>(V) | 0.1/0.1                                     | 0.0-125.0 *12                              | 0.0             |              |                        |
| <i>F 192</i> | 0192              | V/f 5-point setting VF2 frequency           | Hz       | 0.1/0.01                                    | 0.0- <i>F H</i>                            | 0.0             |              |                        |
| <i>F 193</i> | 0193              | V/f 5-point setting VF2 voltage             | %<br>(V) | 0.1/0.1                                     | 0.0-125.0 *12                              | 0.0             |              |                        |
| <i>F 194</i> | 0194              | V/f 5-point setting VF3 frequency           | Hz       | 0.1/0.01                                    | 0.0- <i>F H</i>                            | 0.0             |              |                        |
| <i>F 195</i> | 0195              | V/f 5-point setting VF3 voltage             | %<br>(V) | 0.10.1                                      | 0.0-125.0 *12                              | 0.0             |              |                        |
| <i>F 196</i> | 0196              | V/f 5-point setting VF4 frequency           | Hz       | 0.1/0.01                                    | 0.0- <i>F H</i>                            | 0.0             |              |                        |
| <i>F 197</i> | 0197              | V/f 5-point setting VF4 voltage             | %<br>(V) | 0.1/0.1                                     | 0.0-125.0 *12                              | 0.0             |              |                        |
| <i>F 198</i> | 0198              | V/f 5-point setting VF5 frequency           | Hz       | 0.1/0.01                                    | 0.0- <i>F H</i>                            | 0.0             |              |                        |
| <i>F 199</i> | 0199              | V/f 5-point setting VF5 voltage             | %<br>(V) | 0.1/0.1                                     | 0.0-125.0 *12                              | 0.0             |              |                        |

• Frequency parameters

| Title        | Communication No. | Function                           | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                        | Default setting | User setting | Reference     |
|--------------|-------------------|------------------------------------|------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|---------------|
| <i>F 200</i> | 0200              | Frequency priority selection       | -    | -                                           | 0: <i>F H d</i> (Switchable to <i>F 207</i> by terminal input)<br>1: <i>F H d</i> (Switchable to <i>F 207</i> at 1.0Hz or less of designated frequency) | 0               |              | 5.8<br>6.10.1 |
| <i>F 201</i> | 0201              | VIA input point 1 setting          | %    | 1/1                                         | 0-100                                                                                                                                                   | 0               |              | 6.10.2<br>7.3 |
| <i>F 202</i> | 0202              | VIA input point 1 frequency        | Hz   | 0.1/0.01                                    | 0.0-500.0                                                                                                                                               | 0.0             |              |               |
| <i>F 203</i> | 0203              | VIA input point 2 setting          | %    | 1/1                                         | 0-100                                                                                                                                                   | 100             |              |               |
| <i>F 204</i> | 0204              | VIA input point 2 frequency        | Hz   | 0.1/0.01                                    | 0.0-500.0                                                                                                                                               | *1              |              |               |
| <i>F 205</i> | 0205              | VIA input point 1 rate             | %    | 1/0.01                                      | 0-250                                                                                                                                                   | 0               |              | 6.31          |
| <i>F 206</i> | 0206              | VIA input point 2 rate             | %    | 1/0.01                                      | 0-250                                                                                                                                                   | 100             |              |               |
| <i>F 207</i> | 0207              | Frequency setting mode selection 2 | -    | -                                           | 0-14 (Same as <i>F H d</i> )                                                                                                                            | 1               |              | 5.8<br>6.10.1 |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*2: Default setting values vary depending on the capacity. Refer to section 11.4.

\*12: When *F 70 i = i*, adjustment range is 100%=rated current, or 100%=200V(240V class)/ 400V(500V class).

| Title       | Communication No. | Function                                           | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                             | Default setting | User setting | Reference     |
|-------------|-------------------|----------------------------------------------------|------|---------------------------------------------|----------------------------------------------|-----------------|--------------|---------------|
| <i>F209</i> | 0209              | Analog input filter                                | ms   | 1/1                                         | 2-1000                                       | 64              |              | 6.10.2<br>7.3 |
| <i>F210</i> | 0210              | VIB input point 1 setting                          | %    | 1/1                                         | -100~+100                                    | 0               |              |               |
| <i>F211</i> | 0211              | VIB input point 1 frequency                        | Hz   | 0.1/0.01                                    | 0.0-500.0                                    | 0.0             |              |               |
| <i>F212</i> | 0212              | VIB input point 2 setting                          | %    | 1/1                                         | -100~+100                                    | 100             |              |               |
| <i>F213</i> | 0213              | VIB input point 2 frequency                        | Hz   | 0.1/0.01                                    | 0.0-500.0                                    | *1              |              |               |
| <i>F214</i> | 0214              | VIB input point 1 rate                             | %    | 1/0.01                                      | -250~+250                                    | 0               |              | 6.31<br>6.32  |
| <i>F215</i> | 0215              | VIB input point 2 rate                             | %    | 1/0.01                                      | -250~+250                                    | 100             |              |               |
| <i>F216</i> | 0216              | VIC input point 1 setting                          | %    | 1/1                                         | 0-100                                        | 20              |              | 6.10.2<br>7.3 |
| <i>F217</i> | 0217              | VIC input point 1 frequency                        | Hz   | 0.1/0.01                                    | 0.0-500.0                                    | 0.0             |              |               |
| <i>F218</i> | 0218              | VIC input point 2 setting                          | %    | 1/1                                         | 0-100                                        | 100             |              |               |
| <i>F219</i> | 0219              | VIC input point 2 frequency                        | Hz   | 0.1/0.01                                    | 0.0-500.0                                    | *1              |              |               |
| <i>F220</i> | 0220              | VIC input point 1 rate                             | %    | 1/0.01                                      | 0-250                                        | 0               |              |               |
| <i>F221</i> | 0221              | VIC input point 2 rate                             | %    | 1/0.01                                      | 0-250                                        | 100             |              | 6.31          |
| <i>F239</i> | 0239              | Factory specific coefficient 2A                    | -    | -                                           | -                                            | -               |              | * 3           |
| <i>F240</i> | 0240              | Starting frequency                                 | Hz   | 0.1/0.01                                    | 0.1-10.0                                     | 0.5             |              | 6.11.1        |
| <i>F241</i> | 0241              | Operation starting frequency                       | Hz   | 0.1/0.01                                    | 0.0- <i>FH</i>                               | 0.0             |              | 6.11.2        |
| <i>F242</i> | 0242              | Operation starting frequency hysteresis            | Hz   | 0.1/0.01                                    | 0.0- <i>FH</i>                               | 0.0             |              |               |
| <i>F243</i> | 0243              | Stop frequency setting                             | Hz   | 0.1/0.01                                    | 0.0: Same as <i>F240</i><br>0.1-30.0         | 0.0             |              | 6.11.1        |
| <i>F249</i> | 0249              | PWM carrier frequency during DC braking            | kHz  | 0.1/0.1                                     | 2.0-16.0                                     | 4.0             |              | 6.12.1        |
| <i>F250</i> | 0250              | DC braking starting frequency                      | Hz   | 0.1/0.01                                    | 0.0- <i>FH</i>                               | 0.0             |              |               |
| <i>F251</i> | 0251              | DC braking current                                 | %(A) | 1/1                                         | 0-100 *12                                    | 50              |              |               |
| <i>F252</i> | 0252              | DC braking time                                    | s    | 0.1/0.1                                     | 0.0-25.5                                     | 1.0             |              |               |
| <i>F254</i> | 0254              | Motor shaft fixing control                         | -    | -                                           | 0: Disabled<br>1: Enabled (after DC braking) | 0               |              | 6.12.2        |
| <i>F256</i> | 0256              | Time limit for lower-limit frequency operation     | s    | 0.1/0.1                                     | 0: Disabled<br>0.1-600.0                     | 0.0             |              | 6.13          |
| <i>F257</i> | 0257              | Factory specific coefficient 2B                    | -    | -                                           | -                                            | -               |              | * 3           |
| <i>F258</i> | 0258              | Factory specific coefficient 2C                    | -    | -                                           | -                                            | -               |              | * 3           |
| <i>F259</i> | 0259              | Lower limit frequency reach time limit at start-up | s    | 0.1/0.1                                     | 0.0: Disabled<br>0.1-600.0                   | 0.0             |              | 6.13          |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

\*12: When *F70* != *I*, adjustment range is 100%=rated current, or 100%=200V(240V class)/ 400V(500V class).

| Title | Communication No. | Function                                         | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                      | Default setting | User setting | Reference   |
|-------|-------------------|--------------------------------------------------|------|---------------------------------------------|-----------------------------------------------------------------------|-----------------|--------------|-------------|
| F260  | 0260              | Jog run frequency                                | Hz   | 0.1/0.01                                    | F240—20.0                                                             | 5.0             |              | 6.14        |
| F261  | 0261              | Jog run stopping pattern                         | -    | -                                           | 0: Deceleration stop<br>1: Coast stop<br>2: DC braking stop           | 0               |              |             |
| F262  | 0262              | Panel jog run operation mode                     | -    | -                                           | 0: Invalid<br>1: Valid                                                | 0               |              |             |
| F264  | 0264              | External logic input - UP response time          | s    | 0.1/0.1                                     | 0.0-10.0                                                              | 0.1             |              | 6.10.4      |
| F265  | 0265              | External logic input - UP frequency steps        | Hz   | 0.1/0.01                                    | 0.0-FH                                                                | 0.1             |              |             |
| F266  | 0266              | External logic input - DOWN response time        | s    | 0.1/0.1                                     | 0.0-10.0                                                              | 0.1             |              |             |
| F267  | 0267              | External logic input - DOWN frequency steps      | Hz   | 0.1/0.01                                    | 0.0-FH                                                                | 0.1             |              |             |
| F268  | 0268              | Initial value of UP/DOWN frequency               | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F269  | 0269              | Change of the initial value of UP/DOWN frequency | -    | -                                           | 0: Not changed<br>1: Setting of F268 changed when power is turned off | 1               |              |             |
| F270  | 0270              | Jump frequency 1                                 | Hz   | 0.1/0.01                                    | 0.0-FH                                                                | 0.0             |              | 6.15        |
| F271  | 0271              | Jumping width 1                                  | Hz   | 0.1/0.01                                    | 0.0-30.0                                                              | 0.0             |              |             |
| F272  | 0272              | Jump frequency 2                                 | Hz   | 0.1/0.01                                    | 0.0-FH                                                                | 0.0             |              |             |
| F273  | 0273              | Jumping width 2                                  | Hz   | 0.1/0.01                                    | 0.0-30.0                                                              | 0.0             |              |             |
| F274  | 0274              | Jump frequency 3                                 | Hz   | 0.1/0.01                                    | 0.0-FH                                                                | 0.0             |              |             |
| F275  | 0275              | Jumping width 3                                  | Hz   | 0.1/0.01                                    | 0.0-30.0                                                              | 0.0             |              |             |
| F287  | 0287              | Preset-speed frequency 8                         | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              | 5.7         |
| F288  | 0288              | Preset-speed frequency 9                         | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F289  | 0289              | Preset-speed frequency 10                        | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F290  | 0290              | Preset-speed frequency 11                        | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F291  | 0291              | Preset-speed frequency 12                        | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F292  | 0292              | Preset-speed frequency 13                        | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F293  | 0293              | Preset-speed frequency 14                        | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F294  | 0294              | Preset-speed frequency 15                        | Hz   | 0.1/0.01                                    | LL - UL                                                               | 0.0             |              |             |
| F295  | 0295              | Bumpless operation selection                     | -    | -                                           | 0: Disabled<br>1: Enabled                                             | 0               |              | 5.7<br>6.30 |
| F297  | 0297              | Low voltage operation upper limit frequency      | Hz   | 0.1/0.01                                    | 0.0: Disabled<br>0.1-30.0                                             | 0.0             |              | 6.16        |
| F298  | 0298              | Low voltage operation DC voltage                 | Vdc  | 1/0.1                                       | 240V class: 72(96)-168 *11<br>500V class: 72(120)-336 *11             | 120             |              | 6.17        |

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

\*11: 240V class : 4.0kW or less : 72 to 168V, 5.5kW or more : 96 to 168V.

500V class : 4.0kW or less : 72 to 336V, 5.5kW or more : 120 to 336V.

• Operation mode parameters

| Title | Communication No. | Function                                                       | Unit  | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                       | Default setting | User setting | Reference |
|-------|-------------------|----------------------------------------------------------------|-------|---------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| F300  | 0300              | PWM carrier frequency                                          | kHz   | 0.1/0.1                                     | 2.0-16.0                                                                                                                                                                                                                               | 12.0            |              | 6.18      |
| F301  | 0301              | Auto-restart control selection                                 | -     | -                                           | 0: Disabled<br>1: At auto-restart after momentary stop<br>2: At ST terminal off and on<br>3: 1+2<br>4: At start-up                                                                                                                     | 0               |              | 5.9       |
| F302  | 0302              | Regenerative power ride-through control (Deceleration stop)    | -     | -                                           | 0: Disabled<br>1: Regenerative power ride-through control<br>2: Deceleration stop during power failure<br>3: Synchronized acceleration / deceleration (signal)<br>4: Synchronized acceleration / deceleration (signal + power failure) | 0               |              | 6.19.2    |
| F303  | 0303              | Retry selection (number of times)                              | Times | 1/1                                         | 0: Disabled<br>1-10                                                                                                                                                                                                                    | 0               |              | 6.19.3    |
| F304  | 0304              | Dynamic braking selection                                      | -     | -                                           | 0: Disabled<br>1: Enabled, Resistor overload protection enabled<br>2: Enabled<br>3: Enabled, Resistor overload protection enabled (At ST terminal on)<br>4: Enabled (At ST terminal on)                                                | 0               |              | 6.19.4    |
| F305  | 0305              | Overvoltage limit operation (Deceleration stop mode selection) | -     | -                                           | 0: Enabled<br>1: Disabled<br>2: Enabled (Quick deceleration control)<br>3: Enabled (Dynamic quick deceleration control)                                                                                                                | 2               |              | 6.19.5    |
| F307  | 0307              | Supply voltage correction (output voltage limitation)          | -     | -                                           | 0: Supply voltage uncorrected, output voltage limited                                                                                                                                                                                  | *1              |              | 6.19.6    |
|       |                   |                                                                |       |                                             | 1: Supply voltage corrected, output voltage limited                                                                                                                                                                                    |                 |              |           |
|       |                   |                                                                |       |                                             | 2: Supply voltage uncorrected, output voltage unlimited                                                                                                                                                                                |                 |              |           |
|       |                   |                                                                |       |                                             | 3: Supply voltage corrected, output voltage unlimited                                                                                                                                                                                  |                 |              |           |
| F308  | 0308              | Dynamic braking resistance                                     | Ω     | 0.1/0.1                                     | 1.0-1000                                                                                                                                                                                                                               | *2              |              | 6.19.4    |
| F309  | 0309              | Dynamic braking resistor capacity                              | kW    | 0.01/0.01                                   | 0.01-30.00                                                                                                                                                                                                                             | *2              |              |           |
| F310  | 0310              | Factory specific coefficient 3A                                | -     | -                                           | -                                                                                                                                                                                                                                      | -               |              | *3        |
| F311  | 0311              | Reverse-run prohibition                                        | -     | -                                           | 0: Forward/reverse run permitted<br>1: Reverse run prohibited<br>2: Forward run prohibited                                                                                                                                             | 0               |              | 6.19.7    |
| F312  | 0312              | Random mode                                                    | -     | -                                           | 0: Disabled<br>1: Random mode 1<br>2: Random mode 2<br>3: Random mode 3                                                                                                                                                                | 0               |              | 6.18      |
| F314  | 0314              | Factory specific coefficient 3B                                | -     | -                                           | -                                                                                                                                                                                                                                      | -               |              | *3        |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*2: Default setting values vary depending on the capacity. Refer to section 11.4.

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

| Title         | Communication No. | Function                                                                                                      | Unit     | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                                                                                         | Default setting | User setting | Reference |
|---------------|-------------------|---------------------------------------------------------------------------------------------------------------|----------|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| <i>F 3 16</i> | 0316              | PWM carrier frequency control mode selection                                                                  | -        | -                                           | 0: Carrier frequency without reduction<br>1: Carrier frequency with automatic reduction<br>2: Carrier frequency without reduction<br>Support for 500V models<br>3: Carrier frequency with automatic reduction.<br>Support for 500V models                                                                                                                                                | 1               |              | 6.18      |
| <i>F 3 17</i> | 0317              | Synchronized deceleration time (time elapsed between start of deceleration to stop)                           | s        | 0.1/0.1                                     | 0.0-3600 (360.0)                                                                                                                                                                                                                                                                                                                                                                         | 2.0             |              | 6.19.2    |
| <i>F 3 18</i> | 0318              | Synchronized acceleration time (time elapsed between start of acceleration to achievement of specified speed) | s        | 0.1/0.1                                     | 0.0-3600 (360.0)                                                                                                                                                                                                                                                                                                                                                                         | 2.0             |              |           |
| <i>F 3 19</i> | 0319              | Regenerative over-excitation upper limit                                                                      | %        | 1/1                                         | 100-160                                                                                                                                                                                                                                                                                                                                                                                  | *1              |              | 6.19.5    |
| <i>F 3 20</i> | 0320              | Droop gain                                                                                                    | %        | 0.1/0.1                                     | 0.0-100.0                                                                                                                                                                                                                                                                                                                                                                                | 0.0             |              | 6.20      |
| <i>F 3 23</i> | 0323              | Droop insensitive torque band                                                                                 | %        | 1/1                                         | 0-100                                                                                                                                                                                                                                                                                                                                                                                    | 10              |              |           |
| <i>F 3 24</i> | 0324              | Droop output filter                                                                                           | -        | 0.1/0.1                                     | 0.1-200.0                                                                                                                                                                                                                                                                                                                                                                                | 100.0           |              |           |
| <i>F 3 25</i> | 0325              | Brake releasing waiting time                                                                                  | s        | 0.01/0.01                                   | 0.00-2.50                                                                                                                                                                                                                                                                                                                                                                                | 0.00            |              | 6.22.1    |
| <i>F 3 26</i> | 0326              | Brake releasing small current detection level                                                                 | %<br>(A) | 1/1                                         | 0-100 *12                                                                                                                                                                                                                                                                                                                                                                                | 0               |              |           |
| <i>F 3 27</i> | 0327              | Factory specific coefficient 3C                                                                               | -        | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                        | -               |              | * 3       |
| <i>F 3 28</i> | 0328              | Light-load high-speed operation selection                                                                     | -        | -                                           | 0:Disabled<br>1:High-speed operation speed set automatically (Power running at F command: Increase)<br>2:High-speed operation speed set automatically (Power running at R command: Increase)<br>3:High-speed operation speed set with <i>F 3 30</i> (Power running at F command: Increase)<br>4:High-speed operation speed set with <i>F 3 30</i> (Power running at R command: Increase) | 0               |              | 6.21      |
| <i>F 3 29</i> | 0329              | Light-load high-speed learning function                                                                       | -        | -                                           | 0:No learning<br>1:Forward run learning<br>2:Reverse run learning                                                                                                                                                                                                                                                                                                                        | 0               |              |           |
| <i>F 3 30</i> | 0330              | Automatic light-load high-speed operation frequency                                                           | Hz       | 0.1/0.01                                    | 30.0- <i>U<sub>L</sub></i>                                                                                                                                                                                                                                                                                                                                                               | *1              |              |           |
| <i>F 3 31</i> | 0331              | Light-load high-speed operation switching lower limit frequency                                               | Hz       | 0.1/0.01                                    | 5.0- <i>U<sub>L</sub></i>                                                                                                                                                                                                                                                                                                                                                                | 40.0            |              |           |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

\*12: When *F 70* != 1, adjustment range is 100%=rated current, or 100%=200V(240V class)/ 400V(500V class).

| Title | Communication No. | Function                                                  | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                         | Default setting | User setting | Reference |
|-------|-------------------|-----------------------------------------------------------|------|---------------------------------------------|------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| F 332 | 0332              | Light-load high-speed operation load waiting time         | s    | 0.1/0.1                                     | 0.0-10.0                                                                                 | 0.5             |              | 6.21      |
| F 333 | 0333              | Light-load high-speed operation load detection time       | s    | 0.1/0.1                                     | 0.0-10.0                                                                                 | 1.0             |              |           |
| F 334 | 0334              | Light-load high-speed operation heavy load detection time | s    | 0.1/0.1                                     | 0.0-10.0                                                                                 | 0.5             |              |           |
| F 335 | 0335              | Switching load torque during power running                | %    | 1/0.01                                      | -250- +250                                                                               | 50              |              |           |
| F 336 | 0336              | Heavy-load torque during power running                    | %    | 1/0.01                                      | -250- +250                                                                               | 100             |              |           |
| F 337 | 0337              | Heavy-load torque during constant power running           | %    | 1/0.01                                      | -250- +250                                                                               | 50              |              |           |
| F 338 | 0338              | Switching load torque during regenerative braking         | %    | 1/0.01                                      | -250- +250                                                                               | 50              |              |           |
| F 339 | 0339              | Factory specific coefficient 3D                           | -    | -                                           | -                                                                                        | -               |              | * 3       |
| F 340 | 0340              | Creeping time 1                                           | s    | 0.01/0.01                                   | 0.00-10.00                                                                               | 0.00            |              | 6.22.1    |
| F 341 | 0341              | Braking mode selection                                    | -    | -                                           | 0: Disabled<br>1: Forward winding up<br>2: Reverse winding up<br>3: Horizontal operation | 0               |              |           |
| F 342 | 0342              | Load portion torque input selection                       | -    | -                                           | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4: F 343         | 4               |              |           |
| F 343 | 0343              | Hoisting torque bias input (valid only when F 342=4)      | %    | 1/0.01                                      | -250- +250                                                                               | 100             |              |           |
| F 344 | 0344              | Lowering torque bias multiplier                           | %    | 1/0.01                                      | 0-100                                                                                    | 100             |              |           |
| F 345 | 0345              | Brake release time                                        | s    | 0.01/0.01                                   | 0.00-10.00                                                                               | 0.05            |              |           |
| F 346 | 0346              | Creeping frequency                                        | Hz   | 0.1/0.01                                    | F 240 -20.0                                                                              | 3.0             |              |           |
| F 347 | 0347              | Creeping time 2                                           | s    | 0.01/0.01                                   | 0.00-10.00                                                                               | 0.10            |              | 6.23      |
| F 348 | 0348              | Braking time learning function                            | -    | 1/1                                         | 0:Disabled<br>1: Learning (0 after adjustment)                                           | 0               |              |           |
| F 349 | 0349              | Acceleration/deceleration suspend function                | -    | 1/1                                         | 0:Disabled<br>1:Parameter setting<br>2:Terminal input                                    | 0               |              |           |
| F 350 | 0350              | Acceleration suspend frequency                            | Hz   | 0.1/0.01                                    | 0.0-F H                                                                                  | 0.0             |              |           |
| F 351 | 0351              | Acceleration suspend time                                 | s    | 0.1/0.1                                     | 0.0-10.0                                                                                 | 0.0             |              |           |
| F 352 | 0352              | Deceleration suspend frequency                            | Hz   | 0.1/0.01                                    | 0.0-F H                                                                                  | 0.0             |              |           |
| F 353 | 0353              | Deceleration suspend time                                 | s    | 0.1/0.1                                     | 0.0-10.0                                                                                 | 0.0             |              |           |
| F 359 | 0359              | PID control waiting time                                  | s    | 1/1                                         | 0-2400                                                                                   | 0               |              | 6.24      |
| F 360 | 0360              | PID control                                               | -    | -                                           | 0: Disabled<br>1: Process type PID control<br>2: Speed type PID control                  | 0               |              |           |

| Title | Communication No. | Function                                         | Unit            | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                    | Default setting | User setting | Reference |
|-------|-------------------|--------------------------------------------------|-----------------|---------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| F 361 | 0361              | Delay filter                                     | s               | 0.1/0.1                                     | 0.0-25.0                                                                                                                                                                                                                                                                            | 0.1             |              | 6.24      |
| F 362 | 0362              | Proportional gain                                | -               | 0.01/0.01                                   | 0.01-100.0                                                                                                                                                                                                                                                                          | 0.30            |              |           |
| F 363 | 0363              | Integral gain                                    | s <sup>-1</sup> | 0.01/0.01                                   | 0.01-100.0                                                                                                                                                                                                                                                                          | 0.20            |              |           |
| F 366 | 0366              | Differential gain                                | s               | 0.01/0.01                                   | 0.00-2.55                                                                                                                                                                                                                                                                           | 0.00            |              |           |
| F 367 | 0367              | Process upper limit                              | Hz              | 0.1/0.01                                    | 0.0- <i>F H</i>                                                                                                                                                                                                                                                                     | *1              |              |           |
| F 368 | 0368              | Process lower limit                              | Hz              | 0.1/0.01                                    | 0.0- <i>F 367</i>                                                                                                                                                                                                                                                                   | 0.0             |              |           |
| F 369 | 0369              | PID control feedback signal selection            | -               | -                                           | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4 to 6: -                                                                                                                                                                                                   | 0               |              | 6.10.5    |
| F 372 | 0372              | Process increasing rate (speed type PID control) | s               | 0.1/0.1                                     | 0.1-600.0                                                                                                                                                                                                                                                                           | 10.0            |              |           |
| F 373 | 0373              | Process decreasing rate (speed type PID control) | s               | 0.1/0.1                                     | 0.1-600.0                                                                                                                                                                                                                                                                           | 10.0            |              |           |
| F 375 | 0375              | Factory specific coefficient 3E                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              |           |
| F 376 | 0376              | Factory specific coefficient 3F                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              |           |
| F 378 | 0378              | Number of pulse train input                      | pps             | 1/1                                         | 10-500                                                                                                                                                                                                                                                                              | 25              |              |           |
| F 380 | 0380              | PID forward/reverse characteristics selection    | -               | -                                           | 0: Forward<br>1: Reverse                                                                                                                                                                                                                                                            | 0               |              | 6.24      |
| F 382 | 0382              | Hit and stop control                             | -               | -                                           | 0: Disabled<br>1: Enabled<br>2: -                                                                                                                                                                                                                                                   | 0               |              | 6.22.2    |
| F 383 | 0383              | Hit and stop control frequency                   | Hz              | 0.1/0.01                                    | 0.1-30.0                                                                                                                                                                                                                                                                            | 5.0             |              |           |
| F 384 | 0384              | Factory specific coefficient 3G                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              |           |
| F 385 | 0385              | Factory specific coefficient 3H                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              | * 3       |
| F 386 | 0386              | Factory specific coefficient 3I                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              |           |
| F 389 | 0389              | PID control reference signal selection           | -               | -                                           | 0: <i>F 383</i> / <i>F 3807</i> selected<br>1: Terminal VIA<br>2: Terminal VIB<br>3: <i>F P id</i><br>4: RS485 communication<br>5: UP/DOWN from external logic input<br>6: CANopen communication<br>7: Communication option<br>8: Terminal VIC<br>9, 10: -<br>11: Pulse train input | 0               |              | 6.24      |
| F 390 | 0390              | Factory specific coefficient 3J                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              | * 3       |
| F 391 | 0391              | Hysteresis for lower-limit frequency operation   | Hz              | 0.1/0.01                                    | 0.0- <i>L L</i>                                                                                                                                                                                                                                                                     | 0.2             |              | 6.13      |
| F 394 | 0394              | Factory specific coefficient 3K                  | -               | -                                           | -                                                                                                                                                                                                                                                                                   | -               |              | * 3       |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Torque boost parameters 1

| Title | Communication No. | Function                                               | Unit  | Minimum setting unit<br>Panel/Communication | Adjustment range                                                         | Default setting | User setting | Reference |
|-------|-------------------|--------------------------------------------------------|-------|---------------------------------------------|--------------------------------------------------------------------------|-----------------|--------------|-----------|
| F400  | 0400              | Auto-tuning                                            | -     | -                                           | 0: Auto-tuning disabled                                                  | 0               |              | 6.25      |
|       |                   |                                                        |       |                                             | 1: Initialization of F402 (after execution: 0)                           |                 |              |           |
|       |                   |                                                        |       |                                             | 2: Auto-tuning executed (after execution: 0)                             |                 |              |           |
|       |                   |                                                        |       |                                             | 3: -                                                                     |                 |              |           |
|       |                   |                                                        |       |                                             | 4: Motor constant auto calculation (after execution: 0)                  |                 |              |           |
|       |                   |                                                        |       |                                             | 5: 4+2 (after execution: 0)                                              |                 |              |           |
| F401  | 0401              | Slip frequency gain                                    | %     | 1/1                                         | 0-250                                                                    | 70              |              |           |
| F402  | 0402              | Automatic torque boost value                           | %     | 0.1/0.1                                     | 0.1-30.0                                                                 | * 2             |              |           |
| F405  | 0405              | Motor rated capacity                                   | kW    | 0.01/0.01                                   | 0.01-22.00                                                               | * 2             |              |           |
| F412  | 0412              | Motor specific coefficient 1                           | -     | -                                           | -                                                                        | -               |              | * 4       |
| F415  | 0415              | Motor rated current                                    | A     | 0.01/0.01                                   | 0.01-100.0                                                               | * 2             |              | 6.25      |
| F416  | 0416              | Motor no-load current                                  | %     | 1/1                                         | 10-90                                                                    | * 2             |              |           |
| F417  | 0417              | Motor rated speed                                      | min-1 | 1/1                                         | 100-64000                                                                | *1              |              |           |
| F441  | 0441              | Power running torque limit 1 level                     | %     | 1/1                                         | 0-249%,<br>250:Disabled                                                  | 250             |              | 6.26.1    |
| F443  | 0443              | Regenerative braking torque limit 1 level              | %     | 1/1                                         | 0-249%,<br>250:Disabled                                                  | 250             |              |           |
| F444  | 0444              | Power running torque limit 2 level                     | %     | 1/1                                         | 0-249%,<br>250:Disabled                                                  | 250             |              |           |
| F445  | 0445              | Regenerative braking torque limit 2 level              | %     | 1/1                                         | 0-249%,<br>250:Disabled                                                  | 250             |              |           |
| F451  | 0451              | Acceleration/deceleration operation after torque limit | -     | 1/1                                         | 0: In sync with acceleration / deceleration<br>1: In sync with min. time | 0               |              | 6.26.2    |
| F452  | 0452              | Power running stall continuous trip detection time     | s     | 0.01/0.01                                   | 0.00-10.00                                                               | 0.00            |              | 6.26.3    |
| F454  | 0454              | Constant output zone torque limit selection            | -     | -                                           | 0:Constant output limit<br>1:Constant torque limit                       | 0               |              | 6.26.1    |
| F458  | 0458              | Motor specific coefficient 2                           | -     | -                                           | -                                                                        | -               |              | * 4       |
| F459  | 0459              | Load inertia moment ratio                              | Times | 0.1/0.1                                     | 0.1-100.0                                                                | 1.0             |              | 6.25      |
| F460  | 0460              | Motor specific coefficient 3                           | -     | -                                           | -                                                                        | -               |              | * 4       |
| F461  | 0461              | Motor specific coefficient 4                           | -     | -                                           | -                                                                        | -               |              |           |
| F462  | 0462              | Speed reference filter coefficient                     | -     | -                                           | 0-100                                                                    | 35              |              | 6.25      |
| F467  | 0467              | Motor specific coefficient 5                           | -     | -                                           | -                                                                        | -               |              | * 4       |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*2: Default setting values vary depending on the capacity. Refer to section 11.4.

\*4: Motor specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Input/output parameters 2

| Title   | Communication No. | Function       | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range | Default setting | User setting | Reference |
|---------|-------------------|----------------|------|---------------------------------------------|------------------|-----------------|--------------|-----------|
| F 4 7 0 | 0470              | VIA input bias | -    | 1/1                                         | 0-255            | 128             |              | 6.10.3    |
| F 4 7 1 | 0471              | VIA input gain | -    | 1/1                                         | 0-255            | 128             |              |           |
| F 4 7 2 | 0472              | VIB input bias | -    | 1/1                                         | 0-255            | 128             |              |           |
| F 4 7 3 | 0473              | VIB input gain | -    | 1/1                                         | 0-255            | 128             |              |           |
| F 4 7 4 | 0474              | VIC input bias | -    | 1/1                                         | 0-255            | 128             |              |           |
| F 4 7 5 | 0475              | VIC input gain | -    | 1/1                                         | 0-255            | 128             |              |           |

• Torque boost parameters 2

| Title   | Communications No. | Function                      | Unit | Minimum setting unit<br>Panel/Communications | Adjustment range | Default setting | User setting | Reference |
|---------|--------------------|-------------------------------|------|----------------------------------------------|------------------|-----------------|--------------|-----------|
| F 4 8 0 | 0480               | Motor specific coefficient 6  | -    | -                                            | -                | -               |              | * 4       |
| F 4 8 5 | 0485               | Motor specific coefficient 7  | -    | -                                            | -                | -               |              |           |
| F 4 9 0 | 0490               | Motor specific coefficient 8  | -    | -                                            | -                | -               |              |           |
| F 4 9 3 | 0493               | Motor specific coefficient 11 | -    | -                                            | -                | -               |              |           |
| F 4 9 5 | 0495               | Motor specific coefficient 9  | -    | -                                            | -                | -               |              |           |
| F 4 9 9 | 0499               | Motor specific coefficient 10 | -    | -                                            | -                | -               |              |           |

\*4: Motor specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Acceleration/deceleration time parameters

| Title   | Communication No. | Function                                                        | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                   | Default setting | User setting | Reference |
|---------|-------------------|-----------------------------------------------------------------|------|---------------------------------------------|----------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| F 5 0 0 | 0500              | Acceleration time 2                                             | s    | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                                                | 10.0            |              | 6.27.2    |
| F 5 0 1 | 0501              | Deceleration time 2                                             | s    | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                                                | 10.0            |              |           |
| F 5 0 2 | 0502              | Acceleration/deceleration 1 pattern                             | -    | -                                           | 0: Linear<br>1: S-pattern 1                                                                        | 0               |              | 6.27.1    |
| F 5 0 3 | 0503              | Acceleration/deceleration 2 pattern                             | -    | -                                           | 2: S-pattern 2                                                                                     | 0               |              | 6.27.2    |
| F 5 0 4 | 0504              | Acceleration/deceleration selection (1, 2, 3)<br>(Panel keypad) | -    | -                                           | 1: Acceleration/deceleration 1<br>2: Acceleration/deceleration 2<br>3: Acceleration/deceleration 3 | 1               |              | 6.27.1    |
| F 5 0 5 | 0505              | Acceleration/deceleration 1 and 2 switching frequency           | Hz   | 0.1/0.01                                    | 0.0 (disabled)<br>0.1-UL                                                                           | 0.0             |              |           |
| F 5 0 6 | 0506              | S-pattern lower-limit adjustment amount                         | %    | 1/1                                         | 0-50                                                                                               | 10              |              |           |
| F 5 0 7 | 0507              | S-pattern upper-limit adjustment amount                         | %    | 1/1                                         | 0-50                                                                                               | 10              |              |           |

\*8: These parameters can be changed to 0.01s unit by setting F 5 1 9 = 1.

| Title | Communication No. | Function                                              | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                | Default setting | User setting | Reference     |
|-------|-------------------|-------------------------------------------------------|------|---------------------------------------------|---------------------------------------------------------------------------------|-----------------|--------------|---------------|
| F510  | 0510              | Acceleration time 3                                   | s    | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                             | 10.0            |              | 6.27.2        |
| F511  | 0511              | Deceleration time 3                                   | s    | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                             | 10.0            |              |               |
| F512  | 0512              | Acceleration/deceleration 3 pattern                   | -    | -                                           | 0: Linear<br>1: S-pattern 1<br>2: S-pattern 2                                   | 0               |              |               |
| F513  | 0513              | Acceleration/deceleration 2 and 3 switching frequency | Hz   | 0.1/0.01                                    | 0.0 (disabled)<br>0.1-111                                                       | 0.0             |              |               |
| F515  | 0515              | Deceleration time at emergency stop                   | s    | 0.1/0.1                                     | 0.0-3600 (360.0) *8                                                             | 10.0            |              | 6.29.4        |
| F519  | 0519              | Setting of acceleration/deceleration time unit        | -    | -                                           | 0: -<br>1: 0.01s unit (after execution: 0)<br>2: 0.1s unit (after execution: 0) | 0               |              | 5.2<br>6.27.2 |
| F590  | 0590              | Shock monitoring                                      | -    | -                                           | 0: Disabled<br>1: Current detection<br>2: Torque detection                      | 0               |              | 6.28          |
| F591  | 0591              | Shock monitoring trip/alarm selection                 | -    | -                                           | 0: Alarm only<br>1: Tripping                                                    | 0               |              |               |
| F592  | 0592              | Shock monitoring detection direction selection        | -    | -                                           | 0: Over-current / torque detection<br>1: Low-current / torque detection         | 0               |              |               |
| F593  | 0593              | Shock monitoring detection level                      | %    | 1/0.01                                      | 0-250                                                                           | 150             |              |               |
| F595  | 0595              | Shock monitoring detection time                       | s    | 0.1/0.1                                     | 0.0-10.0                                                                        | 0.5             |              |               |
| F596  | 0596              | Shock monitoring detection hysteresis                 | %    | 1/0.01                                      | 0-100                                                                           | 10              |              |               |
| F597  | 0597              | Shock monitoring detection start waiting time         | s    | 0.1/0.1                                     | 0.0-300.0                                                                       | 0.0             |              |               |
| F598  | 0598              | Shock monitoring detection action selection           | -    | -                                           | 0: During operation<br>1: During operation (except acceleration / deceleration) | 0               |              |               |

\*8: These parameters can be changed to 0.01s unit by setting F519=1.

• Protection parameters

| Title   | Communication No. | Function                                      | Unit         | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                | Default setting | User setting | Reference        |
|---------|-------------------|-----------------------------------------------|--------------|---------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|------------------|
| F 6 0 1 | 0601              | Stall prevention level 1                      | %<br>(A)     | 1/1                                         | 10-199, *12<br>200 (disabled)                                                                                                                                                                   | 150             |              | 6.29.2           |
| F 6 0 2 | 0602              | Inverter trip retention selection             | -            | -                                           | 0: Cleared with power off<br>1: Retained with power off                                                                                                                                         | 0               |              | 6.29.3           |
| F 6 0 3 | 0603              | Emergency stop selection                      | -            | -                                           | 0: Coast stop<br>1: Deceleration stop<br>2: Emergency DC braking<br>3: Deceleration stop (F 5 1 5)<br>4: Quick deceleration stop<br>5: Dynamic quick deceleration stop                          | 0               |              | 6.29.4           |
| F 6 0 4 | 0604              | DC braking time during emergency stop         | s            | 0.1/0.1                                     | 0.0-20.0                                                                                                                                                                                        | 1.0             |              |                  |
| F 6 0 5 | 0605              | Output phase failure detection selection      | -            | -                                           | 0: Disabled<br>1: At start-up (only one time after power on)<br>2: At start-up (each time)<br>3: During operation<br>4: At start-up + during operation<br>5: Detection of cutoff on output side | 0               |              | 6.29.5           |
| F 6 0 7 | 0607              | Motor 150% overload detection time            | s            | 1/1                                         | 10-2400                                                                                                                                                                                         | 300             |              | 5.6<br>6.29.1    |
| F 6 0 8 | 0608              | Input phase failure detection selection       | -            | -                                           | 0: Disabled<br>1: Enabled                                                                                                                                                                       | 1               |              | 6.29.6           |
| F 6 0 9 | 0609              | Small current detection hysteresis            | %            | 1/1                                         | 1-20                                                                                                                                                                                            | 10              |              | 6.29.7           |
| F 6 1 0 | 0610              | Small current trip/alarm selection            | -            | -                                           | 0: Alarm only<br>1: Tripping                                                                                                                                                                    | 0               |              |                  |
| F 6 1 1 | 0611              | Small current detection current               | %<br>(A)     | 1/1                                         | 0-150 *12                                                                                                                                                                                       | 0               |              |                  |
| F 6 1 2 | 0612              | Small current detection time                  | s            | 1/1                                         | 0-255                                                                                                                                                                                           | 0               |              |                  |
| F 6 1 3 | 0613              | Detection of output short-circuit at start-up | -            | -                                           | 0: Each time (standard pulse)<br>1: Only one time after power on (standard pulse)<br>2: Each time (short pulse)<br>3: Only one time after power on (short pulse)                                | 0               |              | 6.29.8           |
| F 6 1 4 | 0614              | Ground fault detection selection              | -            | -                                           | 0: Disabled<br>1: Enabled                                                                                                                                                                       | 1               |              | 6.29.9           |
| F 6 1 5 | 0615              | Over-torque trip/alarm selection              | -            | -                                           | 0: Alarm only<br>1: Tripping                                                                                                                                                                    | 0               |              | 6.29.10          |
| F 6 1 6 | 0616              | Over-torque detection level                   | %            | 1/0.01                                      | 0 (disabled)<br>1-250                                                                                                                                                                           | 150             |              |                  |
| F 6 1 8 | 0618              | Over-torque detection time                    | s            | 0.1/0.1                                     | 0.0-10.0                                                                                                                                                                                        | 0.5             |              |                  |
| F 6 1 9 | 0619              | Over-torque detection hysteresis              | %            | 1/0.01                                      | 0-100                                                                                                                                                                                           | 10              |              |                  |
| F 6 2 0 | 0620              | Cooling fan ON/OFF control                    | -            | -                                           | 0: ON/OFF control<br>1: Always ON<br>2-7: -                                                                                                                                                     | 0               |              | 6.29.11          |
| F 6 2 1 | 0621              | Cumulative operation time alarm setting       | 100<br>hours | 0.1/0.1<br>(=10 hours)                      | 0.0-999.0                                                                                                                                                                                       | 876.0           |              | 6.29.12          |
| F 6 2 5 | 0625              | Factory specific coefficient 6A               | -            | -                                           | -                                                                                                                                                                                               | -               |              | *3               |
| F 6 2 6 | 0626              | Over-voltage stall protection level           | %            | 1/1                                         | 100-150                                                                                                                                                                                         | *2              |              | 6.19.4<br>6.19.5 |

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

\*12: When F 7 0 1 = 1, adjustment range is 100%=rated current, or 100%=200V(240V class)/ 400V(500V class).

| Title | Communication No. | Function                                                      | Unit        | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                   | Default setting | User setting | Reference     |
|-------|-------------------|---------------------------------------------------------------|-------------|---------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|---------------|
| F627  | 0627              | Undervoltage trip/alarm selection                             | -           | -                                           | 0: Alarm only (detection level 60% or less)<br>1: Tripping (detection level 60% or less)<br>2: Alarm only (detection level 50% or less, input AC or DC reactor required)<br>3: -                                                                   | 0               |              | 6.29.13       |
| F629  | 0629              | Factory specific coefficient 6B                               | -           | -                                           | -                                                                                                                                                                                                                                                  | -               |              | *3            |
| F631  | 0631              | Inverter overload detection method                            | -           | -                                           | 0: 150%-60s (120%-60s)<br>1: Temperature estimation                                                                                                                                                                                                | 0               |              | 5.6           |
| F632  | 0632              | Electronic-thermal memory                                     | -           | -                                           | 0: Disabled ( $\leq H_r, F173$ )<br>1: Enabled ( $\leq H_r, F173$ )<br>2: Disabled ( $\leq H_r$ )<br>3: Enabled ( $\leq H_r$ )                                                                                                                     | 0               |              | 5.6<br>6.29.1 |
| F633  | 0633              | Analog input break detection level (VIC)                      | %           | 1/1                                         | 0: Disabled,<br>1-100                                                                                                                                                                                                                              | 0               |              | 6.29.14       |
| F634  | 0634              | Annual average ambient temperature (parts replacement alarms) | -           | -                                           | 1: -10 to +10°C<br>2: 11-20°C<br>3: 21-30°C<br>4: 31-40°C<br>5: 41-50°C<br>6: 51-60°C                                                                                                                                                              | 3               |              | 6.29.15       |
| F643  | 0643              | Factory specific coefficient 6C                               | -           | -                                           | -                                                                                                                                                                                                                                                  | -               |              | *3            |
| F644  | 0644              | Operation selection of analog input break detection (VIC)     | -           | -                                           | 0: Tripping<br>1: Alarm only (Coast stop)<br>2: Alarm only (F649 frequency)<br>3: Alarm only (Maintain running)<br>4: Alarm only (Deceleration stop)                                                                                               | 0               |              | 6.29.14       |
| F645  | 0645              | PTC thermal selection                                         | -           | -                                           | 1: Tripping<br>2: Alarm only                                                                                                                                                                                                                       | 1               |              | 6.29.16       |
| F646  | 0646              | PTC detection resistor value                                  | $\Omega$    | 1/1                                         | 100-9999                                                                                                                                                                                                                                           | 3000            |              |               |
| F648  | 0648              | Number of starting alarm                                      | 10000 times | 0.1/0.1                                     | 0.0-999.0                                                                                                                                                                                                                                          | 999.0           |              | 6.29.17       |
| F649  | 0649              | Fallback frequency                                            | Hz          | 0.1/0.01                                    | $\frac{1}{L} - \frac{U}{L}$                                                                                                                                                                                                                        | 0.0             |              | 6.29.14       |
| F650  | 0650              | Forced fire-speed control selection                           | -           | -                                           | 0: Disabled<br>1: Enabled                                                                                                                                                                                                                          | 0               |              | 6.30          |
| F656  | 0656              | Factory specific coefficient 6D                               | -           | -                                           | -                                                                                                                                                                                                                                                  | -               |              | *3            |
| F657  | 0657              | Overload alarm level                                          | %           | 1/1                                         | 10-100                                                                                                                                                                                                                                             | 50              |              | 5.6           |
| F660  | 0660              | Override addition input selection                             | -           | -                                           | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4: F661                                                                                                                                                                    | 0               |              | 6.31          |
| F661  | 0661              | Override multiplication input selection                       | -           | -                                           | 0: Disabled<br>1: Terminal VIA<br>2: Terminal VIB<br>3: Terminal VIC<br>4: F660                                                                                                                                                                    | 0               |              |               |
| F663  | 0663              | Analog input terminal function selection (VIB)                | -           | -                                           | 0: Frequency command<br>1: Acceleration/deceleration time<br>2: Upper limit frequency<br>3, 4: -<br>5: Torque boost value<br>6: Stall prevention level<br>7: Motor electronic-thermal protection level<br>8 to 10: -<br>11: Base frequency voltage | 0               |              | 6.32          |

\*2: Default setting values vary depending on the capacity. Refer to section 11.4.

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Output parameters

| Title   | Communication No. | Function                                        | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Default setting | User setting | Reference     |
|---------|-------------------|-------------------------------------------------|------|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|---------------|
| F 6 6 7 | 0667              | Integral input power pulse output unit          | -    | -                                           | 0: 0.1kWh<br>1: 1kWh<br>2: 10kWh<br>3: 100kWh                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 1               |              | 6.33.1        |
| F 6 6 8 | 0668              | Integral input power pulse output width         | s    | 0.1/0.1                                     | 0.1-1.0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 0.1             |              |               |
| F 6 6 9 | 0669              | Logic output/pulse train output selection (OUT) | -    | -                                           | 0: Logic output<br>1: Pulse train output                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | 0               |              | 6.33.2        |
| F 6 7 6 | 0676              | Pulse train output function selection (OUT)     | -    | -                                           | 0: Output frequency<br>1: Output current<br>2: Frequency command value<br>3: Input voltage (DC detection)<br>4: Output voltage (command value)<br>5: Input power<br>6: Output power<br>7: Torque<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency<br>13: V/A input value<br>14: V/B input value<br>15: Fixed output 1 (output current 100% equivalent)<br>16: Fixed output 2 (output current 50% equivalent)<br>17: Fixed output 3 (Other than the output current)<br>18: Communication data<br>19: -<br>20: V/C input value<br>21, 22: -<br>23: PID feedback value | 0               |              |               |
| F 6 7 7 | 0677              | Maximum numbers of pulse train output           | kpps | 0.01/0.01                                   | 0.50-2.00                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | 0.80            |              | 6.10.5        |
| F 6 7 8 | 0678              | Pulse train output filter                       | ms   | 1/1                                         | 2-1000                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 64              |              |               |
| F 6 7 9 | 0679              | Pulse train input filter                        | ms   | 1/1                                         | 2-1000                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 2               |              | 6.10.5        |
| F 6 8 1 | 0681              | Analog output signal selection                  | -    | -                                           | 0: Meter option (0 to 1 mA)<br>1: Current (0 to 20 mA) output<br>2: Voltage (0 to 10 V) output                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 0               |              |               |
| F 6 8 4 | 0684              | Analog output filter                            | ms   | 1/1                                         | 2-1000                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | 2               |              | 5.1<br>6.33.3 |
| F 6 9 1 | 0691              | Inclination characteristic of analog output     | -    | -                                           | 0: Negative inclination (downward slope)<br>1: Positive inclination (upward slope)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | 1               |              |               |
| F 6 9 2 | 0692              | Analog output bias                              | %    | 0.1/0.1                                     | -1.0--+100.0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | 0.0             |              | * 3           |
| F 6 9 3 | 0693              | Factory specific coefficient 6E                 | -    | -                                           | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | -               |              |               |

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Operation panel parameters

| Title | Communication No. | Function                                        | Unit  | Minimum setting unit Panel/Communication | Adjustment range                                                                                                                                                                                                             | Default setting | User setting | Reference |
|-------|-------------------|-------------------------------------------------|-------|------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| F 700 | 0700              | Parameter protection selection                  | -     | -                                        | 0: Permitted<br>1: Writing prohibited (Panel and extension panel)<br>2: Writing prohibited (1 + RS485 communication)<br>3: Reading prohibited (Panel and extension panel)<br>4: Reading prohibited (3 + RS485 communication) | 0               |              | 6.34.1    |
| F 701 | 0701              | Current/voltage unit selection                  | -     | -                                        | 0: %<br>1: A (ampere)/V (volt)                                                                                                                                                                                               | 0               |              | 5.10.1    |
| F 702 | 0702              | Frequency free unit display magnification       | Times | 0.01/0.01                                | 0.00: Disabled (display of frequency)<br>0.01-200.0                                                                                                                                                                          | 0.00            |              | 5.10.2    |
| F 703 | 0703              | Frequency free unit coverage selection          | -     | 1/1                                      | 0: All frequencies display<br>1: PID frequencies display                                                                                                                                                                     | 0               |              |           |
| F 705 | 0705              | Inclination characteristic of free unit display | -     | 1/1                                      | 0: Negative inclination (downward slope)<br>1: Positive inclination (upward slope)                                                                                                                                           | 1               |              |           |
| F 706 | 0706              | Free unit display bias                          | Hz    | 0.01/0.01                                | 0.00- $F_H$                                                                                                                                                                                                                  | 0.00            |              |           |
| F 707 | 0707              | Free step 1 (1-step rotation of setting dial)   | Hz    | 0.01/0.01                                | 0.00: Automatic<br>0.01- $F_H$                                                                                                                                                                                               | 0.00            |              | 6.34.4    |
| F 708 | 0708              | Free step 2 (panel display)                     | -     | -                                        | 0: Automatic<br>1-255                                                                                                                                                                                                        | 0               |              |           |
| F 709 | 0709              | Standard monitor hold function                  | -     | -                                        | 0: Real time<br>1: Peak hold<br>2: Minimum hold                                                                                                                                                                              | 0               |              | 6.34.7    |

| Title | Communication No. | Function                        | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Default setting | User setting | Reference                |
|-------|-------------------|---------------------------------|------|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|--------------------------|
| F710  | 0710              | Initial panel display selection | -    | -                                           | 0: Output frequency (Hz/free unit)<br>1: Output current (%A)<br>2: Frequency command value (Hz/free unit)<br>3: Input voltage (DC detection) (%V)<br>4: Output voltage (command value) (%V)<br>5: Input power (kW)<br>6: Output power (kW)<br>7: Torque (%)<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency (Hz/free unit)<br>13: VIA input value (%)<br>14: VIB input value (%)<br>15 to 17: -<br>18: Arbitrary code from communication<br>19: -<br>20: VIC input value (%)<br>21: Pulse train input value (pps)<br>22: -<br>23: PID feedback value (Hz/free unit)<br>24: Integral input power (kWh)<br>25: Integral output power (kWh)<br>26: Motor load factor (%)<br>27: Inverter load factor (%)<br>28: Inverter rated current (A)<br>29: FM output value (%)<br>30: Pulse train output value (pps)<br>31: Cumulative power on time (100 hours)<br>32: Cumulative fan operation time (100 hours)<br>33: Cumulative operation time (100 hours)<br>34: Number of starting (10000 times)<br>35: Forward number of starting (10000 times)<br>36: Reverse number of starting (10000 times)<br>37: Number of trip (times)<br>38, 39: -<br>40: Inverter rated current (Carrier frequency corrected)<br>41 to 51: -<br>52: Frequency command value / output frequency (Hz/free unit) | 0               |              | 6.34.5<br>8.2.1<br>8.3.2 |

| Title   | Communication No. | Function                                           | Unit | Minimum setting unit Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Default setting | User setting | Reference                |
|---------|-------------------|----------------------------------------------------|------|------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|--------------------------|
| F 7 1 1 | 0711              | Status monitor 1                                   | -    | -                                        | 0: Output frequency (Hz/free unit)<br>1: Output current (%A)<br>2: Frequency command value (Hz/free unit)<br>3: Input voltage (DC detection) (%V)<br>4: Output voltage (command value) (%V)<br>5: Input power (kW)<br>6: Output power (kW)<br>7: Torque (%)<br>8: -<br>9: Motor cumulative load factor<br>10: Inverter cumulative load factor<br>11: PBR (Braking resistor) cumulative load factor<br>12: Stator frequency (Hz/free unit)<br>13: VIA input value (%)<br>14: VIB input value (%)<br>15 to 17: -<br>18: Arbitrary code from communication<br>19: -<br>20: VIC input value (%)<br>21: Pulse train input value (pps)<br>22: - | 2               |              | 6.34.6<br>8.2.1<br>8.3.2 |
| F 7 1 2 | 0712              | Status monitor 2                                   | -    | -                                        | 23: PID feedback value (Hz/free unit)<br>24: Integral input power (kWh)<br>25: Integral output power (kWh)<br>26: Motor load factor (%)<br>27: Inverter load factor (%)<br>28: Inverter rated current (A)<br>29: FM output value (%)<br>30: Pulse train output value (pps)<br>31: Cumulative power on time (100 hours)<br>32: Cumulative fan operation time (100 hours)<br>33: Cumulative operation time (100 hours)<br>34: Number of starting (10000 times)<br>35: Forward number of starting (10000 times)                                                                                                                              | 1               |              |                          |
| F 7 1 3 | 0713              | Status monitor 3                                   | -    | -                                        | 36: Reverse number of starting (10000 times)<br>37: Number of trip (times)<br>38, 39: -<br>40: Inverter rated current (Carrier frequency corrected)<br>41 to 51: -<br>52: Frequency command value / output frequency (Hz/free unit)                                                                                                                                                                                                                                                                                                                                                                                                       | 3               |              |                          |
| F 7 1 4 | 0714              | Status monitor 4                                   | -    | -                                        | 0: Clear at coast stop and retained at $\overline{R} \overline{D} F F$<br>1: Retained at coast stop and $\overline{R} \overline{D} F F$<br>2: Clear at coast stop and $\overline{R} \overline{D} F F$<br>3: 2+ clear when $\overline{C} \overline{R} \overline{D} d$ is changed                                                                                                                                                                                                                                                                                                                                                           | 4               |              |                          |
| F 7 1 5 | 0715              | Status monitor 5                                   | -    | -                                        | 0-52 (Same as F 7 1 0)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | 5               |              |                          |
| F 7 1 6 | 0716              | Status monitor 6                                   | -    | -                                        | 0: Deceleration stop<br>1: Coast stop                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | 6               |              |                          |
| F 7 1 7 | 0717              | Status monitor 7                                   | -    | -                                        | 0: Panel frequency ( $F \overline{C}$ )<br>1: Panel frequency ( $F \overline{C}$ ) + Preset speed frequency                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 27              |              |                          |
| F 7 1 8 | 0718              | Status monitor 8                                   | -    | -                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 0               |              |                          |
| F 7 1 9 | 0719              | Selection of operation command clear               | -    | -                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 1               |              | 6.34.8                   |
| F 7 2 0 | 0720              | Initial extension panel display selection          | -    | -                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 0               |              | 6.34.5                   |
| F 7 2 1 | 0721              | Panel stop pattern                                 | -    | -                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 0               |              | 6.34.9                   |
| F 7 2 4 | 0724              | Operation frequency setting target by setting dial | -    | -                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 1               |              | 5.7                      |

| Title | Communication No. | Function                                        | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                        | Default setting | User setting | Reference |
|-------|-------------------|-------------------------------------------------|------|---------------------------------------------|-------------------------------------------------------------------------|-----------------|--------------|-----------|
| F 729 | 0729              | Operation panel override multiplication gain    | %    | 1/0.01                                      | -100-+100                                                               | 0               |              | 6.31      |
| F 730 | 0730              | Panel frequency setting prohibition (F 73)      | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 0               |              | 6.34.1    |
| F 731 | 0731              | Disconnection detection of extension panel      | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 0               |              |           |
| F 732 | 0732              | Local/remote key prohibition of extension panel | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 1               |              |           |
| F 733 | 0733              | Panel operation prohibition (RUN key)           | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 0               |              | 6.34.1    |
| F 734 | 0734              | Panel emergency stop operation prohibition      | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 0               |              |           |
| F 735 | 0735              | Panel reset operation prohibition               | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 0               |              |           |
| F 736 | 0736              | Load/FROD change prohibition during operation   | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 1               |              |           |
| F 737 | 0737              | All key operation prohibition                   | -    | -                                           | 0: Permitted<br>1: Prohibited                                           | 0               |              |           |
| F 738 | 0738              | Password setting (F 700)                        | -    | -                                           | 0: Password unset<br>1-9998<br>9999: Password set                       | 0               |              |           |
| F 739 | 0739              | Password verification                           | -    | -                                           | 0: Password unset<br>1-9998<br>9999: Password set                       | 0               |              |           |
| F 740 | 0740              | Trace selection                                 | -    | -                                           | 0: Disabled<br>1: At tripping<br>2: At triggering<br>3: 1+2             | 1               |              | 6.35      |
| F 741 | 0741              | Trace cycle                                     | -    | -                                           | 0: 4ms<br>1: 20ms<br>2: 100ms<br>3: 1s<br>4: 10s                        | 2               |              |           |
| F 742 | 0742              | Trace data 1                                    | -    | -                                           | 0-42                                                                    | 0               |              |           |
| F 743 | 0743              | Trace data 2                                    | -    | -                                           |                                                                         | 1               |              |           |
| F 744 | 0744              | Trace data 3                                    | -    | -                                           |                                                                         | 2               |              |           |
| F 745 | 0745              | Trace data 4                                    | -    | -                                           |                                                                         | 3               |              |           |
| F 746 | 0746              | Status monitor filter                           | ms   | 1/1                                         | 8-1000                                                                  | 200             |              | 6.34.7    |
| F 748 | 0748              | Integrating wattmeter retention selection       | -    | -                                           | 0: Disabled<br>1: Enabled                                               | 0               |              | 6.36      |
| F 749 | 0749              | Integrating wattmeter display unit selection    | -    | -                                           | 0: 1=1kWh<br>1: 1=10kWh<br>2: 1=100kWh<br>3: 1=1000kWh<br>4: 1=10000kWh | *2              |              |           |

\*2: Default setting values vary depending on the capacity. Refer to section 11.4.

| Title  | Communication No. | Function                       | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                         | Default setting | User setting | Reference           |
|--------|-------------------|--------------------------------|------|---------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|---------------------|
| F 75 0 | 0750              | EASY key function selection    | -    | -                                           | 0: Easy / standard setting mode switching function<br>1: Shortcut key<br>2: Local / remote key<br>3: Monitor peak / minimum hold trigger<br>4: -<br>5: - | 0               |              | 4.5<br>6.16<br>6.37 |
| F 75 1 | 0751              | Easy setting mode parameter 1  | -    | -                                           | 0-2999<br>(Set by communication number)                                                                                                                  | 3<br>(CMod)     |              | 4.5<br>6.37         |
| F 75 2 | 0752              | Easy setting mode parameter 2  | -    | -                                           |                                                                                                                                                          | 4<br>(FMod)     |              |                     |
| F 75 3 | 0753              | Easy setting mode parameter 3  | -    | -                                           |                                                                                                                                                          | 9<br>(ACC)      |              |                     |
| F 75 4 | 0754              | Easy setting mode parameter 4  | -    | -                                           |                                                                                                                                                          | 10<br>(dEC)     |              |                     |
| F 75 5 | 0755              | Easy setting mode parameter 5  | -    | -                                           |                                                                                                                                                          | 12<br>(UL)      |              |                     |
| F 75 6 | 0756              | Easy setting mode parameter 6  | -    | -                                           |                                                                                                                                                          | 13<br>(LL)      |              |                     |
| F 75 7 | 0757              | Easy setting mode parameter 7  | -    | -                                           |                                                                                                                                                          | 600<br>(tHr)    |              |                     |
| F 75 8 | 0758              | Easy setting mode parameter 8  | -    | -                                           |                                                                                                                                                          | 6<br>(FM)       |              |                     |
| F 75 9 | 0759              | Easy setting mode parameter 9  | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 0 | 0760              | Easy setting mode parameter 10 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 1 | 0761              | Easy setting mode parameter 11 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 2 | 0762              | Easy setting mode parameter 12 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 3 | 0763              | Easy setting mode parameter 13 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 4 | 0764              | Easy setting mode parameter 14 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 5 | 0765              | Easy setting mode parameter 15 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 6 | 0766              | Easy setting mode parameter 16 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 7 | 0767              | Easy setting mode parameter 17 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 8 | 0768              | Easy setting mode parameter 18 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 76 9 | 0769              | Easy setting mode parameter 19 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 0 | 0770              | Easy setting mode parameter 20 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 1 | 0771              | Easy setting mode parameter 21 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 2 | 0772              | Easy setting mode parameter 22 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 3 | 0773              | Easy setting mode parameter 23 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 4 | 0774              | Easy setting mode parameter 24 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 5 | 0775              | Easy setting mode parameter 25 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 6 | 0776              | Easy setting mode parameter 26 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |
| F 77 7 | 0777              | Easy setting mode parameter 27 | -    | -                                           |                                                                                                                                                          | 999             |              |                     |

| Title | Communication No. | Function                                                       | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                              | Default setting | User setting | Reference   |
|-------|-------------------|----------------------------------------------------------------|------|---------------------------------------------|---------------------------------------------------------------|-----------------|--------------|-------------|
| F 778 | 0778              | Easy setting mode parameter 28                                 | -    | -                                           | 0-2999<br>(Set by communication number)                       | 999             |              | 4.5<br>6.37 |
| F 779 | 0779              | Easy setting mode parameter 29                                 | -    | -                                           |                                                               | 999             |              |             |
| F 780 | 0780              | Easy setting mode parameter 30                                 | -    | -                                           |                                                               | 999             |              |             |
| F 781 | 0781              | Easy setting mode parameter 31                                 | -    | -                                           |                                                               | 701<br>(F701)   |              |             |
| F 782 | 0782              | Easy setting mode parameter 32                                 | -    | -                                           |                                                               | 50<br>(PSEL)    |              |             |
| F 790 | 0790              | Panel display selection at power on                            | -    | -                                           | 0: <i>HELL0</i><br>1: <i>F 791</i> to <i>F 794</i><br>2, 3: - | 0               |              | 6.34.10     |
| F 791 | 0791              | 1 <sup>st</sup> and 2 <sup>nd</sup> characters of <i>F 790</i> | hex  | -                                           | 0-FFFF                                                        | 2d2d            |              |             |
| F 792 | 0792              | 3 <sup>rd</sup> and 4 <sup>th</sup> characters of <i>F 790</i> | hex  | -                                           | 0-FFFF                                                        | 2d2d            |              |             |
| F 793 | 0793              | 5 <sup>th</sup> and 6 <sup>th</sup> characters of <i>F 790</i> | hex  | -                                           | 0-FFFF                                                        | 2d2d            |              |             |
| F 794 | 0794              | 7 <sup>th</sup> and 8 <sup>th</sup> characters of <i>F 790</i> | hex  | -                                           | 0-FFFF                                                        | 2d2d            |              |             |
| F 799 | 0799              | Factory specific coefficient 7A                                | -    | -                                           | -                                                             | -               |              | *3          |

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

### • Communication parameters

| Title | Communication No. | Function                                                        | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                                                                                                                                                                                                                       | Default setting | User setting | Reference |
|-------|-------------------|-----------------------------------------------------------------|------|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|--------------|-----------|
| F 800 | 0800              | Baud rate                                                       | -    | -                                           | 3: 9600bps<br>4: 19200bps<br>5: 38400bps                                                                                                                                                                                                                                                                               | 4               |              | 6.38.1    |
| F 801 | 0801              | Parity                                                          | -    | -                                           | 0: No parity<br>1: Even parity<br>2: Odd parity                                                                                                                                                                                                                                                                        | 1               |              |           |
| F 802 | 0802              | Inverter number                                                 | -    | 1/1                                         | 0-247                                                                                                                                                                                                                                                                                                                  | 0               |              |           |
| F 803 | 0803              | Communication time-out time                                     | s    | 0.1/0.1                                     | 0.0: Disabled,<br>0.1-100.0                                                                                                                                                                                                                                                                                            | 0.0             |              |           |
| F 804 | 0804              | Communication time-out action                                   | -    | -                                           | 0: Alarm only<br>1: Trip (Coast stop)<br>2: Trip (Deceleration stop)                                                                                                                                                                                                                                                   | 0               |              |           |
| F 805 | 0805              | Communication waiting time                                      | s    | 0.01/0.01                                   | 0.00-2.00                                                                                                                                                                                                                                                                                                              | 0.00            |              |           |
| F 806 | 0806              | Setting of master and slave for communication between inverters | -    | -                                           | 0: Slave (0 Hz command issued in case the master inverter fails)<br>1: Slave (Operation continued in case the master inverter fails)<br>2: Slave (Emergency stop tripping in case the master inverter fails)<br>3: Master (transmission of frequency commands)<br>4: Master (transmission of output frequency signals) | 0               |              |           |
| F 808 | 0808              | Communication time-out detection condition                      | -    | -                                           | 0: Valid at any time<br>1: Communication selection of <i>F 804</i> or <i>F 805</i><br>2: 1+ during operation                                                                                                                                                                                                           | 1               |              |           |

| Title | Communication No. | Function                                | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                                                                                                    | Default setting | User setting | Reference        |
|-------|-------------------|-----------------------------------------|------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------|-----------------|--------------|------------------|
| F810  | 0810              | Communication command point selection   | -    | 1/1                                         | 0: Disabled<br>1: Enabled                                                                                           | 0               |              | 6.10.2<br>6.38.1 |
| F811  | 0811              | Communication command point 1 setting   | %    | 1/1                                         | 0-100                                                                                                               | 0               |              |                  |
| F812  | 0812              | Communication command point 1 frequency | Hz   | 0.1/0.01                                    | 0.0- <i>FH</i>                                                                                                      | 0.0             |              |                  |
| F813  | 0813              | Communication command point 2 setting   | %    | 1/1                                         | 0-100                                                                                                               | 100             |              |                  |
| F814  | 0814              | Communication command point 2 frequency | Hz   | 0.1/0.01                                    | 0.0- <i>FH</i>                                                                                                      | *1              |              |                  |
| F829  | 0829              | Selection of communication protocol     | -    | -                                           | 0: Toshiba inverter protocol<br>1: Modbus RTU protocol                                                              | 0               |              | 6.38.1           |
| F856  | 0856              | Number of motor poles for communication | -    | -                                           | 1: 2 poles<br>2: 4 poles<br>3: 6 poles<br>4: 8 poles<br>5: 10 poles<br>6: 12 poles<br>7: 14 poles<br>8: 16 poles    | 2               |              |                  |
| F870  | 0870              | Block write data 1                      | -    | -                                           | 0: No selection<br>1: Communication command 1<br>2: Communication command 2                                         | 0               |              |                  |
| F871  | 0871              | Block write data 2                      | -    | -                                           | 3: Frequency command value<br>4: Output data on the terminal block<br>5: FM analog output<br>6: Motor speed command | 0               |              |                  |
| F875  | 0875              | Block read data 1                       | -    | -                                           | 0: No selection<br>1: Status information 1<br>2: Output frequency                                                   | 0               |              |                  |
| F876  | 0876              | Block read data 2                       | -    | -                                           | 3: Output current<br>4: Output voltage<br>5: Alarm information                                                      | 0               |              |                  |
| F877  | 0877              | Block read data 3                       | -    | -                                           | 6: PID feedback value<br>7: Input terminal monitor<br>8: Output terminal monitor                                    | 0               |              |                  |
| F878  | 0878              | Block read data 4                       | -    | -                                           | 9: Terminal VIA monitor<br>10: Terminal VIB monitor<br>11: Terminal VIC monitor                                     | 0               |              |                  |
| F879  | 0879              | Block read data 5                       | -    | -                                           | 12: Input voltage (DC detection)<br>13: Motor speed<br>14: Torque                                                   | 0               |              |                  |
| F880  | 0880              | Free notes                              | -    | 1/1                                         | 0-65530 (65535)                                                                                                     | 0               |              | 6.38.3           |
| F898  | 0898              | Factory specific coefficient 8A         | -    | -                                           | -                                                                                                                   | -               |              | *3               |
| F899  | 0899              | Communication function reset            | -    | -                                           | 0: -<br>1: Reset (after execution: 0)                                                                               | 0               |              | 6.38.1           |

\*1: Default setting values vary depending on the setup menu setting. Refer to section 11.5.

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• PM motor parameters

| Title   | Communication No. | Function                         | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range                | Default setting | User setting | Reference      |
|---------|-------------------|----------------------------------|------|---------------------------------------------|---------------------------------|-----------------|--------------|----------------|
| F 9 0 0 | 0900              | Factory specific coefficient 9A  | -    | -                                           | -                               | -               |              | *3             |
| F 9 0 1 | 0901              | Factory specific coefficient 9B  | -    | -                                           | -                               | -               |              |                |
| F 9 0 2 | 0902              | Factory specific coefficient 9C  | -    | -                                           | -                               | -               |              |                |
| F 9 0 9 | 0909              | Factory specific coefficient 9D  | -    | -                                           | -                               | -               |              |                |
| F 9 1 0 | 0910              | Step-out detection current level | %    | 1/0.01                                      | 1-150                           | 100             |              |                |
| F 9 1 1 | 0911              | Step-out detection time          | s    | 0.01/0.01                                   | 0.00: No detection<br>0.01-2.55 | 0.00            |              | 6.39           |
| F 9 1 2 | 0912              | q-axis inductance                | mH   | 0.01/0.01                                   | 0.01-650.0                      | 10.00           |              |                |
| F 9 1 3 | 0913              | d-axis inductance                | mH   | 0.01/0.01                                   | 0.01-650.0                      | 10.00           |              | 6.25 2<br>6.39 |
| F 9 1 4 | 0914              | Factory specific coefficient 9E  | -    | -                                           | -                               | -               |              | * 3            |
| F 9 1 5 | 0915              | Factory specific coefficient 9L  | -    | -                                           | -                               | -               |              |                |
| F 9 1 6 | 0916              | Factory specific coefficient 9F  | -    | -                                           | -                               | -               |              |                |
| F 9 1 7 | 0917              | Factory specific coefficient 9G  | -    | -                                           | -                               | -               |              |                |
| F 9 1 8 | 0918              | Factory specific coefficient 9H  | -    | -                                           | -                               | -               |              |                |
| F 9 1 9 | 0919              | Factory specific coefficient 9I  | -    | -                                           | -                               | -               |              |                |
| F 9 2 0 | 0920              | Factory specific coefficient 9J  | -    | -                                           | -                               | -               |              |                |
| F 9 3 0 | 0930              | Factory specific coefficient 9K  | -    | -                                           | -                               | -               |              |                |

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Traverse parameters

| Title   | Communication No. | Function                   | Unit | Minimum setting unit<br>Panel/Communication | Adjustment range          | Default setting | User setting | Reference |
|---------|-------------------|----------------------------|------|---------------------------------------------|---------------------------|-----------------|--------------|-----------|
| F 9 8 0 | 0980              | Traverse selection         | -    | 1/1                                         | 0: Disabled<br>1: Enabled | 0               |              | 6.40      |
| F 9 8 1 | 0981              | Traverse acceleration time | s    | 0.1/0.1                                     | 0.1-120.0                 | 25.0            |              |           |
| F 9 8 2 | 0982              | Traverse deceleration time | s    | 0.1/0.1                                     | 0.1-120.0                 | 25.0            |              |           |
| F 9 8 3 | 0983              | Traverse step              | %    | 0.1/0.1                                     | 0.0-25.0                  | 10.0            |              |           |
| F 9 8 4 | 0984              | Traverse jump step         | %    | 0.1/0.1                                     | 0.0-50.0                  | 10.0            |              |           |

## • Factory specific parameters

| Title     | Function                     | Reference |
|-----------|------------------------------|-----------|
| R900-R977 | Factory specific coefficient | *3        |

\*3: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

## • Communication option parameters

| Title                           | Function                               | Reference |
|---------------------------------|----------------------------------------|-----------|
| C001-C111, C885-C896, C900-C999 | Communication option common parameters | Note 1)   |
| C120-C148                       | CC-Link option parameters              | E6581830  |
| C150-C164                       | PROFIBUS DP option parameters          | E6581738  |
| C200-C203                       | DeviceNet option parameters            | E6581737  |
| C400-C421, C850-C880            | EtherCAT option parameters             | E6581818  |
| C500-C536                       | EtherNet common parameters             | E6581741  |
| C554-C556                       | EtherNet/IP option parameters          |           |
| C600-C604                       | Modbus TCP option parameters           | E6581911  |
| C700-C789, C800-C830            | CANopen communication parameters       |           |

Note 1) Refer to each Instruction Manual for option about detailed specifications and common parameters.

## 11.4 Default settings by inverter rating

| Inverter type    | Torque boost value | Dynamic braking resistance | Dynamic braking resistor capacity | Automatic torque boost value | Motor rated capacity | Motor rated current | Motor no-load current | Over-voltage stall protection level | Integrating wattmeter display unit selection |
|------------------|--------------------|----------------------------|-----------------------------------|------------------------------|----------------------|---------------------|-----------------------|-------------------------------------|----------------------------------------------|
|                  | $F172$<br>(%)      | $F308$<br>(Ω)              | $F309$<br>(kW)                    | $F402$<br>(%)                | $F405$<br>(kW)       | $F415$<br>(A)       | $F416$<br>(%)         | $F526$<br>(%)                       | $F749$                                       |
| VFS15-2004PM-W   | 6.0                | 200.0                      | 0.12                              | 6.2                          | 0.40                 | 2.00                | 65                    | 136                                 | 0                                            |
| VFS15-2007PM-W   | 6.0                | 200.0                      | 0.12                              | 5.8                          | 0.75                 | 3.40                | 60                    | 136                                 | 0                                            |
| VFS15-2015PM-W   | 6.0                | 75.0                       | 0.12                              | 4.3                          | 1.50                 | 6.20                | 55                    | 136                                 | 0                                            |
| VFS15-2022PM-W   | 5.0                | 75.0                       | 0.12                              | 4.1                          | 2.20                 | 8.90                | 52                    | 136                                 | 0                                            |
| VFS15-2037PM-W*1 | 5.0                | 40.0                       | 0.12                              | 3.4                          | 4.00                 | 14.80               | 48                    | 136                                 | 1                                            |
| VFS15-2055PM-W   | 4.0                | 15.0                       | 0.44                              | 3.0                          | 5.50                 | 21.00               | 46                    | 136                                 | 1                                            |
| VFS15-2075PM-W   | 3.0                | 15.0                       | 0.44                              | 2.5                          | 7.50                 | 28.20               | 43                    | 136                                 | 1                                            |
| VFS15-2110PM-W   | 2.0                | 7.5                        | 0.88                              | 2.3                          | 11.00                | 40.60               | 41                    | 136                                 | 1                                            |
| VFS15-2150PM-W   | 2.0                | 7.5                        | 0.88                              | 2.0                          | 15.00                | 54.60               | 38                    | 136                                 | 1                                            |
| VFS15S-2002PL-W  | 6.0                | 200.0                      | 0.12                              | 8.3                          | 0.20                 | 1.20                | 70                    | 136                                 | 0                                            |
| VFS15S-2004PL-W  | 6.0                | 200.0                      | 0.12                              | 6.2                          | 0.40                 | 2.00                | 65                    | 136                                 | 0                                            |
| VFS15S-2007PL-W  | 6.0                | 200.0                      | 0.12                              | 5.8                          | 0.75                 | 3.40                | 60                    | 136                                 | 0                                            |
| VFS15S-2015PL-W  | 6.0                | 75.0                       | 0.12                              | 4.3                          | 1.50                 | 6.20                | 55                    | 136                                 | 0                                            |
| VFS15S-2022PL-W  | 5.0                | 75.0                       | 0.12                              | 4.1                          | 2.20                 | 8.90                | 52                    | 136                                 | 0                                            |
| VFS15-4004PL-W   | 6.0                | 200.0                      | 0.12                              | 6.2                          | 0.40                 | 1.00                | 65                    | 141                                 | 0                                            |
| VFS15-4007PL-W   | 6.0                | 200.0                      | 0.12                              | 5.8                          | 0.75                 | 1.70                | 60                    | 141                                 | 0                                            |
| VFS15-4015PL-W   | 6.0                | 200.0                      | 0.12                              | 4.3                          | 1.50                 | 3.10                | 55                    | 141                                 | 0                                            |
| VFS15-4022PL-W   | 5.0                | 200.0                      | 0.12                              | 4.1                          | 2.20                 | 4.50                | 52                    | 141                                 | 0                                            |
| VFS15-4037PL-W*1 | 5.0                | 160.0                      | 0.12                              | 3.4                          | 4.00                 | 7.40                | 48                    | 141                                 | 1                                            |
| VFS15-4055PL-W   | 4.0                | 60.0                       | 0.44                              | 2.6                          | 5.50                 | 10.50               | 46                    | 141                                 | 1                                            |
| VFS15-4075PL-W   | 3.0                | 60.0                       | 0.44                              | 2.3                          | 7.50                 | 14.10               | 43                    | 141                                 | 1                                            |
| VFS15-4110PL-W   | 2.0                | 30.0                       | 0.88                              | 2.2                          | 11.00                | 20.30               | 41                    | 141                                 | 1                                            |
| VFS15-4150PL-W   | 2.0                | 30.0                       | 0.88                              | 1.9                          | 15.00                | 27.30               | 38                    | 141                                 | 1                                            |

\*1: When region setting is JP,  $F405$  is set to 3.7(kW).

## 11.5 Default settings by setup menu

| Function                                                 |            | Title                                                                    | Main regions             |                                       |                           |                          |
|----------------------------------------------------------|------------|--------------------------------------------------------------------------|--------------------------|---------------------------------------|---------------------------|--------------------------|
|                                                          |            |                                                                          | EU<br>(Europe)           | ASIA<br>(Asia,<br>Oceania)<br>Note 1) | USA<br>(North<br>America) | JP<br>(Japan)            |
| Frequency                                                |            | UL1<br>UL1<br>F1701<br>F2041<br>F2131<br>F2191<br>F3301<br>F3671<br>F814 | 50.0(Hz)                 | 50.0(Hz)                              | 60.0(Hz)                  | 60.0(Hz)                 |
| Base<br>frequency<br>voltage 1, 2                        | 240V class | ULU/<br>F171                                                             | 230(V)                   | 230(V)                                | 230(V)                    | 200(V)                   |
|                                                          | 500V class |                                                                          | 400(V)                   | 400(V)                                | 460(V)                    | 400(V)                   |
| V/F control mode selection                               |            | Pt                                                                       | 0                        | 0                                     | 0                         | 2                        |
| Supply voltage correction<br>(output voltage limitation) |            | F307                                                                     | 2                        | 2                                     | 2                         | 3                        |
| Regenerative over-<br>excitation upper limit             |            | F319                                                                     | 120                      | 120                                   | 120                       | 140                      |
| Motor rated speed                                        |            | F417                                                                     | 1410(min <sup>-1</sup> ) | 1410(min <sup>-1</sup> )              | 1710(min <sup>-1</sup> )  | 1710(min <sup>-1</sup> ) |

Note1) Refer to section 3.1 about setup menu.

## 11.6 Input Terminal Function

It can be assigned the function No. in the following table to parameter  $F104$ ,  $F108$ ,  $F110$  to  $F118$ ,  $F151$  to  $F156$ ,  $A913$  to  $A916$ .

• Table of input terminal functions 1

| Function No. | Code  | Function                                               | Action                                                                                                                                                                               | Reference       |
|--------------|-------|--------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| 0,1          | -     | No function                                            | Disabled                                                                                                                                                                             | -               |
| 2            | F     | Forward run command                                    | ON: Forward run, OFF: Deceleration stop                                                                                                                                              | 3.2.1           |
| 3            | FN    | Inversion of forward run command                       | Inversion of F                                                                                                                                                                       | 7.2.1           |
| 4            | R     | Reverse run command                                    | ON: Reverse run, OFF: Deceleration stop                                                                                                                                              |                 |
| 5            | RN    | Inversion of reverse run command                       | Inversion of R                                                                                                                                                                       |                 |
| 6            | ST    | Standby                                                | ON: Ready for operation<br>OFF: Coast stop (gate OFF)                                                                                                                                | 3.2.1<br>5.9    |
| 7            | STN   | Inversion of standby                                   | Inversion of ST                                                                                                                                                                      | 6.7.1<br>6.34.8 |
| 8            | RES   | Reset command 1 *2                                     | ON: Acceptance of reset command, ON → OFF: Trip reset                                                                                                                                | 13.2            |
| 9            | RESN  | Inversion of reset command 1 *2                        | Inversion of RES                                                                                                                                                                     |                 |
| 10           | SS1   | Preset-speed command 1                                 | Selection of 15-speed SS1 to SS4 (SS1N to SS4N) (4 bits)                                                                                                                             | 5.7             |
| 11           | SS1N  | Inversion of preset-speed command 1                    |                                                                                                                                                                                      | 7.2.1           |
| 12           | SS2   | Preset-speed command 2                                 |                                                                                                                                                                                      |                 |
| 13           | SS2N  | Inversion of preset-speed command 2                    |                                                                                                                                                                                      |                 |
| 14           | SS3   | Preset-speed command 3                                 |                                                                                                                                                                                      |                 |
| 15           | SS3N  | Inversion of preset-speed command 3                    |                                                                                                                                                                                      |                 |
| 16           | SS4   | Preset-speed command 4                                 |                                                                                                                                                                                      | 5.7             |
| 17           | SS4N  | Inversion of preset-speed command 4                    |                                                                                                                                                                                      |                 |
| 18           | JOG   | Jog run mode                                           | ON: Jogging mode, OFF: Jog run canceled                                                                                                                                              | 6.14            |
| 19           | JOGN  | Inversion of jog run mode                              | Inversion of JOG                                                                                                                                                                     |                 |
| 20           | EXT   | Emergency stop by external signal                      | ON: $\bar{E}$ trip stop, OFF: After stopped by $F603$ , $\bar{E}$ trip                                                                                                               | 6.29.4          |
| 21           | EXTN  | Inversion of emergency stop by external signal         | Inversion of EXT                                                                                                                                                                     |                 |
| 22           | DB    | DC braking command                                     | ON: DC braking, OFF: Brake canceled                                                                                                                                                  | 6.12.1          |
| 23           | DBN   | Inversion of DC braking command                        | Inversion of DB                                                                                                                                                                      |                 |
| 24           | AD2   | 2nd acceleration/deceleration                          | ON: Acceleration/deceleration 2<br>OFF: Acceleration/deceleration 1                                                                                                                  | 6.8.1<br>6.27.2 |
| 25           | AD2N  | Inversion of 2nd acceleration/deceleration             | Inversion of AD2                                                                                                                                                                     |                 |
| 26           | AD3   | 3rd acceleration/deceleration                          | ON: Acceleration/deceleration 3<br>OFF: Acceleration/deceleration 1 or 2                                                                                                             |                 |
| 27           | AD3N  | Inversion of 3rd acceleration/deceleration             | Inversion of AD3                                                                                                                                                                     |                 |
| 28           | VF2   | 2nd V/F control mode switching                         | ON: 2nd V/F control mode<br>(V/F fixed, $F110$ , $F111$ , $F112$ , $F113$ ( $tHr$ when $F632=2$ or 3))<br>OFF: 1st V/F control mode<br>( $Pk$ setting, $uL$ , $uLv$ , $ub$ , $tHr$ ) | 6.8.1           |
| 29           | VF2N  | Inversion of 2nd V/F control mode switching            | Inversion of VF2                                                                                                                                                                     |                 |
| 32           | OCS2  | 2nd stall prevention level                             | ON: Enabled at the value of $F185$ , $F444$ and $F445$<br>OFF: Enabled at the value of $F601$ , $F441$ and $F443$                                                                    | 6.8.1<br>6.29.2 |
| 33           | OCS2N | Inversion of 2nd stall prevention level                | Inversion of OCS2                                                                                                                                                                    |                 |
| 36           | PID   | PID control prohibition                                | ON: PID control prohibited, OFF: PID control enabled                                                                                                                                 | 6.24            |
| 37           | PIDN  | Inversion of PID control prohibition                   | Inversion of PID                                                                                                                                                                     |                 |
| 46           | OH2   | External thermal error input                           | ON: $\bar{OH2}$ trip stop, OFF: Disabled                                                                                                                                             | 7.2.1           |
| 47           | OH2N  | Inversion of external thermal error input              | Inversion of OH2                                                                                                                                                                     |                 |
| 48           | SCLC  | Forced local from communication                        | Enabled during communication<br>ON: Local (Setting of $\bar{CND}$ , $FND$ )<br>OFF: Communication                                                                                    | 6.2.1<br>6.38   |
| 49           | SCLCN | Inversion of forced local from communication           | Inversion of SCLC                                                                                                                                                                    |                 |
| 50           | HD    | Operation hold (hold of 3-wire operation)              | ON: F (forward run), R: (reverse run) held, 3-wire operation<br>OFF: Deceleration stop                                                                                               | 7.2.1           |
| 51           | HDN   | Inversion of operation hold (hold of 3-wire operation) | Inversion of HD                                                                                                                                                                      |                 |

\*2: These functions are cannot be assigned to Always active function selection 1 to 3 ( $F104$ ,  $F108$ ,  $F110$ ).

• Table of input terminal functions 2

| Function No. | Code   | Function                                                        | Action                                                                                                             | Reference       |
|--------------|--------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|-----------------|
| 52           | IDC    | PID integral/differential clear                                 | ON: Integral/differential clear, OFF: Clear canceled                                                               | 6.24            |
| 53           | IDCN   | Inversion of PID integral/differential clear                    | Inversion of IDC                                                                                                   |                 |
| 54           | DR     | PID characteristics switching                                   | ON: Inverted characteristics of $F380$ selection<br>OFF: Characteristics of $F380$ selection                       |                 |
| 55           | DRN    | Inversion of PID characteristics switching                      | Inversion of DR                                                                                                    | 6.30            |
| 56           | FORCE  | Forced run operation                                            | ON: Forced run operation if specified faults are occurred ( $F299$ frequency)<br>OFF: Normal operation             |                 |
| 57           | FORCEN | Inversion of forced run operation                               | Inversion of FORCE                                                                                                 |                 |
| 58           | FIRE   | Fire speed operation                                            | ON: Fire speed operation ( $F299$ frequency)<br>OFF: Normal operation                                              |                 |
| 59           | FIREN  | Inversion of fire speed operation                               | Inversion of FIRE                                                                                                  | 6.23            |
| 60           | DWELL  | Acceleration/deceleration suspend signal                        | ON: Acceleration/deceleration suspend<br>OFF: Normal operation                                                     |                 |
| 61           | DWELLN | Inversion of acceleration/deceleration suspend signal           | Inversion of DWELL                                                                                                 |                 |
| 62           | KEB    | Power failure synchronized signal                               | ON: Deceleration stop with synchronizing when power failure<br>OFF: Normal operation                               | 6.19.2          |
| 63           | KEBN   | Inversion of power failure synchronized signal                  | Inversion of KEB                                                                                                   |                 |
| 64, 65       |        | Factory specific coefficient                                    | -                                                                                                                  | *1              |
| 70, 71       |        | Factory specific coefficient                                    | -                                                                                                                  | *1              |
| 74           | CKWH   | Integrating wattmeter(kWh) display clear                        | ON: Integrating wattmeter(kwh) monitor display clear<br>OFF: Disabled                                              | 6.36            |
| 75           | CKWHN  | Inversion of integrating wattmeter display clear                | Inversion of CKWH                                                                                                  |                 |
| 76           | TRACE  | Trace back trigger signal                                       | ON: Trigger(start) signal of trace function<br>OFF: Disabled                                                       | 6.35            |
| 77           | TRACEN | Inversion of trace back trigger signal                          | Inversion of TRACE                                                                                                 |                 |
| 78           | HSL    | Light-load high-speed operation prohibitive signal              | ON: Light-load high-speed operation prohibited<br>OFF: Light-load high-speed operation permitted                   | 6.21            |
| 79           | HSLN   | Inversion of light-load high-speed operation prohibitive signal | Inversion of HSL                                                                                                   |                 |
| 80           | HDRY   | Holding of RY-RC terminal output                                | ON: Once turned on, RY-RC are held on.<br>OFF: The status of RY-RC changes in real time according to conditions.   | 7.2.2           |
| 81           | HDRYN  | Inversion of holding of RY-RC terminal output                   | Inversion of HDRY                                                                                                  |                 |
| 82           | HDOU   | Holding of OUT-NO terminal output                               | ON: Once turned on, OUT-NO are held on.<br>OFF: The status of OUT-NO changes in real time according to conditions. |                 |
| 83           | HDOUN  | Inversion of holding of OUT-NO terminal output                  | Inversion of HDOU                                                                                                  | 6.10.4          |
| 88           | UP     | Frequency UP                                                    | ON: Frequency increased<br>OFF: Frequency increase canceled                                                        |                 |
| 89           | UPN    | Inversion of frequency UP                                       | Inversion of UP                                                                                                    |                 |
| 90           | DWN    | Frequency DOWN                                                  | ON: Frequency decreased<br>OFF: Frequency decrease canceled                                                        |                 |
| 91           | DWNN   | Inversion of frequency DOWN                                     | Inversion of DWN                                                                                                   |                 |
| 92           | CLR    | Clear frequency UP/DOWN                                         | OFF □ ON: Clear frequency UP/DOWN                                                                                  |                 |
| 93           | CLRN   | Inversion of clear frequency UP/DOWN                            | Inversion of CLR                                                                                                   | 3.2.1<br>6.34.8 |
| 96           | FRR    | Coast stop command                                              | ON: Coast stop (Gate OFF)<br>OFF: Coast stop canceled                                                              |                 |
| 97           | FRRN   | Inversion of coast stop command                                 | Inversion of FRR                                                                                                   | 7.2.1           |
| 98           | FR     | Forward/reverse selection                                       | ON: Forward command<br>OFF: Reverse command                                                                        |                 |
| 99           | FRN    | Inversion of forward/reverse selection                          | Inversion of FR                                                                                                    |                 |

\*1: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

• Table of input terminal functions 3

| Function No. | Code   | Function                                             | Action                                                                                                                                                                                     | Reference |
|--------------|--------|------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| 100          | RS     | Run/Stop command                                     | ON: Run command<br>OFF: Stop command                                                                                                                                                       | 7.2.1     |
| 101          | RSN    | Inversion of run/Stop command                        | Inversion of RS                                                                                                                                                                            |           |
| 104          | FCHG   | Frequency setting mode forced switching              | ON: $F207(F200=0)$<br>OFF: $F00d$                                                                                                                                                          | 6.2.1     |
| 105          | FCHGN  | Inversion of frequency setting mode forced switching | Inversion of FCHG                                                                                                                                                                          |           |
| 106          | FMTB   | Frequency setting mode terminal block                | ON: Terminal block (VIA) enabled<br>OFF: Setting of $F00d$                                                                                                                                 |           |
| 107          | FMTBN  | Inversion of frequency setting mode terminal block   | Inversion of FMTB                                                                                                                                                                          |           |
| 108          | CMTB   | Command mode terminal block                          | ON: Terminal block enabled<br>OFF: Setting of $F00d$                                                                                                                                       |           |
| 109          | CMTBN  | Inversion of command mode terminal block             | Inversion of CMTB                                                                                                                                                                          |           |
| 110          | PWE    | Parameter editing permission                         | ON: Parameter editing permitted<br>OFF: Setting of $F100$                                                                                                                                  | 6.34.1    |
| 111          | PWEN   | Inversion of parameter editing permission            | Inversion of PWE                                                                                                                                                                           |           |
| 120          | FSTP1  | Fast stop command 1                                  | ON: Dynamic quick deceleration command<br>OFF: Forced deceleration canceled<br>(Note that operation is resumed when forced deceleration is canceled)                                       | 6.1.4     |
| 121          | FSTP1N | Inversion of fast stop command 1                     | Inversion of FSTP1                                                                                                                                                                         |           |
| 122          | FSTP2  | Fast stop command 2                                  | ON: Automatic deceleration<br>OFF: Forced deceleration canceled<br>(Note that operation is resumed when forced deceleration is canceled)                                                   |           |
| 123          | FSTP2N | Inversion of fast stop command 2                     | Inversion of FSTP2                                                                                                                                                                         |           |
| 134          | TVS    | Traverse permission signal                           | ON: Permission signal of traverse operation<br>OFF: Normal operation                                                                                                                       | 6.40      |
| 135          | TVSN   | Inversion of traverse permission signal              | Inversion of TVS                                                                                                                                                                           |           |
| 136          | RSC    | Low voltage operation signal                         | ON: Low voltage operation<br>OFF: Low voltage operation canceled                                                                                                                           | 6.17      |
| 137          | RSCN   | Inversion of low voltage operation signal            | Inversion of RSC                                                                                                                                                                           |           |
| 140          | SLOWF  | Forward deceleration                                 | ON: Forward operation with $F383$ frequency<br>OFF: Normal operation                                                                                                                       | 6.22.2    |
| 141          | SLOWFN | Inversion of forward deceleration                    | Inversion of SLOWF                                                                                                                                                                         |           |
| 142          | STOPF  | Forward stop                                         | ON: Forward stop, OFF: Normal operation                                                                                                                                                    |           |
| 143          | STOPFN | Inversion of forward stop                            | Inversion of STOPF                                                                                                                                                                         |           |
| 144          | SLOWR  | Reverse deceleration                                 | ON: Reverse operation with $F383$ frequency<br>OFF: Normal operation                                                                                                                       |           |
| 145          | SLOWRN | Inversion of reverse deceleration                    | Inversion of SLOWR                                                                                                                                                                         |           |
| 146          | STOPR  | Reverse stop                                         | ON: Reverse stop, OFF: Normal operation                                                                                                                                                    |           |
| 147          | STOPRN | Inversion of reverse stop                            | Inversion of STOPR                                                                                                                                                                         |           |
| 148 to 151   |        | Factory specific coefficient                         | -                                                                                                                                                                                          | *1        |
| 152          | MOT2   | No.2 motor switching<br>(AD2+VF2+OCS2)               | ON: No.2 motor<br>( $Pt=0, F107, F111, F112, F113$ (tHr when $F632=2$ or 3), $F185, F500, F501, F503$ )<br>OFF: No.1 motor (Set value of $Pt, uL, uL, uL, uL, tHr, RCL, dEL, F502, F601$ ) | 6.8.1     |
| 153          | MOT2N  | Inversion of No.2 motor switching<br>(AD2+VF2+OCS2)  | Inversion of MOT2                                                                                                                                                                          |           |
| 158          | RES2   | Reset command 2 *2                                   | ON: Trip reset                                                                                                                                                                             | 13.2      |
| 159          | RES2N  | Inversion of reset command 2 *2                      | Inversion of RES2                                                                                                                                                                          |           |
| 200          | PWP    | Parameter editing prohibition                        | ON: Parameter editing prohibited<br>OFF: Setting of $F100$                                                                                                                                 | 6.34.1    |
| 201          | PWPN   | Inversion of parameter editing prohibition           | Inversion of PWP                                                                                                                                                                           |           |
| 202          | PRWP   | Parameter reading prohibition                        | ON: Parameter reading / editing prohibited<br>OFF: Setting of $F100$                                                                                                                       |           |
| 203          | PRWPN  | Inversion of parameter reading prohibition           | Inversion of PRWP                                                                                                                                                                          |           |

\*1: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

\*2: These functions are cannot be assigned to Always active function selection 1 to 3 ( $F104, F108, F110$ ).

Note 1: Function No. that are not described in the table above are assigned "No function".

• Input terminal function priority

| Code                        | Function No.                     | 2,3<br>4,5 | 6,7 | 8,9 | 10,11<br>12,13<br>14,15<br>16,17 | 18<br>19 | 20<br>21 | 22<br>23 | 24,25<br>28,29<br>32,33 | 36,37<br>52,53<br>54,55 | 48<br>49<br>106<br>107<br>108<br>109 | 50<br>51 | 88,89<br>90,91<br>92,93 | 96<br>97 | 110<br>111<br>200<br>201 | 122<br>123 |
|-----------------------------|----------------------------------|------------|-----|-----|----------------------------------|----------|----------|----------|-------------------------|-------------------------|--------------------------------------|----------|-------------------------|----------|--------------------------|------------|
| F/<br>R                     | 2,3<br>4,5                       |            | X   | ○   | ○                                | ○        | X        | X        | ○                       | ○                       | ○                                    | ○        | ○                       | X        | ○                        | X          |
| ST                          | 6,7                              | ⊗          |     | ○   | ⊗                                | ⊗        | ○        | ⊗        | ○                       | ○                       | ○                                    | ⊗        | ○                       | ○        | ○                        | ⊗          |
| RES                         | 8,9                              | ○          | ○   |     | ○                                | ○        | X        | ○        | ○                       | ○                       | ○                                    | ○        | ○                       | ○        | ○                        | ○          |
| SS1/<br>SS2/<br>SS3/<br>SS4 | 10,11<br>12,13<br>14,15<br>16,17 | ○          | X   | ○   |                                  | X        | X        | X        | ○                       | ○                       | ○                                    | ○        | ○                       | X        | ○                        | X          |
| JOG                         | 18,19                            | ○          | X   | ○   | ⊗                                |          | X        | X        | ○                       | ⊗                       | ○                                    | X        | ○                       | X        | ○                        | X          |
| EXT                         | 20,21                            | ⊗          | ○   | ⊗   | ⊗                                | ⊗        |          | ⊗        | ○                       | ○                       | ○                                    | ⊗        | ○                       | ○        | ○                        | ⊗          |
| DB                          | 22,23                            | ⊗          | X   | ○   | ⊗                                | ⊗        | X        |          | ○                       | ⊗                       | ○                                    | ⊗        | ○                       | X        | ○                        | X          |
| AD2/<br>VF2/<br>OCS2        | 24,25<br>28,29<br>32,33          | ○          | ○   | ○   | ○                                | ○        | ○        | ○        |                         | ○                       | ○                                    | ○        | ○                       | ○        | ○                        | ○          |
| PID/<br>IDC/<br>PIDSW       | 36,37<br>52,53<br>54,55          | ○          | ○   | ○   | ○                                | X        | ○        | X        | ○                       |                         | ○                                    | ○        | ○                       | ○        | ○                        | ○          |
| SCLC/<br>FMTB/<br>CMTB      | 48,49<br>106,107<br>108,109      | ○          | ○   | ○   | ○                                | ○        | ○        | ○        | ○                       | ○                       |                                      | ○        | ○                       | ○        | ○                        | ○          |
| HD                          | 50,51                            | ○          | X   | ○   | ○                                | X        | X        | X        | ○                       | ○                       | ○                                    |          | ○                       | X        | ○                        | X          |
| UP/<br>DWN/<br>CLR          | 88,89<br>90,91<br>92,93          | ○          | ○   | ○   | ○                                | ○        | ○        | ○        | ○                       | ○                       | ○                                    | ○        |                         | ○        | ○                        | ○          |
| FRR                         | 96,97                            | ⊗          | ○   | ○   | ⊗                                | ⊗        | ○        | ⊗        | ○                       | ○                       | ○                                    | ⊗        | ○                       |          | ○                        | ⊗          |
| PWE/<br>PWP                 | 110,111<br>200,201               | ○          | ○   | ○   | ○                                | ○        | ○        | ○        | ○                       | ○                       | ○                                    | ○        | ○                       | ○        |                          | ○          |
| FST                         | 122,123                          | ⊗          | X   | ○   | ⊗                                | ⊗        | X        | ⊗        | ○                       | ○                       | ○                                    | ⊗        | ○                       | X        | ○                        |            |

⊗ Priority ○ Enabled X Disabled

## 11.7 Output Terminal Function

It can be assigned the function No. in the following table to parameter  $F 130$  to  $F 138$ ,  $F 157$ ,  $F 158$ .

### • Table of output terminal functions 1

| Function No. | Code  | Function                                                                                              | Action                                                                                                                                                                                                          | Reference      |
|--------------|-------|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
| 0            | LL    | Frequency lower limit                                                                                 | ON: Output frequency is more than $L L$<br>OFF: Output frequency is $L L$ or less                                                                                                                               | 5.4            |
| 1            | LLN   | Inversion of frequency lower limit                                                                    | Inversion of LL                                                                                                                                                                                                 |                |
| 2            | UL    | Frequency upper limit                                                                                 | ON: Output frequency is $U L$ or more<br>OFF: Output frequency is less than $U L$                                                                                                                               |                |
| 3            | ULN   | Inversion of frequency upper limit                                                                    | Inversion of UL                                                                                                                                                                                                 | 6.5.1<br>7.2.2 |
| 4            | LOW   | Low-speed detection signal                                                                            | ON: Output frequency is $F 100$ or more<br>OFF: Output frequency is less than $F 100$                                                                                                                           |                |
| 5            | LOWN  | Inversion of low-speed detection signal                                                               | Inversion of LOW                                                                                                                                                                                                |                |
| 6            | RCH   | Output frequency attainment signal<br>(acceleration/deceleration completed)                           | ON: Output frequency is within command frequency $\pm F 102$<br>OFF: Output frequency is more than command frequency $\pm F 102$                                                                                | 6.5.2<br>7.2.2 |
| 7            | RCHN  | Inversion of output frequency attainment signal<br>(inversion of acceleration/deceleration completed) | Inversion of RCH                                                                                                                                                                                                |                |
| 8            | RCHF  | Set frequency attainment signal                                                                       | ON: Output frequency is within $F 10 \pm F 102$<br>OFF: Output frequency is more than $F 10 \pm F 102$                                                                                                          |                |
| 9            | RCHFN | Inversion of set frequency attainment signal                                                          | Inversion of RCHF                                                                                                                                                                                               | 7.2.2          |
| 10           | FL    | Fault signal (trip output)                                                                            | ON: Inverter tripped<br>OFF: Inverter not tripped                                                                                                                                                               |                |
| 11           | FLN   | Inversion of fault signal (inversion of trip output)                                                  | Inversion of FL                                                                                                                                                                                                 |                |
| 14           | POC   | Over-current detection pre-alarm                                                                      | ON: Output current is $F 60$ or more<br>OFF: Output current is less than $F 60$                                                                                                                                 | 6.29.2         |
| 15           | POCN  | Inversion of over-current detection pre-alarm                                                         | Inversion of POC                                                                                                                                                                                                |                |
| 16           | POL   | Overload detection pre-alarm                                                                          | ON: $F 65$ (%) or more of calculated value of overload protection level<br>OFF: Less than $F 65$ (%) of calculated value of overload protection level                                                           |                |
| 17           | POLN  | Inversion of overload detection pre-alarm                                                             | Inversion of POL                                                                                                                                                                                                | 7.2.2          |
| 20           | POH   | Overheat detection pre-alarm                                                                          | ON: Approx. 95°C or more of IGBT element<br>OFF: Less than approx. 95°C of IGBT element (90°C or less after detection is turned on)                                                                             |                |
| 21           | POHN  | Inversion of overheat detection pre-alarm                                                             | Inversion of POH                                                                                                                                                                                                |                |
| 22           | POP   | Overvoltage detection pre-alarm                                                                       | ON: Overvoltage limit in operation<br>OFF: Overvoltage detection canceled                                                                                                                                       | 6.19.5         |
| 23           | POPEN | Inversion of overvoltage detection pre-alarm                                                          | Inversion of POP                                                                                                                                                                                                |                |
| 24           | MOFF  | Power circuit undervoltage detection                                                                  | ON: Power circuit undervoltage ( $UOFF$ ) detected<br>OFF: Undervoltage detection canceled                                                                                                                      |                |
| 25           | MOFFN | Inversion of power circuit undervoltage detection                                                     | Inversion of MOFF                                                                                                                                                                                               | 6.29.13        |
| 26           | UC    | Small current detection                                                                               | ON: After output current comes to $F 6$ or less, value of less than $F 6 \pm F 609$ for $F 6$ set time<br>OFF: Output current is more than $F 6$ or less<br>( $F 6 \pm F 609$ or more after detection turns on) |                |
| 27           | UCN   | Inversion of small current detection                                                                  | Inversion of UC                                                                                                                                                                                                 |                |
| 28           | OT    | Over-torque detection                                                                                 | ON: After torque comes to $F 6$ or more, value of more than $F 6 \pm F 6$ for $F 6$ set time<br>OFF: Torque is less than $F 6$ or less<br>( $F 6 \pm F 6$ or less after detection turns on)                     | 6.29.10        |
| 29           | OTN   | Inversion of over-torque detection                                                                    | Inversion of OT                                                                                                                                                                                                 |                |

• Table of output terminal functions 2

| Function No. | Code   | Function                                              | Action                                                                                                                                                                                                    | Reference |
|--------------|--------|-------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| 30           | POLR   | Braking resistor overload pre-alarm                   | ON: 50% or more of calculated value of $F309$ set overload protection level<br>OFF: Less than 50% of calculated value of $F309$ set overload protection level                                             | 6.19.4    |
| 31           | POLRN  | Inversion of braking resistor overload pre-alarm      | Inversion of POLR                                                                                                                                                                                         |           |
| 40           | RUN    | Run/stop                                              | ON: While operation frequency is output or DC braking is in operation ( $d b$ )<br>OFF: Operation stopped                                                                                                 | 7.2.2     |
| 41           | RUNN   | Inversion of run/stop                                 | Inversion of RUN                                                                                                                                                                                          |           |
| 42           | HFL    | Serious failure                                       | ON: At trip $*2$<br>OFF: Other than those trip above                                                                                                                                                      |           |
| 43           | HFLN   | Inversion of serious failure                          | Inversion of HFL                                                                                                                                                                                          |           |
| 44           | LFL    | Light failure                                         | ON: At trip ( $0L1\sim3, 0P1\sim3, 0H, 0L1\sim3, 0Lr$ )<br>OFF: Other than those trip above                                                                                                               |           |
| 45           | LFLN   | Inversion of light failure                            | Inversion of LFL                                                                                                                                                                                          |           |
| 50           | FAN    | Cooling fan ON/OFF                                    | ON: Cooling fan is in operation<br>OFF: Cooling fan is off operation                                                                                                                                      | 6.29.11   |
| 51           | FANN   | Inversion of cooling fan ON/OFF                       | Inversion of FAN                                                                                                                                                                                          |           |
| 52           | JOG    | In jogging operation                                  | ON: In jogging operation<br>OFF: Other than jogging operation                                                                                                                                             | 6.14      |
| 53           | JOGN   | Inversion of in jogging operation                     | Inversion of JOG                                                                                                                                                                                          |           |
| 54           | JBM    | Operation panel / terminal block operation            | ON: At terminal block operation command<br>OFF: Other than those operation above                                                                                                                          | 6.2.1     |
| 55           | JBMN   | Inversion of operation panel/terminal block operation | Inversion of JBM                                                                                                                                                                                          |           |
| 56           | COT    | Cumulative operation time alarm                       | ON: Cumulative operation time is $F621$ or more<br>OFF: The cumulative operation time is less than $F621$                                                                                                 | 6.29.12   |
| 57           | COTN   | Inversion of cumulative operation time alarm          | Inversion of COT                                                                                                                                                                                          |           |
| 58           | COMOP  | Communication option communication error              | ON: Communication error of communication option occurs<br>OFF: Other than those above                                                                                                                     | 6.38      |
| 59           | COMOPN | Inversion of communication option communication error | Inversion of COMOP                                                                                                                                                                                        |           |
| 60           | FR     | Forward/reverse run                                   | ON: Reverse run<br>OFF: Forward run<br>(Operation command state is output while motor operation is stopped. No command is to OFF.)                                                                        | 7.2.2     |
| 61           | FRN    | Inversion of forward/reverse run                      | Inversion of FR                                                                                                                                                                                           |           |
| 62           | RDY1   | Ready for operation 1                                 | ON: Ready for operation (with ST / RUN)<br>OFF: Other than those above                                                                                                                                    |           |
| 63           | RDY1N  | Inversion of ready for operation 1                    | Inversion of RDY1                                                                                                                                                                                         |           |
| 64           | RDY2   | Ready for operation 2                                 | ON: Ready for operation (without ST / RUN)<br>OFF: Other than those above                                                                                                                                 |           |
| 65           | RDY2N  | Inversion of ready for operation 2                    | Inversion of RDY2                                                                                                                                                                                         |           |
| 68           | BR     | Brake release                                         | ON: Brake exciting signal<br>OFF: Brake releasing signal                                                                                                                                                  | 6.22      |
| 69           | BRN    | Inversion of brake release                            | Inversion of BR                                                                                                                                                                                           |           |
| 70           | PAL    | Pre-alarm                                             | ON: One of the following is turned on<br>ON POL, POHR, POT, MOFF, UC, OT, LL stop, COT, and momentary power failure deceleration stop.<br>Or $L, P, 0r, H$ issues an alarm<br>OFF: Other than those above | 7.2.2     |
| 71           | PALN   | Inversion of pre-alarm                                | Inversion of PAL                                                                                                                                                                                          |           |
| 78           | COME   | RS485 communication error                             | ON: Communication error occurred<br>OFF: Communication works                                                                                                                                              | 6.38      |
| 79           | COMEN  | Inversion of RS485 communication error                | Inversion of COME                                                                                                                                                                                         |           |

\*2: At trip  $0CL, 0CA, EPH1, EPH0, 0L, 0L2, 0L3, 0L3, 0H2, E, EEP1\sim3, Err2\sim5, UC, UP1, Etn, Etn1\sim3, EF2, PrF, EtyP, E-13, E-18\sim21, E-23, E-26, E-32, E-37, E-39$ .

• Table of output terminal functions 3

| Function No. | Code   | Function                                               | Action                                                                                                                                                                                                                                 | Reference |
|--------------|--------|--------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| 92           | DATA1  | Designated data output 1                               | ON: bit0 of FA50 is ON<br>OFF: bit0 of FA50 is OFF                                                                                                                                                                                     | 6.38      |
| 93           | DATA1N | Inversion of designated data output 1                  | Inversion of DATA1                                                                                                                                                                                                                     |           |
| 94           | DATA2  | Designated data output 2                               | ON: bit1 of FA50 is ON<br>OFF: bit1 of FA50 is OFF                                                                                                                                                                                     |           |
| 95           | DATA2N | Inversion of designated data output 2                  | Inversion of DATA2                                                                                                                                                                                                                     |           |
| 106          | LLD    | Light load output                                      | ON: Less than heavy load torque ( $F 3 3 5 \sim F 3 3 8$ )<br>OFF: heavy load torque ( $F 3 3 5 \sim F 3 3 8$ ) or more                                                                                                                | 6.21      |
| 107          | LLDN   | Inversion of light load output                         | Inversion of LLD                                                                                                                                                                                                                       |           |
| 108          | HLD    | Heavy load output                                      | ON: Heavy load torque ( $F 3 3 5 \sim F 3 3 8$ ) or more<br>OFF: Less than heavy load torque ( $F 3 3 5 \sim F 3 3 8$ )                                                                                                                |           |
| 109          | HLDN   | Inversion of heavy load output                         | Inversion of HLD                                                                                                                                                                                                                       |           |
| 120          | LLS    | Lower limit frequency stop                             | ON: Lower limit frequency continuous operation<br>OFF: Other than those above                                                                                                                                                          | 6.13      |
| 121          | LLSN   | Inversion of lower limit frequency stop                | Inversion of LLS                                                                                                                                                                                                                       |           |
| 122          | KEB    | Power failure synchronized operation                   | ON: Power failure synchronized operation<br>OFF: Other than those above                                                                                                                                                                | 6.19.2    |
| 123          | KEBN   | Inversion of power failure synchronized operation      | Inversion of KEB                                                                                                                                                                                                                       |           |
| 124          | TVS    | Traverse in progress                                   | ON: Traverse in progress<br>OFF: Other than those above                                                                                                                                                                                | 6.40      |
| 125          | TVSN   | Inversion of traverse in progress                      | Inversion of TVS                                                                                                                                                                                                                       |           |
| 126          | TVSD   | Traverse deceleration in progress                      | ON: Traverse deceleration in progress<br>OFF: Other than those above                                                                                                                                                                   |           |
| 127          | TVSDN  | Inversion of traverse deceleration in progress         | Inversion of TVSD                                                                                                                                                                                                                      |           |
| 128          | LTA    | Parts replacement alarm                                | ON: Any one of cooling fan, control board capacitor, or main circuit capacitor reaches parts replacement time<br>OFF: Any one of cooling fan, control board capacitor, or main circuit capacitor does not reach parts replacement time | 6.29.15   |
| 129          | LTAN   | Inversion of parts replacement alarm                   | Inversion of LTA                                                                                                                                                                                                                       |           |
| 130          | POT    | Over-torque detection pre-alarm                        | ON: Torque current is 70% of $F 6 1 6$ setting value or more<br>OFF: Torque current is less than $F 6 1 6 \times 70\% \sim F 6 1 9$                                                                                                    | 6.29.10   |
| 131          | POTN   | Inversion of over-torque detection pre-alarm           | Inversion of POT                                                                                                                                                                                                                       |           |
| 132          | FMOD   | Frequency setting mode selection 1/2                   | ON: Select frequency setting mode selection 2 ( $F 2 0 1$ )<br>OFF: Select frequency setting mode selection 1 ( $F 1 0 0$ )                                                                                                            | 5.8       |
| 133          | FMODN  | Inversion of frequency setting mode selection 1/2      | Inversion of FMOD                                                                                                                                                                                                                      |           |
| 136          | FLC    | Panel / remote selection                               | ON: Operation command or panel<br>OFF: Other than those above                                                                                                                                                                          | 6.2.1     |
| 137          | FLCN   | Inversion of panel / remote selection                  | Inversion of FLC                                                                                                                                                                                                                       |           |
| 138          | FORCE  | Forced continuous operation in progress                | ON: Forced continuous operation in progress<br>OFF: Other than those above                                                                                                                                                             | 6.30      |
| 139          | FORCEN | Inversion of forced continuous operation in progress   | Inversion of FORCE                                                                                                                                                                                                                     |           |
| 140          | FIRE   | Specified frequency operation in progress              | ON: Specified Frequency operation in progress<br>OFF: Other than those above                                                                                                                                                           |           |
| 141          | FIREN  | Inversion of specified frequency operation in progress | Inversion of FIRE                                                                                                                                                                                                                      |           |

• Table of output terminal functions 4

| Function No. | Code  | Function                                                   | Action                                                                                                                | Reference |
|--------------|-------|------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|-----------|
| 144          | PIDF  | Signal in accordance of frequency command                  | ON: Frequency commanded by $F\ 3\ 8\ 9$ and $F\ 3\ 6\ 9$ are within $\pm F\ 1\ 6\ 7$ .<br>OFF: Other than those above | 6.24      |
| 145          | PIDFN | Inversion of signal in accordance of frequency command     | Inversion of PIDF                                                                                                     |           |
| 146          | FLR   | Fault signal (output also at a retry waiting)              | ON: While inverter is tripped or retried<br>OFF: While inverter is not tripped and not retried                        | 6.19.3    |
| 147          | FLRN  | Inversion of fault signal (output also at a retry waiting) | Inversion of FLR                                                                                                      |           |
| 150          | PTCA  | PTC input alarm signal                                     | ON: PTC thermal input value is $F\ 6\ 4\ 6$ or more<br>OFF: PTC thermal input value is less than $F\ 6\ 4\ 6$         | 6.29.16   |
| 151          | PTCAN | Inversion of PTC input alarm signal                        | Inversion of PTCA                                                                                                     |           |
| 152 to 153   |       | Factory specific coefficient                               | -                                                                                                                     | *1        |
| 154          | DISK  | Analog input break detection alarm                         | ON: VIB terminal input value is $F\ 6\ 3\ 3$ or less<br>OFF: VIB terminal input value is more than $F\ 6\ 3\ 3$       | 6.29.14   |
| 155          | DISKN | Inversion of analog input break detection alarm            | Inversion of DISK                                                                                                     |           |
| 156          | LI1   | F terminal status                                          | ON: F terminal is ON status<br>OFF: F terminal is OFF status                                                          | 7.2.2     |
| 157          | LI1N  | Inversion of F terminal status                             | Inversion of LI1                                                                                                      |           |
| 158          | LI2   | R terminal status                                          | ON: R terminal is ON status<br>OFF: R terminal is OFF status                                                          |           |
| 159          | LI2N  | Inversion of R terminal status                             | Inversion of LI2                                                                                                      |           |
| 160          | LTAf  | Cooling fan replacement alarm                              | ON: Cooling fan reaches parts replacement time<br>OFF: Cooling fan does not reach parts replacement time              | 6.29.15   |
| 161          | LTAfN | Inversion of cooling fan replacement alarm                 | Inversion of LTAf                                                                                                     |           |
| 162          | NSA   | Number of starting alarm                                   | ON: Number of starting alarm is $F\ 6\ 4\ 8$ or more<br>OFF: Number of starting alarm is less than $F\ 6\ 4\ 8$       | 6.29.17   |
| 163          | NSAN  | Inversion of number of starting alarm                      | Inversion of NSA                                                                                                      |           |
| 166          | DACC  | Acceleration operation in progress                         | ON: Acceleration operation in progress<br>OFF: Other than those above                                                 | 7.2.2     |
| 167          | DACCN | Inversion of acceleration operation in progress            | Inversion of DACC                                                                                                     |           |
| 168          | DDEC  | Deceleration operation in progress                         | ON: Deceleration operation in progress<br>OFF: Other than those above                                                 |           |
| 169          | DDECN | Inversion of deceleration operation in progress            | Inversion of DDEC                                                                                                     |           |
| 170          | DRUN  | Constant speed operation in progress                       | ON: Constant speed operation in progress<br>OFF: Other than those above                                               |           |
| 171          | DRUNN | Inversion of constant speed operation in progress          | Inversion of DRUN                                                                                                     |           |
| 172          | DDC   | DC braking in progress                                     | ON: DC braking in progress<br>OFF: Other than those above                                                             | 6.12.1    |
| 173          | DDCN  | Inversion of DC braking in progress                        | Inversion of DDC                                                                                                      |           |
| 174 to 179   |       | Factory specific coefficient                               | -                                                                                                                     | *1        |
| 180          | IPU   | Integral input power pulse output signal                   | ON: Integral input power unit reach<br>OFF: Other than those above                                                    | 6.33.1    |
| 182          | SMPA  | Shock monitoring pre-alarm signal                          | ON: Current / torque value reach the shock monitoring detection condition<br>OFF: Other than those above              | 6.28      |
| 183          | SMPAN | Inversion of Shock monitoring pre-alarm signal             | Inversion of SMPA                                                                                                     |           |
| 222 to 253   |       | Factory specific coefficient                               | -                                                                                                                     | *1        |
| 254          | AOFF  | Always OFF                                                 | Always OFF                                                                                                            | 7.2.2     |
| 255          | AON   | Always ON                                                  | Always ON                                                                                                             |           |

\*1: Factory specific coefficient parameters are manufacturer setting parameters. Do not change the value of these parameters.

Note 1: As function No. that are not described in the table above are assigned "No function", output signal is always "OFF" at even number, output signal is always "ON" at odd number.

## 11.8 Application easy setting

When 1 to 7 is set by parameter *RUR* (Application easy setting), the parameters of the table below are set to parameter *F 75 1* to *F 78 2* (Easy setting mode parameter 1 to 32).

Parameter *F 75 1* to *F 78 2* are displayed at easy setting mode.

Refer to section 4.2 about easy setting mode.

| <i>RUR</i>    | 1: Initial easy setting | 2: Conveyor  | 3: Material handling | 4: Hoisting  | 5: Fan       | 6: Pump      | 7: Compressor |
|---------------|-------------------------|--------------|----------------------|--------------|--------------|--------------|---------------|
| <i>F 75 1</i> | <i>C00d</i>             | <i>C00d</i>  | <i>C00d</i>          | <i>C00d</i>  | <i>C00d</i>  | <i>C00d</i>  | <i>C00d</i>   |
| <i>F 75 2</i> | <i>F00d</i>             | <i>F00d</i>  | <i>F00d</i>          | <i>F00d</i>  | <i>F00d</i>  | <i>F00d</i>  | <i>F00d</i>   |
| <i>F 75 3</i> | <i>RCC</i>              | <i>RCC</i>   | <i>RCC</i>           | <i>RCC</i>   | <i>RCC</i>   | <i>RCC</i>   | <i>RCC</i>    |
| <i>F 75 4</i> | <i>dEC</i>              | <i>dEC</i>   | <i>dEC</i>           | <i>dEC</i>   | <i>dEC</i>   | <i>dEC</i>   | <i>dEC</i>    |
| <i>F 75 5</i> | <i>UL</i>               | <i>UL</i>    | <i>UL</i>            | <i>UL</i>    | <i>FH</i>    | <i>FH</i>    | <i>FH</i>     |
| <i>F 75 6</i> | <i>LL</i>               | <i>LL</i>    | <i>LL</i>            | <i>LL</i>    | <i>UL</i>    | <i>UL</i>    | <i>UL</i>     |
| <i>F 75 7</i> | <i>tHr</i>              | <i>tHr</i>   | <i>tHr</i>           | <i>tHr</i>   | <i>LL</i>    | <i>LL</i>    | <i>LL</i>     |
| <i>F 75 8</i> | <i>FN</i>               | <i>FN</i>    | <i>FN</i>            | <i>FN</i>    | <i>tHr</i>   | <i>tHr</i>   | <i>tHr</i>    |
| <i>F 75 9</i> | -                       | <i>Pt</i>    | <i>Pt</i>            | <i>Pt</i>    | <i>FN</i>    | <i>FN</i>    | <i>FN</i>     |
| <i>F 76 0</i> | -                       | <i>0Ln</i>   | <i>0Ln</i>           | <i>0Ln</i>   | <i>Pt</i>    | <i>Pt</i>    | <i>Pt</i>     |
| <i>F 76 1</i> | -                       | <i>Sc 1</i>  | <i>Sc 1</i>          | <i>F304</i>  | <i>F20 1</i> | <i>F20 1</i> | <i>F2 16</i>  |
| <i>F 76 2</i> | -                       | <i>Sc 2</i>  | <i>Sc 2</i>          | <i>F308</i>  | <i>F20 2</i> | <i>F20 2</i> | <i>F2 17</i>  |
| <i>F 76 3</i> | -                       | <i>Sc 3</i>  | <i>Sc 3</i>          | <i>F309</i>  | <i>F20 3</i> | <i>F20 3</i> | <i>F2 18</i>  |
| <i>F 76 4</i> | -                       | <i>Sc 4</i>  | <i>Sc 4</i>          | <i>F328</i>  | <i>F20 4</i> | <i>F20 4</i> | <i>F2 19</i>  |
| <i>F 76 5</i> | -                       | <i>Sc 5</i>  | <i>Sc 5</i>          | <i>F329</i>  | <i>F20 7</i> | <i>F20 7</i> | <i>F2 1d</i>  |
| <i>F 76 6</i> | -                       | <i>Sc 6</i>  | <i>Sc 6</i>          | <i>F330</i>  | <i>F2 16</i> | <i>F2 16</i> | <i>F359</i>   |
| <i>F 76 7</i> | -                       | <i>Sc 7</i>  | <i>Sc 7</i>          | <i>F33 1</i> | <i>F2 17</i> | <i>F2 17</i> | <i>F360</i>   |
| <i>F 76 8</i> | -                       | <i>F20 1</i> | <i>F240</i>          | <i>F332</i>  | <i>F2 18</i> | <i>F2 18</i> | <i>F36 1</i>  |
| <i>F 76 9</i> | -                       | <i>F20 2</i> | <i>F243</i>          | <i>F333</i>  | <i>F2 19</i> | <i>F2 19</i> | <i>F36 2</i>  |
| <i>F 77 0</i> | -                       | <i>F20 3</i> | <i>F250</i>          | <i>F334</i>  | <i>F295</i>  | <i>F295</i>  | <i>F36 3</i>  |
| <i>F 77 1</i> | -                       | <i>F20 4</i> | <i>F25 1</i>         | <i>F340</i>  | <i>F30 1</i> | <i>F30 1</i> | <i>F366</i>   |
| <i>F 77 2</i> | -                       | <i>F240</i>  | <i>F25 2</i>         | <i>F34 1</i> | <i>F30 2</i> | <i>F30 2</i> | <i>F36 7</i>  |
| <i>F 77 3</i> | -                       | <i>F243</i>  | <i>F30 4</i>         | <i>F345</i>  | <i>F30 3</i> | <i>F30 3</i> | <i>F368</i>   |
| <i>F 77 4</i> | -                       | <i>F250</i>  | <i>F308</i>          | <i>F346</i>  | <i>F633</i>  | <i>F6 10</i> | <i>F369</i>   |
| <i>F 77 5</i> | -                       | <i>F25 1</i> | <i>F309</i>          | <i>F347</i>  | <i>F66 7</i> | <i>F6 11</i> | <i>F37 2</i>  |
| <i>F 77 6</i> | -                       | <i>F25 2</i> | <i>F50 2</i>         | <i>F400</i>  | <i>F668</i>  | <i>F6 12</i> | <i>F37 3</i>  |
| <i>F 77 7</i> | -                       | <i>F30 4</i> | <i>F506</i>          | <i>F405</i>  | -            | <i>F633</i>  | <i>F380</i>   |
| <i>F 77 8</i> | -                       | <i>F308</i>  | <i>F50 7</i>         | <i>F4 15</i> | -            | <i>F66 7</i> | <i>F389</i>   |
| <i>F 77 9</i> | -                       | <i>F309</i>  | <i>F70 1</i>         | <i>F4 17</i> | -            | <i>F668</i>  | <i>F39 1</i>  |
| <i>F 78 0</i> | -                       | <i>F70 1</i> | -                    | <i>F648</i>  | -            | -            | <i>F62 1</i>  |
| <i>F 78 1</i> | <i>F70 1</i>            | <i>F70 2</i> | -                    | <i>F70 1</i> | -            | -            | -             |
| <i>F 78 2</i> | <i>PSEL</i>             | <i>PSEL</i>  | <i>PSEL</i>          | <i>PSEL</i>  | <i>PSEL</i>  | <i>PSEL</i>  | <i>PSEL</i>   |

## 11.9 Unchangeable parameters in running

For reasons of safety, the following parameters cannot be changed during inverter running.  
Change parameters while inverter stops.

### [Basic parameters]

|               |                                       |               |                                    |
|---------------|---------------------------------------|---------------|------------------------------------|
| <i>RUF</i>    | (Guidance function)                   | <i>FND</i> *1 | (Frequency setting mode selection) |
| <i>RUR</i>    | (Application easy setting)            | <i>FH</i>     | (Maximum frequency)                |
| <i>RU1</i>    | (Automatic acceleration/deceleration) | <i>Pl</i>     | (V/F control mode selection)       |
| <i>RU2</i>    | (Torque boost setting macro function) | <i>LP</i>     | (Default setting)                  |
| <i>CND</i> *1 | (Command mode selection)              | <i>SEt</i>    | (Checking the region setting)      |

### [Extended parameters]

|                            |                                 |
|----------------------------|---------------------------------|
| <i>F104</i> to <i>F156</i> | <i>F405</i> to <i>F417</i>      |
| <i>F190</i> to <i>F199</i> | <i>F451</i>                     |
| <i>F207/F258/F261</i>      | <i>F454, F458</i>               |
| <i>F301, F302</i>          | <i>F480</i> to <i>F495</i>      |
| <i>F304</i> to <i>F316</i> | <i>F519/F603/F605/F608/F613</i> |
| <i>F319</i>                | <i>F626</i> to <i>F631</i>      |
| <i>F328</i> to <i>F330</i> | <i>F644/F669/F681/F750/F899</i> |
| <i>F340, F341</i>          | <i>F909</i> to <i>F913</i>      |
| <i>F346</i>                | <i>F915, F916</i>               |
| <i>F348, F349</i>          | <i>F980</i>                     |
| <i>F360/F369</i>           | <i>R900</i> to <i>R917</i>      |
| <i>F375</i> to <i>F378</i> | <i>R973</i> to <i>R977</i>      |
| <i>F389/F400</i>           |                                 |

\*1: *CND* and *FND* can be changed during operation by setting *F736=0*.

(Note) Refer to "Communication manual" about parameter Cxxx.

## 12. Specifications

### 12.1 Models and their standard specifications

#### ■ Standard specifications

| Item                         |                                              | Specification                               |              |                   |                |                |                |                |                |                |  |
|------------------------------|----------------------------------------------|---------------------------------------------|--------------|-------------------|----------------|----------------|----------------|----------------|----------------|----------------|--|
| Input voltage                |                                              | 3-phase 240V                                |              |                   |                |                |                |                |                |                |  |
| Applicable motor (kW)        |                                              | 0.4                                         | 0.75         | 1.5               | 2.2            | 4.0            | 5.5            | 7.5            | 11             | 15             |  |
| Rating                       | Type                                         | VFS15                                       |              |                   |                |                |                |                |                |                |  |
|                              | Form                                         | 2004PM-W                                    | 2007PM-W     | 2015PM-W          | 2022PM-W       | 2037PM-W       | 2055PM-W       | 2075PM-W       | 2110PM-W       | 2150PM-W       |  |
|                              | Capacity (kVA) Note 1)                       | 1.3                                         | 1.8          | 3.0               | 4.2            | 6.7            | 10.5           | 12.6           | 20.6           | 25.1           |  |
|                              | Rated output current (A) Note 2)             | 3.3<br>(3.3)                                | 4.8<br>(4.4) | 8.0<br>(7.9)      | 11.0<br>(10.0) | 17.5<br>(16.4) | 27.5<br>(25.0) | 33.0<br>(33.0) | 54.0<br>(49.0) | 66.0<br>(60.0) |  |
|                              | Output voltage Note 3)                       | 3-phase 200V to 240V                        |              |                   |                |                |                |                |                |                |  |
| Power supply                 | Overload current rating                      | 150%~60 seconds, 200%~0.5 second            |              |                   |                |                |                |                |                |                |  |
|                              | Voltage-frequency                            | 3-phase 200V to 240V - 50/60Hz              |              |                   |                |                |                |                |                |                |  |
|                              | Allowable fluctuation                        | Voltage 170V to 264V Note 4), frequency ±5% |              |                   |                |                |                |                |                |                |  |
|                              | Required Power supply capacity (kVA) Note 5) | 1.4                                         | 2.5          | 4.3               | 5.7            | 9.2            | 13.8           | 17.8           | 24.3           | 31.6           |  |
| Protective method (IEC60529) |                                              | IP20                                        |              |                   |                |                |                |                |                |                |  |
| Cooling method               |                                              | Self-cooling                                |              | Forced air-cooled |                |                |                |                |                |                |  |
| Color                        |                                              | RAL7016                                     |              |                   |                |                |                |                |                |                |  |
| Built-in filter              |                                              | Basic filter                                |              |                   |                |                |                |                |                |                |  |

| Item                         |                                              | Specification                              |              |                   |              |                |                                             |              |              |              |              |                |                |                |                |
|------------------------------|----------------------------------------------|--------------------------------------------|--------------|-------------------|--------------|----------------|---------------------------------------------|--------------|--------------|--------------|--------------|----------------|----------------|----------------|----------------|
| Input voltage                |                                              | 1-phase 240V                               |              |                   |              |                | 3-phase 500V                                |              |              |              |              |                |                |                |                |
| Applicable motor (kW)        |                                              | 0.2                                        | 0.4          | 0.75              | 1.5          | 2.2            | 0.4                                         | 0.75         | 1.5          | 2.2          | 4.0          | 5.5            | 7.5            | 11             | 15             |
| Rating                       | Type                                         | VFS15S                                     |              |                   |              |                | VFS15                                       |              |              |              |              |                |                |                |                |
|                              | Form                                         | 2002PL                                     | 2004PL       | 2007PL            | 2015PL       | 2022PL         | 4004PL                                      | 4007PL       | 4015PL       | 4022PL       | 4037PL       | 4055PL         | 4075PL         | 4110PL         | 4150PL         |
|                              | Capacity (kVA) Note 1)                       | 0.6                                        | 1.3          | 1.8               | 3.0          | 4.2            | 1.1                                         | 1.8          | 3.1          | 4.2          | 7.2          | 10.9           | 13.0           | 21.1           | 25.1           |
|                              | Rated output current (A) Note 2)             | 1.5<br>(1.5)                               | 3.3<br>(3.3) | 4.8<br>(4.4)      | 8.0<br>(7.9) | 11.0<br>(10.0) | 1.5<br>(1.5)                                | 2.3<br>(2.1) | 4.1<br>(3.7) | 5.5<br>(5.0) | 9.5<br>(8.6) | 14.3<br>(13.0) | 17.0<br>(17.0) | 27.7<br>(25.0) | 33.0<br>(30.0) |
|                              | Rated output voltage Note 3)                 | 3-phase 200V to 240V                       |              |                   |              |                | 3-phase 380V to 500V                        |              |              |              |              |                |                |                |                |
| Power supply                 | Overload current rating                      | 150%~60 seconds, 200%~0.5 second           |              |                   |              |                | 150%~60 seconds, 200%~0.5 second            |              |              |              |              |                |                |                |                |
|                              | Voltage- frequency                           | 1-phase 200V to 240V – 50/60Hz             |              |                   |              |                | 3-phase 380V to 500V - 50/60Hz              |              |              |              |              |                |                |                |                |
|                              | Allowable fluctuation                        | Voltage 170V to 264V Note 4), frequency±5% |              |                   |              |                | Voltage 323V to 550V Note 4), frequency ±5% |              |              |              |              |                |                |                |                |
|                              | Required Power supply capacity (kVA) Note 5) | 0.8                                        | 1.4          | 2.3               | 4.0          | 5.4            | 1.6                                         | 2.7          | 4.7          | 6.4          | 10.0         | 15.2           | 19.5           | 26.9           | 34.9           |
| Protective method (IEC60529) |                                              | IP20                                       |              |                   |              |                | IP20                                        |              |              |              |              |                |                |                |                |
| Cooling method               |                                              | Self-cooling                               |              | Forced air-cooled |              |                | Forced air-cooled                           |              |              |              |              |                |                |                |                |
| Color                        |                                              | RAL7016                                    |              |                   |              |                | RAL7016                                     |              |              |              |              |                |                |                |                |
| Built-in filter              |                                              | EMC filter                                 |              |                   |              |                | EMC filter                                  |              |              |              |              |                |                |                |                |

Note 1. Capacity is calculated at 220V for the 240V models, at 440V for the 500V models.

Note 2. Indicates rated output current setting when the PWM carrier frequency (parameter  $F_{300}$ ) is 4kHz or less. When exceeding 4kHz, the rated output current setting is indicated in the parentheses. It needs to be further reduced for PWM carrier frequencies above 12 kHz.

The rated output current is reduced even further for 500V models with a supply voltage of 480V or more.

The default setting of the PWM carrier frequency is 12kHz.

Note 3. Maximum output voltage is the same as the input voltage.

Note 4. At 180V-264V for the 240V models, at 342V-550V for the 500V models when the inverter is used continuously (load of 100%).

Note 5. Required power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).

## ■ Common specification

| Item                        |                                                 | Specification                                                                                                                                                                                                                                                                                                                                  |
|-----------------------------|-------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Principal control functions | Control system                                  | Sinusoidal PWM control                                                                                                                                                                                                                                                                                                                         |
|                             | Output voltage range (Note1)                    | Adjustable within the range of 50 to 330V (240V class) and 50 to 660V (500V class) by correcting the supply voltage                                                                                                                                                                                                                            |
|                             | Output frequency range                          | 0.1 to 500.0Hz, default setting: 0.5 to 80Hz, maximum frequency: 30 to 500Hz                                                                                                                                                                                                                                                                   |
|                             | Minimum setting steps of frequency              | 0.1Hz: analog input (when the max. frequency is 100Hz), 0.01Hz: Operation panel setting and communication setting                                                                                                                                                                                                                              |
|                             | Frequency accuracy                              | Digital setting: within $\pm 0.01\%$ of the max. frequency ( $-10$ to $+60^{\circ}\text{C}$ )<br>Analog setting: within $\pm 0.5\%$ of the max. frequency ( $25^{\circ}\text{C} \pm 10^{\circ}\text{C}$ )                                                                                                                                      |
|                             | Voltage/frequency characteristics               | V/f constant, variable torque, automatic torque boost, vector control, automatic energy-saving, dynamic automatic energy-saving control (for fan and pump), PM motor control, V/F 5-point setting, Auto-tuning, Base frequency (20-500Hz) adjusting to 1 & 2, torque boost (0-30%) adjusting to 1 & 2, adjusting frequency at start (0.1-10Hz) |
|                             | Frequency setting signal                        | Setting dial on the front panel, external frequency potentiometer (connectable to a potentiometer with a rated impedance of 1k-10k $\Omega$ ), 0-10Vdc / -10-+10Vdc (input impedance: 30k $\Omega$ ), 4-20mA $\text{dc}$ (input impedance: 250 $\Omega$ )                                                                                      |
|                             | Terminal block base frequency                   | The characteristic can be set arbitrarily by two-point setting. Possible to set: analog input (VIA, VIB, VIC)                                                                                                                                                                                                                                  |
|                             | Frequency jump                                  | Three frequencies can be set. Setting of the jump frequency and the range                                                                                                                                                                                                                                                                      |
|                             | Upper- and lower-limit frequencies              | Upper-limit frequency: 0.5 to max. frequency, lower-limit frequency: 0 to upper-limit frequency                                                                                                                                                                                                                                                |
|                             | PWM carrier frequency                           | Adjustable range of 2.0k to 16.0kHz (default: 12.0kHz)                                                                                                                                                                                                                                                                                         |
|                             | PID control                                     | Setting of proportional gain, integral gain, differential gain and control waiting time. Checking whether the amount of processing amount and the amount of feedback agree.                                                                                                                                                                    |
| Operation specifications    | Acceleration/deceleration time                  | Selectable from among acceleration/deceleration times 1 & 2 & 3 (0.0 to 3600 sec.). Automatic acceleration/deceleration function. S-pattern acceleration/deceleration 1 & 2 and S-pattern adjustable. Control of forced rapid deceleration and dynamic rapid deceleration.                                                                     |
|                             | DC braking                                      | Braking start-up frequency: 0 to maximum frequency, braking rate: 0 to 100%, braking time: 0 to 25.5 seconds, emergency DC braking, motor shaft fixing control.                                                                                                                                                                                |
|                             | Dynamic Braking Drive Circuit                   | Control and drive circuit is built in the inverter with the braking resistor outside (optional).                                                                                                                                                                                                                                               |
|                             | Input terminal function (programmable)          | Possible to select from among about 110 functions, such as forward/reverse run signal input, jog run signal input, operation base signal input and reset signal input, to assign to 8 input terminals. Logic selectable between sink and source.                                                                                               |
|                             | Output terminal functions (programmable)        | Possible to select from among about 150 functions, such as upper/lower limit frequency signal output, low speed detection signal output, specified speed reach signal output and failure signal output, to assign to FL relay output, open collector output terminal, and RY output terminals.                                                 |
|                             | Forward/reverse run                             | The RUN and STOP keys on the operation panel are used to start and stop operation, respectively. Forward/reverse run possible through communication and logic inputs from the terminal block.                                                                                                                                                  |
|                             | Jog run                                         | Jog mode, if selected, allows jog operation from the terminal block and also from remote keypad.                                                                                                                                                                                                                                               |
|                             | Preset speed operation                          | Frequency references + 15-speed operation possible by changing the combination of 4 contacts on the terminal block.                                                                                                                                                                                                                            |
|                             | Retry operation                                 | Capable of restarting automatically after a check of the main circuit elements in case the protective function is activated. 10 times (Max.) (selectable with a parameter)                                                                                                                                                                     |
|                             | Various prohibition settings / Password setting | Possible to write-protect parameters and to prohibit the change of panel frequency settings and the use of operation panel for operation, emergency stop or resetting. Possible to write-protect parameters by setting 4 digits password and terminal input.                                                                                   |
|                             | Regenerative power ride-through control         | Possible to keep the motor running using its regenerative energy in case of a momentary power failure (default: OFF).                                                                                                                                                                                                                          |
|                             | Auto-restart operation                          | In the event of a momentary power failure, the inverter reads the rotational speed of the coasting motor and outputs a frequency appropriate to the rotational speed in order to restart the motor smoothly. This function can also be used when switching to commercial power.                                                                |
|                             | Light-load high-speed operation                 | Increases the operating efficiency of the machine by increasing the rotational speed of the motor when it is operated under light load.                                                                                                                                                                                                        |
|                             | Drooping function                               | When two or more inverters are used to operate a single load, this function prevents load from concentrating on one inverter due to unbalance.                                                                                                                                                                                                 |
|                             | Override function                               | External input signal adjustment is possible to the operation frequency command value.                                                                                                                                                                                                                                                         |
|                             | Relay output signal                             | 1c- contact output and 1a- contact output (Note2)<br>Maximum switching capacity : 250Vac-2A , 30Vdc-2A ( $\cos\Phi=1$ : at resistive load),<br>250Vac-1A ( $\cos\Phi=0.4$ ) , 30Vdc-1A (L/R=7ms)<br>Minimum permissible load : 5Vdc-100mA, 24Vdc-5mA                                                                                           |

<Continued overleaf>

&lt;Continued&gt;

| Item                |                                   | Specification                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Protective function | Protective function               | Stall prevention, current limitation, over-current, output short circuit, over-voltage, over-voltage limitation, undervoltage, ground fault detection, input phase failure, output phase failure, overload protection by electronic thermal function, armature over-current at start-up, load side over-current at start-up, over-torque, undercurrent, overheating, cumulative operation time, life alarm, emergency stop, braking resistor overcurrent / overload, various pre-alarms                                                       |
|                     | Electronic thermal characteristic | Switching between standard motor and constant-torque VF motor, switching between motors 1 & 2, setting of overload trip time, adjustment of stall prevention levels 1 & 2, selection of overload stall                                                                                                                                                                                                                                                                                                                                        |
|                     | Reset function                    | Panel reset / External signal reset / Power supply reset. This function is also used to save and clear trip records.                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Display function    | Alarms                            | Overcurrent, overvoltage, overload, overheat, communication error, under-voltage, setting error, retry in process, upper/lower limits                                                                                                                                                                                                                                                                                                                                                                                                         |
|                     | Causes of failures                | Overcurrent, overvoltage, overheat, output short-circuit, ground fault, overload on inverter, arm overcurrent at start-up, overcurrent on the load side at start-up, CPU fault, EEPROM fault, RAM fault, ROM fault, communication error. (Selectable: dynamic braking resistor overload, emergency stop, under-voltage, small current, over-torque, low-torque, motor overload, input phase failure, output phase failure)                                                                                                                    |
|                     | Monitoring function               | Output frequency, frequency command value, operation frequency command, forward/reverse run, output current, input voltage (DC detection), output voltage, torque, inverter load factor, motor load factor, braking resistor load factor, input power, output power, information on input terminals, information on output terminals, overload and region setting, version of CPU1, version of CPU2, PID feedback value, stator frequency, causes of past trips 1to 8, parts replacement alarm, cumulative operation time, number of starting |
|                     | Past trip monitoring function     | Stores data on the past eight trips: number of trips that occurred in succession, output frequency, frequency command value, forward/reverse run, output current, input voltage (DC detection), output voltage, information on input terminals, information on output terminals, and cumulative operation time when each trip occurred.                                                                                                                                                                                                       |
|                     | Output for frequency meter        | Analog output for meter: 1mA dc full-scale dc ammeter<br>0 - 20mA (4 to 20mA) output: DC ammeter (allowable load resistance: 600Ω or less)<br>0 - 10V output: DC voltmeter (allowable load resistance: 1kΩ or more)<br>Maximum resolution: 1/1000                                                                                                                                                                                                                                                                                             |
|                     | 4-digit 7-segments LED            | Frequency: inverter output frequency.<br>Alarm: overcurrent alarm "L", overvoltage alarm "P", overload alarm "L", overheat alarm "H", communication alarm "L".<br>Status: inverter status (frequency, cause of activation of protective function, input/output voltage, output current, etc.) and parameter settings.<br>Free-unit display: arbitrary unit (e.g. rotating speed) corresponding to output frequency                                                                                                                            |
|                     | Indicator                         | Lamps indicating the inverter status by lighting, such as RUN lamp, MON lamp, PRG lamp, % lamp, Hz lamp. The charge lamp indicates that the main circuit capacitors are electrically charged.                                                                                                                                                                                                                                                                                                                                                 |
| Environments        | Location of use                   | Indoors, not exposed to direct sunlight, corrosive gas, explosive gas, flammable gas, oil mist, or dust; and vibration of less than 5.9m/s <sup>2</sup> (10 to 55Hz)                                                                                                                                                                                                                                                                                                                                                                          |
|                     | Elevation                         | 3000 m or less (current reduction required over 1000 m) Note 3)                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|                     | Ambient temperature               | -10 to +60°C Note 4)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                     | Storage temperature               | -25 to +70°C                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                     | Relative humidity                 | 5 to 95% (free from condensation and vapor)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

Note 1. Maximum output voltage is the same as the input voltage.

Note 2. A chattering (momentary ON/OFF of contact) is generated by external factors of the vibration and the impact, etc. In particular, please set the filter of 10ms or more, or timer for measures when connecting it directly with input unit terminal of programmable controller. Please use the OUT terminal as much as possible when the programmable controller is connected.

Note 3. Current must be reduced by 1% for each 100 m over 1000 m. For example, 90% at 2000m and 80% at 3000m.

Note 4. When using the inverter in locations with temperatures above 40°C, remove the protective label on the top of the inverter and use the inverter with the output current reduced according to section 6.18.

To align the inverters side-by-side horizontally, remove the protective label on the top of the inverter before use. When using the inverter in locations with temperatures above 40°C, use the inverter with the output current reduced.

## 12.2 Outside dimensions and mass

### ■ Outside dimensions and mass

| Voltage class | Applicable motor (kW) | Inverter type   | Dimensions (mm) |     |       |     |       |     |     |     | Drawing | Approx. weight (kg) |
|---------------|-----------------------|-----------------|-----------------|-----|-------|-----|-------|-----|-----|-----|---------|---------------------|
|               |                       |                 | W               | H   | D     | W1  | H1    | H2  | D2  |     |         |                     |
| 3-phase 240V  | 0.4                   | VFS15-2004PM-W  | 72              | 130 | 120   | 60  | 121.5 | 13  | 7.5 | A   | 0.9     |                     |
|               | 0.75                  | VFS15-2007PM-W  |                 |     |       |     |       |     |     |     |         | 1.0                 |
|               | 1.5                   | VFS15-2015PM-W  | 130             |     | 93    | 1.4 |       |     |     |     |         |                     |
|               | 2.2                   | VFS15-2022PM-W  | 105             |     |       |     |       |     |     | B   | 1.4     |                     |
|               | 4.0                   | VFS15-2037PM-W  | 140             | 170 | 150   | 126 | 157   | 14  |     |     | C       | 2.2                 |
|               | 5.5                   | VFS15-2055PM-W  |                 |     |       |     |       |     |     | D   | 3.5     |                     |
|               | 7.5                   | VFS15-2075PM-W  | 150             | 220 | 170   | 130 | 210   | 12  |     |     | 3.6     |                     |
|               | 11                    | VFS15-2110PM-W  |                 |     |       |     |       |     |     | E   | 6.8     |                     |
|               | 15                    | VFS15-2150PM-W  | 180             | 310 | 190   | 160 | 295   | 20  |     |     | 6.9     |                     |
| 1-phase 240V  | 0.2                   | VFS15S-2002PL-W | 72              | 130 | 101   | 131 | 13    | 7.5 | A   | 0.8 |         |                     |
|               | 0.4                   | VFS15S-2004PL-W |                 |     | 120   | 60  |       |     |     | 1.0 |         |                     |
|               | 0.75                  | VFS15S-2007PL-W |                 |     | 135   |     |       |     |     | 1.1 |         |                     |
|               | 1.5                   | VFS15S-2015PL-W |                 |     | 121.5 |     | B     |     | 1.6 |     |         |                     |
|               | 2.2                   | VFS15S-2022PL-W | 105             |     | 150   | 93  |       |     | 12  | 1.6 |         |                     |
| 3-phase 500V  | 0.4                   | VFS15-4004PL-W  | 107             | 130 |       |     | 121.5 | 13  | 7.5 | B   | 1.4     |                     |
|               | 0.75                  | VFS15-4007PL-W  |                 |     |       |     |       |     |     |     |         | 1.5                 |
|               | 1.5                   | VFS15-4015PL-W  |                 |     |       |     |       |     |     |     |         | 1.5                 |
|               | 2.2                   | VFS15-4022PL-W  |                 |     |       |     |       |     |     | C   | 2.4     |                     |
|               | 4.0                   | VFS15-4037PL-W  | 140             | 170 | 160   | 126 | 157   | 14  |     |     | 2.6     |                     |
|               | 5.5                   | VFS15-4055PL-W  |                 |     |       |     |       |     |     | D   | 3.9     |                     |
|               | 7.5                   | VFS15-4075PL-W  | 150             | 220 | 170   | 130 | 210   | 12  |     |     | 4.0     |                     |
|               | 11                    | VFS15-4110PL-W  |                 |     |       |     |       |     |     | E   | 6.4     |                     |
|               | 15                    | VFS15-4150PL-W  | 180             | 310 | 190   | 160 | 295   | 20  |     |     | 6.5     |                     |

## ■ Outline drawing




Fig.A




Fig.B

\*58mm for 1-phase 240V-1.5, 2.2kW models.




Fig.C

\*Above dimension is the size of EMP009Z, 45mm and 59mm for EMP008Z.

Note 1. To make it easier to grasp the dimensions of each inverter, dimensions common to all inverters in these figures are shown with numeric values but not with symbols.

Here are the meanings of the symbols used.

W: Width, H: Height, D: Depth

W1: Mounting dimension (horizontal)

H1: Mounting dimension (vertical)

H2: Height of EMC plate mounting area

D2: Depth of setting dial

Note 2. Here are the available EMC plates.

Fig.A: EMP007Z

Fig.B: EMP008Z

Fig.C: EMP008Z for 3-phase 500V-2.2, 4.0kW models

EMP009Z for 3-phase 240V-4.0kW model

Fig.D: EMP010Z

Fig.E: EMP011Z

Note 3. The models shown in Fig. A and Fig. B are fixed at two points: in the upper left and lower right corners.

Note 4. The model shown in Fig. A is not equipped with a cooling fan.

Note 5. The cooling fan of 1-phase 240V-1.5, 2.2kW models are on the upper side of the inverter.




Fig.D




Fig.E

# 13. Before making a service call

## - Trip information and remedies

### 13.1 Trip /Alarm causes and remedies

When a problem arises, diagnose it in accordance with the following table.

If it is found that replacement of parts is required or the problem cannot be solved by any remedy described in the table, contact your Toshiba distributor.

[Trip information]

| Error code             | Failure code | Problem                                                   | Possible causes                                                                                                                                                                                                                                                                                                                                                                                                   | Remedies                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------|--------------|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| $\overline{OC1}$       | 0001         | Overcurrent during acceleration                           | <ul style="list-style-type: none"> <li>The acceleration time <math>\overline{ACC}</math> is too short.</li> <li>The V/F setting is improper.</li> <li>A restart signal is input to the rotating motor after a momentary stop, etc.</li> <li>A special motor (e.g. motor with a small impedance) is used.</li> <li>Low inductance motor especially High speed motor is used.</li> </ul>                            | <ul style="list-style-type: none"> <li>Increase the acceleration time <math>\overline{ACC}</math>.</li> <li>Check the V/F parameter setting.</li> <li>Use <math>\overline{F301}</math> (auto-restart) and <math>\overline{F302}</math> (ride-through control).</li> <li>In case of <math>P\&gt;0</math>, <math>i</math>, <math>\gamma</math>, decrease <math>\omega b</math>.</li> <li>In case of <math>P\leq 0</math>, set <math>\overline{F415}</math> (Motor rated current) and make an auto-tuning.</li> <li>Choose the higher power range drive. (1 class up drive is recommended.)</li> </ul> |
| $\overline{OC2}$       | 0002         | Overcurrent during deceleration                           | <ul style="list-style-type: none"> <li>The deceleration time <math>\overline{DEC}</math> is too short.</li> <li>Low inductance motor especially High speed motor is used.</li> </ul>                                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Increase the deceleration time <math>\overline{DEC}</math>.</li> <li>Choose the higher power range drive. (1 class up drive is recommended.)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                      |
| $\overline{OC3}$       | 0003         | Overcurrent during constant speed operation               | <ul style="list-style-type: none"> <li>The load fluctuates abruptly.</li> <li>The load is in an abnormal condition.</li> <li>Low inductance motor especially High speed motor is used.</li> </ul>                                                                                                                                                                                                                 | <ul style="list-style-type: none"> <li>Reduce the load fluctuation.</li> <li>Check the load (operated machine).</li> <li>Choose the higher power range drive. (1 class up drive is recommended.)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                         |
| $\overline{OCL}$       | 0004         | Overcurrent (An overcurrent on the load side at start-up) | <ul style="list-style-type: none"> <li>The insulation of the output main circuit or motor is defective.</li> <li>The motor has too small impedance.</li> </ul>                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>Check the secondary wiring and insulation state.</li> <li>Set <math>\overline{F512}=2, 3</math>.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| $\overline{OCR}$       | 0005         | Overcurrent at start-up                                   | <ul style="list-style-type: none"> <li>A main circuit element is defective.</li> </ul>                                                                                                                                                                                                                                                                                                                            | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| *<br>$\overline{EPH1}$ | 0008         | Input phase failure                                       | <ul style="list-style-type: none"> <li>A phase failure occurred in the input line of the main circuit.</li> <li>The capacitor in the main circuit lacks capacitance.</li> </ul>                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>Check the main circuit input line for phase failure.</li> <li>Check the capacitor in the main circuit for exhaustion.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                             |
| *<br>$\overline{EPH0}$ | 0009         | Output phase failure                                      | <ul style="list-style-type: none"> <li>A phase failure occurred in the output line of the main circuit.</li> </ul>                                                                                                                                                                                                                                                                                                | <ul style="list-style-type: none"> <li>Check the main circuit output line, motor, etc. for phase failure.</li> <li>Select output phase failure detection parameter <math>\overline{F605}</math>.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                         |
| $\overline{OP1}$       | 000A         | Overvoltage during acceleration                           | <ul style="list-style-type: none"> <li>The input voltage fluctuates abnormally.</li> <li>(1) The power supply has a capacity of 500kVA or more.</li> <li>(2) A power factor improvement capacitor is opened or closed.</li> <li>(3) A system using a thyristor is connected to the same power distribution line.</li> <li>A restart signal is input to the rotating motor after a momentary stop, etc.</li> </ul> | <ul style="list-style-type: none"> <li>Insert a suitable input reactor.</li> <li>Use <math>\overline{F301}</math> (auto-restart) and <math>\overline{F302}</math> (ride-through control).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                |

\* This marking trips can be selected valid or invalid by parameters.

(Continued overleaf)

(Continued)

| Error code | Failure code | Problem                                     | Possible causes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Remedies                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------|--------------|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OP2        | 000B         | Overvoltage during deceleration             | <ul style="list-style-type: none"> <li>The deceleration time <math>d\bar{E}\bar{L}</math> is too short. (Regenerative energy is too large.)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>Increase the deceleration time <math>d\bar{E}\bar{L}</math>.</li> </ul>                                                                                                                                                                                                                                                                                                                 |
|            |              |                                             | <ul style="list-style-type: none"> <li>Overvoltage limit operation <math>F3\bar{D}5</math> is set to 1. (Disabled).</li> <li>The input voltage fluctuates abnormally.               <ol style="list-style-type: none"> <li>The power supply has a capacity of 500kVA or more.</li> <li>A power factor improvement capacitor is opened and closed.</li> <li>A system using a thyristor is connected to the same power distribution line.</li> </ol> </li> </ul>                                                           | <ul style="list-style-type: none"> <li>Set overvoltage limit operation <math>F3\bar{D}5</math> to 0. 2. 3.</li> <li>Insert a suitable input reactor.</li> </ul>                                                                                                                                                                                                                                                                |
| OP3        | 000C         | Overvoltage during constant-speed operation | <ul style="list-style-type: none"> <li>The input voltage fluctuates abnormally.               <ol style="list-style-type: none"> <li>The power supply has a capacity of 500kVA or more.</li> <li>A power factor improvement capacitor is opened or closed.</li> <li>A system using a thyristor is connected to the same power distribution line.</li> </ol> </li> <li>The motor is in a regenerative state because the load causes the motor to run at a frequency higher than the inverter output frequency.</li> </ul> | <ul style="list-style-type: none"> <li>Insert a suitable input reactor.</li> <li>Install an optional dynamic braking resistor. (optional)</li> </ul>                                                                                                                                                                                                                                                                           |
| OL1        | 000D         | Inverter overload                           | <ul style="list-style-type: none"> <li>The acceleration time <math>R\bar{L}\bar{L}</math> is too short.</li> <li>The DC braking amount is too large.</li> <li>The V/F setting is improper.</li> <li>A restart signal is input to the rotating motor after a momentary stop, etc.</li> <li>The load is too large.</li> </ul>                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Increase the acceleration time <math>R\bar{L}\bar{L}</math>.</li> <li>Reduce the DC braking amount <math>F2\bar{S}1</math> and the DC braking time <math>F2\bar{S}2</math>.</li> <li>Check the V/F parameter setting.</li> <li>Use <math>F3\bar{D}1</math> (auto-restart) and <math>F3\bar{D}2</math> (ride-through control).</li> <li>Use an inverter with a larger rating.</li> </ul> |
|            |              |                                             | <ul style="list-style-type: none"> <li>The V/F setting is improper.</li> <li>The motor is locked up.</li> <li>Low-speed operation is performed continuously.</li> <li>An excessive load is applied to the motor during operation.</li> </ul>                                                                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>Check the V/F parameter setting.</li> <li>Check the load (operated machine).</li> <li>Adjust <math>OL\bar{n}</math> to the overload that the motor can withstand during operation in a low speed range.</li> </ul>                                                                                                                                                                      |
| OL3        | 003E         | Main module overload                        | <ul style="list-style-type: none"> <li>The carrier frequency is high and load current has increased at low speeds (mainly at 15Hz or less).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>Raise the operation frequency.</li> <li>Reduce the load.</li> <li>Reduce the carrier frequency.</li> <li>When an operating motor is started up at 0Hz, use the auto-restart function.</li> <li>Set carrier frequency control mode selection <math>F3\bar{1}6</math> to 1 (carrier frequency with automatic reduction).</li> </ul>                                                       |
| OLr        | 000F         | Dynamic braking resistor overload trip      | <ul style="list-style-type: none"> <li>The deceleration time is too short.</li> <li>Dynamic braking is too large.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>Increase the deceleration time <math>d\bar{E}\bar{L}</math>.</li> <li>Increase the capacity of dynamic braking resistor (wattage) and adjust PBR capacity parameter <math>F3\bar{D}9</math>.</li> </ul>                                                                                                                                                                                 |
| *<br>OLt   | 0020         | Over-torque trip 1                          | <ul style="list-style-type: none"> <li>Over-torque reaches to a detection level during operation.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>Enable <math>F6\bar{1}5</math> (over-torque trip selection).</li> <li>Check system error.</li> </ul>                                                                                                                                                                                                                                                                                    |
| OLt2       | 0041         | Over-torque trip 2                          | <ul style="list-style-type: none"> <li>Output current reached <math>F6\bar{D}1</math> or more and maintain in <math>F4\bar{Y}2</math> during power running.</li> <li>Power running torque reached <math>F4\bar{Y}1</math> or more and maintain in <math>F4\bar{Y}2</math> during power running.</li> </ul>                                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>Reduce the load.</li> <li>Increase the stall prevention level or power running torque limit level.</li> </ul>                                                                                                                                                                                                                                                                           |

\* This marking trips can be selected valid or invalid by parameters.

(Continued overleaf)

(Continued)

| Error code  | Failure code | Problem                                         | Possible causes                                                                                                                                                                                                                                                                                                                      | Remedies                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------|--------------|-------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| *<br>0E C 3 | 0048         | Over-torque / Overcurrent fault                 | <ul style="list-style-type: none"> <li>Power running torque or output current reached <math>F 5 9 3</math> or more and maintain in <math>F 5 9 5</math> during power running.</li> </ul>                                                                                                                                             | <ul style="list-style-type: none"> <li>Enable <math>F 5 9 1</math>.</li> <li>Reduce the load.</li> <li>Check system error.</li> </ul>                                                                                                                                                                                                                                                                                                      |
| *<br>0E C 3 | 0049         | Small-torque / Small-current fault              | <ul style="list-style-type: none"> <li>Power running torque or output current decreased <math>F 5 9 3</math> or less and maintain in <math>F 5 9 5</math> during power running.</li> </ul>                                                                                                                                           | <ul style="list-style-type: none"> <li>Enable <math>F 5 9 1</math>.</li> <li>Check system error.</li> </ul>                                                                                                                                                                                                                                                                                                                                |
| 0H          | 0010         | Overheat                                        | <ul style="list-style-type: none"> <li>The cooling fan does not rotate.</li> <li>The ambient temperature is too high.</li> <li>The vent is blocked up.</li> <li>A heat generating device is installed close to the inverter.</li> <li>The ambient temperature is too low.</li> <li>Wire of internal thermistor is broken.</li> </ul> | <ul style="list-style-type: none"> <li>The fan requires replacement if it does not rotate during operation.</li> <li>Restart the operation by resetting the inverter after it has cooled down enough.</li> <li>Secure sufficient space around the inverter.</li> <li>Do not place any heat generating device near the inverter.</li> <li>Operate at a specified ambient temperature.</li> <li>Contact your Toshiba distributor.</li> </ul> |
| 0H 2        | 002E         | Thermal fault stop command from external device | <ul style="list-style-type: none"> <li>A thermal trip command (input terminal function: <math>Y 5</math> or <math>Y 7</math>) is issued by an external control device.</li> </ul>                                                                                                                                                    | <ul style="list-style-type: none"> <li>The motor is overheated, so check whether the current flowing into the motor exceeds the rated current.</li> </ul>                                                                                                                                                                                                                                                                                  |
| E           | 0011         | Emergency stop                                  | <ul style="list-style-type: none"> <li>During automatic operation or remote operation, a stop command is entered from the operation panel or a remote input device.</li> </ul>                                                                                                                                                       | <ul style="list-style-type: none"> <li>Reset the inverter.</li> <li>If the emergency stop signal is input, reset after releasing this signal.</li> </ul>                                                                                                                                                                                                                                                                                   |
| E E P 1     | 0012         | EEPROM fault 1                                  | <ul style="list-style-type: none"> <li>A data writing error occurs.</li> </ul>                                                                                                                                                                                                                                                       | <ul style="list-style-type: none"> <li>Turn off the inverter, then, turn it again. If it does not recover from the error, contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                     |
| E E P 2     | 0013         | EEPROM fault 2                                  | <ul style="list-style-type: none"> <li>Power supply is cut off during <math>E P</math> operation and data writing is aborted.</li> <li>The error occurred when various data was written.</li> </ul>                                                                                                                                  | <ul style="list-style-type: none"> <li>Turn the power off temporarily and turn it back on, and then try <math>E P</math> operation again.</li> <li>Write the data again. Contact your Toshiba distributor when it happening frequently.</li> </ul>                                                                                                                                                                                         |
| E E P 3     | 0014         | EEPROM fault 3                                  | <ul style="list-style-type: none"> <li>A data reading error occurred.</li> </ul>                                                                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li>Turn off the inverter, then, turn it again. If it does not recover from the error, contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                     |
| E r r 2     | 0015         | Main unit RAM fault                             | <ul style="list-style-type: none"> <li>The control RAM is defective.</li> </ul>                                                                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                        |
| E r r 3     | 0016         | Main unit ROM fault                             | <ul style="list-style-type: none"> <li>The control ROM is defective.</li> </ul>                                                                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                        |
| E r r 4     | 0017         | CPU fault 1                                     | <ul style="list-style-type: none"> <li>The control CPU is defective.</li> </ul>                                                                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                        |
| E r r 5     | 0018         | Communication error                             | <ul style="list-style-type: none"> <li>The communication was broken off.</li> </ul>                                                                                                                                                                                                                                                  | <ul style="list-style-type: none"> <li>Check the remote control device, cables, etc.</li> </ul>                                                                                                                                                                                                                                                                                                                                            |
| E r r 8     | 001B         | Optional unit fault 1                           | <ul style="list-style-type: none"> <li>An optional unit has failed. (such as a communication option)</li> </ul>                                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Check the connection of optional unit.</li> </ul>                                                                                                                                                                                                                                                                                                                                                   |
| E r r 9     | 001C         | Remote keypad disconnection fault               | <ul style="list-style-type: none"> <li>After run signal is activated by RUN key of the remote keypad, disconnection is occurred in 10 seconds or more.</li> </ul>                                                                                                                                                                    | <ul style="list-style-type: none"> <li>In case the remote keypad is disconnected, press STOP key before.</li> <li>This fault is disabled by <math>F 7 3 1 = 1</math> setting.</li> </ul>                                                                                                                                                                                                                                                   |
| *<br>0E     | 001D         | Low-current operation fault                     | <ul style="list-style-type: none"> <li>The output current decreased to a low-current detection level during operation.</li> </ul>                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>Enable <math>F 6 1 0</math> (low-current detection).</li> <li>Check the suitable detection level for the system (<math>F 6 0 9</math>, <math>F 6 1 1</math>, <math>F 6 1 2</math>).</li> <li>Contact your Toshiba distributor if the setting is correct.</li> </ul>                                                                                                                                 |
| *<br>0P 1   | 001E         | Undervoltage fault (main circuit)               | <ul style="list-style-type: none"> <li>The input voltage (in the main circuit) is too low.</li> </ul>                                                                                                                                                                                                                                | <ul style="list-style-type: none"> <li>Check the input voltage.</li> <li>Enable <math>F 6 2 7</math> (undervoltage trip selection).</li> <li>To take measures to momentary power failure, set <math>F 6 2 7 = 0</math>. Regenerative power ride-through control <math>F 3 0 2</math> and Auto-restart control selection <math>F 3 0 1</math>.</li> </ul>                                                                                   |

\* This marking trips can be selected valid or invalid by parameters.

(Continued overleaf)

(Continued)

| Error code                                                  | Failure code                 | Problem                            | Possible causes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Remedies                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------------------------------------------------|------------------------------|------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| $E\bar{t}n$<br>$E\bar{t}n1$<br>$E\bar{t}n2$<br>$E\bar{t}n3$ | 0028<br>0054<br>0055<br>0056 | Auto-tuning error                  | <ul style="list-style-type: none"> <li>The motor parameter <math>uL</math>, <math>uL\bar{u}</math>, <math>F4\bar{Q}5</math>, <math>F415</math>, <math>F417</math> are not set correctly.</li> <li>The motor with the capacity of 2 classes or less than the inverter is used.</li> <li>The output cable is too thin.</li> <li>The inverter is used for loads other than those of three-phase induction motors.</li> <li>The motor is not connected.</li> <li>The motor is rotating.</li> <li>Parameter <math>P\bar{k}=\bar{6}</math> is set and High speed motor is connected.</li> </ul> | <ul style="list-style-type: none"> <li>Set the left column parameters correctly as a motor name plate and make an auto-tuning again.</li> <li>Set parameter <math>F41\bar{6}</math> to smaller 70% of the present value, and execute the auto-tuning again.</li> <li>Set the left column parameters correctly as a motor name plate and make an auto-tuning again.</li> <li>Then set <math>F4\bar{Q}\bar{Q}=1</math>, when trip occurs.</li> <li>Connect the motor.</li> <li>Check whether the secondary magnetic contactor.</li> <li>Make an auto-tuning again after the rotation of the motor stops.</li> <li>Choose the higher power range drive. (1 class up drive is recommended.)</li> </ul> |
| $E\bar{F}2$                                                 | 0022                         | Ground fault                       | <ul style="list-style-type: none"> <li>A ground fault occurs in the output cable or the motor.</li> <li>Overcurrent of dynamic braking resistor</li> <li>When inverters are fed by AC power supply and connected with common DC bus link, unnecessary trip occurs.</li> </ul>                                                                                                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>Check the cable and the motor for ground faults.</li> <li>Increase the deceleration time <math>d\bar{E}\bar{C}</math>.</li> <li>Set the supply voltage correction <math>F3\bar{Q}7</math> to 1 or 3.</li> <li>Set the parameter <math>F\bar{6}14</math> to <math>\bar{Q}</math> "Disabled".</li> </ul>                                                                                                                                                                                                                                                                                                                                                      |
| *<br>$S\bar{O}U\bar{t}$                                     | 002F                         | Step-out (for PM motor drive only) | <ul style="list-style-type: none"> <li>The motor shaft is locked.</li> <li>One output phase is open.</li> <li>An impact load is applied.</li> <li>Using the DC braking function.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>Unlock the motor shaft.</li> <li>Check the interconnect cables between the inverter and the motor.</li> <li>Prolong the acceleration / deceleration time.</li> <li>Turn off the Step-out function when using the DC braking function or change the DC braking to Servo lock function.</li> </ul>                                                                                                                                                                                                                                                                                                                                                            |
| $E\bar{t}yP$                                                | 0029                         | Inverter type error                | <ul style="list-style-type: none"> <li>It may be a breakdown failure.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| $E-13$                                                      | 002D                         | Over speed fault                   | <ul style="list-style-type: none"> <li>The input voltage fluctuates abnormally.</li> <li>Over speed fault due to the overvoltage limit operation.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Check the input voltage.</li> <li>Install an optional dynamic braking resistor. (optional)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| *<br>$E-18$                                                 | 0032                         | Analog input break detection fault | <ul style="list-style-type: none"> <li>The input signal from VIC is equal to or less than the <math>F\bar{6}33</math> setting.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <ul style="list-style-type: none"> <li>Check the VIC signal cable for breaks. Also, check the input signal value or setting of <math>F\bar{6}33</math>.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| $E-19$                                                      | 0033                         | CPU communications error           | <ul style="list-style-type: none"> <li>A communications error occurs between control CPUs.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| $E-2\bar{Q}$                                                | 0034                         | Over torque boost fault            | <ul style="list-style-type: none"> <li>The automatic torque boost parameter <math>F4\bar{Q}2</math> setting is too high.</li> <li>The motor has too small impedance.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                           | <ul style="list-style-type: none"> <li>Set a lower automatic torque boost parameter <math>F4\bar{Q}2</math> setting.</li> <li>Make an auto-tuning.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| $E-21$                                                      | 0035                         | CPU fault 2                        | <ul style="list-style-type: none"> <li>The control CPU is defective.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| $E-23$                                                      | 0037                         | Optional unit fault 2              | <ul style="list-style-type: none"> <li>An optional device is defective.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| $E-2\bar{6}$                                                | 003A                         | CPU fault 3                        | <ul style="list-style-type: none"> <li>The control CPU is defective.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| $E-27$                                                      | 0057                         | Internal circuit fault             | <ul style="list-style-type: none"> <li>Internal circuit is defective.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| $E-31$                                                      | 0063                         | Heavy cycle of main power ON/OFF   | <ul style="list-style-type: none"> <li>Main power ON/OFF during running is repeated frequently.</li> <li>Initial failure if it is caused by other reasons.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li>Reduce the frequency of repetition of main power ON/OFF during running.</li> <li>Contact your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| $E-32$                                                      | 0040                         | PTC fault                          | <ul style="list-style-type: none"> <li>PTC thermal protection is occurred.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li>Check the PTC in motor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| $E-37$                                                      | 0045                         | Servo lock fault                   | <ul style="list-style-type: none"> <li>The motor shaft is not locked in servo lock operation.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <ul style="list-style-type: none"> <li>Reduce the load in servo lock operation.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

\* This marking trips can be selected valid or invalid by parameters.

(Continued overleaf)

(Continued)

|        |      |                              |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                           |
|--------|------|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E - 39 | 0047 | Auto-tuning error (PM motor) | <ul style="list-style-type: none"> <li>When auto-tuning (relating parameters are <math>P\ell=5</math>, <math>F400=2</math>), the current of the permanent magnet motor exceeded the threshold level.</li> <li>The inductance of permanent magnet motor is too small.</li> </ul> | <ul style="list-style-type: none"> <li>Auto tuning for permanent magnet motor is not allowed for this motor, please measure inductance with the LCR meter etc.</li> </ul> |
|--------|------|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

[Alarm information] Each message in the table is displayed to give a warning but does not cause the inverter to trip.

| Error code                          | Problem                                                                            | Possible causes                                                                                                                                                                                                                                                                 | Remedies                                                                                                                                                                   |
|-------------------------------------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>OFF</i>                          | ST (assigned standby function) terminal OFF                                        | <ul style="list-style-type: none"> <li>The ST-CC (or P24) circuit is opened.</li> </ul>                                                                                                                                                                                         | <ul style="list-style-type: none"> <li>Close the ST-CC (or P24) circuit.</li> </ul>                                                                                        |
| <i>UOFF</i>                         | Undervoltage in main circuit                                                       | <ul style="list-style-type: none"> <li>The supply voltage between R, S and T is under voltage.</li> <li>Internal communication fault.</li> </ul>                                                                                                                                | <ul style="list-style-type: none"> <li>Measure the main circuit supply voltage. If the voltage is at a normal level, the inverter requires repairing for fault.</li> </ul> |
| <i>retry</i>                        | Retry in process                                                                   | <ul style="list-style-type: none"> <li>The inverter is in process of retry.</li> <li>A momentary stop occurred. The motor speed is being detected.</li> </ul>                                                                                                                   | <ul style="list-style-type: none"> <li>The inverter restarts automatically. Be careful of the machine because it may suddenly restart.</li> </ul>                          |
| <i>Err 1</i>                        | Frequency point setting error alarm                                                | <ul style="list-style-type: none"> <li>The frequency setting signals at points 1 and 2 are set too close to each other.</li> </ul>                                                                                                                                              | <ul style="list-style-type: none"> <li>Set the frequency setting signals at points 1 and 2 apart from each other.</li> </ul>                                               |
| <i>Clr</i>                          | Clear command acceptable                                                           | <ul style="list-style-type: none"> <li>This message is displayed when pressing the STOP key while an error code is displayed.</li> </ul>                                                                                                                                        | <ul style="list-style-type: none"> <li>Press the STOP key again to clear the trip.</li> </ul>                                                                              |
| <i>EOFF</i>                         | Emergency stop command acceptable                                                  | <ul style="list-style-type: none"> <li>The operation panel is used to stop the operation in automatic control or remote control mode.</li> </ul>                                                                                                                                | <ul style="list-style-type: none"> <li>Press the STOP key for an emergency stop. To cancel the emergency stop, press any other key.</li> </ul>                             |
| <i>H/L</i><br><i>LO</i>             | Setting error alarm / An error code and data are displayed alternately twice each. | <ul style="list-style-type: none"> <li>An error is found in a setting when data is reading or writing.</li> </ul>                                                                                                                                                               | <ul style="list-style-type: none"> <li>Check whether the setting is made correctly.</li> </ul>                                                                             |
| <i>HEAd/End</i>                     | Display of first/last data items                                                   | <ul style="list-style-type: none"> <li>The first and last data item in the <i>RUH</i> data group is displayed.</li> </ul>                                                                                                                                                       | <ul style="list-style-type: none"> <li>Press MODE key to exit the data group.</li> </ul>                                                                                   |
| <i>db</i>                           | DC braking                                                                         | <ul style="list-style-type: none"> <li>DC braking in process</li> </ul>                                                                                                                                                                                                         | <ul style="list-style-type: none"> <li>The message goes off in several tens of seconds if no problem occurs. (Note 1)</li> </ul>                                           |
| <i>E1</i><br><i>E2</i><br><i>E3</i> | Flowing out of excess number of digits                                             | <ul style="list-style-type: none"> <li>The number of digits such as frequencies is more than 4. (The upper digits have a priority.)</li> </ul>                                                                                                                                  | <ul style="list-style-type: none"> <li>Lower the frequency free unit magnification <math>F702</math>.</li> </ul>                                                           |
| <i>StOP</i>                         | Momentary power failure deceleration stop prohibition function activated.          | <ul style="list-style-type: none"> <li>The slowdown stop prohibition function set with <math>F302</math> (momentary power failure ride-through operation) is activated.</li> </ul>                                                                                              | <ul style="list-style-type: none"> <li>To restart operation, reset the inverter or input an operation signal again.</li> </ul>                                             |
| <i>LStP</i>                         | Auto-stop because of continuous operation at the lower-limit frequency             | <ul style="list-style-type: none"> <li>The automatic stop function selected with <math>F256</math> was activated.</li> </ul>                                                                                                                                                    | <ul style="list-style-type: none"> <li>This function is cancelled, when frequency reference reaches <math>LL+0.2\text{Hz}</math> or operation command is OFF.</li> </ul>   |
| <i>init</i>                         | Parameters in the process of initialization                                        | <ul style="list-style-type: none"> <li>Parameters are being initialized to default values.</li> </ul>                                                                                                                                                                           | <ul style="list-style-type: none"> <li>Normal if the message disappears after a while (several seconds to several tens of seconds).</li> </ul>                             |
| <i>R-Q1</i>                         | Points setting alarm 1                                                             | <ul style="list-style-type: none"> <li>In case of <math>P\ell=7</math>, there are same setting value at least two on parameter <math>\omega L</math>, <math>F190</math>, <math>F192</math>, <math>F194</math>, <math>F196</math>, or <math>F198</math> except 0.0Hz.</li> </ul> | <ul style="list-style-type: none"> <li>Set the points to different values.</li> </ul>                                                                                      |
| <i>R-Q2</i>                         | Points setting alarm 2                                                             | <ul style="list-style-type: none"> <li>In case of <math>P\ell=7</math>, the inclination of <math>V/f</math> is too high.</li> </ul>                                                                                                                                             | <ul style="list-style-type: none"> <li>Set the inclination of <math>V/f</math> to be flat.</li> </ul>                                                                      |

Note 1) When the DC braking (DB) function is assigned by using the input terminal function 22 or 23, it is normal if "db" disappears when opening the circuit between the terminal and CC (or P24).

(Continued overleaf)

(Continued)

| Error code                | Problem                                                        | Possible causes                                                                                                                                                                                                                                                                                                                   | Remedies                                                                                                                                                                                 |
|---------------------------|----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>R-05</i>               | Output frequency upper limit                                   | <ul style="list-style-type: none"> <li>An attempt was made to operate at a frequency higher than 10 times the base frequency (<i>UL</i> or <i>F170</i>).</li> </ul>                                                                                                                                                               | <ul style="list-style-type: none"> <li>Operate at a frequency within 10 times the base frequency.</li> </ul>                                                                             |
| <i>R-17</i>               | Operation panel key alarm                                      | <ul style="list-style-type: none"> <li>The RUN or STOP key is held down for more than 20 seconds.</li> <li>The RUN or STOP key is faulty.</li> </ul>                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Check the operation panel.</li> </ul>                                                                                                             |
| <i>R-27</i>               | Control terminal block connection alarm                        | <ul style="list-style-type: none"> <li>Control terminal block comes off.</li> <li>Internal circuit is defective.</li> </ul>                                                                                                                                                                                                       | <ul style="list-style-type: none"> <li>Install the control terminal block to the inverter.</li> <li>Contact your Toshiba distributor.</li> </ul>                                         |
| <i>R-28</i>               | S3 terminal alarm                                              | <ul style="list-style-type: none"> <li>Slide switch SW2 and parameter <i>F147</i> settings are different.</li> </ul>                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Match the settings of SW2 and <i>F147</i>. Power supply OFF and ON after these settings.</li> </ul>                                               |
| <i>Rtn</i>                | Auto-tuning                                                    | <ul style="list-style-type: none"> <li>Auto-tuning in process</li> </ul>                                                                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Normal if it the message disappears after a few seconds.</li> </ul>                                                                               |
| <i>R-18</i>               | Break in analog signal cable                                   | <ul style="list-style-type: none"> <li>The signal input via VIC is below the analog signal detection level set with <i>F633</i> and setting value of <i>F644</i> is one or more.</li> </ul>                                                                                                                                       | <ul style="list-style-type: none"> <li>Check the cables for breaks. And check the setting of input signal or setting value of <i>F633</i> and <i>F644</i>.</li> </ul>                    |
| <i>F1rE</i>               | In forced operation                                            | <ul style="list-style-type: none"> <li>"<i>F1rE</i>" and operation frequency is displayed alternately in operation of forced fire-speed control.</li> </ul>                                                                                                                                                                       | <ul style="list-style-type: none"> <li>It is normal the alarm is gone out after the forced fire-speed control operation.</li> </ul>                                                      |
| <i>PR55</i> / <i>FR1L</i> | Password verification result                                   | <ul style="list-style-type: none"> <li>After the password setting (<i>F738</i>), the password was input to <i>F739</i> (password verification).</li> </ul>                                                                                                                                                                        | <ul style="list-style-type: none"> <li>If the password is correct, <i>PR55</i> is displayed and if it is incorrect, <i>FR1L</i> is displayed.</li> </ul>                                 |
| <i>ERSY</i> / <i>SEd</i>  | Switching display of Easy setting mode / Standard setting mode | <ul style="list-style-type: none"> <li>The EASY key was pushed in the standard monitor mode.</li> </ul>                                                                                                                                                                                                                           | <ul style="list-style-type: none"> <li>When <i>ERSY</i> is displayed, setting mode becomes easy setting mode. When <i>SEd</i> is displayed, it becomes standard setting mode.</li> </ul> |
| <i>SEt</i> (Note 2)       | Input requirement of region setting                            | <ul style="list-style-type: none"> <li>A region setting is not input yet.</li> <li>Power supplied to the inverter at first time</li> <li>As checking the region setting parameter <i>SEt</i> is set to 0, inverter return to default setting.</li> <li>As <i>SEt</i> is set to 13, inverter return to default setting.</li> </ul> | <ul style="list-style-type: none"> <li>Set a region setting by using setting dial. Refer to section 3.1.</li> </ul>                                                                      |
| <i>nErr</i>               | No trip of past trip                                           | <ul style="list-style-type: none"> <li>No new record of past trip, after past trips were clear.</li> </ul>                                                                                                                                                                                                                        | <ul style="list-style-type: none"> <li>Normal operation.</li> </ul>                                                                                                                      |
| <i>n---</i>               | No detailed information of past trip                           | <ul style="list-style-type: none"> <li>The detailed information of past trip is read by pushing the center of setting dial during blinking <i>nErr</i> ⇔ number.</li> </ul>                                                                                                                                                       | <ul style="list-style-type: none"> <li>Normal operation. To be returned by pressing MODE key.</li> </ul>                                                                                 |

Note 2) *SEt* is blinking after power supply is on. In this time, the keys are not operated.  
But parameter *SEt* is lighting as same as other parameters and is not blinking.

(Prealarm display)

|          |                     |                                                |
|----------|---------------------|------------------------------------------------|
| <i>ℓ</i> | Overcurrent alarm   | Same as <i>OL</i> (overcurrent)                |
| <i>P</i> | Overvoltage alarm   | Same as <i>OP</i> (overvoltage)                |
| <i>L</i> | Overload alarm      | Same as <i>OL 1</i> and <i>OL 2</i> (overload) |
| <i>H</i> | Overheat alarm      | Same as <i>OH</i> (overheat)                   |
| <i>t</i> | Communication alarm | Same as <i>Err 5</i> (communication fault)     |

If two or more problems arise simultaneously, one of the following alarms appears and blinks.

*ℓ P, P L, ℓ P L*

The blinking alarms *ℓ, P, L, H, t* are displayed in this order from left to right.

## 13.2 Restoring the inverter from a trip

Do not reset the inverter when tripped because of a failure or error before eliminating the cause. Resetting the tripped inverter before eliminating the problem causes it to trip again.

The inverter can be restored from a trip by any of the following operations:

- (1) By turning off the power (Keep the inverter off until the LED turns off.)  
Note) See inverter trip hold selection  $F602$  for details.
- (2) By means of an external signal (Short circuit across RES and CC (or P24) on control terminal block → Open): The reset function must be assigned to the input terminal block. (function number 8, 9)
- (3) By panel keypad operation
- (4) By inputting a trip clear signal from communication  
(Refer to communication manual (E6581913) for details.)

To reset the inverter by panel keypad operation, follow these steps.

1. Press the STOP key and make sure that  $\text{C.L.r}$  is displayed.
  2. Pressing the STOP key again will reset the inverter if the cause of the trip has already been eliminated.
- When any overload function ( $\text{OL1}$ : inverter overload,  $\text{OL2}$ : motor overload,  $\text{OLr}$ : braking resistor overload) is active, the inverter cannot be reset by inputting a reset signal from an external device or by operation panel operation before the virtual cooling time has passed.

Virtual cooling time ...  $\text{OL1}$ : about 30 seconds after the occurrence of a trip

$\text{OL2}$ : about 120 seconds after a occurrence of a trip

$\text{OLr}$ : about 20 seconds after a occurrence of a trip


- As to  $\text{OL3}$  (Main module overload), there is no virtual cooling time.
- In case of a trip due to overheat ( $\text{OH}$ ), the inverter checks the temperature within. Wait until the temperature in the inverter falls sufficiently before resetting the inverter.
- The inverter cannot be reset while the emergency stop signal is being input from the terminal.
- The inverter cannot be reset while the pre-alarm is occurred.

### [Caution]

Turning the inverter off then turning it on again resets the inverter immediately. You can use this mode of resetting if there is a need to reset the inverter immediately. Note, however, that this operation may damage the system or the motor if it is repeated frequently.

## 13.3 If the motor does not run while no trip message is displayed...

If the motor does not run while no trip message is displayed, follow these steps to track down the cause.



## 13.4 How to determine the causes of other problems

The following table provides a listing of other problems, their possible causes and remedies.

| Problems                                                          | Causes and remedies                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The motor runs in the wrong direction.                            | <ul style="list-style-type: none"> <li>• Invert the phases of the output terminals U/T1, V/T2 and W/T3.</li> <li>• Invert the forward/reverse run-signal terminals of the external input device. (Refer to section 7.2.1)</li> <li>• Change the setting of the parameter <math>F_r</math> in the case of panel operation.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| The motor runs but its speed does not change normally.            | <ul style="list-style-type: none"> <li>• The load is too heavy. Reduce the load.</li> <li>• The soft stall function is activated. Disable the soft stall function. (Refer to section 5.6)</li> <li>• The maximum frequency <math>F_H</math> and the upper limit frequency <math>U_L</math> are set too low. Increase the maximum frequency <math>F_H</math> and the upper limit frequency <math>U_L</math>.</li> <li>• The frequency setting signal is too low. Check the signal set value, circuit, cables, etc.</li> <li>• Check the setting characteristics (point 1 and point 2 settings) of the frequency setting signal parameters. (Refer to section 6.10.2)</li> <li>• If the motor runs at a low speed, check to see that the stall prevention function is activated because the torque boost value is too large. Adjust the torque boost value (<math>\alpha b</math>) and the acceleration time (<math>RCL</math>). (Refer to section 6.4 and 5.2)</li> </ul> |
| The motor does not accelerate or decelerate smoothly.             | <ul style="list-style-type: none"> <li>• The acceleration time (<math>RCL</math>) or the deceleration time (<math>dEL</math>) is set too short. Increase the acceleration time (<math>RCL</math>) or the deceleration time (<math>dEL</math>).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| A too large current flows into the motor.                         | <ul style="list-style-type: none"> <li>• The load is too heavy. Reduce the load.</li> <li>• If the motor runs at a low speed, check whether the torque boost value is too large. (Refer to section 6.4)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| The motor runs at a higher or lower speed than the specified one. | <ul style="list-style-type: none"> <li>• The motor has an improper voltage rating. Use a motor with a proper voltage rating.</li> <li>• The motor terminal voltage is too low. Check the setting of the base frequency voltage parameter (<math>\alpha L \alpha</math>). (Refer to section 5.5)<br/>Replace the cable with a cable larger in diameter.</li> <li>• The reduction gear ratio, etc., are not set properly. Adjust the reduction gear ratio, etc.</li> <li>• The output frequency is not set correctly. Check the output frequency range.</li> <li>• Adjust the base frequency. (Refer to section 5.5)</li> </ul>                                                                                                                                                                                                                                                                                                                                            |
| The motor speed fluctuates during operation.                      | <ul style="list-style-type: none"> <li>• The load is too heavy or too light. Reduce the load fluctuation.</li> <li>• The inverter or motor used does not have a rating large enough to drive the load. Use an inverter or motor with a rating large enough.</li> <li>• Check whether the frequency setting signal changes.</li> <li>• If the V/F control selection parameter <math>P_L</math> is set at 3, check the vector control setting, operation conditions, etc. (Refer to section 6.3)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Parameter settings cannot be changed.                             | <ul style="list-style-type: none"> <li>• Change the setting of the parameter setting selection prohibited parameter <math>F700</math> to 0 (enabled) if it is set to 1 to 4 (prohibited).</li> <li>• Set the verification code to <math>F739</math>, if password has entered by the password setting <math>F738</math>. (Refer to section 6.34.1)</li> <li>• Switch off the logic input terminal, if this terminal is assigned to input terminal menu 200 to 203 (Parameter editing / reading prohibition).</li> <li>• For reasons of safety, some parameters cannot be reprogrammed while the inverter is running. (Refer to section 11.9)</li> </ul>                                                                                                                                                                                                                                                                                                                   |

### How to cope with parameter setting-related problems

|                                                                                 |                                                                                                                                                                              |
|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| If you forget parameters which have been reset                                  | <ul style="list-style-type: none"> <li>• You can search for all reset parameters and change their settings.<br/>* Refer to section 4.3.1 for details.</li> </ul>             |
| If you want to return all reset parameters to their respective default settings | <ul style="list-style-type: none"> <li>• You can return all parameters which have been reset to their default settings.<br/>* Refer to section 4.3.2 for details.</li> </ul> |

## 14. Inspection and maintenance

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>The equipment must be inspected daily.<br/>If the equipment is not inspected and maintained, errors and malfunctions can not be discovered which could lead to accidents.</li> <li>Before inspection, perform the following steps.             <ol style="list-style-type: none"> <li>Shut off all input power to the inverter.</li> <li>Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.</li> <li>Use a tester that can measure DC voltages (400V/800V DC or more), and check that the voltage to the DC main circuits (across PA/+ - PC/-) does not exceed 45V.</li> </ol> </li> </ul> <p><b>Performing an inspection without carrying out these steps first could lead to electric shock.</b></p> |

Be sure to inspect the inverter regularly and periodically to prevent it from breaking down because of the environment of use, such as temperature, humidity, dust and vibration, or deterioration of its components with aging.

### 14.1 Regular inspection

Since electronic parts are susceptible to heat, install the inverter in a cool, well-ventilated and dust-free place. This is essential for increasing the service life.

The purpose of regular inspections is to maintain the correct environment of use and to find any sign of failure or malfunction by comparing current operation data with past operation records.

| Subject of inspection           | Inspection procedure             |                  |                                                               | Criteria for judgment                                                                                                                                              |
|---------------------------------|----------------------------------|------------------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                 | Inspection item                  | Inspection cycle | Inspection method                                             |                                                                                                                                                                    |
| 1. Indoor environment           | 1) Dust, temperature and gas     | Occasionally     | 1) Visual check, check by means of a thermometer, smell check | 1) Improve the environment if it is found to be unfavorable.                                                                                                       |
|                                 | 2) Drop of water or other liquid | Occasionally     | 2) Visual check                                               | 2) Check for any trace of water condensation.                                                                                                                      |
|                                 | 3) Room temperature              | Occasionally     | 3) Check by means of a thermometer                            | 3) Max. temperature: 60°C                                                                                                                                          |
| 2. Units and components         | 1) Vibration and noise           | Occasionally     | Tactile check of the cabinet                                  | If something unusual is found, open the door and check the transformer, reactors, contactors, relays, cooling fan, etc., inside. If necessary, stop the operation. |
| 3. Operation data (output side) | 1) Load current                  | Occasionally     | Moving-iron type AC ammeter                                   | To be within the rated current, voltage and temperature.<br>No significant difference from data collected in a normal state.                                       |
|                                 | 2) Voltage (*)                   | Occasionally     | Rectifier type AC voltmeter                                   |                                                                                                                                                                    |
|                                 | 3) Temperature                   | Occasionally     | Thermometer                                                   |                                                                                                                                                                    |

\*) The voltage measured may slightly vary from voltmeter to voltmeter. When measuring the voltage, always take readings from the same circuit tester or voltmeter.

## ■ Check points

1. Something unusual in the installation environment
2. Something unusual in the cooling system
3. Unusual vibration or noise
4. Overheating or discoloration
5. Unusual odor
6. Unusual motor vibration, noise or overheating
7. Adhesion or accumulation of foreign substances (conductive substances)

## ■ Cautions about cleaning

To clean the inverter, wipe dirt off only its surface with a soft cloth but do not try to remove dirt or stains from any other part. If stubborn stains persist, remove them by wiping gently with a cloth dampened with neutral detergent or ethanol.

Never use any of the chemicals in the table below; the use of any of them may damage or peel the coating away from molded parts (such as plastic covers and units) of the inverter.

|            |                   |                   |
|------------|-------------------|-------------------|
| Acetone    | Ethylene chloride | Tetrachloroethane |
| Benzen     | Ethyl acetate     | Trichloroethylene |
| Chloroform | Glycerin          | Xylene            |

## 14.2 Periodical inspection

Make a periodical inspection at intervals of 3 to 6 months depending on the operating conditions.

|  <b>Warning</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Mandatory action | <ul style="list-style-type: none"> <li>• Before inspection, perform the following steps.               <ol style="list-style-type: none"> <li>(1) Shut off all input power to the inverter.</li> <li>(2) Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.</li> <li>(3) Use a tester that can measure DC voltages (400V/800V DC or more), and check that the voltage to the DC main circuits (across PA/+ - PC/-) does not exceed 45V.</li> </ol>               Performing an inspection without carrying out these steps first could lead to electric shock.             </li> </ul> |
| <br>Prohibited       | <ul style="list-style-type: none"> <li>• Do not replace parts.<br/>This could be a cause of electric shock, fire and bodily injury. To replace parts, call your Toshiba distributor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                            |

## ■ Check items


1. Check to see if all screwed terminals are tightened firmly. If any screw is found loose, tighten it again with a screwdriver.
2. Check to see if all caulked terminals are fixed properly. Check them visually to see that there is no trace of overheating around any of them.
3. Check all cables and wires for damage. Check them visually.
4. Remove dirt and dust. With a vacuum cleaner, remove dirt and dust. When cleaning, clean the vents and the printed circuit boards. Always keep them clean to prevent an accident due to dirt or dust.
5. If no power is supplied to the inverter for a long time, the performance of its large-capacity electrolytic capacitor declines.

When leaving the inverter unused for a long time, supply it with electricity once every two years, for 5 hours or more each, to recover the performance of the large-capacity electrolytic capacitor. And also check the function of the inverter. It is advisable not to supply the commercial power directly to the inverter but to gradually increase the power supply voltage with a transformer, etc.

6. If the need arises, conduct an insulation resistance test on the main circuit terminal block only, using a 500V insulation resistance tester. Never conduct an insulation resistance test on control terminals other than terminals on the printed circuit board or on control terminals. When testing the motor for insulation resistance, separate it from the inverter in advance by disconnecting the cables from the inverter output terminals U/T1, V/T2 and W/T3. When conducting an insulation resistance test on peripheral circuits other than the motor circuit, disconnect all cables from the inverter so that no voltage is applied to the inverter during the test.

Standard: Several MΩ or more. (Built-in noise filter cause to detect low insulation resistance.)

(Note) Before an insulation resistance test, always disconnect all cables from the main circuit terminal block and test the inverter separately from other equipment.



7. Never test the inverter for dielectric strength. A dielectric test may cause damage to its components.
8. Voltage and temperature check

Recommended voltmeter : Input side ... Moving-iron type voltmeter (⚡)

Output side ... Rectifier type voltmeter (⚡)

It will be very helpful for detecting a defect if you always measure and record the ambient temperature before, during and after the operation.

## ■ Replacement of expendable parts

The inverter is composed of a large number of electronic parts including semiconductor devices.

The following parts deteriorate with the passage of time because of their composition or physical properties.

The use of aged or deteriorated parts leads to degradation in the performance or a breakdown of the inverter. To avoid such trouble, the inverter should be checked periodically.

Note) Generally, the life of a part depends on the ambient temperature and the conditions of use. The life spans listed below are applicable to parts when used under normal environmental conditions.

### 1) Cooling fan

The fan for cooling heat-generating parts has a service life of about ten years. The fan also needs to be replaced if it makes a noise or vibrates abnormally.

### 2) Smoothing capacitor

The smoothing aluminum electrolytic capacitor in the main circuit DC section degrades in performance because of ripple currents, etc. It becomes necessary to replace the capacitor after it is used for about 10 years under normal conditions. Since the smoothing capacitor is mounted on a printed circuit board, it must be replaced together with the circuit board.

<Criteria for appearance check>

- Absence of liquid leak
- Safety valve in the depressed position
- Measurement of electrostatic capacitance and insulation resistance

Note: Checking the life alarm function is useful for roughly determining the parts replacement time.

To ensure customer safety, you should never replace parts on your own. (It is also possible to monitor the part replacement alarm and output a signal.)

## ■ Standard replacement cycles of principal parts

As guides, the table below lists part replacement cycles that were estimated based on the assumption that the inverter would be used in a normal use environment under normal conditions (ambient temperature, ventilation conditions, and energizing time). The replacement cycle of each part does not mean its service life but the number of years over which its failure rate does not increase significantly.

Also, make use of the life alarm function.

| Part name                                                          | Standard replacement cycle Note 1: | Replacement mode and others                                          |
|--------------------------------------------------------------------|------------------------------------|----------------------------------------------------------------------|
| Cooling fan                                                        | 10 years                           | Replacement with a new one (To be determined after inspection)       |
| Main circuit aluminum electrolytic capacitor                       | 10 years Note 2                    | Replacement with a new one (To be determined after inspection)       |
| Relays                                                             | -                                  | Whether to replace or not depends on the check results               |
| Aluminum electrolytic capacitor mounted on a printed circuit board | 10 years Note 2                    | Replace with a new circuit board (To be determined after inspection) |

Note 1: The replacement cycle is calculated on the assumption that the average ambient temperature over a year is 40°C and operates 24 hours a day. The environment must be free of corrosive gases, oil mist and dust.

Note 2: Figures are for when the inverter output current is 80% of the rated current of the inverter.

Note 3: The life of parts varies greatly depending on the operating environment.

## 14.3 Making a call for servicing

If defective conditions are encountered, please contact your Toshiba distributor.

When making a call for servicing, please inform us of the contents of the rating label on the right panel of the inverter, the presence or absence of optional devices, etc., in addition to the details of the failure.

## 14.4 Keeping the inverter in storage

Take the following precautions when keeping the inverter in storage temporarily or for a long period of time.

1. Store the inverter in a well-ventilated place away from heat, damp, dust and metal powder.
2. If no power is supplied to the inverter for a long time, the performance of its large-capacity electrolytic capacitor declines.

When leaving the inverter unused for a long time, supply it with electricity once every two years, for 5 hours or more each, to recover the performance of the large-capacity electrolytic capacitor. And also check the function of the inverter. It is advisable not to supply the commercial power directly to the inverter but to gradually increase the power supply voltage with a transformer, etc.

## 15. Warranty

Any part of the inverter that proves defective will be repaired and adjusted free of charge under the following conditions:

1. This warranty applies only to the inverter main unit.
2. Any part of the inverter which fails or is damaged under normal use within twelve months from the date of delivery shall be repaired free of charge.
3. For the following kinds of failure or damage, the repair cost shall be borne by the customer even within the warranty period.
  - Failure or damage caused by improper or incorrect use or handling, or unauthorized repair or modification of the inverter
  - Failure or damage caused by the inverter falling or an accident during transportation after the purchase
  - Failure or damage caused by fire, salty water or wind, corrosive gas, earthquake, storm or flood, lightning, abnormal voltage supply, or other natural disasters
  - Failure or damage caused by the use of the inverter for any purpose or application other than the intended one
4. All expenses incurred by Toshiba for on-site services shall be charged to the customer, unless a service contract is signed beforehand between the customer and Toshiba, in which case the service contract has priority over this warranty.

## 16. Disposal of the inverter

|  Caution                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Mandatory<br>action | <ul style="list-style-type: none"><li>• If you dispose of the inverter, have it done by a specialist in industry waste disposal(*). If you dispose of the inverter by yourself, this can result in explosion of capacitor or produce noxious gases, resulting in injury.</li><li>(*) Persons who specialize in the processing of waste and known as "industrial waste product collectors and transporters" or "industrial waste disposal persons". Please observe any applicable law, regulation, rule or ordinance for industrial waste disposal.</li></ul> |

For safety's sake, do not dispose of the disused inverter yourself but ask an industrial waste disposal agent.

Disposing of the inverter improperly could cause its capacitor to explode and emit toxic gas, causing injury to persons.

# TOSHIBA

## TOSHIBA INDUSTRIAL PRODUCTS SALES CORPORATION

Global Industrial Products Business Unit  
9-11, Nihonbashi-Honcho 4-Chome,  
Chuo-ku, Tokyo, 103-0023, Japan  
TEL : +81-(0)3-3457-8128  
FAX : +81-(0)3-5444-9252

TOSHIBA INTERNATIONAL CORPORATION  
13131 West Little York RD., Houston,  
TX 77041, U.S.A  
TEL : +1-713-466-0277  
FAX : +1-713-466-8773

TOSHIBA INFRASTRUCTURE SYSTEMS  
SOUTH AMERICA LTD  
Av. Ibirapuera 2.332, Torre I, 5th floor  
Moema, 04028-003, Sao Paulo-SP, Brazil  
TEL : +55-(0)11-4083-7900  
FAX : +55-(0)11-4083-7910

TOSHIBA ASIA PACIFIC PTE, LTD  
152 Beach Rd., #16-00 Gateway East,  
Singapore 189721  
TEL : +65-6297-0990  
FAX : +65-6297-5510

TOSHIBA CHINA CO., LTD  
HSBC Tower, 1000 Lujiazui Ring Road,  
Pudong New Area, Shanghai  
200120, The People's Republic of China  
TEL : +86-(0)21-6841-5666  
FAX : +86-(0)21-6841-1161

TOSHIBA INTERNATIONAL CORPORATION PTY, LTD  
2 Morton Street Parramatta, NSW2150, Australia  
TEL : +61-(0)2-9768-6600  
FAX : +61-(0)2-9890-7542

TOSHIBA CIS LIMITED LIABILITY COMPANY  
Kievskaya st., entrance 7, floor 12  
Moscow, 121059, Russian Federation  
TEL : +7-(0)495-642-8929  
FAX : +7-(0)495-642-8908

TOSHIBA INDIA PRIVATE LIMITED  
3rd Floor, Building No.10, Tower B,  
Phase-II, DLF Cyber City, Gurgaon-122002 India  
TEL : +91-(0)124-4996600  
FAX : +91-(0)124-4996623

TOSHIBA INFORMATION, INDUSTRIAL AND POWER  
SYSTEMS TAIWAN CORP  
6f, No66, Sec1 Shin Sheng N.RD, Taipei, Taiwan  
TEL : +886-(0)2-2581-3639  
FAX : +886-(0)2-2581-3631

- For further information, please contact your nearest Toshiba Representative or Global Industrial Products Business Unit-Producer Goods.
- The data given in this manual are subject to change without notice.