

- 1) cut and polish the fibers
- 2) insert the fibers into the holes

option 1:

- 3) pull back the fibers from the front end so the fiber end is 1-2mm below the surface of the front Al plate
- 4) "drop" the silver shine into the hole ("dip")
- 5) "drop" a small amount of glue into the hole ("dip") to fix the silver shine in place

option 2:

- 3) cut the fiber end at the same level as the front end;
- 4) paint the whole surface with TiO<sub>2</sub> paint

