Westward Operating Instructions and Parts Manual Model 3JR71A

Please read and save these instructions. Read through this owner's manual carefully before using product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.



Portable Air Compressor

Description

Low maintenance, oil-less portable air compressor designed for use in the home with a 50/50 duty cycle. The 20 gallon capacity air tank is equipped with check valve, unloader valve, pressure switch, safety valve air regulator, and tank pressure gauge.

Unpacking

Remove unit from carton and discard all packaging. Save all literature.

After unpacking unit, inspect carefully for any damage that may have occurred during transit. Check for loose, missing, or damaged parts. Shipping damage claim must be filed with carrier.



Specifications

Model F	Max. Pressure	Tank Size (gallons)	Current Required	Volts/Hertz/ Phase		SCFM@90 PSIG
3JR71A	135	20	15 AMP	120/60/1	8.3	5.8

Dimensions

Length	Width	Height	Shipping Weight
33.38"	16.63"	31.75"	142 lbs.



orbest #356