

# VL6180X interleaved mode explanation

By Colin Ramrattan

Main components	
VL6180X	Proximity and ambient light sensing (ALS) module

## **Purpose and benefits**

The purpose of this document is to explain in further detail the interleaved feature of the VL6180X.

It is assumed that customers who use this document can communicate with the VL6180X through  $I^2C$  and are now looking for more information on the interleaved operation mode.





## Description

Interleaved mode is a term used to describe a continuous mode of operation in the VL6180X where the Ambient Light Sensor (ALS) and Ranging functions continuously perform measurements over a user specified period. This operation is beneficial to users that would like to have continuous measurements from both the ALS and range functions of the VL6180X.



DT0017 Rev 1

1/5

Figure 2 below shows a timeline of how the ALS and ranging are executed when interleaved mode is enabled.





## Enabling Interleaved Mode:

The following registers in Table 1 are used in interleaved operation.

### Table 1. Overview of registers to set using interleaved operation

Register Name	Register Address	Description
SYSALS_ INTERMEASUREMENT_PERIOD	0x03E	This will define the time between the ALS measurements. Note: The host must ensure that the inter-measurement time is not exceeded See Table XXX.
SYSALS_INTEGRATION_PERIOD	0x040	The integration period is the time the ALS will integrate based on the current light conditions. This is chosen by the user.
SYSALS_START	0x038	This register is used to select continuous mode operation for the ALS measurements. If the interleaved mode enable bit is set, a range measurement will be performed after each ALS measurement
SYSRANGE_MAX_ CONVERGENCE_TIME	0x01C	This will define the maximum time allowed for a range measurement to complete. Note: The maximum time set cannot be more than the ALS inter-measurement period.
SYSRANGE_START	0x018	This register is used to select either continuous or single shot range measurements. Note: in interleaved mode, this register is ignored.
INTERLEAVED_MODE_ENABLED	0x2A3	To enable interleaved mode, this register must be set to 0x01.

www.st.com

The following registers shown in Table 1 are a subset of what is used in normal operation of the VL6180X. The user is advised to refer to the datasheet for further information on how to set-up GPIO modes, interrupt conditions and other functions of the VL6180X.

To set-up interleaved mode, the user should decide the rate at which the device will report ALS and range measurements. Once the time is chosen, the user must ensure this time does not violate the following equations for proper operation.

ALS Inter-Measurement period (ALS IMP)

ALS IMP > [(1.1 \* ALS INTEGRATION PERIOD) + (RANGE MAX CONVERGENCE TIME + 5ms)] / 0.9

The equation above will ensure the system will have enough time to process each measurement while continuing to report the appropriate measurements for ranging and ALS.

Table 2 below shows an example of 10Hz operation along with the maximum permissible settings for 10Hz operation. The ALS Integration period and max convergence time should not be increased further but can be reduced from the example below.

lable 2. 10Hz interleaved operation example				
Parameter Name	Time Required	Register address and value to write.		
Inter-measurement period	100ms	Address (0x03E), write value 0x0A		
ALS Integration period	50ms	Address (0x040), write value 0x32		
Range Max convergence time	30ms	Address (0x01C), write value 0x1E		

..... 1.1 ....

Table 3 below shows an example of 20Hz operation along with the maximum permissible settings for 10Hz operation. The ALS Integration period and max convergence time should not be increased further but can be reduced from the example below.

#### Table 3. 20Hz interleaved operation example

Parameter Name	Time Required	Register address and value to write.
Inter-measurement period	50ms	Address (0x03E), write value 0x05
ALS Integration period	20ms	Address (0x040), write value 0x14
Range Max convergence time	18ms	Address (0x01C), write value 0x12

For completeness, Table 3 below shows the user where the settings for interleaved operation should be applied. Note that this is just a subset of what is required for normal operation and the user is advised to refer to the datasheet for additional functions with the VL6180X.







## Support material

Related design support material		
MOB-EK2-180-01/1 Product/ system evaluation board		
Documentation		
Datasheet: VL6180X - Proximity and ambient light sensing (ALS) module		

## **Revision history**

Date	Version	Changes
27-MAY-2014	1	Initial release



DT0017 Rev 1

www.st.com

#### Please Read Carefully

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

ST PRODUCTS ARE NOT DESIGNED OR AUTHORIZED FOR USE IN: (A) SAFETY CRITICAL APPLICATIONS SUCH AS LIFE SUPPORTING, ACTIVE IMPLANTED DEVICES OR SYSTEMS WITH PRODUCT FUNCTIONAL SAFETY REQUIREMENTS; (B) AERONAUTIC APPLICATIONS; (C) AUTOMOTIVE APPLICATIONS OR ENVIRONMENTS, AND/OR (D) AEROSPACE APPLICATIONS OR ENVIRONMENTS. WHERE ST PRODUCTS ARE NOT DESIGNED FOR SUCH USE, THE PURCHASER SHALL USE PRODUCTS AT PURCHASER'S SOLE RISK, EVEN IF ST HAS BEEN INFORMED IN WRITING OF SUCH USAGE, UNLESS A PRODUCT IS EXPRESSLY DESIGNATED BY ST AS BEING INTENDED FOR "AUTOMOTIVE, AUTOMOTIVE SAFETY OR MEDICAL" INDUSTRY DOMAINS ACCORDING TO ST PRODUCT DESIGN SPECIFICATIONS. PRODUCTS FORMALLY ESCC, QML OR JAN QUALIFIED ARE DEEMED SUITABLE FOR USE IN AEROSPACE BY THE CORRESPONDING GOVERNMENTAL AGENCY.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

## © 2014 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel -Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com



DT0017 Rev 1