# CIOSSPad PORTABLE DIGITAL NOTEPAD

Upload

### Portable

Take notes anytime, anywhere with a CrossWriter<sup>™</sup> pen and any letter- or memo-size pad of paper.

#### Digital

Instantly capture 50+ pages of your handwritten notes (CrossPad) or 80+ pages (CrossPad XP) for transfer to your PC.

### **Productive**

Use included software to store, search, cut-and-paste, and share digital notes.

Features IBM<sub>®</sub> Ink Manager<sup>™</sup> note management software.



Choose from two Portable Digital Notepad (PDN) styles.

#### **CrossPad**

6x9

8<sup>5</sup>x11

Letter-size for 8.5" x 11" tablets 2.2 pounds 14" x 9.8" x .75" 1 MB Flash ROM Stores 50+ letter-size pages of notes, sketches and diagrams.

CrossPad XP Memo-size for 6" x 9" tablets 1.5 pounds 11.875" x 7.75" x .875" 1 MB Flash ROM Stores 80+ memo-size pages of notes, sketches and diagrams.

## CrossPad™

### Convenient pen holder.

Snap-in, spring-loaded pen holder ensures your CrossWriter™ pen is always within reach. (CrossPad XP only)

### More ink on board.

A tray in the side of the notepad holds five replacement ink cartridges.



#### CrossWriter™ Digital Pen.

A small RF (radio frequency) transmitter sends pen stroke data to the notepad automatically when the pen makes contact.

### Powerful software.

IBM® Ink Manager™ software provides powerful note editing, searching, organization and sharing tools.

CrossPad XP shown right



CrossPad and CrossPad XP Portable Digital Notepads (PDN). Revolutionary tools that let you upload all your notes right into your PC.

#### Take it with you.

At 1.5 pounds and 7/8" thick (CrossPad XP) and 2.2 pounds and 3/4" thick (Cross-Pad) these tools travel light and work smart.

#### Tablet friendly.

Slip the backing card of any memo-size, 6" x 9" (CrossPad XP) or letter-size, 8.5" x 11" (CrossPad) tablet into the slot provided.

### Store all your notes.

CrossPad XP captures 80+ memo-size pages and CrossPad 50+ letter-size pages of notes, sketches and diagrams.

#### Power to spare

The four AAA batteries in both notepads have an average life of 3-4 months. The single CrossWriter AAAA battery has a 6-12 month average life.

> Serial transfer cable included

#### Keyword

Used to index Summons a key ideas visually menu of control (on your tablet) settings and user and (digitally on preferences. your PC).

Menu



#### Page Backward Moves you back

one page in your digital notes. Confirms that the notepad is "on" and the pen is transmitting.

Shows previous, current and next page, current page number and whether a page has captured any digital ink. Indicates the remaining notepad battery power.



#### Page Forward Moves you ahead one page in your digital notes.




Used to answer "no" to menu display questions. Yes Used to answer "yes" to menu display questions.



THE SIMPLICITY OF THE PEN.

THE POWER OF THE PC.




#### Keyword

When you circle a word and mark it with the Keyword button you can use it later as a convenient search term.

### Take Notes.

Capture your thoughts. With ink. On paper. As you write CrossPad XP (shown) records 80+ pages of your handwritten notes or sketches.



Keep all your notes on your PC, sorted by topic into "Notebook" files you create. Search Ink Manager notebooks by "Keyword," "Bookmark" and date. in his bas to her designs himse in Meeting Notes a CRITICAL ACTION ITEMS 8. Juni Junio Tought Should ι.

> Print or fax Ink Manager Notebook files. Share notes by email with other Windows users. Export notes to other applications in .PS, .JPG, .TIF, or .BMP formats.

### Work Smart.

3

Organize your notes in one place. In "Notebook" files you create. Store, search, cut/paste and email digital notes with IBM Ink Manager software.



2

### Upload to PC.

Transfer digital notes from your CrossPad to your PC.

## CrossPad PORTABLE DIGITAL NOTEPAD

CrossPad / CrossPad XP

System Contents Cross Portable Digital Notepad CrossWriter<sup>™</sup> Digital Pen Serial Transfer Cable Four (4) AAA Batteries (notepad) One (1) AAAA battery (pen) IBM® Ink Manager<sup>™</sup> Software (CD-ROM) Five (5) Replacement Ink Cartridges CrossPad Support Materials Orientation Guide User Guide Supplemental Handwriting Guide Quick Reference Card

#### **PC System Requirements**

Windows® 95, 98 or NT® 4.0 Pentium® or better processor 50 MB hard-disk space I6 MB RAM minimum 32 MB recommended 32 MB minimum for NT 4.0 One available 9-pin COM port CD-ROM drive

#### **File Formats**

Ink Manager creates .INK format files. Share them by email with other Windows users as self-executable, read-only files. Save them in .PS, .JPG, .TIF, or .BMP formats for export to other applications.

Cross, CrossPad XP, CrossWriter, DigitalWriter, iPen and Write on your pad right into your pc are registered trademarks or trademarks of A.T. Cross Company and/or its subsidiaries. IBM and Ink Manager are registered trademarks or trademarks of the International Business Machines Corporation. Windows and Windows NT are registered trademarks of Microsoft Corporation. Pentium is a generatered trademark of Intel Corporation.

All rights reserved. Digital pen made in USA. Digital notepad made in China. Printed in the USA. © 1998 A.T. Cross Company. CROSS pen computing group

www.cross-pcg.com 800.510.9660