




2002 Catalog Excerpts Table of Contents

For additional information visit us on the web at <http://usa.hamamatsu.com>

CONTENTS

Index by Type Number	2
----------------------------	---

About Photomultiplier Tube

Construction and Operating Characteristics	4
Connections to External Circuits	14
Selection Guide by Applications	16

Side-on Type Photomultiplier Tubes

13 mm Dia. Types	22
28 mm Dia. Types with UV to Visible Sensitivity	24
28 mm Dia. Types with UV to Near IR Sensitivity	26
13 mm Dia. Types, 28 mm Dia. Types with Solar Blind Response	28

Head-on Type Photomultiplier Tubes

10 mm Dia. Types, 13 mm Dia. Types	30
19 mm Dia. Types	32
25 mm Dia. Types	34
28 mm Dia. Types	36
38 mm Dia. Types	38
51 mm Dia. Types with Plastic Base	40
51 mm Dia. Types with Glass Base	42
76 mm Dia. Types, 127 mm Dia. Types	46

Special Purpose Photomultiplier Tubes

Hemispherical Envelope Types	48
Special Envelope Types	48
Metal Package Photomultiplier Tubes	50
Tubes for High Magnetic Environments	54
Position Sensitive Types	56
Microchannel Plate-Photomultiplier Tubes (MCP-PMTs)	58

Gain Characteristics 60

Voltage Distribution Ratio 62

Replacement Information 63

Photomultiplier Tube Assemblies 64

Accessories for Photomultiplier Tubes

Socket Assemblies	72
Preamplifier Units	94
High Voltage Power Supplies	96
Thermoelectric Coolers	102
Magnetic Shield Cases	106
Housings, Power and Signal Cables, Connector Adapters.....	107
Related Products for Photon Counting	108

Electron Multipliers 110

Cautions and Warranty 112

Typical Photocathode Spectral Response 113

Typical Photocathode Spectral Response 114

Index by Type Number

Type No.	Product	Page	Type No.	Product	Page
R105	Side-on PMT	24	R2362	Electron Multiplier	110
R212	Side-on PMT	24	R2368	Side-on PMT	26
R316-02	Head-on PMT	36	H2431-50	PMT Assembly	64
R329-02	Head-on PMT	42	R2486-02	Position-Sensitive PMT	56
R331-05	Head-on PMT	42	R2496	Head-on PMT	30
R374	Head-on PMT	36	R2557	Head-on PMT	30
R375	Head-on PMT	44	E2624 Series	Socket Assembly	78
R464	Head-on PMT	42	R2658	Side-on PMT	26
R474	Electron Multiplier	110	R2693	Side-on PMT	24
R515	Electron Multiplier	110	E2924 Series	Socket Assembly	78
R550	Head-on PMT	40	R2949	Side-on PMT	26
R580	Head-on PMT	38	E2979 Series	Socket Assembly	79
R595	Electron Multiplier	110	H3164-10	PMT Assembly	64
R596	Electron Multiplier	110	H3165-10	PMT Assembly	64
R632-01	Head-on PMT	32	H3178-51	PMT Assembly	64
R636-10	Side-on PMT	26	R3234-01	Head-on PMT	40
R647	Head-on PMT	30	R3292-02	Position-Sensitive PMT	56
R649	Head-on PMT	42	R3310-02	Head-on PMT	44
C659 Series	Thermoelectric Cooler	104	C3350	Power Supply	100
R669	Head-on PMT	44	C3360	Power Supply	101
E717 Series	Socket Assembly	78	R3478	Head-on PMT	32
R759	Head-on PMT	30	R3550A	Head-on PMT	34
R821	Head-on PMT	32	H3695-10	PMT Assembly	64
E849 Series	Socket Assembly	78	R3788	Side-on PMT	24
E850 Series	Socket Assembly	78	R3809U Series	MCP-PMT	58
R877	Head-on PMT	46	R3810	Side-on PMT	22
R928	Side-on PMT	26	R3811	Side-on PMT	22
R943-02	Head-on PMT	44	C3830	Power Supply	99
R972	Head-on PMT	32	C3866	Photon Counting Unit	108
E974 Series	Socket Assembly	78	R3886	Head-on PMT	38
R980	Head-on PMT	38	R3896	Side-on PMT	26
E989 Series	Magnetic Shield Case	106	R3991	Head-on PMT	32
E990 Series	Socket Assembly	78	R3998-02	Head-on PMT	36
R1080	Head-on PMT	30	R4124	Head-on PMT	30
R1166	Head-on PMT	32	R4143	Head-on PMT	46
E1168 Series	Power and Signal Cable	107	R4177-01	Head-on PMT	30
E1198 Series	Socket Assembly	79	A4184 Series	Connector Adapter	107
R1250	Head-on PMT	46	R4220	Side-on PMT	24
R1288A	Head-on PMT	34	R4607-01	Head-on PMT	42
R1306	Head-on PMT	40	R4632	Side-on PMT	26
R1307	Head-on PMT	46	C4710 Series	Power Supply	98
E1341-01	Housing	107	C4720	Power Supply	99
R1387	Head-on PMT	38	C4877	Thermoelectric Cooler	102
E1435 Series	Socket Assembly	79	C4878	Thermoelectric Cooler	102
R1450	Head-on PMT	32	C4900 Series	Power Supply	97
R1463	Head-on PMT	30	R4998	Head-on PMT	34
R1477-06	Side-on PMT	26	R5070A	Head-on PMT	34
R1513	Head-on PMT	46	R5108	Side-on PMT	26
R1527	Side-on PMT	24	R5150-10	Electron Multiplier	110
R1548	Rectangular Dual PMT	48	R5496	Head-on PMT	42
R1584	Head-on PMT	46	R5505	Head-on PMT for Highly Magnetic Field	54
R1617	Head-on PMT	32	C5594	Preamplifier Unit	94
R1635	Head-on PMT	30	R5610	Head-on PMT	32
R1705	Head-on PMT	38	R5611-01	Head-on PMT	32
E1761 Series	Socket Assembly	78	E5780	Socket Assembly	79
R1767	Head-on PMT	38	E5859 Series	Socket Assembly	79
R1828-01	Head-on PMT	40	R5900U	Metal Package PMT	52
R1878	Head-on PMT	32	R5900U-00-L16	Metal Package PMT	52
R1893	Head-on PMT	30	R5900U-00-M4	Metal Package PMT	52
R1894	Head-on PMT	30	R5900U-01-L16	Metal Package PMT	52
R1924A	Head-on PMT	34	R5912	Hemispherical PMT	48
R1925A	Head-on PMT	34	R5916U Series	MCP-PMT	58
H1949-51	PMT Assembly	64	R5924	Head-on PMT for Highly Magnetic Field	54
R2066	Head-on PMT	38	R5929	Head-on PMT	36
R2078	Head-on PMT	34	R5983	Side-on PMT	24
R2083	Head-on PMT	42	R5984	Side-on PMT	26
R2154-02	Head-on PMT	40	E5996	Socket Assembly	79
E2183 Series	Socket Assembly	78	R6091	Head-on PMT	46
R2228	Head-on PMT	36	R6094	Head-on PMT	36
R2248	Rectangular PMT	48	R6095	Head-on PMT	36
E2253 Series	Socket Assembly	78	E6133-04	Socket Assembly	79
R2257	Head-on PMT	44	H6152-70	PMT Assembly	64

Type No.	Product	Page
H6156-50	PMT Assembly	64
R6231	Head-on PMT	40
R6233	Head-on PMT	46
R6234	Hexagonal PMT	48
R6235	Hexagonal PMT	48
R6236	Rectangular PMT	48
R6237	Rectangular PMT	48
C6270	Socket Assembly	92
C6271	Socket Assembly	92
E6316 Series	Socket Assembly	79
R6350	Side-on PMT	22
R6352	Side-on PMT	22
R6353	Side-on PMT	22
R6354	Side-on PMT	28
R6355	Side-on PMT	22
R6356-06	Side-on PMT	22
R6357	Side-on PMT	22
R6358	Side-on PMT	22
H6410	PMT Assembly	64
R6427	Head-on PMT	36
C6438	Preamplifier Unit	94
C6465	Photon Counting Unit	108
R6504	Head-on PMT for Highly Magnetic Field	54
H6520	PMT Assembly	64
H6524	PMT Assembly	64
H6525	PMT Assembly	64
H6527	PMT Assembly	64
H6528	PMT Assembly	64
H6533	PMT Assembly	64
H6559	PMT Assembly	64
H6612	PMT Assembly	64
H6614-70	PMT Assembly	64
E6736	Socket Assembly	79
R6834	Head-on PMT	36
R6836	Head-on PMT	36
R6925	Side-on PMT	24
E7083	Socket Assembly	79
R7154	Side-on PMT	28
H7195	PMT Assembly	64
R7205-01	Head-on PMT	36
R7206-01	Head-on PMT	36
C7246 Series	Socket Assembly	90
C7247 Series	Socket Assembly	90
H7260	PMT Assembly	64
R7311	Side-on PMT	28
C7319	Preamplifier Unit	94
R7400U	Metal Package PMT	50
R7400U-01	Metal Package PMT	50
R7400U-02	Metal Package PMT	50
R7400U-03	Metal Package PMT	50
R7400U-04	Metal Package PMT	50
R7400U-06	Metal Package PMT	50
R7401	Metal Package PMT	50
H7415	PMT Assembly	64
E7514	Socket Assembly	79
H7546	PMT Assembly	64
R7639	Side-on PMT	28
E7693	Socket Assembly	79
E7694 Series	Socket Assembly	79
R7761	Head-on PMT for Highly Magnetic Field	54
R7899	Head-on PMT	34
H8318-70	PMT Assembly	64
H8409-70	PMT Assembly	64
R8487	Side-on PMT	28
R8520U-00-C12	Metal Package PMT	52
H8711	PMT Assembly	64
M8784	Counting Board	109
1P21	Side-on PMT	24
1P28	Side-on PMT	24
931A	Side-on PMT	24
931B	Side-on PMT	24
R331	Head-on PMT	43

Type numbers shown in "Notes"

Type No.	Product	Page
R585	Head-on PMT	43
R647P	Head-on PMT	31
R750	Head-on PMT	33
R758-10	Side-on PMT	27
R760	Head-on PMT	31
R877-01	Head-on PMT	47
R955	Side-on PMT	27
R960	Head-on PMT	31
R976	Head-on PMT	33
R1080P	Head-on PMT	31
R1081	Head-on PMT	31
R1104	Head-on PMT	37
R1166P	Head-on PMT	33
R1288A-01	Head-on PMT	35
R1450-12	Head-on PMT	33
R1463P	Head-on PMT	31
R1464	Head-on PMT	33
R1508	Head-on PMT	39
R1509	Head-on PMT	39
R1527P	Side-on PMT	25
R1548-02	Rectangular Dual PMT	49
R1635P	Head-on PMT	31
R1924P	Head-on PMT	35
R1926A	Head-on PMT	35
R2027	Head-on PMT	33
R2059	Head-on PMT	41
R2076	Head-on PMT	33
R2256-02	Head-on PMT	43
R2295	Head-on PMT	33
H2431-50	PMT Assembly	43
R2658P	Side-on PMT	27
R2693P	Side-on PMT	25
R3235-01	Head-on PMT	41
R3256	Head-on PMT	41
H3378-50	PMT Assembly	43
R3479	Head-on PMT	33
R3810P	Side-on PMT	23
R3878	Head-on PMT	31
R4141	Head-on PMT	31
R4220P	Side-on PMT	25
R5113-02	Head-on PMT	43
R5320	Head-on PMT	35
R5611	Head-on PMT	33
R5900U-03	Metal Package PMT	53
R5900U-03-M4	Metal Package PMT	53
R5900U-03-L16	Metal Package PMT	53
R5900U-04-L16	Metal Package PMT	53
R5900U-06-L16	Metal Package PMT	53
R5900U-07-L16	Metal Package PMT	53
R5983P	Side-on PMT	25
H6152-70	PMT Assembly	55
R6249P	Head-on PMT	37
R6350P	Side-on PMT	23
R6351	Side-on PMT	23
R6353P	Side-on PMT	23
R6358P	Side-on PMT	23
H6533	PMT Assembly	35
H6614-70	PMT Assembly	55
R6835	Head-on PMT	37
R7207-01	Head-on PMT	37
R7400U-20	Metal Package PMT	51
R7400P	Metal Package PMT	51
R7402	Metal Package PMT	51
R7446	Side-on PMT	25
R7447	Side-on PMT	25
R7449	Head-on PMT	37
R7459	Head-on PMT	37
R7511	Side-on PMT	29
R7899-01	Head-on PMT	35
H8318-70	PMT Assembly	55
H8409-70	PMT Assembly	55
R8486	Side-on PMT	29

HAMAMATSU

HAMAMATSU PHOTONICS K.K., Electron Tube Center

314-5, Shimokanzo, Toyooka-village, Iwata-gun, Shizuoka-ken, 438-0193, Japan

Telephone: (81)539/62-5248, Fax: (81)539/62-2205

<http://www.hamamatsu.com>

Main Products

Electron Tubes

Photomultiplier Tubes
Light Sources
Microfocus X-ray Sources
Image Intensifiers
X-ray Image Intensifiers
Microchannel Plates
Fiber Optic Plates

Opto-semiconductors

Si Photodiodes
Photo IC
PSD
InGaAs PIN photodiodes
Compound semiconductor photosensors
Image sensors
Light emitting diodes
Application products and modules
Optical communication devices
High energy particle/X-ray detectors

Imaging and Processing Systems

Video Cameras for Measurement
Image Processing Systems
Streak Cameras
Optical Measurement Systems
Imaging and Analysis Systems

JUN. 2002 REVISED

Information in this catalog is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omission.

Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein.

© 2002 Hamamatsu Photonics K.K.

Sales Offices

ASIA:

HAMAMATSU PHOTONICS K.K.

325-6, Sunayama-cho,
Hamamatsu City, 430-8587, Japan
Telephone: (81)53-452-2141, Fax: (81)53-456-7889

U.S.A.:

HAMAMATSU CORPORATION

Main Office
360 Foothill Road, P.O. BOX 6910,
Bridgewater, N.J. 08807-0910, U.S.A.
Telephone: (1)908-231-0960, Fax: (1)908-231-1218
E-mail: usa@hamamatsu.com

Western U.S.A. Office:

Suite 110, 2875 Moorpark Avenue
San Jose, CA 95128, U.S.A.
Telephone: (1)408-261-2022, Fax: (1)408-261-2522
E-mail: usa@hamamatsu.com

United Kingdom:

HAMAMATSU PHOTONICS UK LIMITED

2 Howard Court, 10 Tewin Road Welwyn Garden City
Hertfordshire AL7 1BW, United Kingdom
Telephone: 44-(0)1707-294888, Fax: 44-(0)1707-325777
E-mail: info@hamamatsu.co.uk

France, Portugal, Belgium, Switzerland, Spain:

HAMAMATSU PHOTONICS FRANCE S.A.R.L.

8, Rue du Saule Trapu, Parc du Moulin de Massy,
91882 Massy Cedex, France
Telephone: (33)1 69 53 71 00
Fax: (33)1 69 53 71 10
E-mail: infos@hamamatsu.fr

Swiss Office:

Richtersmattweg 6a
CH-3054 Schüpfen, Switzerland
Telephone: (41)31/879 70 70,
Fax: (41)31/879 18 74
E-mail: swiss@hamamatsu.ch

Belgian Office:

7, Rue du Bosquet
B-1348 Louvain-La-Neuve, Belgium
Telephone: (32)10 45 63 34
Fax: (32)10 45 63 67
E-mail: epirson@hamamatsu.com

Spanish Office:

Centro de Empresas de Nuevas Tecnologías
Parque Tecnológico del Valles
08290 CERDANYOLA, (Barcelona) Spain
Telephone: (34)93 582 44 30
Fax: (34)93 582 44 31
E-mail: spain@hamamatsu.com

Germany, Denmark, Netherland:

HAMAMATSU PHOTONICS DEUTSCHLAND GmbH

Arzbergerstr. 10,
D-82211 Herrsching am Ammersee, Germany
Telephone: (49)8152-375-0, Fax: (49)8152-2658
E-mail: info@hamamatsu.de

Danish Office:

Erantisvej 5, DK-8381 Tilst, Denmark
Telephone: (45)4346/6333, Fax: (45)4346/6350
E-mail: lkoldbaek@hamamatsu.de

Netherlands Office:

PO Box 50.075, 1305 AB Almere The Netherland
Telephone: (31)36-5382123, Fax: (31)36-5382124
E-mail: hamamatsu_NL@compuserve.com

Poland Office:

ul. Chodkiewicza 8, PL-02525 Warsaw, Poland
Telephone: (48)22-660-8340, Fax: (48)22-660-8352
E-mail: info@hamamatsu.de

North Europe:

HAMAMATSU PHOTONICS NORDEN AB

Smidesvägen 12
SE-171 41 Solna, Sweden
Telephone: (46)8-509-031-00, Fax: (46)8-509-031-01
E-mail: info@hamamatsu.se

Italy:

HAMAMATSU PHOTONICS ITALIA S.R.L.

Strada della Moia, 1/E
20020 Arese, (Milano), Italy
Telephone: (39)02-935 81 733, Fax: (39)02-935 81 741
E-mail: info@hamamatsu.it

Rome Office:

Via Fosso del Torrino, 51, 00144 Roma, Italy
Telephone: (39)06-52246492, Fax: (39)06-52246493
E-mail: inforoma@hamamatsu.it

Hong Kong:

HAKUTO ENTERPRISES LTD.

Room 404, Block B,
Seaview Estate, Watson Road, North Point, Hong Kong
Telephone: (852)25125729, Fax: (852)28073155

Taiwan:

HAKUTO Taiwan Ltd.

3F-6, No. 188, Section 5, Nanking East Road
Taipei, Taiwan R.O.C.
Telephone: (886)2-2753-0188, Fax: (886)2-2746-5282

KORYO ELECTRONICS CO., LTD.

9F-7, No.79, Hsin Tai Wu Road
Sec.1, Hsi-Chih, Taipei, Taiwan, R.O.C.
Telephone: (886)2-2698-1143, Fax: (886)2-2698-1147

Republic of Korea:

SANGKI TRADING CO., LTD.

Suite 431, World Vision Bldg.,
24-2, Yoido-Dong, Youngdeungpo-ku,
Seoul, 150-010 Republic of Korea
Telephone: (82)2-780-8515, Fax: (82)2-784-6062

Singapore:

HAKUTO SINGAPORE PTE. LTD.

Block 2, Kaki Bukit Avenue 1, #04-01 to #04-04
Kaki Bukit Industrial Estate, Singapore 417938
Telephone: (65)7458910, Fax: (65)7418201