




Quick Installation Guide – KB982W




1 Install batteries in mouse




2 Install batteries in keyboard




3 Turn off PC and connect RF receiver




4 Turn on PC and press button on RF receiver




5 Using a pen press button underneath keyboard leg



6 Press button on RF receiver again



7 Using a pen press button underneath mouse



8 Install software CD and reboot PC