LEFT

Table 1: HRS detector long checklist part A. Completed by DLAMINI Date 02 - OCTOBER, 2014

1	12	The air cooling in the detector but is operational
2	2	Fresh air flow is turned on for PMTs on S0, S1 and S2m detectors, P ¿ 0.5 inches
3	10	
4	12	
5	V	The cooling fan is working on the Trigger Supervisor crate
6	VZ	Each of the cooling fans (4 of them) is working in the FastBus relay rack
7		The cooling fans are working on the VDC level translator panel
8		The cooling fan is working in the VME slow control VME crate
9	U	Power to the front-end discs is turned ON for the S2m and cooling fans are operational.
10	VZ,	The control of the MLU (VME) unit for the trigger is operational (via GUI)
11	VZ	The control of the HV crate for the detector is operational (via GUI)
12	VZ'	The internet connection to each of the three FastBus CPUs is operational (via GIU)
13	8	The internet connection to the VME CPU is operational (via GIU)
14		The internet connection to the Trigger Supervisor CPU is operational (via GIU)
15	V	All high voltage and signal cables in the detector but are secured 2 No second in the
16		The VDC gas flows are turned on at a level of 30 in the flowmeters ~ 35
17		The flow is seen from the exhaust bubblers/flowmeters
18	∇	The power supply is turned on for the VDC amplifier cards (+5V, 10A)
19		The level translators (+5V and -5V), and the threshold control (+3V, 0.1A)
20	12	The VDC HV power is set at 3.5 kV and the leakage current is below 0.01 μA

Table 2: HRS detector long checklist part B. Completed by DIAMIN Date 02 , OGOSER, 2014

	1	The Straw chamber gas flow is turned on at a level of 45 in the flowmeter ~20 The pressure on the gauge is about 0.2 inches. • 4	
23		The power supply is turned on for the amplifier cards and the threshold control.	
24	V	The AC power of the level translator box is ON.	
25	4	The Straw chamber HV power is set at 1.6 kV and 1.8 KV	
26	VZ	the leakage current on each of the six lines is below 0.001 mA.	
27		Power to the front-end discs is turned ON for the S2m and cooling fans are operational.	
28	VZ	The S2m HV power is set at 1.6 kV settings and the current at each of the 32 channels is <1 mA The S2m scaler rates are below 2 kHz in each of the 32 channels.	5-1.8
29			
30	Z	The S0 HV power is set at 1.8 kV settings and the current in both channels is $<1 \text{ mA.} [1.1-1.2]$	KV
31		The S0 scaler rates are below 2 kHz.	
32	12	The Gas Cherenkov, GC, CO2 flow is turned ON at the level of 50 at the flowmeter.	
33		The GC HV power is set at ±6 kV settings and the current at each of the 10 channels is <1 mA	-1.187
34	12	The GC scaler rates are below 10 kHz in each of the 10 channels.	· JA
Date		Check performed Check approved (B. Wojtsekhowski)	

RIGHT

Table 1: HRS detector long checklist part A. Completed by

. Date

1	The air cooling in the detector but is operational
2	Fresh air flow is turned on for PMTs on S0, S1 and S2m detectors, P ¿ 0.5 inches
3	Each of the cooling fans (9 of them) is working in the electronics relay racks
4	The cooling fan is working on the VME crate
5	The cooling fan is working on the Trigger Supervisor crate
6	Each of the cooling fans (4 of them) is working in the FastBus relay rack
7	The cooling fans are working on the VDC level translator panel
8	The cooling fan is working in the VME slow control VME crate
9	Power to the front-end discs is turned ON for the S2m and cooling fans are operational
10	The control of the MLU (VME) unit for the trigger is operational (via GUI)
11	The control of the HV crate for the detector is operational (via GUI)
12	The internet connection to each of the three FastBus CPUs is operational (via CHI)
13	The internet connection to the VME CPU is operational (via GIU)
14	The internet connection to the Trigger Supervisor CPU is operational (via GIU)
15	All high voltage and signal cables in the detector but are secured
16	The VDC gas flows are turned on at a level of 30 in the flowmeters
17	The flow is seen from the exhaust bubblers/flowmeters
18	The power supply is turned on for the VDC amplifier cards (+5V, 10A)
19	The level translators (+5V and -5V), and the threshold control (+3V, 0.1A)
20	The VDC HV power is set at 3.5 kV and the leakage current is below 0.01 μΛ

Page 7: HRS detector long checklist part B. Completed by

. Date

Date		Check performed Check approved (B. Wojtsekhowski)
34	X	The GC scaler rates are below 10 kHz in each of the 10 channels.
33	K	The GC HV power is set at 1.6 kV settings and the current at each of the 10 channels is <1 mA
32	Ø	The Gas Cherenkov, GC, CO2 flow is turned ON at the level of 50 at the flowmeter. Low from
31	K	The S0 scaler rates are below 2 kHz.
30	X	The S0 HV power is set at 1.8 kV settings and the current in both channels is <1 mA.
29	X	The S2m scaler rates are below 2 kHz in each of the 32 channels.
28	X	The S2m HV power is set at 1.6 kV settings and the current at each of the 32 channels is <1 m
27		Power to the front-end discs is turned ON for the S2m and cooling fans are operational.
26		the leakage current on each of the six lines is below 0.001 mA.
25	×	The Straw chamber HV power is set at 1.6 kV and
24		The AC power of the level translator box is ON.
23		The power supply is turned on for the amplifier cards and the threshold control.
22		The pressure on the gauge is about 0:2 inches.
21		The Straw chamber gas flow is turned on at a level of 45 in the flow meter ~ 20