Field Mapping of Vertical Coils and BigBite Fringe Field

Yi Qiang Duke University

Transversity Collaboration Meeting Oct 9, 2007

Parameters of Three Coils

Coils	Radius (cm)	Field Direction	Field (G)	
Small	66.75	Z	28	
Large	75.80	Х	28	
Vertical 94.62		Y	28	

Measured Volume

■ A volume of a cake box with R = 20 cm and H = 25 cm



Symmetries in Gradients

 Static magnetic field in vacuum satisfies the following Maxwell equation:

$$\nabla \cdot \vec{B} = 0 \qquad \nabla \times \vec{B} = 0$$

So the components of gradients have the following relations and only 5 independent elements left:

$$dBx / dx + dBy / dy + dBz / dz = 0$$

$$dBx / dy = dBy / dx$$

$$dBy / dz = dBz / dy$$

$$dBz / dx = dBx / dz$$

Gradients in Vertical Coil

- With I = 16 A, the average field generated by vertical coils is about 31 Gaus in Y direction.
- Most gradients measured in the volume are well within our requirement (Absolute values < 10 mG/cm):</p>

Component	Gradient (mG/cm)	Component	Gradient (mG/cm)	
dBx/dy	-1.1±5.4	dBx/dx	1.8±3.7	
dBy/dz	-3.6±7.4	dBy/dy	-3.4 ± 5.0	
dBz/dx	0.5±3.4	dBz/dz	1.6±4.6	

 Large gradients (~20 mG/cm) only happen at the edge of the volume, espcially at Y=20 cm plane.

Comparison to Simulation



Shielding of BigBite Fringe Field



Previous Result without Shielding

- Measured by Xiaofeng, Chiranjib, Xin and Huan.
- Measured with 710 A current



dBz/dx = 31 mG/cm

dBx/dz = 29 mG/cm

Fringe Field with Shielding

- Measured with 710 A current
- Field Gradients are quite uniform ($\sim \pm 3$ mG/cm)
- Average values are:

Component	Gradient (mG/cm)	Component	Gradient (mG/cm)	
dBx/dy	-1.8	dBx/dx 7.		
dBy/dz	-4.0	dBy/dy	2.2	
dBz/dx 14.1		dBz/dz	-9.9	

A factor of 2 reduction!

Some Plots of BB Fringe Field





Fringe Field in Different Experiments

dBx/dx (mG/cm)



	Transver- sity	g2/d2	(e,e'd)	
Angle of BigBite	-7°	2.8°		
dBx/dx (mG/cm)	11.1	3.6	6.5	
dBz/dz (mG/cm)	-13.3	-5.8	-8.7	
dBz/dx (mG/cm)	11.7	16.3	15.1	

Additional Gradients from Different Coil Setups

Mis-alignment from ideal position:





Anti-Helmholtz Coil:



Effects of Different Setups

- Titled coils (Opening to X direction by $\Delta \theta = 0.05$):
 - \Box Create a uniform additional gradient of dBy/dx = 15 mG/cm;
 - No other significant gradient components.
- Shifted coils (Shifted in X direction by $\Delta x = 10$ cm):
 - Create a non-uniform gradient in dBx/dx and dBy/dy along x direction (±10 mG/cm);
- Anti-Helmholtz coils (I = 1 A):
 - Create uniform additional gradients in dBy/dy, dBx/dx and dBz/dz with dBx/dx = dBz/dz = - 0.5 dBy/dy = 12 mG/cm;
 - No other significant gradient components.

Side Effect of Shielding

- Mirror coils created by the big iron shielding add unwanted gradients.
- Simulations were carried out to calculate the total gradients generated by coils, BigBite fringe field and mirror coils.
- Average gradients were obtained at pumping chamber and target chamber to get optimum field orientation.

Cell Configuration



Best Choices of Field Orientations

Gradient	t (mG/cm)	dBx/dy	dBy/dz	dBz/dx	dBx/dx	dBy/dy	dBz/dz
By =	Target Chamber	0.0±1.7	10.3±1.0	11.9±0.7	11.2±1.3	2.2±0.2	-13.3±1.1
28 G	Pumping Chamber	0.7±0.6	7.9±0.8	13.5±0.4	9.7±0.6	0.8±1.0	-10.5±0.6
By =	Target Chamber	-3.4±0.9	-18.9±0.8	11.9±0.7	11.2±1.3	2.2±0.2	-13.3±1.1
-28 G	Pumping Chamber	-4.6±0.7	-17.6±0.8	12.1±0.3	11.4±0.5	2.8±1.1	-14.2±0.9
Bx =	Target Chamber	-1.7±0.4	-4.3±0.1	18.0±1.6	15.7±5.3	4.8±2.2	-20.5±3.3
28 G	Pumping Chamber	-2.4±1.1	-2.8±1.4	18.4±1.3	15.5±1.2	-0.8±2.1	-14.7±1.8
Bx = -28 G	Target Chamber	-1.7±0.4	-4.3±0.1	5.9±2.7	6.7±2.8	-0.5±1.8	-6.2±1.2
	Pumping Chamber	-1.5±1.2	-6.3±1.4	7.2±1.4	5.5±1.3	4.5±2.1	-10.0±1.6

Best Choices Cont.

- The best orientations of holding field are By = 28 G and Bx = -28 G.
- The large gradient of dBx/dx, dBy/dy and dBz/dz can be corrected by existing anti-helmholtz coils of X and Z direction to less than 5 mG/cm.
- With By = 28 G, dBy/dz and dBz/dx are still quite large (10~13 mG/cm). The impact on AFP loss needs to be investigated.