




2002 Catalog Excerpts

Photomultiplier Tube Assemblies

For additional information visit us on the web at <http://usa.hamamatsu.com>

Photomultiplier Tube Assemblies



TACCF0133

Photomultiplier Tube Assemblies

Photomultiplier tube assemblies are made up of a photomultiplier tube, a voltage-divider circuit and other components, all integrated into a single case.

Type No.	Assembly Dia. (mm)	PMT Dia. (inch)	Built-in PMT	Curve Code	Wavelength (nm)	Out-line No.	Dynode Structure / Stages	Max. Rating		Cathode Sensitivity		
								Anode to Cathode Voltage Max. (V)	Divider Current Max. (mA)	Anode to Cathode Supply Voltage (V)	Luminous Typ. ($\mu\text{A}/\text{lm}$)	Blue Sensitivity Index (CS 5-58) Typ.
H3164-10	$\phi 10.5$	3/8	R1635	400K	300 to 650	①	L/8	-1500	0.41	-1250	100	9.5
H3695-10	$\phi 11.3$	3/8	R2496	400S	160 to 650	②	L/8	-1500	0.37	-1250	100	9.5
H3165-10	$\phi 14.3$	1/2	R647	400K	300 to 650	③	L/10	-1250	0.34	-1000	110	10.0
H6520	$\phi 23.5$	3/4	R1166	400K	300 to 650	④	L/10	-1250	0.33	-1000	110	10.5
H6524	$\phi 23.5$	3/4	R1450	400K	300 to 650	⑤	L/10	-1800	0.43	-1500	115	11.0
H6612	$\phi 23.5$	3/4	R3478	400K	300 to 650	⑥	L/8	-1800	0.35	-1700	115	11.0
H6152-70	$\phi 31.0$	1	R5505	—	300 to 650	⑦	FM/15	+2300	0.41	+2000	80	9.5
H6533	$\phi 31.0$	1	R4998	400K	300 to 650	⑧	L/10	-2500	0.36	-2250	70	9.0
H7415	$\phi 33.0$	1-1/8	R6427	400K	300 to 650	⑨	L/10	-2000	0.41	-1500	95	11.0
H3178-51	$\phi 47.0$	1-1/2	R580	400K	300 to 650	⑩	L/10	-1750	0.63	-1500	95	11.0
H8409-70	$\phi 38.0$	1-1/2	R7761	—	300 to 650	⑪	FM/19	+2300	0.33	+2000	80	9.5
H6410	$\phi 60.0$	2	R329-02	400K	300 to 650	⑫	L/12	-2700	0.67	-2000	90	10.5
H1949-51	$\phi 60.0$	2	R1828-01	400K	300 to 650	⑬	L/12	-3000	0.70	-2500	90	10.5
H2431-50	$\phi 60.0$	2	R2083	400K	300 to 650	⑭	L/8	-3500	0.61	-3000	80	10.0
H6614-70	$\phi 60.0$	2	R5924	—	300 to 650	⑮	FM/19	+2300	0.33	+2000	70	9.0
H6156-50	$\phi 60.0$	2	R5496	400K	300 to 650	⑯	L/10	-3000	0.71	-2500	80	10.0
H7195	$\phi 60.0$	2	R329-02	400K	300 to 650	⑰	L/12	-2700	1.23	-2000	90	10.5
H8318-70	$\phi 71.0$	2-1/2	R6504	—	300 to 650	⑱	FM/19	+2300	0.33	+2000	70	9.0
H6559	$\phi 83.0$	3	R6091	400K	300 to 650	⑲	L/12	-2500	0.62	-2000	90	10.5
H6525	$\phi 84.5$	3	R4143	400K	300 to 650	⑳	L/12	-3000	0.70	-2500	80	9.5
H6527	$\phi 142.0$	5	R1250	400K	300 to 650	㉑	L/14	-3000	1.02	-2000	70	9.0
H6528	$\phi 142.0$	5	R1584	400U	185 to 650	㉒	L/14	-3000	1.02	-2000	70	9.0
H8711	$\square 30$	—	R5900-00-M16	—	300 to 650	㉓	MC/12	-1000	0.35	-800	80	8.5
H7546	$\square 30$	—	R5900-00-M64	—	300 to 650	㉔	MC/12	-1000	0.46	-800	80	8.5
H7260	$\square 52 \times 24$	—	R7259	—	185 to 650	㉕	MC/10	-900	0.37	-800	70	8.0

CAUTION: Photomultiplier tube assemblies are not designed to operate in a vacuum.


Anode Characteristics

Luminous Typ. (A/lm)	Gain Typ.	Dark Current		Time Response			Pulse Linearity		Notes	Type No.
		Typ. (nA)	Max. (nA)	Tr Typ. (ns)	Tt Typ. (ns)	TTS Typ. (ns)	2 % Typ. (mA)	5 % Typ. (mA)		
100	1.1×10^6	1	50	0.8	9.0	0.5	3	7	H3164-11 (with 50 Ω *)	H3164-10
100	1.1×10^6	2	50	0.7	9.0	0.5	3	7	H3695-11 (with 50 Ω *)	H3695-10
150	1.4×10^6	1	2	2.5	24	1.6	3	7	H3165-11 (with 50 Ω *)	H3165-10
110	1.0×10^6	1	5	2.5	27	2.8	2	7	H6520-01 (with 50 Ω *)	H6520
200	1.7×10^6	3	50	1.8	19	0.76	2	8	H6524-01 (with 50 Ω *)	H6524
200	1.7×10^6	10	300	1.3	14	0.36	2	8	H6612-01 (with 50 Ω *)	H6612
40	5.0×10^5	5	30	1.5	5.6	0.35	180	250		H6152-70
400	5.7×10^6	100	800	0.7	10	0.16	40	70	H6610 (R5320)	H6533
475	5.0×10^6	10	200	1.7	16	0.5	10	30	H7415-01 (with 50 Ω *) H7416 (R7056)	H7415
75	7.9×10^5	2	15	2.7	40	4.5	150	200		H3178-51
800	1.0×10^7	15	100	2.1	7.5	0.35	350	500		H8409-70
270	3.0×10^6	10	100	2.7	40	1.1	100	200	H6521 (R2256) H6522 (R5113)	H6410
1800	2.0×10^7	50	400	1.3	28	0.55	100	200	H3177-50 (R2059)	H1949-51
200	2.5×10^6	100	800	0.7	16	0.37	100	150	H3378-50 (R3377)	H2431-50
700	1.0×10^7	30	200	2.5	9.5	0.44	500	700		H6614-70
1000	1.3×10^7	100	800	1.5	24	0.27	100	150		H6156-50
270	3.0×10^6	10	100	2.7	40	1.1	80	110		H7195
700	1.0×10^7	50	300	2.7	11	0.47	700	1000		H8318-70
900	1.0×10^7	30	120	2.3	40	1.5	80	110		H6559
400	5.0×10^6	50	500	1.8	32	0.6	100	180		H6525
1000	1.4×10^7	50	300	2.5	54	1.2	100	150		H6527
1000	1.4×10^7	50	300	2.5	54	1.2	100	150		H6528
280	3.5×10^6	0.8/ch	—	0.83	—	0.3	0.5/ch	1/ch	16 Multianode H8711-10 (Taper Divider Type)	H8711
24	3.0×10^5	0.2/ch	—	1.0	—	0.3	0.3/ch	0.6/ch	64 Multianode	H7546
140	2.0×10^6	0.2/ch	2/ch	0.6	—	0.18	0.6/ch	0.8/ch	32 Linearanode H7260A (-HV Cable Input Type)	H7260

Note: * marks = 50 Ω is a terminal resistor at anode output.


Photomultiplier Tube Assemblies Dimensional Outlines and Diagrams (Unit: mm)

① H3164-10




TPMHA0309EB

② H3695-10




TPMHA0310EC

③ H3165-10




TPMHA0311EB

④ H6520




TPMHA0312EB

5 H6524




TPMHA0313EA

6 H6612




TPMHA0315EA

7 H6152-70



TPMHA0470EA


8 H6533



TPMHA0317EB


Photomultiplier Tube Assemblies Dimensional Outlines and Diagrams (Unit: mm)

9 H7415




TPMHA0318EB

10 H3178-51




TPMHA0320EB

11 H8409-70




TPMHA0476EA

12 H6410




TPMHA0324EB

13 H1949-51




TPMHA0326EC

14 H2431-50




TPMHA0327EB

15 H6614-70



TPMHA0472EA


16 H6156-50



TPMHA0489EA

Photomultiplier Tube Assemblies Dimensional Outlines and Diagrams (Unit: mm)


17 H7195



* MAGNETIC SHIELD IS CONNECTED TO GND INSIDE OF THIS PRODUCT.


TPMHA0323EB

18 H8318-70



TPMHA0473EA


19 H6559



* MAGNETIC SHIELD IS CONNECTED TO GND INSIDE OF THIS PRODUCT.

TPMHA0331EB



20 H6525



* MAGNETIC SHIELD IS CONNECTED TO GND INSIDE OF THIS PRODUCT.


TPMHA0330EB

21 H6527, H6528




TPMHA0332CE

22 H8711




TPMHA0487EA

23 H7546



TPMHA0488EA

24 H7260



TPMHA0485ED

Notes

A Types marked * are newly listed in this catalog.

B See pages 114 and 115 for typical spectral response charts.

C Photocathode materials


BA :	Bialkali
LBA :	Low noise bialkali
HBA :	High temperature bialkali
MA :	Multialkali
EMA :	Extended red multialkali
DIA :	Diamond

Other photocathodes are indicated by the element symbols.

D Window materials

MF :	MgF ₂
Q :	Quartz (Fused silica or synthetic silica)
K :	Borosilicate glass
U :	UV glass

E Base diagram



F Dynode structure

B :	Box-and-grid
VB :	Venetian blind
CC :	Circular-cage
L :	Linear-focused
B + L :	Box and linear-focused
FM :	Fine mesh
CM :	Coarse mesh
MC :	Metal channel

G See page 78 for suitable socket assemblies.

Mating sockets (E678 series)

*: A socket will be supplied with the tube.

No mark: Sockets may be obtained from electronics supply houses or our sales office.

H Operating ambient temperature range for the photomultiplier itself is -30 °C to +50 °C except for some types of tubes.

However, when photomultiplier tubes are operated below -30 °C at their base section, please consult us in advance.

J Averaged over any interval of 30 seconds maximum.

K Measured at the peak sensitivity wavelength.

L See page 62 for voltage distribution ratio.

M Anode characteristics are measured with the supply voltage and voltage distribution ratio specified by Note L.

Cathode and anode characteristics are measured under the following conditions if noted.

- a at 122 nm
- b at 254 nm
- c at 852 nm
- d Measured using a red filter Toshiba IR-D80A
- e at 4 A/lm
- f at 10 A/lm
- g at 1000 A/lm
- h Dark count per second (s⁻¹)
- i Dark count per second (s⁻¹) after one hour storage at -20 °C
- k Background noise per minute (min⁻¹)

Caution and Warranty

SAFETY PRECAUTIONS

WARNING



A high voltage is applied to a photomultiplier tube during operation. Always provide adequate safety measures to prevent the operator or service personnel from electrical shock and the equipment from being damaged.



The outer surface of metal package PMT R7400 and R5900 is connected to the cathode. When this PMT is operated with a high negative voltage applied to the cathode, the package is also at a high negative voltage so caution is required.

HANDLING PRECAUTIONS

● Handle tubes with extreme care.

Photomultiplier tubes have evacuated glass envelopes. Allowing the glass to be scratched or subjected to shock can cause cracks. Take extreme care during handling, particularly for tubes with graded sealing on synthetic silica bulbs.

● Keep faceplate and base clean.

Do not touch the faceplate and base with bare hands. Dirt and grime on the faceplate causes loss of transmittance and dirt or grime on the base may cause ohmic leakage. If the faceplate becomes soiled wipe it clean using alcohol.

● Do not expose to strong light.

The photocathode of photomultiplier tubes may be damaged if exposed to direct sunlight or intense illumination. Never allow strong light to strike the photocathode.

● Carefully handle tubes with a glass base.

Photomultiplier tubes with a glass base (also called button stem) are less rugged than tubes with a plastic base, so sufficient care must be taken when handling this type of tube. When fabricating a voltage-divider circuit by soldering resistors and capacitors to socket lugs, solder them while the tube is fully inserted into the socket.

● Helium permeation through silica bulb

Helium will permeate through silica bulbs and increase noise, leading to damage that makes photomultiplier tubes unusable. Avoid operating or storing them in an atmosphere where helium is present.

WARRANTY

Hamamatsu photomultiplier tubes and related products are warranted to the original purchaser for a period of 12 months after delivery. The warranty is limited to repair or replacement of a defective product due to defects in workmanship or materials used in its manufacture.

Even if within the warranty period, the warranty shall not apply to failures due to misuse, mishandling, modification by the customer, or to accidents such as natural or man-made disasters.

The customer should inspect and test all products as soon as they are delivered.

ORDERING INFORMATION

Photomultiplier tubes and related products are warranted to the original purchaser. This catalog lists photomultiplier tubes and related products currently available from Hamamatsu Photonics. Please select those products that best match your design specifications. If you do not find the products you want in this catalog, feel free to contact our sales office nearest you. We will modify our current products or design new types to meet your specific needs.

* Characteristics and specifications in this catalog are subject to change without prior notice due to product improvement or other factors.

Before you design equipment according to the characteristics and specifications of our products listed in this catalog, please con-

HAMAMATSU

HAMAMATSU PHOTONICS K.K., Electron Tube Center

314-5, Shimokanzo, Toyooka-village, Iwata-gun, Shizuoka-ken, 438-0193, Japan

Telephone: (81)539/62-5248, Fax: (81)539/62-2205

<http://www.hamamatsu.com>

Main Products

Electron Tubes

Photomultiplier Tubes
Light Sources
Microfocus X-ray Sources
Image Intensifiers
X-ray Image Intensifiers
Microchannel Plates
Fiber Optic Plates

Opto-semiconductors

Si Photodiodes
Photo IC
PSD
InGaAs PIN photodiodes
Compound semiconductor photosensors
Image sensors
Light emitting diodes
Application products and modules
Optical communication devices
High energy particle/X-ray detectors

Imaging and Processing Systems

Video Cameras for Measurement
Image Processing Systems
Streak Cameras
Optical Measurement Systems
Imaging and Analysis Systems

JUN. 2002 REVISED

Information in this catalog is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omission. Specifications are subject to change without notice. No patent rights are granted to any of the circuits described herein.
© 2002 Hamamatsu Photonics K.K.

Sales Offices

ASIA:

HAMAMATSU PHOTONICS K.K.

325-6, Sunayama-cho,
Hamamatsu City, 430-8587, Japan
Telephone: (81)53-452-2141, Fax: (81)53-456-7889

U.S.A.:

HAMAMATSU CORPORATION

Main Office
360 Foothill Road, P.O. BOX 6910,
Bridgewater, N.J. 08807-0910, U.S.A.
Telephone: (1)908-231-0960, Fax: (1)908-231-1218
E-mail: usa@hamamatsu.com

Western U.S.A. Office:

Suite 110, 2875 Moorpark Avenue
San Jose, CA 95128, U.S.A.
Telephone: (1)408-261-2022, Fax: (1)408-261-2522
E-mail: usa@hamamatsu.com

United Kingdom:

HAMAMATSU PHOTONICS UK LIMITED

2 Howard Court, 10 Tewin Road Welwyn Garden City
Hertfordshire AL7 1BW, United Kingdom
Telephone: 44-(0)1707-294888, Fax: 44-(0)1707-325777
E-mail: info@hamamatsu.co.uk

France, Portugal, Belgium, Switzerland, Spain:

HAMAMATSU PHOTONICS FRANCE S.A.R.L.

8, Rue du Saule Trapu, Parc du Moulin de Massy,
91882 Massy Cedex, France
Telephone: (33)1 69 53 71 00
Fax: (33)1 69 53 71 10
E-mail: infos@hamamatsu.fr

Swiss Office:

Richtersmattweg 6a
CH-3054 Schüpfen, Switzerland
Telephone: (41)31/879 70 70,
Fax: (41)31/879 18 74
E-mail: swiss@hamamatsu.ch

Belgian Office:

7, Rue du Bosquet
B-1348 Louvain-La-Neuve, Belgium
Telephone: (32)10 45 63 34
Fax: (32)10 45 63 67
E-mail: epirson@hamamatsu.com

Spanish Office:

Centro de Empresas de Nuevas Tecnologías
Parque Tecnológico del Valles
08290 CERDANYOLA, (Barcelona) Spain
Telephone: (34)93 582 44 30
Fax: (34)93 582 44 31
E-mail: spain@hamamatsu.com

Germany, Denmark, Netherland:

HAMAMATSU PHOTONICS DEUTSCHLAND GmbH

Arzbergerstr. 10,
D-82211 Herrsching am Ammersee, Germany
Telephone: (49)8152-375-0, Fax: (49)8152-2658
E-mail: info@hamamatsu.de

Danish Office:

Erantisvej 5, DK-8381 Tilst, Denmark
Telephone: (45)4346/6333, Fax: (45)4346/6350
E-mail: lkoldbaek@hamamatsu.de

Netherlands Office:

PO Box 50.075, 1305 AB Almere The Netherland
Telephone: (31)36-5382123, Fax: (31)36-5382124
E-mail: hamamatsu_NL@compuserve.com

Poland Office:

ul. Chodkiewicza 8, PL-02525 Warsaw, Poland
Telephone: (48)22-660-8340, Fax: (48)22-660-8352
E-mail: info@hamamatsu.de

North Europe:

HAMAMATSU PHOTONICS NORDEN AB

Smidesvägen 12
SE-171 41 Solna, Sweden
Telephone: (46)8-509-031-00, Fax: (46)8-509-031-01
E-mail: info@hamamatsu.se

Italy:

HAMAMATSU PHOTONICS ITALIA S.R.L.

Strada della Moia, 1/E
20020 Arese, (Milano), Italy
Telephone: (39)02-935 81 733, Fax: (39)02-935 81 741
E-mail: info@hamamatsu.it

Rome Office:

Via Fosso del Torrino, 51, 00144 Roma, Italy
Telephone: (39)06-52246492, Fax: (39)06-52246493
E-mail: inforoma@hamamatsu.it

Hong Kong:

HAKUTO ENTERPRISES LTD.

Room 404, Block B,
Seaview Estate, Watson Road, North Point, Hong Kong
Telephone: (852)25125729, Fax: (852)28073155

Taiwan:

HAKUTO Taiwan Ltd.

3F-6, No. 188, Section 5, Nanking East Road
Taipei, Taiwan R.O.C.
Telephone: (886)2-2753-0188, Fax: (886)2-2746-5282

KORYO ELECTRONICS CO., LTD.

9F-7, No.79, Hsin Tai Wu Road
Sec.1, Hsi-Chih, Taipei, Taiwan, R.O.C.
Telephone: (886)2-2698-1143, Fax: (886)2-2698-1147

Republic of Korea:

SANGKI TRADING CO., LTD.

Suite 431, World Vision Bldg.,
24-2, Yoido-Dong, Youngdeungpo-ku,
Seoul, 150-010 Republic of Korea
Telephone: (82)2-780-8515, Fax: (82)2-784-6062

Singapore:

HAKUTO SINGAPORE PTE. LTD.

Block 2, Kaki Bukit Avenue 1, #04-01 to #04-04
Kaki Bukit Industrial Estate, Singapore 417938
Telephone: (65)7458910, Fax: (65)7418201